

Product Manual 26289 (Revision G, 2/2014)
Original Instructions



L-Series Position Controller with CAN Capability

Installation, Programming, & Troubleshooting Manual



General Precautions Read this entire manual and all other publications pertaining to the work to be performed before installing, operating, or servicing this equipment.

Practice all plant and safety instructions and precautions.

Failure to follow instructions can cause personal injury and/or property damage.



Revisions

This publication may have been revised or updated since this copy was produced. To verify that you have the latest revision, check manual 26311, Revision Status & Distribution Restrictions of Woodward Technical Publications, on the publications page of the Woodward website:

www.woodward.com/publications

The latest version of most publications is available on the *publications page*. If your publication is not there, please contact your customer service representative to get the latest copy.



Proper Use

Any unauthorized modifications to or use of this equipment outside its specified mechanical, electrical, or other operating limits may cause personal injury and/or property damage, including damage to the equipment. Any such unauthorized modifications: (i) constitute "misuse" and/or "negligence" within the meaning of the product warranty thereby excluding warranty coverage for any resulting damage, and (ii) invalidate product certifications or listings.



If the cover of this publication states "Translation of the Original Instructions" please note:

Translated Publications

The original source of this publication may have been updated since this translation was made. Be sure to check manual 26311, Revision Status & Distribution Restrictions of Woodward Technical Publications, to verify whether this translation is up to date. Out-of-date translations are marked with . Always compare with the original for technical specifications and for proper and safe installation and operation procedures.

Revisions—Changes in this publication since the last revision are indicated by a black line alongside the text.

Woodward reserves the right to update any portion of this publication at any time. Information provided by Woodward is believed to be correct and reliable. However, no responsibility is assumed by Woodward unless otherwise expressly undertaken.

Contents

WARNINGS AND NOTICES	IV
ELECTROSTATIC DISCHARGE AWARENESS	v
REGULATORY COMPLIANCE	VI
CHAPTER 1. GENERAL INFORMATION. Purpose and Scope. How to Use This Manual. Intended Applications. Introduction. Programmable Features. Service Tool Software.	1 1 1 1
CHAPTER 2. SYSTEM DESCRIPTION/APPLICATION OVERVIEW	
System Operation	9 10
CAN Communications	
Error Handling Fine fault confinement Bit-wise Arbitration L-Series CAN Specifics	11 11 11
Data Frame	12
Device Identifier Transmitted CAN Messages	13
Incoming CAN Commands	
Faults	
CHAPTER 3. INSTALLATION	
Introduction	
Unpacking	
Mechanical Installation	
Electrical Installation Description of Electrical I/O	30
CHAPTER 4. SERVICE TOOL	43
Introduction Description	
Getting Started	45
L-Series Configuration Configuration Parameters	
Position Calibration and Verification	
Calibration Sequence Overview	63
CHAPTER 5. TROUBLESHOOTING	
Introduction	67
General System Troubleshooting Guide	
Engine/Generator Troubleshooting Troubleshooting Diagnostic Flags	
Electrical Troubleshooting Guide	

Contents

74
74
74
75
75
76
76
77
78
79
81
85
86

The following are trademarks of Woodward, Inc.: Woodward

The following are trademarks of their respective companies: DeviceNet (Open DeviceNet Vendor Association, Inc.) Windows, Windows Vista (Microsoft Corporation)

ii Woodward

Illustrations and Tables

Figure 2-1. System Overview	4
Figure 2-2. Functional Overview	
Figure 2-3. Position Demand Logic	
Figure 2-4. PWM Linear Demand to Position	7
Figure 2-5. PWM Non-Linear Demand to Position	
Figure 2-6. Analog 0–5 V Linear Demand to Position	
Figure 2-7. Analog 0–5 V Non-Linear Demand to Position	
Figure 2-8. CAN 2.0B ("extended CAN") Data Frame	
Figure 2-9. Example J1939 Arbitration Field	
Figure 3-1. L-Series Outline Drawing	
Figure 3-2. L-Series Cover Types	
Figure 3-3a. L-Series Shaft Types	
Figure 3-3b. L-Series Shaft Types	
Figure 3-3c. L-Series Shaft Types	
Figure 3-4. Typical L-Series Position Control Application Wiring	
Figure 3-5. Acceptable PWM Input Types	
Figure 3-6. Relay Driver Output	
Figure 3-7. Typical AUX1 and AUX2 Usage	
Figure 3-8 CAN System Wiring Example	
Figure 3-9. CAN Shielding	
Figure 3-10. Ground Junction Point	
Figure 4-1. Example Service Tool Screen	
Figure 4-2. Typical Programming Datalink Harness Wiring	
Figure 4-3. Configuration Selection Options	47
Figure 4-4. Configuration Editor—Overview Tab	48
Figure 4-5. Configuration Editor—Setup tab	
Figure 4-6. Configuration Editor—Discrete Output Tab	
Figure 4-7. Configuration Editor—Alarm/Shutdown Tab	
Figure 4-8. Configuration Editor— Security Tab	
Figure 4-9. Security Tab Set Password Pop-up	
Figure 4-10. Security Tab Set Password Pop-up	
Figure 4-11. Service Tool—Overview Tab	
Figure 4-12. Service Tool – Alarms Tab	
Figure 4-13. Service Tool – Shutdowns Tab	
Figure 4-14. Service Tool – Internal Shutdowns Tab	
Figure 4-15. Service Tool—Identification Tab	
Figure 4-16. Service Tool—PID Tuning Window	62
Figure 4-17. Service Tool—PID Tuning Properties Window	62
Figure 4-18. Service Tool—Verify Position Calibration	
Figure 4-19. Service Tool—Manual Position Calibration	
Figure 4-20. Service Tool—Manual Position Calibration Settings	
Figure 4-21. Service Tool – Auto Position Calibration	
FIGURE CEL DOUE FIGUREL-SERES RESOURSE	04

Woodward iii

Warnings and Notices

Important Definitions



This is the safety alert symbol. It is used to alert you to potential personal injury hazards. Obey all safety messages that follow this symbol to avoid possible injury or death.

- DANGER—Indicates a hazardous situation which, if not avoided, will result in death or serious injury.
- WARNING—Indicates a hazardous situation which, if not avoided, could result in death or serious injury.
- CAUTION—Indicates a hazardous situation which, if not avoided, could result in minor or moderate injury.
- **NOTICE**—Indicates a hazard that could result in property damage only (including damage to the control).
- **IMPORTANT**—Designates an operating tip or maintenance suggestion.

MARNING

Overspeed /
Overtemperature /
Overpressure

The engine, turbine, or other type of prime mover should be equipped with an overspeed shutdown device to protect against runaway or damage to the prime mover with possible personal injury, loss of life, or property damage.

The overspeed shutdown device must be totally independent of the prime mover control system. An overtemperature or overpressure shutdown device may also be needed for safety, as appropriate.



Personal Protective Equipment

The products described in this publication may present risks that could lead to personal injury, loss of life, or property damage. Always wear the appropriate personal protective equipment (PPE) for the job at hand. Equipment that should be considered includes but is not limited to:

- Eye Protection
- Hearing Protection
- Hard Hat
- Gloves
- Safety Boots
- Respirator

Always read the proper Material Safety Data Sheet (MSDS) for any working fluid(s) and comply with recommended safety equipment.



Start-up

Be prepared to make an emergency shutdown when starting the engine, turbine, or other type of prime mover, to protect against runaway or overspeed with possible personal injury, loss of life, or property damage.



Automotive Applications On- and off-highway Mobile Applications: Unless Woodward's control functions as the supervisory control, customer should install a system totally independent of the prime mover control system that monitors for supervisory control of engine (and takes appropriate action if supervisory control is lost) to protect against loss of engine control with possible personal injury, loss of life, or property damage.

iv Woodward

NOTICE

Battery Charging Device To prevent damage to a control system that uses an alternator or battery-charging device, make sure the charging device is turned off before disconnecting the battery from the system.

Electrostatic Discharge Awareness

NOTICE

Electrostatic Precautions

Electronic controls contain static-sensitive parts. Observe the following precautions to prevent damage to these parts:

- Discharge body static before handling the control (with power to the control turned off, contact a grounded surface and maintain contact while handling the control).
- Avoid all plastic, vinyl, and Styrofoam (except antistatic versions) around printed circuit boards.
- Do not touch the components or conductors on a printed circuit board with your hands or with conductive devices.

To prevent damage to electronic components caused by improper handling, read and observe the precautions in Woodward manual 82715, Guide for Handling and Protection of Electronic Controls, Printed Circuit Boards, and Modules.

Follow these precautions when working with or near the control.

- Avoid the build-up of static electricity on your body by not wearing clothing made of synthetic materials. Wear cotton or cotton-blend materials as much as possible because these do not store static electric charges as much as synthetics.
- 2. Do not remove the printed circuit board (PCB) from the control cabinet unless absolutely necessary. If you must remove the PCB from the control cabinet, follow these precautions:
 - Do not touch any part of the PCB except the edges.
 - Do not touch the electrical conductors, the connectors, or the components with conductive devices or with your hands.
 - When replacing a PCB, keep the new PCB in the plastic antistatic
 protective bag it comes in until you are ready to install it. Immediately
 after removing the old PCB from the control cabinet, place it in the
 antistatic protective bag.

Regulatory Compliance

European Compliance for CE Marking:

These listings are limited only to those units bearing the CE Marking.

EMC Directive: Declared to 89/336/EEC COUNCIL DIRECTIVE

of 03 May 1989 on the approximation of the laws of the Member States relating to electromagnetic

compatibility.

Other European Compliance:

Compliance with the following European Directives or standards does not qualify this product for application of the CE Marking.

Machinery Directive: Compliance as a component with 98/37/EC

COUNCIL DIRECTIVE of 23 July 1998 on the approximation of the laws of the Member States

relating to machinery.

North American Compliance:

These listings are limited only to those units bearing the CSA agency identification.

CSA: CSA Certified for Class I, Division 2, Groups A,

B, C & D, T3C at 105 °C Ambient for use in

Canada and the United States.

Certificate #1380416

This product is certified as a component for use in other equipment. The final combination is subject to acceptance by CSA International (or UL) or local inspection.

The L-Series is suitable for use in Class I, Division 2, Groups A, B, C, D per CSA for Canada and U.S. or non-hazardous locations only.

Wiring must be in accordance with North American Class I, Division 2 wiring methods as applicable, and in accordance with the authority having jurisdiction.

Field wiring must be suitable for at least 105 °C.

The actuator should be protected from exposure to sunlight and rain.



EXPLOSION HAZARD—Do not connect or disconnect while circuit is live unless area is known to be non-hazardous.

Substitution of components may impair suitability for Class I, Division or Zone applications.



RISQUE D'EXPLOSION—Ne pas raccorder ni débrancher tant que l'installation est sous tension, sauf en cas l'ambiance est décidément non dangereuse.

La substitution de composants peut rendre ce matériel inacceptable pour les emplacements de Classe I, applications Division ou Zone.

vi Woodward

Chapter 1. General Information

Purpose and Scope

The purpose of this manual is to provide the necessary background information for applying the L-Series control to gas/gasoline reciprocating engines. Topics covered include mechanical installation, electrical wiring, software programming, and troubleshooting. While this manual is primarily targeted at OEM customers, OEMs themselves may find it useful to copy some of the information from this manual into their application user manuals.

This manual does not contain instructions for the operation of the complete engine system. For engine or plant operating instructions, contact the plant-equipment manufacturer.

This revision of the manual applies to L-Series Position Control models with software 5418-2225 (non-CAN), 5418-2560, 5418-3479, 5418-6750 or newer. Available functionality can vary with software version; differences are identified where applicable. The software version part number can be identified on the Identification tab of the Service Tool.

How to Use This Manual

The following summarizes how to install an L-Series actuator into a new or existing system:

- Unbox and inspect the hardware.
- Mount and wire the hardware following the procedures and recommendations in Chapter 3.
- Optionally configure the control using the Service Tool (Chapter 4).
- Optionally stroke the valve and verify dynamics and functionality.
- Troubleshooting guidelines are provided in Chapter 5.
- Specifications are provided in Appendix C.

Intended Applications

The L-Series control is designed for various industrial applications, including but not limited to generator sets, welders, portable refrigeration units, irrigation pumps, chipper shredders, and mobile industrial gas or gasoline reciprocating engines. Key environmental characteristics of these applications include extended industrial operating temperatures (–40 to +105 °C/–40 to +221 °F), Industrial EMC Requirements, electrical transients, and lower operating voltages (12/24 V).

Introduction

The L-Series provides a building block approach to total engine management. The modular bi-directional actuator design easily attaches to fuel pumps, mixers, or throttle bodies. For information on Woodward throttle body applications, refer to manual 26249 (ITB and LC-50).

Woodward also offers L-Series actuator versions for Speed Control and Process Control, like Air/Fuel Ratio control, applications. Refer to manuals 26250 (Speed Control) and 26251 (Process Control).

The L-Series position control accepts a position command and drives the 0–60 degree output shaft to the commanded position based on an internal shaft position sensor. The high-efficiency torque motor delivers 0.34 N·m (0.25 lb-ft) nominally over 60° travel range to operate fuel or air control devices (see specifications in Appendix C for torque performance over the full product temperature range).

The L-Series position control accepts either a PWM command, a CAN command, or a 0–5 V command for output positioning. The command signals are issued by the appropriate supervisory engine management system, and the L-Series must be set up properly in software to expect the correct signal for the application. The position command input can also be set up with a primary and a backup input, providing redundancy.

For status purposes, a relay driver output is available that changes state whenever a fault or error condition is experienced by the L-Series controller.

If the system so requires, the L-Series provides a direct position output signal in the form of a dc voltage. The throttle position (TPS) output represents full counterclockwise (CCW) to clockwise (CW) rotation of the actuator shaft, and thus gives the operator an external position indication after installation and while the unit is operating.

More detail on the features of the L-Series can be found later in this manual.



When included with an ITB, the actuator depends solely on the return spring inside the throttle body assembly to drive toward minimum fuel when not powered, therefore other positive shutdown devices like fuel shut-off solenoids are recommended to ensure shutdown upon loss of signal to the control system. Also, separate overspeed trip devices are always mandatory.

Programmable Features

Control setup and tuning is accomplished through the use of a PC (personal computer), Woodward Service Tool software, and a programming harness. The features identified below are described in Chapters 2 and 4. Briefly, the programmable features include:

- General Setup Parameters
 - o Position Demand Select (Primary/Backup; CAN, PWM or Analog)
 - o Fail Position
 - o Min Position Direction (CCW or CW)
 - o Actuator Curve Selection (Linear or Non-linear)
- CAN Setup (CAN-capable units only)
 - o CAN Protocol
 - o Fail Timeout
 - o CAN Device Identifier(s)
 - o CAN ID Discrete Input (5418-3479 or newer)
 - PWM Setup Parameters
 - o PWM Drive Select (Push-Pull, High-Side Drive or Low-Side Drive)
 - PWM Offset
 - Valve Position Control Parameters

- Non-Linear Actuator Settings
 - o Position Request (5 curve input points)
 - o Actuator Position (5 curve output points)
- Discrete Output Settings
 - o Output's Non-Fault Condition (ON or OFF)
 - o Fault Selections as Discrete Output Indications
- Fault Settings
 - o Latching or Non-Latching Fault Indications
 - o Position Error Magnitude & Delay
 - o Fault Selections as Alarms or Shutdowns

Service Tool Software

The L-Series Service Tool software is a Microsoft Windows based GUI (graphic user interface). The Service Tool Software is compatible with Windows 95/98/NT/00 and gives the OEM the ability to:

- Configure product settings based on application requirements
- Tune the control with the engine running during application development
- Create configuration files for downloading into multiple controls
- Download configuration files
- Extract and view fault codes for field diagnosis
- Update control dynamics during field service
- Calibrate the control for user stops

Detailed descriptions of software installation are available in Chapter 4.

Chapter 2. System Description/Application Overview

System Operation

The L-Series actuator is ready for operation immediately (within 0.25 second on non-CAN units) when the power supply is connected. Power may be connected to the control at the same time the engine starter motor is engaged. Upon power-up, the actuator will immediately go to the commanded position. The actuator will then drive to maintain the position commanded by the supervisory control.

Optionally, a Run Enable input can be used to activate or de-activate the L-Series output. It can also be used to reset shutdown fault conditions.

Upon an engine shutdown command, the independent engine shutdown solenoid or solenoid valve in the fuel supply should be de-activated and the power supply disconnected from the speed control. This shutdown signal should be sent directly from the engine control panel and should be independent and separate from the L-Series controller.




Figure 2-1. System Overview

Driver Input Power

The L-Series will handle a voltage range of 10 to 28 Vdc at full specified torque. The actuator is functional in the range of 8 to 32 Vdc, but accuracy and/or torque can be diminished at the extreme ends of this range.

The supply voltage failure levels are below 6.25 V and above 33 V. The unit can be configured to either alarm or shutdown upon detection of a supply voltage fault.

L-Series Position Control Functional Overview




Figure 2-2. Functional Overview

Position Command Signal

The L-Series can accept either a single position command or a redundant position command. A redundant command uses two position commands, one as the primary command and one as a backup. If the primary should fail, the unit could continue to run using the backup command (see Figure 2-1). The command source can be sent over CAN, as a PWM command signal input, or an analog 0–5 Vdc command signal input, depending on how the software application is configured.




Figure 2-3. Position Demand Logic

PWM Position Command

The PWM will function with various types of input sources, including high-side, low-side open collector, and push-pull—depending on the configuration. It will handle a PWM frequency range from 300 to 1500 Hz at amplitudes ranging from 5 V up to battery voltage. Normal operating range is from 10% to 90% duty cycle, representing the hard stops in the actuator (Figure 2-4). The input can be optionally set to a non-linear mode which provides a 5-point curve relationship between position signal and desired position (Figure 2-5).

The input failure levels are below 3% and above 97% duty cycle. The unit can be configured to either alarm or shut down on detection of a position command failure. The shutdown failsafe position is also user-configurable and can be set to any point between 0% and 100%.

A user-configurable offset is available to adjust the input duty-cycle reading, as needed.




Figure 2-4. PWM Linear Demand to Position




Figure 2-5. PWM Non-Linear Demand to Position

Analog (0-5 V) Position Command

The 0–5 V input uses a different pin in the connector, and it has a usable range of 0.5 to 4.5 V to command the throttle from minimum to maximum position (Figure 2-6). The input can be optionally set to a non-linear mode which provides a 5-point curve relationship between position signal and desired position (Figure 2-7).

The input failure levels are below 0.2 V and above 4.8 V. The units can be configured to alarm or shut down on detection of a position command failure (loss of all position command inputs). The shutdown failsafe position is also user-configurable and can be set to any point between 0% and 100%.




Figure 2-6. Analog 0–5 V Linear Demand to Position




Figure 2-7. Analog 0–5 V Non-Linear Demand to Position

CAN Position Command

On CAN-capable units, CANbus can be used to monitor unit status and/or control the commanded position. The CAN messaging is selectable between J1939 and CANopen. CAN details are provided later in this chapter. Two identical J1939 L-Series devices on the same bus are handled when using a CAN ID discrete input (available in firmware 5418-3479 and newer). When used, the device identifier discrete input is read on power-up to determine its identity (open/false selects device 1, and closed/true selects device 2).

When used as a position command, a minimum update rate is expected or a CAN fault will be issued. This update rate is user-configurable. The L-Series can be configured to alarm or shut down on detection of a position command failure (loss of all position command inputs). The shutdown failsafe position is also user-configurable and can be set to any point between 0% and 100%.

Discrete Output

A discrete output is provided to serve as a status indicator. This switchable discrete output is a closure to ground capable of sinking 250 mA with an output voltage rise of less than 1.5 V, and it is available to power external relays for devices such as alarms or fuel shutoff solenoids. The circuit is protected internally against overcurrent and inductive spikes, so external clamping is not necessary.

This output can be configured to be either normally on/open (preferred failsafe setting) or normally off/closed. In addition, the faults that drive the relay status can be configured individually. For details refer to Chapter 4 (Service Tool).

There are two conditions that will prevent the discrete output from operating correctly. The first is if battery positive is accidentally connected to it, and the second is if it is shorted to ground. The circuit will protect itself in the event of a mis-wire, but it will hold the output open (floating) until the fault is removed.

Run Enable Discrete Input

An optional Run Enable discrete input can be configured for use. The Run Enable operation provides a closed-to-run function which, when open, forces the shaft controller into a low-current "limp" mode. The Run Enable can also be used to clear a latching shutdown condition since a closure of the input will issue a reset command.

Actual Position Feedback (TPS)

The L-Series provides a 0–5 V signal representing actual shaft rotational position, where 0.75 V and 4.25 V correspond to full counterclockwise to clockwise rotation, respectively. This signal is fed directly off the position sensor to ensure no delays are introduced by the processor. However, this signal is also uncorrected, so the difference between this signal and actual position can vary up to ±10% over the operating temperature range.

Additional Inputs/Outputs

Auxiliary Inputs—There are four auxiliary inputs on the L-Series controller, all of which are capable of both analog and discrete functions. They can all be functionally defined for purpose in the software application. Although they are very flexible, two of them are shared with the serial communications, so will be unavailable if the L-Series is connected to the Service Tool. More detail concerning the auxiliary inputs is provided in Chapter 3 (Installation).

5 V Output—A 5 Vdc output has been provided on the L-Series actuator to power external sensors, if necessary. The 5 V output is limited to 10 mA, but this is sufficient for most light-duty ratiometric sensors.

Temperature Sensing

The L-Series has an on-board temperature sensor to monitor board temperatures and protect the unit from overtemperature. This temperature is monitored and a fault is annunciated if the set point is exceeded.

Current Limiting based on Temperature

The controller provides actuator current limiting based on the electronics temperature. Dependent on board and actuator thermal models, the software reduces current as necessary to avoid conditions that would damage the device due to extreme temperatures.

Current limiting based on temperature begins when the combined current and temperature environment causes board temperatures greater than 117 °C. The limit curve is a linear derate from full current at 117 °C down to zero current at 125 °C. At 117 °C (125 °C in software version 5418-2225), an OverTemp fault is annunciated. Depending on the current (actuator torque) and ambient operating temperatures, the unit may never reach a reduced level.

RS-232 Communications

RS-232 communications are available on the L-Series when used with an external transceiver connected to pins 4 and 6. Serial communications allow for the use of a service and configuration tool with the L-Series actuator. The simplest way to establish this interface is to use Woodward kit # 8923-1061.

Functions available through this port include tuning, monitoring, and configuration of the position controller. Detailed driver status information is also available.

Any RS-232 wiring must meet the requirements in the EIA RS-232 Standard document. The RS-232 standard states that the length of the RS-232 cable between the driver and the PC must be less than 50 ft (15 m) with a total capacitance less than 2500 pF. The RS-232 data rate is fixed at 19.2 kbps. The communication port is non-isolated and susceptible to both EMI noise and ground loops related to PC connections and typical industrial environments.



The service port is not isolated and is not intended to function while the prime mover is in normal operation. The service port is provided for configuration and setup only.

CAN Communications

To use CAN (Controller Area Network), the L-Series version that supports CAN must be purchased. The L-Series Position Control can provide either J1939 or CANopen, based on the CAN Protocol setting in the Service Tool. AUX3 and AUX4 inputs are not available for other I/O options since they are used for CAN communications.

CAN Basics

Data messages transmitted from any node on a CAN bus do not contain addresses of either the transmitting node, or of any intended receiving node. Instead, the content of the message is labeled by an identifier that is unique throughout the network. All other nodes on the network receive the message and each performs an acceptance test on the identifier to determine if the message, and thus its content, is relevant to that particular node.

If the message is relevant, it will be processed; otherwise it is ignored. The unique identifier also determines the priority of the message. The lower the numerical value of the identifier, the higher the priority. In situations where two or more nodes attempt to transmit at the same time, a non-destructive arbitration technique guarantees that messages are sent in order of priority and that no messages are lost.

Error Handling

The error handling of CAN is one of the really strong advantages of the protocol. The error detection mechanisms are extensive and the fault confinement algorithms are well developed. The error handling and retransmission of the messages is done automatically by the CAN hardware.

The error handling aims at detecting errors in messages appearing on the CAN bus, so that the transmitter can retransmit an erroneous message. Every CAN controller along a bus will try to detect errors within a message. If an error is found, the discovering node will transmit an Error Flag, thus destroying the bus traffic. The other nodes will detect the error caused by the Error Flag (if they haven't already detected the original error) and take appropriate action, i.e. discard the current message.

Fine fault confinement

A faulty node within a system can ruin the transmission of a whole system, by occupying all the available bandwidth. The CAN protocol has a built-in feature that prevents a faulty node from blocking the system. A faulty node is eventually excluded from further sending on the CAN bus.

Bit-wise Arbitration

The priority of a CAN message is determined by the numerical value of its identifier. The numerical value of each message identifier (and thus the priority of the message) is assigned during the initial phase of system design.

The identifier with the lowest numerical value has the highest priority. Any potential bus conflicts are resolved by bit wise arbitration in accordance with the wired-and mechanism, by which a dominant state (logic 0) overwrites a recessive state (logic 1).

L-Series CAN Specifics

Parameter Format

The L-Series uses a little-endian format when handling multiple-byte parameters (i.e. a position demand of 50% is \$FF0F, not \$0FFF). All parameters shall use this format unless otherwise specified.

CAN Bit Timing

The L-Series bit timing is limited to provide a data rate of 250 kbps only.

CAN Fault Indication

When a CAN position command is configured, if new position updates from CAN are not received within the configured CAN Fail Timeout a CAN Demand Fault is annunciated. Faults are globally configured as either latching or non-latching. An option is available to latch-in the CAN fault, to ensure a CAN fault is annunciated over the CAN link when configured as non-latching.

Position Tamper Fault

A position tamper fault can be configured to ensure the primary demand matches the backup CAN demand. The criteria for matching is defined by the CAN Tracking Error Maximum and Delay settings (found on the Alarm/Shutdown tab in the Configuration Editor). If the difference between the primary demand and the CAN backup is greater than the Maximum for the Delay time, a Position Tamper Fault is issued and the primary demand is no longer used – the CAN demand is used instead. To use this fault, CAN must be configured as the backup demand and the position tamper fault must be enabled (Setup tab of Configuration Editor). This fault is disabled if CAN is failed (no signal or updates too slow).

J1939

This section describes the communication that will take place over the J1939 Data Link when the optional CAN communication link is used and configured for J1939. For details, see SAE J1939/11.

Data Frame

The L-Series uses CAN 2B with 29-bit identifiers.

The Data Frame is the most common message type. It comprises the following major parts:

- The Arbitration Field which determines the priority of the message when two
 or more nodes are contending for the bus. The Arbitration Field contains: a
 29-bit Identifier (which also contains two recessive bits: SRR and IDE) and
 the RTR bit.
- The Data Field which contains zero to eight bytes of data.
- The CRC Field which contains a 15-bit checksum calculated on most parts of the message. This checksum is used for error detection.
- An Acknowledgement Slot. Any CAN controller that has been able to correctly receive the message sends an Acknowledgement bit at the end of each message. The transmitter checks for the presence of the Acknowledge bit and retransmits the message if no acknowledge was detected.



Figure 2-8. CAN 2.0B ("extended CAN") Data Frame.

J1939 Example Arbitration field (information only) using 29 bits:




Figure 2-9. Example J1939 Arbitration Field

Device Identifier

The Device Identifier is a Service Tool configurable parameter. The default is 18 (0x12), with an allowed range of 18 to 21 (12 to 15 hex), allowing multiple L-Series controllers on a single CAN link. The configured Device Identifier affects the PDU Specific portion of the incoming position demand message.

Transmitted CAN Messages

The following information is sent over the CAN:

- Actual Valve Position, Desired Valve Position, and Internal Electronics Temperature
- L-Series Fault Status (Alarms and Shutdowns)

The following information is sent over the CAN upon request:

• Software Version Number, Parameter File name, and Serial Number

The L-Series Position Controller receives the following information over CAN:

Position Demand

Valve Position Message

Description	Value	
Transmission repetition rate	100 ms*	
Data length	8 bytes	
Data page	0	
PDU format	255	FFh
PDU specific	251	FBh
Default priority	7	_
Parameter Group Number	65531	FFFBh

*Transmission rate is 1 second with software 5418-2560, 100 ms in newer versions.

Byte: 1 Actual valve position

- 2 Desired valve position
- 3 Electronics Temperature
- 4...8 Reserved

Actual valve position—Measured position. A value of 0% represents min and a value of 100% represents max.

Data length: 1 byte

Resolution: 1 / 2.55 % / bit, 0 offset

Range: 0 to 100% (scaled from 0 to FF hex)

Error Indicator set if: None

Desired valve position—Desired position. A value of 0% represents min and a value of 100% represents max.

Data length: 1 byte

Resolution: 1 / 2.55 % / bit, 0 offset

Range: 0 to 100% (scaled from 0 to FF hex)

Error Indicator set if: None

Electronics Temperature—internal temperature of the L-Series electronics. A value of 0% represents min and a value of 100% represents max.

Data length: 1 byte

Resolution: 1 °C / bit, -40 °C offset

Range: -40 to +210 °C (scaled from 0 to FA hex)

Error Indicator set if: Temperature sensor failed

Requested Messages

The software version number, parameter filename, and serial number messages can be requested using the request message below.

Request message

Description	Value		
Transmission repetition rate	On requ	On request	
Data length	3 bytes	3 bytes	
Data page	0	0	
PDU format	234	EAh	
PDU specific	L-Series	L-Series address	
Default priority	6	6	
Parameter Group Number	х	EAxxh	

Byte: 1..3 requested data PGN (byte 3 is msb)

4..8 reserved

Software Version Number Response Message

Description	Value	Value	
Transmission repetition rate	On requ	On request	
Data length	8 bytes	8 bytes	
Data page	0	0	
PDU format	255	FFh	
PDU specific	218	DAh	
Default priority	6		
Parameter Group Number	65498	FFDAh	

Byte: 1...8 Software version identifier. 8-bytes, 1 character/byte.

The software version format is limited to 8 characters and is based on the software number and revision, excluding the '5418-'. For example the value for '5418-2560 NEW' is '2560 NEW'. The software version can also be found on the service tool Identification tab (Software Part Number).

Parameter Filename Response Message

Description	Value	
Transmission repetition rate	On request	
Data length	8 bytes	
Data page	0	
PDU format	255	FFh
PDU specific	219	DBh
Default priority	6	
Parameter Group Number	65499	FFDBh

Byte: 1...8 Parameter file identifier. 8-bytes, 1 character/byte.

The parameter filename is the first 8 characters of the name of the last settings file loaded into the device. The parameter filename can also be found on the service tool Identification tab (Configuration Identifier).

Serial Number Response Message

Description	Value	
Transmission repetition rate	On request	
Data length	8 bytes	
Data page	0	
PDU format	255	FFh
PDU specific	220	DCh
Default priority	6	
Parameter Group Number	65500	FFDCh

Byte: 1...8 Serial Number identifier. 8-bytes, 1 character/byte.

The serial number can also be found on the service tool Identification tab.

Example:

Request of software version -- device 18 (0x12)

18EA1200x with data 00 FF DA

Response

18FFDA12x with data 32 33 36 32 20 4E 45 57 (ASCII for '2362 NEW')

Diagnostics from L-Series Valve

The L-Series transmits the current status of its diagnostics, regardless of the fault mapping used (i.e. Alarm vs Shutdown). The diagnostics status indications are bit mapped to indicate the active or in-active state (see Bit Code Legend section). Two bits are used for every fault condition to indicate the status.

The diagnostics message is transmitted repeatedly with all the diagnostic bits set appropriately to indicate their current status.

Diagnostics Message

Description	Value		
Transmission repetition rate	100 ms*		
Data length	8 bytes	8 bytes	
Data page	0		
PDU format	255	FFh	
PDU specific	0	00h	
Default priority	6		
Parameter Group Number	65280	FF00h	

*Transmission rate is 1 second with software 5418-2560, 100 ms in newer versions.

Byte: 1..4 Diagnostics 5...8 Reserved

Bit code legend

The following diagnostics and events status will be sent by the L-Series actuator in a sequence.

Bit code	Description
00	Inactive
01	Active
10	Reserved
11	Not Available

Bit position in a byte is "7 6 5 4 3 2 1 0"

Bit position 0 is least significant bit.

Example: Bit position 1 is "1" and all others bits are "0", byte value is 2.

Diagnostic codes

The following diagnostics will be sent by the L-Series actuator.

Diagnostics	J-1939 data frame bit position
Watch Dog Reset	0,1
Brown Out Reset	2,3
(HPCR1 hardware indication in 5418-6750)	
EEPROM Fail	4,5
Position Sensor Fail	6,7
Temperature Sensor Fail	8,9
Voltage Sense Fail	10,11
Relay Short Fail	12,13
Position Demand Failed	14,15
OverTemp	16,17
Position Error	18,19
Position Tamper Fault	20,21
Spare — (Brown Out Reset in 5418-6750)	22,23
Analog Demand Failed (input out of range)	24,25
PWM Demand Failed (duty cycle out of range)	26,27
CAN Demand Failed	28,29
Stop Command from Run Enable Input	30,31

Incoming CAN Commands

This section lists all messages which will be received by the L-Series valve. The PGN for commanded position must be different for each L-Series valve and is determined by the configured Device Identifier.

Description	Value	
Transmission repetition rate	>5 ms	
Data length	8 bytes	•
Data page	0	
PDU format	255	FFh
PDU specific	XX**	xxh**
Default priority	1	
Parameter Group Number	**	FFxxh**

^{**} This value is set to the Device Identifier.

Byte: 1...2 Valve Position Demand

3...8 Reserved

Based on the allowed Device Identifier of 12-15h, the values are limited to the following table.

Description	L-Series Device Address 12h	L-Series Device Address 13h	L-Series Device Address 14h	L-Series Device Address 15h
Transmission repetition rate	> 5 ms	> 5 ms	> 5 ms	> 5 ms
Data length	8 bytes	8 bytes	8 bytes	8 bytes
Data page	0	0	0	0
PDU format	255 FFh	255 FFh	255 FFh	255 FFh
PDU specific	18 12h	19 13h	20 14h	21 15h
Default priority	1	1	1	1
Parameter Group Number	65298 FF12h	65299 FF13h	65300 FF14h	65301 FF15h

Byte: 1...2 Valve Position Demand

3...8 Reserved

Valve Position Demand

Data length: 2 bytes

Resolution: 1/81.92 %/bit, 0 offset

Range: 0 to 100 % (scaled from 0 to 1FFF hex)

CANopen

Overview

CANopen is a networking system based on the CAN serial bus. CANopen assumes that the device's hardware has a CAN transceiver and CAN controller as specified in ISO 11898. The CANopen specification covers both application layer and communication profile. The CANopen profile family specifies standardized communication mechanisms and device functionality. It is maintained by an international users' and manufacturers' group called CAN in Automation (CiA).

The L-Series CANopen Data Link is functional when the optional CAN communication link is used and the CAN Protocol is configured for CANopen. For details on the CANopen protocol, refer to CiA DS301 Version 4.02.

Initially only one L-Series was going to be on a single CAN link. This requirement has recently changed and some areas of this document will also change as a result.

Device Identifier

The Device Identifier is a Service Tool configurable parameter, allowing multiple L-Series controllers on a single CAN link. Allowed values for the Device Identifier are from 1 to 127.

The configured Device Identifier affects the COB-ID of the incoming message. COB-IDs follow the predefined connection set as defined on page 78 of DS301.

Heartbeat

The L-Series heartbeat message is transmitted at the user-defined Heartbeat Producer Time set using the Service Tool.

Network Management (NMT) States

The NMT state machine is implemented per the DS301 standard. When the L-Series powers up, it will transfer through the Initialization state to the Pre-Operational state where it will remain until commanded into the Operational state.

The following are not supported:
Synchronization (SYNC) object
Node Guarding
Service Data Objects (SDOs) -- (except for the Identity object, Device Type, and Error Register)
Time Stamp Object
Emergency Object

In the Pre-Operational State: Module Control Services (NMT commands) are handled Heartbeat is functional SDOs (those supported) are functional

In the Operational State:

All communication objects are handled including PDOs (Process Data Objects)

In the Stopped State:
Module Control Services (NMT commands) are handled
Heartbeat is functional

The following Module Control (NMT Zero) services are supported: Start Remote Node
Stop Remote Node
Enter Pre-Operational mode
Reset Node
Reset Communication

Requested Messages

The software version number, parameter filename, and serial number messages can be obtained using a request of the Identity Object. The Identity Object is accessed via SDO upload at OD Index 0x1018.

The Identity Object supports 4 sub indexes:

The Vendor ID for Woodward is 0x170

The Product Code for Position Control is 0x1

The Revision Number is defined to be the firmware number plus rev (i.e.

firmware 5418-2560 rev NEW would be '541825600')

The Serial Number is a unique identifier set at the factory.

Received Messages

The L-Series receives only one input command from CAN, the position demand setting. To use this input, either the primary or backup position command signal must t be set for 'CAN'. The maximum message receive frequency that the L-Series can respond to is 9 ms. The minimum receive rate, prior to an annunciated fault, is determined by the CAN Fault Timeout setting in the Service Tool.

PDO1 (Rx) - Message size is 2 bytes

Byte	Parameter	Scaling
1 -2	Position Demand (Low byte first)	0 to 100% (scaled from 0 to 1FFF hex)

Transmitted Messages

The transmitted parameters are shown in Table 1. These parameters are transmitted at a frequency of one per second.

PDO1 (Tx) - Message size is 8 bytes. Unused bytes will be set to FF

Byte	Parameter	Scaling
1	Actual Position	0 to 100% (scaled from 0
		to FF hex)
2	Desired Position	0 to 100% (scaled from 0
		to FF hex)
3	Diagnostics 1	Bit field
	Bit0 – Watchdog Reset	
	Bit1 – Brownout Reset	
	Bit2 – EEPROM Fault	
	Bit3 – Position Sensor Fault	
	Bit4 – Temperature Sensor Fault	
	Bit5 – Supply Voltage Fault	
	Bit6 – Discrete Out / Relay Fault	
	Bit7 – Position Command Fault	

Byte	Parameter	Scaling
4	Diagnostics 2 Bit0 – Over temperature Bit1 – Position Error Bit2 – Position Tamper Fault Bit3 – (spare) Bit4 – Analog Posn Command Fault Bit5 – PWM Fault Bit6 – CAN Fault Bit7 – Run Enable Fault	Bit field
5	Internal Temperature	-40 to +215 °C, -40 offset (scaled from 0 to FF hex)
6	spare	
7	spare	
8	spare	

Faults

Faults are separated into two categories: Logged Faults and Current Faults. The Current Faults are volatile and reset every time power is applied. Current Faults are detected faults that are presently active; they may latch or not latch depending on the fault. All latching Current Faults are reset by a power cycle or Service Tool reset. All logged faults are latched and written to the EEPROM. They must be cleared through the Service Tool.

A fault can have three effects on the control: change the discrete output state (Alarm), Shutdown–drive to fail direction and change the discrete output state (Alarm), or Shutdown–go limp and change the discrete output state (Alarm). A parameter is available to configure the fault to either an alarm or a shutdown. The shutdown action performed (go limp or drive to fail position) is fault-dependent. Some faults are dedicated shutdowns and cannot be configured—they are identified as such below. A "go limp" command overrides a "drive to fail position" if more than one fault is set.

Faults can be configured as either latching or non-latching. This is a general setting that applies to all faults, unless otherwise noted. When configured as non-latching, a Reset is not needed. If latching mode is configured, a Reset or power-cycle is required to clear the fault and resume positioning.

Watchdog Reset

Watchdog Reset is true if a watchdog timer timeout occurred which resulted in a reset of the microprocessor. This is a hard-coded alarm. If detected, the control will attempt to continue normal operation.

Brownout Reset

Brownout Reset is true if CPU Voltage drops below 4.2 V but not below 1 V. The brownout detect circuit will reset the CPU. This is a hard-coded alarm. If detected, the control will attempt to continue normal operation.

EEPROM Fail

EEPROM Fail indicates failure or corruption of the internal non-volatile memory. If the CRC is not correct for the EEPROM data, this fault will be set true. This is a hard-coded internal shutdown. If detected, the control output will go limp. A power cycle is required to clear this fault.

Position Sense Fail

This indicates a failure of the internal Position Sensor. This is a hard-coded internal shutdown. If detected, the control output will drive to the Shutdown Position using current control. This fault latches and requires a reset or power cycle to clear.

Failure levels: >4.75 V and < 0.25 V

Persistence: 650 ms

Voltage Sense Fail

Indicates an out-of-range signal on the input power. Could indicate input power out of range or a fault in the supply voltage sense circuitry.

Failure levels: >33 V and <6.25 V

Persistence: 650 ms

Can be configured as an alarm or shutdown. If configured as a shutdown, the control will drive to Shutdown Position (using current control) if this fault is detected. If configured as an alarm, the control will internally default to an assumed 32 V power supply voltage (decreased torque at lower actual voltages) and attempt to continue normal operation if this fault is detected. The value displayed on the Service Tool will show sensed value, not default.

Temp Sense Fail

Indicates a failure of the internal on-board Temperature Sensor.

Failure levels: >150 °C and <-45 °C

Persistence: 650 ms

Hysteresis: 5 °C (<145 °C or >-40 °C to clear)

Can be configured as an alarm or shutdown. If configured as a shutdown, the control will drive to Shutdown Position (using position control) if this fault is detected.

OverTemp

If the on-board temperature sensor reads above 117 °C (125 °C for 5418-2225 software), this error will be set. Above 117 °C, the temperature-based current limiting begins. At 125 °C, the current limiting based on temperature will effectively make the output "limp" by reducing the drive current to zero.

Failure levels: >117 °C (>125 °C in version 5418-2225)

Persistence: 650 ms

Hysteresis: 5 °C (<112 °C to clear) (<120 °C in version 5418-2225)

Can be configured as an alarm or shutdown. If configured as a shutdown, the control will go limp if this fault is detected. If configured as an alarm, the control will attempt to continue normal operation.

Position Error

Position Error detection logic will indicate a difference between commanded position and actual position exceeded for longer than the set delay. The error magnitude and duration are customer-configurable parameters.

Failure levels: Set by customer variable, Error > |PosErrorMax| Persistence: Set by customer variable, Position Error Delay.

Hysteresis: none

Override: Whenever the current is being limited to a factor of 1/2 normal maximum or less. This would be because of high temperature (see section on Temp Sensing and Current Limiting) or a shutdown that causes the output to go "limp".

Can be configured as an alarm or shutdown. If configured as a shutdown, the control will drive to Shutdown Position (using position control) if this fault is detected. If configured as an alarm, the control will attempt to continue normal operation.

Relay Output Shorted

The relay driver is thermally protected against wiring errors. If incorrectly wired, the output will turn off and then set the Error Bit.

Can be configured as an alarm or shutdown. If configured as a shutdown, the control will drive to Shutdown Position (using position control) if this fault is detected. If configured as an alarm, the control will attempt to continue normal operation.

PWM Input Failed (Position Demand Failed)

PWM Input Failed is only active when the position demand is configured for 'PWM'.

Can be configured as an alarm or shutdown. If configured as a shutdown, the control will drive to Shutdown Position (using position control) if this fault is detected. If configured as an alarm, the control will attempt to continue normal operation.

Failure levels: >97% Duty and < 3% Duty

Persistence: 250 ms

Hysteresis: 1% (<96% or >4% to clear)

0..5 V Analog (AUX2) Input Failed (Position Demand Failed)

Analog (AUX2) Input Failed is only active when the position demand is configured for '0..5 V'.

Can be configured as an alarm or shutdown. If configured as a shutdown, the control will drive to Shutdown Position (using position control) if this fault is detected. If configured as an alarm, the control will attempt to continue normal operation.

Failure levels: >4.8 V and < 0.2 V

Persistence: 650 ms

Hysteresis: 0.05 V (<4.75 V or >0.025 V to clear)

CAN Fault

CAN command failed is only active when the position demand is configured for 'CAN'

Indication that CAN messages (PDO Rx) are received at a rate slower than the configured minimum update rate (CAN Fail Timeout). This only applies to commands configured to be received over CAN.

Can be configured as an alarm or shutdown. If configured as a shutdown, the control will drive to Shutdown Position (using position control) if this fault is detected. If configured as an alarm, the control will attempt to continue normal operation.

Run Enable Shutdown

The Run Enable discrete input is opened and CAN communications are stopped (CAN Fail) if a CAN position demand input is configured. If CAN is not used, the shutdown follows the Run Enable input. The shutdown is only active when Run Enable is configured for use.

This is a hard-coded shutdown. The control will go limp if this condition is detected.

Tamper Fault

CAN command failed is only active when the backup position demand is configured for 'CAN' and Tamper Fault is enabled.

Indication that the primary position command does not match the CAN position command. When this condition is detected the primary command will be "faulted" and the backup (CAN) command will be used.

Can be configured as an alarm or shutdown. If configured as a shutdown, the control will drive to Shutdown Position (using position control) if this fault is detected. If configured as an alarm, the control will attempt to continue normal operation.

Failure levels: Set by customer variable, |Error| > CAN Tracking Error Max

Persistence: Set by customer variable, CAN Tracking Error Delay

Override: Fault is disabled for CAN Fault

Chapter 3. Installation

Introduction

This chapter provides instructions on how to mount and connect the L-Series controller into a system. Hardware dimensions are provided for mounting the device to a specific application.

MARNING

EXPLOSION HAZARD—Do not connect or disconnect while circuit is live unless area is known to be non-hazardous.

Substitution of components may impair suitability for Class I, Division or Zone applications.

<u>M</u>WARNING

External fire protection is not provided in the scope of this product. It is the responsibility of the user to satisfy any applicable requirements for their system.



Due to the hazardous location listings associated with this product, proper wire type and wiring practices are critical to operation.



Due to typical noise levels in turbine or engine environments, hearing protection should be worn when working on or around the L-Series.



The surface of this product can become hot enough or cold enough to be a hazard. Use protective gear for product handling in these circumstances. Temperature ratings are included in the specification section of this manual.



Do not connect any cable grounds to "instrument ground", "control ground", or any non-earth ground system. Make all required electrical connections based on the wiring diagrams (Figure 3-4).

General Installation, Operation Notes and Requirements

MARNING

Use an independent device for positive shutdown, such as a fuel shut-off valve is highly recommended. Failure to comply with this recommendation can cause personal injury and/or property damage.

Use of an external spring to return to minimum fuel is highly recommended. Failure to comply with this recommendation can cause personal injury and/or property damage.

Use of a predicted min fuel shutdown procedure is highly recommended. Failure to comply with this recommendation can cause personal injury and/or property damage.

Unpacking

Be careful when unpacking the actuator. Check the unit for signs of damage, such as bent or dented panels, scratches, and loose or broken parts. Notify the shipper and Woodward if damage is found.

Mechanical Installation

Mounting Location

Locate the L-Series control a distance from sources of extreme radiant heat, such as exhaust manifolds or turbochargers. The operating temperature range of the control is –40 to +105 °C (–40 to +221 °F). In spark-ignited applications, make sure the L-Series is located away from the ignition coil, and that harness wires are not routed next to the spark plug wires.

Mounting Orientation


While it is not a requirement, it is good practice to orient the connector feature on the control in a horizontal or downward orientation to minimize fluid accumulation between the enclosure and the mating connector's gasket.

Actuator Configuration

The L-Series actuator utilizes a 2" (51 mm) square mounting bolt pattern and is intended to fit within an envelope of 2.618 x 2.618 x 2.540 (66.50 x 66.50 x 64.52 mm) with the short dimension along the shaft axis. Two shaft seal configurations are available, an internal lip seal and an external lip seal with spring backup (Figure 3-2). In addition, six independent output shaft configurations are available (Figure 3-3). Consult Woodward Applications Engineering for the application appropriate seal and shaft configuration.

Mounting Hardware

Use #10 or M5 fasteners to attach the L-Series control to the mounting bracket. The bracket and attaching hardware must be designed to hold the weight and to withstand the vibration associated with prime mover mounting. Use the appropriate fasteners for securing the mounting bracket to the engine.



NOTES:

- 1. MOUNTING HARDWARE TO BE SOCKET HEAD CAP SCREWS
 -- #10(.190)-24, M5, OR EQUIVALENT.
 NO WASHERS TO BE USED.
 RECOMMENDED SCREW TORQUE = 35 IN-LB [4 N-M].
- 2. FOR BRACKET-MOUNT APPLICATION, A BRACKET DUT-OF-FLATNESS OF .010 [0.25] MAXIMUM IS RECOMMENDED.
- 3. FOR CONNECTOR INFORMATION, REFER TO CONNECTOR TABLE AND APPROPRIATE WIRING DIAGRAM.
- 4. USE OF INTERNAL ACTUATOR STOPS IN APPLICATION NOT RECOMMENDED. TORQUE AGAINST STOPS NOT TO EXCEED 200 IN-OZ.
- 5. DIMENSIONS ARE SHOWN IN INCHES [MM].
- 6. DETAILS SHOWN HERE ARE COMMON TO ALL ACTUATOR ASSEMBLIES. HENCE, NEITHER COVERS NOR SHAFTS ARE SHOWN IN THESE VIEWS. SEE COVER AND SHAFT DETAILS ELSEWHERE IN THIS MANUAL.

INTEGRATED DEUTSCH CONNECTOR (REF: DT04-12PA)				
ITEM	RECOMMENDED	OPTIONAL .		
MATING CONNECTOR	DT06-12SA-P012	DT06-12SA		
SECONDARY LOCK	W12S-P012	W12S		
SOCKETS	0462-201-16141	0462-201-16141		
WIRING HARNESS STRESS RELIEF SUPPORT	WITHIN 16 INCHES FROM CONNECTOR			
NOTE: IN THE EVENT A WIRE IS NOT USED FOR EACH OF THE 12 PINS ON THE CONTROL, A DEUTSCH 114017 PLUG MUST BE USED IN PLACE OF FACH MISSING WIRE TO ENVIRONMENTALLY SEAL THE CONTROL.				




Figure 3-1. L-Series Outline Drawing

COVER TYPE 1
INTERNAL LIP SEAL
SHAFT TYPE 1 PHANTOM / INCHES [MM]

COVER TYPE 2

EXTERNAL SPRING-LOADED LIP SEAL
SHAFT TYPE 1 PHANTOM / INCHES [MM]






Figure 3-2. L-Series Cover Types

SHAFT TYPE 1 2X FLATS, THREADED AXIAL HOLE COVER TYPE 1 PHANTOM / INCHES [MM]



SHAFT TYPE 2 Ø.2480, 1X CROSS HOLE COVER TYPE 2 PHANTOM / INCHES [MM]








Figure 3-3a. L-Series Shaft Types

SHAFT TYPE 3 Ø.3095, 1X CROSS HOLE COVER TYPE 1 PHANTOM / INCHES [MM]



SHAFT TYPE 4 Ø.2480, 1X CROSS HOLE COVER TYPE 1 PHANTOM / INCHES [MM]






Figure 3-3b. L-Series Shaft Types




Figure 3-3c. L-Series Shaft Types

Electrical Installation

A wiring pin-out of the L-Series control, as viewed by looking into the control's connector feature, is shown in Figure 3-4. Typical connections to external devices are also shown.

The L-Series has an operating voltage range of 8 to 32 Vdc with nominal voltages of 12 or 24 Vdc. The power supply is reverse polarity protected, and consumes 32 W maximum power at a peak current of 1 A (32 V) assuming 4 Ω stator resistance at 25 °C. These assumptions are based on the fact that the software limits the power to the rotary actuator to 25 W at any given time and input voltage (in the valid range). The control system should be protected with a 6 A slow-blow fuse in the voltage supply lines. Typical max average current is 2.1 A, or max 25 W at 12 V. The application should be configured to turn on power to the actuator when the engine is first cranked.

NOTICE

Centralized load suppression is required when using an L-Series. The L-Series power supply input is not designed to withstand transient events typical of industrial or automotive environments (alternator load dump or power line surge). The centralized suppression must limit transient events to less than 45 V at the L-Series input power terminals.

Electrical Connections



EXPLOSION HAZARD—Do not connect or disconnect while circuit is live unless area is known to be non-hazardous.

Substitution of components may impair suitability for Class I, Division or Zone applications.

Prior to installation, refer to the wiring diagrams and the representative I/O interfaces schematic in this chapter. Also, review the hardware I/O specifications in Appendix C.

NOTICE

The control will only meet ingress protection specifications while the Deutsch connector is installed in the unit. As such, the unit should not be exposed to operating environments unless the mating connector is installed. In addition, if a wire is not used for each of the 12 pins on the control, a Deutsch 114017 plug must be used in place of each missing wire. Failure to adhere to these guidelines may result in product failure or decreased life.

Use 16 to 18 AWG (1 to 1.5 mm²) stranded copper wire with insulation that meets temperature requirements in the harness design. A wiring harness stress relief within 16" (406 mm) of the control's connector is recommended. Limit all I/O and signal lines to less than 30 m (98 ft). Also limit input power (B+/B–) connections to an earth grounded battery or conditioned power interface to less than 10 m (33 ft) from the L-Series product.



A conditioned power interface is an interface which offers equivalent common mode and differential mode conditioning of that of a grounded 24 V lead acid battery.

Dress the harness with wire loom to contain it in a single bundle. Use grommets when passing the harness through metal panels.

Connector

The following Deutsch connector components are recommended for harness designs:

Ü		Recommended	Optional
Mating Cor	nector	DT06-12SA-P012	•
Secondar		W12S-P012	
	ockets	0462-201-16141	1062-16-0122
Crim	np Tool	HDT-48-00	DTT-16-00
Sealir	ng Plug	114017	

For convenience, Woodward part number 8928-396 is a kit that provides all the necessary Deutsch components (crimp tool **not** included).



Crimping methods for the Deutsch connector pins must be followed as prescribed by the manufacturer. Woodward is not responsible for damage or loss of performance resulting if any other method of crimping is used. Use of the listed part numbers of Deutsch connector components is strongly recommended.




Figure 3-4. Typical L-Series Position Control Application Wiring

Connector		
Pin #	Description	Comment
1	+12 V/24 Vdc Input Power	Supply power
2	TPS Signal Output	Direct position feedback output indication
3	PWM – / AUX –	Ground for the PWM or AUX command signal common
4	RS-232 transmit / CAN H	For use with the service tool and CAN
5	Input Power Ground	Ground for the 12 V/24 V input power
6	RS-232 receive / CAN L	For use with the service tool and CAN
7	5 V Out	Power for external sensors (10 mA max)
8	Aux Input 1	Optional Run Enable discrete input
9	Relay Driver Output	Status / fault detection output
10	Aux Input 2	0–5 V command signal input
11	PWM +	PWM command signal input
12	Ignition Input	Not used—Leave open

Description of Electrical I/O

Representative circuitry for the L-Series inputs/outputs is provided in Figure 3-5 below.

Power Supply Input (+12 Vdc/24 Vdc at pin 1, ground at pin 5)—The L-Series is configured for 12 or 24 V nominal operation, although it will handle 8–32 V. The power supply terminals are reverse polarity protected, and in the case that a reverse polarity condition exists, the L-Series actuator will not power-up and will remain at the minimum stop if attached to a throttle body with an internal return spring.

Woodward recommends using a 6 A slow-blow fuse on the power supply line feeding pin 1 of the L-Series actuator.



The input power must be fused. Failure to fuse the L-Series could, under exceptional circumstances, lead to personal injury, damage to the control valve, and/or explosion.

PWM Command Input (+PWM at pin 11, PWM ground at pin 3)—This actuator can be configured to handle a PWM signal from a high-side or low-side open-collector or open-drain source, as well as from a push-pull (customer pull-up) source. The necessary pull-up and pull-down voltages to accommodate the open-collector sources are handled within the L-Series actuator. Nominally, the frequency of PWM is 1 kHz, but it will handle the full range of 300 to 1500 Hz. See Figure 3-5 below, which describes the possible input types and configurations for the PWM input.



This actuator can also be commanded using an analog signal of 0–5 V. See the description below for the auxiliary input pins. AUX2 is used as the analog command input. The PWM and AUX2 input pins should not be tied together.

TPS Output (pin 2, referenced to either pin 3 or pin 5)—This pin feeds the output of the Hall effect position sensor to the terminal wiring. The output range of this pin should be approximately 0.75 Vdc when the actuator is full counterclockwise (when viewed at the end of the shaft), and approximately 4.25 Vdc when the actuator is at full clockwise. This gives the end user an indication of throttle position.




It is recommended that the TPS output be used to externally verify that the position command and subsequent actual position matches the command signal sent. In addition to a positioning error validation, the TPS signal should be monitored to detect out-of-range errors on the TPS output. Failure to comply with this recommendation can result in undetected system faults, and in extreme cases, can cause personal injury and/or property damage.



This output is meant for an approximate indication of shaft position only. The unconditioned output accuracy must be considered when using this signal externally. Refer to the specification for TPS accuracy.

For this type of PWM Source...

...the L-Series PWM Input looks like...



Push-Pull PWM Source (three kinds)




Figure 3-5. Acceptable PWM Input Types

RS-232 Connections (pin 4 and pin 6)—These pins are for serial communication with the L-Series actuator. An external RS-232 transceiver is necessary to make communications possible with the Woodward L-Series Service Tool. A connectivity kit can be purchased from Woodward to accomplish this. Further instructions for using this connectivity kit are provided in Chapter 4. See also the description below on Auxiliary Inputs.

Relay Driver Output (pin 9)—This pin provides the end user with a means for detecting a fault or shutdown condition that is experienced by the L-Series actuator. It is a low-side driver capable of sinking 250 mA (not to exceed 500 mA) through an external load such as a lamp or relay. This circuit is internally protected against over-current conditions and inductive flyback, such as from a relay coil. By default, this circuit will be configured in a failsafe manner, meaning it will be active (conducting) when no fault exists, but if power is lost or a fault is detected by the L-Series actuator, the circuit will open. See Figure 3-6 below for typical usage of this feature.



It is recommended the Relay Output be configured for the failsafe 'Normally On' mode, to ensure maximum fault protection and annunciation. Failure to follow these guidelines could, under exceptional circumstances, lead to personal injury and/or property damage.




Figure 3-6. Relay Driver Output

5 V Output (pin 7, referenced to pin 3)—The +5 Vdc Power Output is intended to power any external transducer that depends on a steady 5 V source. The maximum output current is 10 mA.

Auxiliary Inputs (pins 4, 6, 8, and 10)—The L-Series has three dedicated digital inputs (AUX2, AUX3, and AUX4) used to activate various features of the control. Shorting an auxiliary input pin to battery voltage activates it. Removing battery voltage from an input pin or shorting the pin to ground deactivates the input. If it is decided not to use battery voltage with the auxiliary digital inputs, it is recommended that at least 3 V be present on an input pin in order to change its state from inactive to active. All discrete inputs will be the same voltage as the system power supply and will be active only while the input is in a high state. For AUX2, AUX3, and AUX4, greater than 2.5 Vdc is considered high, and less than 0.8 Vdc is considered low. For the AUX1 discrete input only, the input must exceed 3 V to activate the discrete state. AUX3 and AUX4 are also used for digital communications such as RS-232 (service tool) or CAN (If the CAN option was purchased). RS-232 and CAN will NOT run simultaneously.

When used as a position control, AUX1 on the L-Series actuator can be configured as a run enable discrete input. This configuration must be specified in the configuration of the device using the Service Tool. If AUX1 is selected to perform the run enable function, then 5 V (5–32 V) applied to pin 8 will allow the control to run normally. When this input is opened, the actuator will be in standby mode. When in stand-by, the actuator driver will be disabled, and the shaft will be limp.


AUX2 can be used as a 0–5 V command signal for position control. The software must recognize that the unit is expecting an analog command as opposed to a PWM command. See Figure 3-7 below for typical usage of AUX1 and AUX2 when the L-Series is configured as a position control. when the L-Series is configured as a position control.



This actuator can also be commanded using a PWM signal. See the description above in the PWM Command Input section. The PWM and AUX2 input pins should not be tied together.



All connector pins are short-circuit protected to ground and power except pins 3 and 5, which are not protected against shorts to battery positive. Installation of a fuse on the power ground wire to pin 5 would provide protection to these pins but does not mean one is not needed in the power connection. Pin 1 (B+) still needs protection against a short to ground.



^{**} if optional external Run Enable is chosen during L-Series configuration, Aux. 1 can be used to enable or disable the actuator output shaft torque.

Figure 3-7. Typical AUX1 and AUX2 Usage



When using a CAN-enabled L-Series actuator, if AUX3 or AUX4 are used as discrete inputs, do not tie pin 4 or pin 6 directly to the BAT+ input (pin 1). Doing so can damage the control. If it is desired to use AUX3 and/or AUX4 as discrete input(s) instead of CAN, connect to the supplied 5 V output (pin 7), or use an independent power source of less than 10 Vdc.

Communications

The L-Series can communicate using CANbus protocol or serially using RS-232. CAN is an optional feature that requires additional hardware and a CAN-capable processor. For protocol details, refer to the CAN section in chapter 4 of this manual.

RS-232 communications are available on the L-Series when used with an external transceiver connected to pins 4 and 6. Serial communications allow for the use of a service and configuration tool with the L-Series actuator. The simplest way to establish this interface is to use Woodward kit # 8923-1061.

On CAN-capable units, both CAN and RS-232 share the same I/O pins. The L-Series performs a check on these pins in power-up to determine if the Service Tool is attempting to communicate with the unit. If not, CAN is initialized and used. When finished with the Service Tool functions, disconnecting the RS-232 communications and cycling the input power will re-establish CAN communications.

RS-232/Service Tool Connections (pin 4 and pin 6)

These pins are for serial communication with the L-Series actuator. An external RS-232 transceiver is necessary to make communications possible with the Woodward L-Series Service Tool. A connectivity kit can be purchased from Woodward to accomplish this. Further instructions for using this connectivity kit are provided in Chapter 4.

It is recommended that the OEM or packager provide a breakout cable that is connected to the L-Series service port and run to an easily accessible area on the engine. The service port is absolutely necessary to set up and troubleshoot the L-Series.

Any RS-232 wiring must meet the requirements in the EIA RS-232 Standard document. The RS-232 standard states that the length of the RS-232 cable between the driver and the PC must be less than 50 ft (15 m) with a total capacitance less than 2500 pF. The RS-232 data rate is fixed at 19.2 kbps. The communication port is non-isolated and susceptible to both EMI noise and ground loops related to PC connections and typical industrial environments.

Functions available through the Service Tool include tuning, monitoring, and configuration of the position controller. Detailed driver status information is also available. For details, refer to the Service Tool chapters of this manual.



The service port is not isolated and is not intended to function while the prime mover is in normal operation. The service port is provided for configuration and setup only.

CAN Connections (pin 4 and pin 6)

As a general rule for CAN networks, use the following and refer to the table below.

- Wiring length restrictions depend on the baud rate used and the L-Series only supports 250 kbps.
- The "Trunk" is the length between the two units at the physical ends of the network; or the two termination points if the end units have a drop cable.
- The "Cumulative Drop" is the added length of all drop wires from the trunk to the devices.
- The "Maximum Drop" is the maximum allowed for any 1 drop.

The limits below are the maximum allowed by the CAN standard, when isolated. Shorter lengths in practice are highly recommended in order to maintain a high level of reliability.



Since the L-Series CAN communications is not isolated, a distance of 40 meters should not be exceeded without adding an isolator.

Baud Rate	Trunk Length	Cumulative Drop	Maximum Drop
250 kbps	250 m (820 ft)	78 m (256 ft)	6 m (20 ft)

CAN Network Termination

CAN networks must be terminated with a $121\Omega\pm1\%$ differential resistance at each end of the network. It is necessary to terminate the network to prevent interference caused by signal reflections. Depending on length, may CAN networks will not operate at all without the proper termination. Generally it is recommended not to build the termination into a node since CAN is intended to be a plug-n-play type network with RIUP (remove and insert under power). However, no specific restrictions are placed on the inclusion of termination resistors in a node.

Termination resistors must be installed only at the physical ends of the network. Terminating other midpoint units can overload the network and stop all communications. As a rule, no matter how many units are on a network, there should never be more than two terminations installed.

If termination resistors are provided within a node, the EMC test should be conducted both using and not using the termination network to validate that both wiring versions provide acceptable results. This assumes the termination network can be disabled which is generally true.

Termination is a simple 121Ω , $\frac{1}{4}$ watt, $\frac{1}{6}$ metal film resistor placed between CAN high and CAN low terminals (differential termination) on or near the two end units.

CAN Network Construction

While there are a number of different ways to physically connect devices on a network, the most reliable method for multi-drop networks is a "daisy chain" configuration also called a "zero drop length" connection. A "backbone with stubs" is also acceptable, but will require more attention to wiring for reliable performance. In a daisy chain, wires are run from device one to device two to device three, etc. In a backbone with stubs, a main trunk line is run between the two devices that are physically farthest apart, and then stub lines are run from the intermediate devices to the trunk line. Stubs should be kept as short as possible and may never exceed 6 m (20 ft). See wiring example below for a graphical representation.

In most applications, a ground wire is needed between all units on the network. The preferred method for isolated ports is to include a separate wire in the CAN cable. This keeps the communications and ground reference at the same potential at all times. For this reason the recommended cable types below are DeviceNet cables, which include an extra wiring pair.

Non-isolated nodes may not have a signal ground available for connection. If a signal ground is not available, use the alternate wiring scheme of connecting the CAN ground wire from the isolated nodes to the B- terminal at a non-isolated node (this is typically the signal reference for CAN if isolation is not provided).




Figure 3-8 CAN System Wiring Example

CAN Cable Recommendations

Use only recommended shielded cabling for a CAN network. Correct cable is available from Belden, Lapp Cable, or other suppliers providing an equivalent cable.

Here are the cable specifications from the DeviceNet standard, a good source for CAN requirements.

Data main	100 1400/ -14 MIL-	
Data pair	120 ±10% at 1 MHz	
impedance		
Cable capacitance	12 pF/ft at 1 kHz (nominal)	
Capacitive	1200 pF/1000 ft at 1 kHz	
unbalance		
Propagation delay	1.36 ns/ft (maximum)	
DC Resistance	6.9Ω / 1000 ft @ 20°C (maximum)	
Data Pair	19 strands, 1.0 mm ² corresponds to 18 AWG, individually tinned,	
	3 twists/foot	
Power Pair	19 strands, 1.5 mm ² corresponds to ~16 AWG, individually tinned,	
	3 twists/foot	
Drain / Shield Wire	19 strands Tinned Copper shielding braid or shielding braid and	
	foil	
Cable type	twisted pair cable. 2x2 lines	
Bend Radius	20 x diameter during installation or 7 x diameter fixed position	
Signal attenuation	0.13 dB/100 ft @ 125 kHz (maximum)	
	0.25 dB/100 ft @ 500 kHz (maximum)	
	0.40 dB/100 ft @ 1000 kHz (maximum)	

"DeviceNet" cable is a good example of CAN cable but caution should be used as most DeviceNet cables are not rated for on-engine temperatures.

When using DeviceNet cables, only use the "Thick" or "Trunk" cable. The advantage of "Thick" cables is the conductor size. Larger gauge conductors fare much better in high vibration environments.

Below are two example DeviceNet CAN cables that are suitable for on-engine use if the wiring area stays below 75°C. Other cables may exist.

Part Number	Description
Belden 3082A	PVC, 18 AWG shielded data pair, 15 AWG shielded power pair. 300 V insulation.
Belden 7896A	PVC, 18 AWG shielded data pair, 16 AWG shielded power pair. 600 V insulation.
Lapp Cable 2710-250	Halogen free, 18 AWG shielded data pair, 15 AWG shielded power pair. 300 V
	insulation

CAN Shielding

Shielded cable is required for industrial applications. Only very cost sensitive automotive applications attempt to use unshielded cable for communications. Unshielded cables and improperly shielded cables are likely to cause communication problems and unreliable control operation. The standard for CAN networks is that each device will have an ac-coupled (connected through a 0.01 µF coupling capacitor) shield connection and a single shield ground location will be provided. The ground location does not have to be at a unit connector, it can be any convenient place in the system but should be the same ground as used for the system power.




Figure 3-9. CAN Shielding

Ground Junction (see Figure 3-10)—This grounding junction is provided for joining external ground wires. THERE IS NOT AN INTERNAL CONNECTION TO CIRCUIT GROUND. Terminal pins 3 and 5 must be used for access to the circuit ground. This junction point is completely electrically isolated from the L-Series actuator's electronics, and is solely for convenience during installation.




Figure 3-10. Ground Junction Point

Chapter 4. Service Tool

Introduction

This chapter covers the process of tuning, configuring, calibrating, and servicing the control via the L-Series Service Tool. It is assumed that the control has already been installed on the engine.



Many applications are delivered pre-configured, calibrated, and tuned. These units do not require the use of the Service Tool.

Description

The Service Tool software is used to configure, tune, and troubleshoot the L-Series controller. This chapter describes installation and use of the Service Tool. It identifies the parameters available that can be viewed. It also provides detailed information on configuring and setting up the L-Series to the customer-specific field application.

The Service Tool software resides on a PC (personal computer) and communicates to the L-Series through connector pins 4 and 6. An external RS-232 transceiver is necessary to make communications possible with the Woodward L-Series service tool. A connectivity kit (Woodward # 8923-1061) can be purchased from Woodward to accomplish this.




Figure 4-1. Example Service Tool Screen

The following hardware is required to work with the L-Series control:


- PC-compatible laptop or desktop computer with at least one available serial communications port, and Windows 2000/XP/Vista/7 or greater as the operating system.
- Programming/datalink harness as shown in Figure 4-2.

In addition to the hardware, the following are the distributions of tool software needed to communicate with the control:

• Woodward part number 9927-1222, L-Series Service Tool

NOTICE

There is a potential for serial port damage when communicating with the L-Series control. This is caused by a difference in ac voltage between neutral and earth ground. If the PC RS-232 port ground is referenced to ac neutral, and the L-Series control is referenced to battery ground (ac earth ground), a large amount of current can be experienced. To avoid this situation, we strongly recommend placing an isolation transformer between the ac outlet and the PC.



Pinouts Viewed Looking into Control Connector and Computer Connector

Figure 4-2. Typical Programming Datalink Harness Wiring

Getting Started

Installation Procedure

The Service Tool software can be downloaded and installed from the Woodward internet site (**www.woodward.com**).

What to do next

After the software is installed, connect a serial communications cable between the RS-232 connections on the L-Series control and an unused serial port on your computer. Run the Service Tool program and select the appropriate comm port. Once connected to the control, the status bar will display 'connected' and the Service Tool screen will populate with monitor parameters.

On CAN versions, the Communication/Connect command must be issued prior to powering-up the L-Series. Since the same I/O pins are used for both Service Tool and CAN communications, the only time the Service Tool is enabled is on power up. If a Service Tool connect is detected, CAN will be disabled and the Service Tool communications will remain active.



An unsafe condition could occur with improper use of these software tools. Only trained personnel should have access to these tools.

Service Tool Help

More help on using Service Tool is available and included with the installation of the Service Tool product. Service Tool Help can be accessed from the Service Tool 'Contents' drop-down window selection under the Help menu located on the Main Window.

Software Version Identification

The Service Tool software version can found by selecting 'About' under the Help menu. The L-Series software version can be found on the right-most tab sheet (Identification) of the Service Tool screen. The Service Tool and Control must be connected to view this information. Refer to this version information in any correspondence with Woodward.

Configuration Password

If a password has been saved in the configuration file, the file cannot be opened without first entering the password. Once a configuration with a password has been loaded into the L-Series driver, the control configuration cannot be opened without the password. All other service tool functions do not require a password including: writing over a password protected file configuration, writing over a password protected control configuration, using the Position Calibration Tool, and using the Edit Position PID.

L-Series Configuration

The L-Series can be configured either on-line or off-line. On-line configuration can only be performed when the Service Tool is connected to and communicating with the L-Series control. Off-line configuration can be done at any time, however, settings will not take effect until they are loaded into the control.



If using non-linear mode, control power must be cycled after loading a new configuration.

The current L-Series control configuration settings can be viewed at any time when connected to the control by opening the Configuration Editor (File/Open Control Configuration). See Figure 4-3.

A Configuration Summary worksheet is provided in Appendix Bf this manual to allow documentation of application configuration settings.

OEM Configuration File Data

The OEM can save configuration file specific data with the service tool by selecting Properties under the File menu pull down. This is a text field and can be used to store data such as:

- Customer
- Engine Type
- Application Type
- Notes

Configuring the Unit—On-Line

Unit configuration is summarized as follows:

- Open the Configuration Editor Dialog by selecting 'File/Open Control Configuration'.
- Edit the configuration settings.
- Load the configuration to the L-Series control.



As changes are made to Configuration parameters, they are not used by the driver until a 'load' command is issued. Selecting the 'Close Window' box/button closes the Configuration Editor and does not make any changes to the driver.

Configuring the Unit—Off-Line

Unit configuration is summarized as follows:

- Open the Configuration Editor Dialog using the File/New or File/Open options.
- Edit the configuration settings.
- Save the configuration to a file. At a later date simply open the configuration and load it into the control.




Figure 4-3. Configuration Selection Options

Configuration Parameters

There are five tab sheets that contain all the configuration settings: Overview, Setup, Discrete Output, Alarm/Shutdown and Security.

Overview Tab Sheet

The Overview tab (Figure 4-4) contains general positioning settings for the application. A description of each configuration parameter and its adjustment range is also available in the contents of the Service Tool Help.




Figure 4-4. Configuration Editor—Overview Tab

Min Position

Sets the position controller direction. Allowed values: CW and CCW.

Shutdown/ Fail Position

Sets the position controller position, in percent, when a shutdown condition is detected. Allowed values: 0-100%.

Note: If the Shutdown/Fail Position is not set to '0.0', the 'Actuator fails to a non-zero position.' indication is activated. This is to alert the user of a potential unsafe condition.

Friction/Dither Setting

Sets the position controller's friction and dither values. This parameter should be set to zero (no effect) while tuning the PID and then increased for optimum response. If unsure, a typical value would be 25. Allowed values: 0–100.

Proportional Gain

Sets the position controller PID's proportional gain. Increased gain corresponds to increased PID output (higher proportional = faster response). This setting can also be dynamically adjusted using the PID Tuning screen. Allowed values: 0–100%.

Integral Gain

Sets the position controller PID's integral gain. Increased gain corresponds to increased PID output (higher integral = faster response). This setting can also be dynamically adjusted using the PID Tuning screen. Allowed values: 0–100%.

Derivative Gain

Sets the position controller PID's derivative gain. Increased gain corresponds to increased PID output (higher derivative = faster response). This setting can also be dynamically adjusted using the PID Tuning screen. Allowed values: 0–100%.

Setup Tab Sheet

The Setup tab (figure 4-5) provides all the position demand settings for the application including PWM, analog and CAN setup parameters. Changing the Demand Input Source will modify the parameter settings available as well as the displayed indications within the Service Tool.

A description of each configuration parameter and its adjustment range is also available in the contents of the Service Tool Help.

Demand Input Source

The Position Demand Source can be set to one of the following:

Single Selects a single, non-redundant position demand input. Selects a redundant (primary/backup) position demand

Primary Position Demand Input

The Primary Position Demand source can be set to one of the following:

PWM Selects a PWM position demand input.

Analog Selects an analog (0–5 V) position demand input.

CAN Selects a CAN position demand input.

Backup Position Demand Input

The Backup Position Demand source can be set to one of the following:

PWM Selects a PWM position demand input.

Analog Selects an analog (0–5 V) position demand input.

CAN Selects a CAN position demand input.

Note: The Primary and Backup Position Demand input cannot be set to the same source.

Maximum Demand Difference - <u>(only displayed if configured for Redundant Demand Inputs)</u>

Sets the max difference between primary and backup demands.

Allowed values: 0.0 to 100%




Figure 4-5. Configuration Editor—Setup tab

PWM Settings - (only displayed if PWM is selected as a Demand Input)

Two additional configuration parameters appear when the position demand is set to PWM (see Figure 4-6).

PWM Pull Up Select

Selects the appropriate PWM source. This configures the L-Series input internally to provide the proper pull-up logic. For details on selection of this parameter, refer to Chapter 3. Allowed values: Push-Pull, High Side Drive, or Low Side Drive.

PWM Offset

Sets the PWM Duty cycle offset. This setting is provided to compensate for duty cycle variations in PWM input frequencies, voltages, and types. Allowed values: -5.01 to +5.01%

CAN Settings – Only displayed with CAN-capable versions

CAN Fail Timeout - <u>(only displayed if CAN is selected as a Demand Input)</u> Sets the maximum allowed delay between CAN receive / inputs (Rx), in seconds, before a CAN Fault is annunciated. Allowed values: 0–10 seconds

Determines the J1939 device identification scheme. When set to Aux2, the state of the Aux2 input on power-up will determine the source address as set by the CAN Device Identifier (true/closed selects the value set by CAN Device Identifier 2, and false/open selects CAN Device Identifier 1). Allowed values: Not Used or Aux 2.

CAN Device Identifier (1)

Sets the CAN Device ID (source address) when selected by the CAN ID discrete input (input is false) or when the CAN ID discrete input is not used. Allowed values: 18–21

CAN Device Identifier 2 Only available in software 5418-3479 or newer Sets the CAN Device ID (source address) when selected by the CAN ID discrete input (input is true). Allowed values: 18–21

CAN Protocol Select

Selects the desired CAN protocol. For protocol details refer to the CAN section in chapter 2.

Allowed values: J1939 or CANopen.

Enable Position Tamper Fault - <u>(only displayed if CAN is selected as the Backup Position Demand Input)</u>

When selected, activates the Position Tamper Fault logic which disables the Primary Demand if it doesn't track the CAN demand.

Heartbeat Producer Time - <u>(only displayed if CAN Protocol is CANopen)</u> Sets the time increment for sending CANopen NMT heartbeat messages, in seconds. Allowed values: 0–10 seconds

Run Enable Select

Determines the functionality of Run Enable.

Allowed values: Not Used or Aux 1.

Non-linear Actuator

Selects either a Linear position command, when unchecked, or a Nonlinear 5-point curve command. Linear/Nonlinear refers to the relationship between the position requested and the position commanded to the position PID. When this box is checked, additional parameters appear to set up the 5-point demand curve (Figure 4-6).



If the non-linear curve is changed, control power must be cycled.

Position Request (%)

There are five breakpoint values that correspond to the position requested by the analog or PWM input signal. These values set up the curve inputs. Allowed values: 0–100%.

These values must maintain a monotonic increase in their values, in order from lowest to highest. Also, after the configuration is loaded into the control, power must be cycled on the control before the settings take effect.

Actuator Position (%)

There are five breakpoint values that correspond to the modified actuator position command. These values set up the curve outputs. Allowed values: 0–100%.

Discrete Output Tab Sheet

The Discrete Output (figure 4-6) screen contains the discrete output configuration settings. If the discrete output is not used, then these settings can be skipped.

Relay Output Configuration

The relay output can be configured to one of the following:

Normally On Sets the relay driver to a normally on mode that turns off

for any of the faults selected. This is the preferred,

failsafe output configuration.

Normally Off Sets the relay driver to a normally off mode that turns on

for any of the faults selected.



It is recommended that the Relay Output be configured for the failsafe 'Normally On' mode, to ensure maximum fault protection and annunciation. Failure to follow these guidelines could, under exceptional circumstances, lead to personal injury and/or property damage.

Relay Output Fault Selections

The list of faults displayed can be individually selected to activate the relay output. Any of the selected faults will either turn the output off if configured for Normally On or turn the output on if configured for Normally Off.



It is recommended that all faults be configured to activate the discrete output, this ensures maximum fault annunciation.




Figure 4-6. Configuration Editor—Discrete Output Tab

Alarm/Shutdown Tab Sheet

The Alarm/Shutdown (figure 4-7) screen contains the alarm and shutdown configuration settings.

Shutdown/Alarm Fault Selections

The list of faults displayed can be individually selected to either perform a Shutdown or just Alarm (no action).



It is recommended that all faults be configured as shutdowns, this ensures maximum fault protection. Failure to follow these guidelines could, under exceptional circumstances, lead to personal injury and/or property damage.

Enable Fault Latching

This setting determines whether the faults are latching or non-latching. When set to latching, a reset command is required to clear the fault.

Enable CAN Fault Latching – (only displayed on CAN units if Enable Fault Latching is false)

This setting determines whether the CAN fault is latching or non-latching. This option is provided to latch-in the CAN fault even though all other faults are set to non-latching.

Position Error Maximum (%)

Maximum deviation between the actual position and the position command. If the Error is exceeded for longer than the Position Error Delay, then the Position Error fault is annunciated. Allowed values: 0–100%.

Position Error Delay (sec)

Delay for position error annunciation. Allowed values: 0–10 seconds.

CAN Tracking Error Maximum (%) – (only displayed if Position Tamper Fault is used)

Maximum deviation between the primary position demand and the CAN position demand. If the Error is exceeded for longer than the CAN Tracking Error Delay, then the Position Tamper Fault is annunciated.

Allowed values: 0–100% but must be greater than the Max Demand Difference setting.

CAN Tracking Error Delay (sec)

Delay for Position Tamper Fault. Allowed values: 0-10 seconds.




Figure 4-7. Configuration Editor—Alarm/Shutdown Tab

Security Tab Sheet

The security (figure 4-8) screen contains the security configuration settings.




Figure 4-8. Configuration Editor— Security Tab

Security Configurations

All checked features will have the security password enforced prior to allowing the function. Unchecked features will not be prompted with a password.

Read Configuration

When checked, requires a password before the configuration can be read from the L-Series control (protects Open From Control execution).

This is the minimum level of protection and is required in order to use any other security option.

Configuration Load

When checked, requires a password before a configuration can be loaded into the L-Series control (protects Load to Control execution).

Position Calibration

When checked, requires a password before the position calibration mode can be entered (protects Manual and Automatic Position Calibration menu options).

Position PID Edit

When checked, requires a password before allowing tuning to the position PID (protects Edit Position PID menu option).



Figure 4-9. Security Tab Set Password Pop-up

Loading the Configuration (Save)

Select the File/'Load to Control' option from the menu or Blue Arrow icon on the Configuration Editor to load the changes into the control. The L-Series process must be zero prior to allowing a 'Load' command. This feature can be optionally password protected.




Figure 4-10. Security Tab Set Password Pop-up

Monitoring the Driver

The Service Tool has five different tab sheets to monitor driver parameters. The tab sheet screens include:

- Overview (Figure 4-11)
- Alarms (Figure 4-12)
- Shutdowns (Figure 4-13)
- Internal Shutdowns (Figure 4-14)
- Identification (Figures 4-15)

Each screen displays the position setpoint and actual position values.

Position Setpoint

Displayed value of the position demand, in percent.

Actual Position

Displayed value of the actual position, in percent.

Status Bar Indications

At the bottom of the Service Tool window is a status bar. The status bar has two sections. The bottom left section displays communication status and bottom right section displays alarm & shutdown status.

Communication Status

This section of the status bar shows the status of communication between the service tool and the L-Series Driver. For more information, see Establishing Communication.

- Connected—The Service Tool is connected to and communicating with the driver.
- Not Connected—The Service Tool is not connected to the driver.
- Connecting—The Service Tool is attempting to connect to the driver. This
 message is displayed when Connect is selected from the Communications
 menu or when attempting to re-establish communication to the driver. If the
 connection is lost it will continuously attempt to re-connect.

Alarm Status

Indicates that one or more alarms on the Alarms screen is active.

Shutdown Status

Indicates that one or more shutdowns on the Shutdowns or Internal Shutdowns screen is active.

Overview Parameters Screen

To monitor the overview parameters, go to the Overview page (figure 4-11) on the main window.




Figure 4-11. Service Tool—Overview Tab

Supply Voltage

Displayed value of the input power, in volts, as read by the processor.

Power Demand

Displayed value of the power demanded, in watts, as read by the processor. This is an indication of the work output.

Electronics Temperature

Displayed value of the electronics temperature sensor, in degrees Celsius, as read by the processor. The temperature sensor is physically located between the electronics module and the LAT motor.

PWM Input (Duty Cycle)

Displayed value of the PWM input, in percent duty cycle. This indication is displayed only when the position demand is set to 'PWM'.

AUX2 Input

Displayed value of the analog 0–5 V input, in volts. This indication is displayed only when the position demand is set to '0.5 V'.

Discrete Output

On/Off status of the discrete output command. The indicator is illuminated when the channel is commanded to ON and grayed-out when the command signal is OFF.

Run Enabled

Open (off) / Closed (on) indication of the Run Enable discrete input.

Full Travel Position Setpoint

Indication of the position setpoint in terms of total overall unit travel. Useful if a less than full-travel user-calibrated range is used.

Full Travel Actual Position

Indication of the actual position in terms of total overall unit travel. Useful if a less than full-travel user-calibrated range is used.

Full Travel Sensor Position

Indication of the position in terms of total overall unit travel before linearization. This value will match the TPS output.

Shutdown and Alarm Indications

The Shutdown and Alarm screens display the status is both active and logged fault conditions. The logged indications provide a history of events even after the unit has been power-cycle of run again.



Indicates a logged alarm condition.



Indicates an active alarm condition.



Indicates a logged shutdown condition.



Indicates an active shutdown condition.

An active fault is one that is currently active or latched in the control. The latching/non-latching faults configuration setting factors into this indication. If the fault is latching, then an active fault could either be one that is still present or one that occurred but has not been reset. Latched faults can be cleared by cycling power on the L-Series control or by selecting the 'Reset Alarms and Shutdowns' button on any of the Alarm or Shutdown screens.

A logged fault is one that occurred but is no longer currently active or latched in the control. Logged faults are permanently cleared by selecting the 'Reset Logged Alarms and Shutdowns' button on any of the Alarm or Shutdown screens.

Alarms Screen

To monitor the alarm conditions, go to the Alarms page on the main window. The values displayed on this screen dynamically change with the fault configuration. Refer to chapter 2 for a complete listing and details of all the faults.




Figure 4-12. Service Tool – Alarms Tab

Shutdowns and Internal Shutdowns Screens

To monitor the shutdown conditions, go to the Shutdowns and the Internal Shutdowns pages on the main window. The values displayed on the Shutdowns screen dynamically change with the fault configuration. Refer to chapter 2 for a complete listing and details of all the faults.




Figure 4-13. Service Tool – Shutdowns Tab




Figure 4-14. Service Tool – Internal Shutdowns Tab

Identification Screen

To monitor the L-Series product identification, go to the Identification (figure 4-15) page on the main window.





Figure 4-15. Service Tool—Identification Tab

Tuning the PID

The Service Tool can be used to tune the PID or to just trend/monitor the PID output. To get to the PID Tuning screen, select the Edit Position PID from the Tools menu selection.



The L-Series controller can be put into a manual control mode from this screen by selecting the "Enable Manual Position Tuning' checkbox (Figure 4-16). Once in manual mode, the position setpoint box is highlighted and the value displayed is actively positioning the output. Use this command to create step changes for the PID and monitor the response using the displayed trend.

Pressing the Properties button pops open the Properties Window (Figure 4-17). From this window the user can adjust the trending window properties including the update rate and display range.




Figure 4-16. Service Tool—PID Tuning Window




Figure 4-17. Service Tool—PID Tuning Properties Window

Position Calibration and Verification


Position calibration is available to map the position command input to the actual rotational travel of the unit. It is only used when the full travel of the actuator is constrained or limited such that 0 to 60 degrees of travel is not used. For example, an application-specific position calibration could map 0–100% position command to 10–40 degrees actual rotation.

There are two methods available to perform a position calibration: Automatic or Manual. If the application has hard stops that correspond to the actual min/max travel, then either Auto or Manual methods can be used—although auto is easier. If hard stops are not available, then the auto method will give invalid results and the manual method must be followed.

The Service Tool can be used to calibrate the control to end user stops (physical or soft) or to verify the position calibration. To get to the Position Calibration screens select the desired function from Position Calibration under the Tools menu selection.



Position Calibration is only used when the full travel of the actuator is constrained or limited such that 0 to 60 degrees of travel is not used.



Calibration Sequence Overview

The following outlines the basic steps required to execute the position calibration.

Automatic Mode

- 1. Select Automatic Position Calibration Mode.
- 2. Select CW or CCW Direction.
- 3. L-Series automatically rotates in both CW and CCW directions until the stops are detected. The values are then captured and stored.
- 4. When completed, cycle the power on the L-Series.
- 5. It is recommended that a Position Verification be performed to confirm the calibration is correct. See Position Verification below.

Manual

- 1. Determine to rotational travel limits. This can be done by positioning the unit to the minimum and maximum positions and recording the position settings.
- 2. Select Manual Position Calibration Mode.
- 3. Select Direction.
- 4. Enter the pre-determined rotational travel limits values.
- 5. When completed, cycle the power on the L-Series.
- 6. It is recommended that a Position Verification be performed to confirm the calibration is correct. See Position Verification below.

Position Verification

When the Verify Position screen is entered, the control is put into position control and the position is set to the position the control was at when the screen was entered. The screen displays the "User" Requested Position, Actual Position, Minimum Position, and Maximum Position (see figure 4-18). These User Positions are calculated from the user-calibrated stops.

The Full Travel Actual Position is the full stroke factory position without user stops after software linearization. The Full Travel Sensor Position is the full stroke factory position without user stops before software linearization. The Full Travel Sensor Position will match the TPS Output Signal.

The Verify Position screen can be used to check the calibration or to get the minimum and maximum position values for the manual calibration. If the Enable Requested Position Tuning box is checked the valve can be positioned anywhere from 0 to 100% of the user minimum and maximum stops by entering a value into the Requested Position. If the Enable Requested Position Tuning box is unchecked the valve will go limp and can be physical positioned by hand.



If the full factory position calibration range is not being used (the Manual or Automatic Calibration has been performed) and the minimum position direction is changed, the calibration must be run again for the Verify Position mode to work correctly.




Figure 4-18. Service Tool—Verify Position Calibration

Manual

The manual calibration mode is used to set the minimum position and fail direction and to calibrate the valve to user soft stops (inside of any physical stops). The first screen to appear when entering the manual mode is used to set the minimum position and fail direction. This setting must be correct before manually calibrating the valve.





Figure 4-19. Service Tool—Manual Position Calibration

The next screen is used to set the minimum and maximum positions for the user soft stops. To find the minimum and maximum soft stops use the verify position mode described above to position the valve and use the Full Travel Actual Position reading for minimum and maximum position values.






Figure 4-20. Service Tool—Manual Position Calibration Settings

Automatic

The automatic calibration mode is used to set the minimum position and fail direction and to calibrate the valve to user physical stops (mechanical hard stops). Like the manual mode, the first screen to appear is used to set the minimum position and fail direction. This setting must be correct before automatic calibration is performed.

After setting minimum position and fail direction the screen below will appear. The control is now moving first to the CCW stop and then to the CW stop to get the physical minimum and maximum positions.



After leaving this mode, power must be cycled for the new settings to take effect.




Figure 4-21. Service Tool – Auto Position Calibration

Chapter 5. Troubleshooting

Introduction

This chapter presents several broad categories of application failures typically experienced in the field, possible causes, and some tests used to verify the causes. Because the exact failure experienced in the field is the product of the mechanical/electrical failure combined with the configuration file resident in the control, it is left as the OEM's responsibility to create a more detailed troubleshooting chart for the end user. Ideally, this end-user troubleshooting chart will contain information about mechanical, electrical, engine, and load failures in addition to the possible governor failures. For more detailed information about governor system failure modes and effects, contact Woodward for a copy of the system DFMEA.

The troubleshooting scenarios listed below assume that the end user has a digital multi-meter at his disposal for testing voltages and checking continuity, and assume that the application has been engineered and tested thoroughly.

General System Troubleshooting Guide

The following is a general troubleshooting guide for areas to check which may present potential difficulties. By making these checks appropriate to your engine/turbine before contacting Woodward for technical assistance, your system problems can be more guickly and accurately assessed.

- Valves
- Is the wiring correct?
- Is the direction of the stroke correct?
- Is the direction of the failsafe shutdown correct?
- Does the valve move through its proper stroke smoothly?
- Does the valve travel its full stroke?
- Can mid-stroke be obtained and held?
- Does the valve fully seat (close)?
- Does the valve fully open?

Engine/Generator Troubleshooting

Problem	Possible Cause	Suggested Test/Correction
Engine does not start	Stuck throttle/frozen shaft	Move throttle by hand. Assess smoothness,
		friction, and return spring force.
	Power not applied to control	Disconnect starter motor solenoid. Disconnect harness from governor. Activate application. Test for +12/24 V between +12/24 V pin and ground pin.
	Run Enable not closed	Verify status of input. Measure input. Verify input and configuration using Service Tool.
	No configuration or incorrect configuration in controller.	Using Service Tool, read configuration from controller and evaluate parameters for correction.
	Fault detected in controller.	Using Service Tool, read faults from controller. Verify/correct any shutdown conditions.
Engine unstable	Improperly tuned dynamics.	Using Service Tool, tune the position dynamics.
	Intermittent position command input signal.	Using Service Tool, verify fault indications.
	Device sending position command is sending oscillating signal.	Measure input signal. Verify signal using Service Tool.
Poor frequency control	Improperly tuned dynamics.	Using Service Tool, tune the position dynamics.
	Friction/dither improperly set.	Using Service Tool, adjust the Friction/Dither setting.
Unable to develop full power	Non-indexed linkage slipped on shaft.	Manually verify full travel of throttle plate.
	Fault detected in controller.	Using Service Tool, view status of fault codes. Take appropriate action for active faults.
Not controlling at desired position setpoint	PWM input signal inaccuracy.	Measure input duty cycle and convert to percentage. Verify controller signal using Service Tool. If different, adjust the PWM Offset value in the Configuration Editor.
	Wiring fault or ground loop.	Check the wiring.
		Look for loose connections and disconnected or misconnected cables and connections.
		Remove all wiring except the position command and power input and verify operation/functionality.
	Analog input signal inaccuracy.	Measure the analog command voltage arriving at pin 10 to verify that it is at the expected value in the range of 0.5 to 4.5 V. Use the service tool to verify that AUX2 is being read correctly.
	Output shaft is bound or sticking.	Manually verify full shaft movement. Use the "verify position" function of the service tool (Chapter 4).
Discrete output not working	Wiring fault.	Check the wiring leading to pin 9 for open connections or misconnections.
		Verify that pin 9 is not connected directly to input power or ground.
	Configuration.	Using the Service Tool, verify that the faults and shutdowns are selected properly and that the output is configured for expected operation (either normally "on" or normally "off").

Problem	Possible Cause	Suggested Test/Correction
Service Tool not communicating–'Not Connected' status	Wiring fault.	Check AUX3 and AUX4 for loose or misconnected connections.
indicated		Verify harness setup and connections (see chapter 4)
		Check that Service Tool is running.
		Verify the port setting is correct.
	CAN is enabled.	Must be 'connecting' during power-up on CAN units.
Service Tool not communicating–'Error message displayed on PC when trying to connect	Old version of Service Tool or file corruption or bad install.	Re-install Service Tool, get the latest version from the Woodward web site (www.woodward.com)
Service Tool will not accept password	Cap Lock is on.	Password is case sensitive, make sure you enter the password correctly using upper and lower case.
		If password is lost contact the OEM for retrieval.

Troubleshooting Diagnostic Flags

Error Flag	Description	Possible Source	Possible Action
Supply Voltage	The power supply voltage	Bad or damaged battery.	Replace battery.
Failure	is higher than the diagnostic limits.	Defective battery charging system.	Fix battery charging system.
	The Power supply voltage is lower than the diagnostic limits.	Incorrect setting of power supply voltage level.	Set correct voltage levels on power supply.
	, and the second	Power supply wiring to long or to thin. Control will flag low voltage during higher power uses.	Make sure wiring is of the correct thickness and length according to manual.
Temperature Sense Failed	This error is set if the temperature inside the control is higher or lower than allowed by the	Control has been placed in an environment that is too hot or too cold.	Lower temperature by adding cooling, heat shielding, moving the unit, etc.
	specifications.	The internal temperature sensor is defective. This can be determined	Increase temperature by adding heat.
		by checking the temperature of the unit and comparing this to the service tool value of the electronics temperature.	Return unit to Woodward for repair.
Position Error	If the demanded position and the actual position are outside the configured	Incorrect position control dynamics or friction setting.	Check/tune position dynamics using the Service Tool.
	limits.	Binding or excessive friction in the actuator linkage, or stops are set inside the desired range of travel.	Perform a position calibration.
			Check all mechanical linkages and stops.
Position Sensor Failure	If the internal position sensor is outside the diagnostic limits.	Internal failure of position sensor.	Return unit to Woodward.
Internal Shutdown	All internal shutdowns will set this flag.	The Control is defective.	Return unit to Woodward.
EEPROM Failure	The software can't write to the EEPROM.	The Control is defective.	Return unit to Woodward.
	The software can't read from the EEPROM.		
Brown Out Reset	The brown out detection flag indicates power to the	Power source voltage drop.	Possible power problem.
	Control has sagged to a point of non-operation and is now restored.	Loss of power or intermittent power supply wiring.	Check wiring for bad or loss connection.
		Power supply wiring to long or to thin. L-Series will reset during transient power uses.	Make sure wiring is of the correct thickness and length according to manual.
Watchdog Reset	If the watchdog has reset the Control, this flag will set.	After software update, the software watchdog will reset the Control.	This is a normal situation. Reset the error code and reset the stored errors.
		The software is disrupted by EMI or an internal component failure.	This is an abnormal situation. Return the unit to Woodward.

Error Flag	Description	Possible Source	Possible Action
Overtemperature	High internal temperature.	Detection of high of temperature.	Check ambient temperature around Control.
			Verify temperature reading using service tool.
			If the temperatures seem normal, could indicate a problem with the temperature sensor.
Relay Fail Short	Control detected a fault in the discrete out wiring.	Incorrect or intermittent wiring problem.	Check wiring for bad or lost connection.
Run Enable Shutdown	Control detected that the Run Enable discrete in is not active, and CAN	Incorrect or intermittent wiring problem.	Check wiring for bad or lost connection.
	communications have stopped.	Incorrect configuration.	Verify configuration. Check Run Enable setting.
Position Demand Failed	Control detected all position demands failed.	Incorrect or intermittent wiring problem.	Check wiring for bad or lost connection.
		Incorrect configuration.	Verify configuration. Check Run Enable setting.
Analog Demand Failed	Control detected analog (0–5 V) position demand failed.	Incorrect or intermittent wiring problem.	Check wiring for bad or lost connection. Following Analog Input troubleshooting listed below.
		Incorrect configuration.	Verify configuration.
PWM Demand Failed	Control detected PWM position demand failed.	Incorrect or intermittent wiring problem.	Check wiring for bad or lost connection. Following PWM Input troubleshooting listed below.
		Incorrect configuration.	Verify configuration. Check Run Enable setting.
CAN Demand Failed	Indication that CAN messages (PDO Rx) are received at a rate slower than the configured	Incorrect or intermittent wiring problem.	Check wiring for bad or lost connection. Follow the CAN troubleshooting listed below.
	minimum update rate (CAN Fail Timeout).	Incorrect configuration.	Verify CAN configuration settings.
		Device not sending updates fast enough or regularly (bursts).	Verify ECM messages and update rates. Verify configuration of L-Series min update rate.
Position Tamper Fault	Control determined the primary demand is not tracking the CAN position	Incorrect or intermittent wiring problem.	Check wiring for bad or lost connection.
	demand.	Incorrect configuration.	Verify configuration. Check CAN Tracking settings.

Electrical Troubleshooting Guide

Analog Input

If the Analog Input is not functioning properly, verify the following:

- Measure the input voltage. It should be in the range of 0.5–4.5 V.
- Check the values seen by the L-Series driver using the Service Tool and verify that it matches the input signal.
- Verify that there are no or minimal ac components to the Analog Input signal. AC components can be caused by improper shielding.
- Check the wiring. If the inputs are reading 0 or the engineering units that correspond to 0 V, look for loose connections and disconnected / misconnected cables/connections.
- Check the software configuration to ensure that the input is configured properly as the Demand Source.

PWM Input

If the PWM input is not functioning properly, verify the following:

- Measure the input voltage, frequency, and duty cycle.
- Check the values seen by the L-Series driver using the Service Tool and verify that is matches the input signal.
- Check the wiring. Look for loose connections and disconnected / misconnected cables/connections.
- Check the software configuration to ensure that the input is configured properly as the demand source.

CAN Input

If the CAN connection is not functioning properly, verify the following:

- Check the values seen by the L-Series driver, if any, using the Service Tool and verify that is matches the sent signal and/or received signal.
- Check the wiring. Look for loose connections and disconnected / misconnected cables/connections. Verify 120 Ohm resistor at ends of transmission lines.
- Check the software configuration to ensure that the signal is configured properly (Device ID, fail timeout, protocol, etc).

Run Enable Discrete Input

If the run enable discrete input is not functioning properly, verify the following:

- Measure the input voltage on the terminal block. It should be in the range of 10–28 Vdc.
- Check the status of the input from the Overview screen of the Service Tool.
- Check the wiring, looking for loose connections or misconnected cables.
- Verify the input is properly configured.
- Verify the position demand configuration. If CAN is configured, the shutdown will only occur after the input is open and CAN communications have stopped (CAN Fail).

Alarm or Shutdown Conditions

If the L-Series control has any alarm or shutdown conditions, refer to Chapter 2 for details on the exact cause of the condition. The Service Tool must be used to determine the cause of any shutdown or alarm condition. Refer also to the 'Troubleshooting Diagnostics Flags' section above.

Discrete Output

If the discrete output is not functioning properly, verify the following:

- Measure the output voltage on the terminal block. It should be in the range of 10–28 Vdc when the output is off/false. The voltage will be in this range only if all shutdowns are false. This can be verified through the Service Tool.
- Check the wiring, looking for loose connections or disconnected / misconnected cables.
- Verify the configuration of the output.

Service Tool

If the service tool is not functioning properly, review the installation information in Chapter 4. Verify the following:

- Check the wiring, looking for loose connections or disconnected / misconnected cables.
- Check that Service Tool is running. Verify the Port setting is correct.
- Follow on-screen error messages. Re-install software as needed. The latest version of software is available for download from the Woodward web site (www.woodward.com).

Chapter 6. Product Support and Service Options

Product Support Options

If you are experiencing problems with the installation, or unsatisfactory performance of a Woodward product, the following options are available:

- 1. Consult the troubleshooting guide in the manual.
- 2. Contact the **OE Manufacturer or Packager** of your system.
- 3. Contact the **Woodward Business Partner** serving your area.
- 4. Contact Woodward technical assistance via email (<u>EngineHelpDesk@Woodward.com</u>) with detailed information on the product, application, and symptoms. Your email will be forwarded to an appropriate expert on the product and application to respond by telephone or return email.
- 5. If the issue cannot be resolved, you can select a further course of action to pursue based on the available services listed in this chapter.

OEM or Packager Support: Many Woodward controls and control devices are installed into the equipment system and programmed by an Original Equipment Manufacturer (OEM) or Equipment Packager at their factory. In some cases, the programming is password-protected by the OEM or packager, and they are the best source for product service and support. Warranty service for Woodward products shipped with an equipment system should also be handled through the OEM or Packager. Please review your equipment system documentation for details.

Woodward Business Partner Support: Woodward works with and supports a global network of independent business partners whose mission is to serve the users of Woodward controls, as described here:

- A Full-Service Distributor has the primary responsibility for sales, service, system integration solutions, technical desk support, and aftermarket marketing of standard Woodward products within a specific geographic area and market segment.
- An Authorized Independent Service Facility (AISF) provides authorized service that includes repairs, repair parts, and warranty service on Woodward's behalf. Service (not new unit sales) is an AISF's primary mission.
- A Recognized Engine Retrofitter (RER) is an independent company that
 does retrofits and upgrades on reciprocating gas engines and dual-fuel
 conversions, and can provide the full line of Woodward systems and
 components for the retrofits and overhauls, emission compliance upgrades,
 long term service contracts, emergency repairs, etc.

A current list of Woodward Business Partners is available at www.woodward.com/directory.

Product Service Options

Depending on the type of product, the following options for servicing Woodward products may be available through your local Full-Service Distributor or the OEM or Packager of the equipment system.

- Replacement/Exchange (24-hour service)
- Flat Rate Repair
- Flat Rate Remanufacture

Replacement/Exchange: Replacement/Exchange is a premium program designed for the user who is in need of immediate service. It allows you to request and receive a like-new replacement unit in minimum time (usually within 24 hours of the request), providing a suitable unit is available at the time of the request, thereby minimizing costly downtime.

This option allows you to call your Full-Service Distributor in the event of an unexpected outage, or in advance of a scheduled outage, to request a replacement control unit. If the unit is available at the time of the call, it can usually be shipped out within 24 hours. You replace your field control unit with the like-new replacement and return the field unit to the Full-Service Distributor.

Flat Rate Repair: Flat Rate Repair is available for many of the standard mechanical products and some of the electronic products in the field. This program offers you repair service for your products with the advantage of knowing in advance what the cost will be.

Flat Rate Remanufacture: Flat Rate Remanufacture is very similar to the Flat Rate Repair option, with the exception that the unit will be returned to you in "likenew" condition. This option is applicable to mechanical products only.

Returning Equipment for Repair

If a control (or any part of an electronic control) is to be returned for repair, please contact your Full-Service Distributor in advance to obtain Return Authorization and shipping instructions.

When shipping the item(s), attach a tag with the following information:

- return number:
- name and location where the control is installed;
- name and phone number of contact person;
- complete Woodward part number(s) and serial number(s);
- description of the problem;
- instructions describing the desired type of repair.

Packing a Control

Use the following materials when returning a complete control:

- protective caps on any connectors;
- antistatic protective bags on all electronic modules;
- packing materials that will not damage the surface of the unit;
- at least 100 mm (4 inches) of tightly packed, industry-approved packing material;
- a packing carton with double walls;
- a strong tape around the outside of the carton for increased strength.



To prevent damage to electronic components caused by improper handling, read and observe the precautions in Woodward manual 82715, *Guide for Handling and Protection of Electronic Controls, Printed Circuit Boards, and Modules*.

Replacement Parts

When ordering replacement parts for controls, include the following information:

- the part number(s) (XXXX-XXXX) that is on the enclosure nameplate;
- the unit serial number, which is also on the nameplate.

Products Used In

Engineering Services

Woodward's Full-Service Distributors offer various Engineering Services for our products. For these services, you can contact the Distributor by telephone or by email.

- Technical Support
- Product Training
- Field Service

Products Used In

Technical Support is available from your equipment system supplier, your local Full-Service Distributor, or from many of Woodward's worldwide locations, depending upon the product and application. This service can assist you with technical questions or problem solving during the normal business hours of the Woodward location you contact.

Product Training is available as standard classes at many Distributor locations. Customized classes are also available, which can be tailored to your needs and held at one of our Distributor locations or at your site. This training, conducted by experienced personnel, will assure that you will be able to maintain system reliability and availability.

Field Service engineering on-site support is available, depending on the product and location, from one of our Full-Service Distributors. The field engineers are experienced both on Woodward products as well as on much of the non-Woodward equipment with which our products interface.

For information on these services, please contact one of the Full-Service Distributors listed at www.woodward.com/directory.

Contacting Woodward's Support Organization

For the name of your nearest Woodward Full-Service Distributor or service facility, please consult our worldwide directory published at www.woodward.com/directory.

You can also contact the Woodward Customer Service Department at one of the following Woodward facilities to obtain the address and phone number of the nearest facility at which you can obtain information and service.

Products Used In

Electrical Power Systems	Engine Systems	Industrial Turbomachinery
Liectrical i ower Systems	Liigine Systems	Systems
FacilityPhone Number	FacilityPhone Number	FacilityPhone Number
Brazil+55 (19) 3708 4800	Brazil+55 (19) 3708 4800	Brazil+55 (19) 3708 4800
China+86 (512) 6762 6727	China+86 (512) 6762 6727	China+86 (512) 6762 6727
Germany:	Germany +49 (711) 78954-510	India+91 (129) 4097100
Kempen+49 (0) 21 52 14 51	India+91 (129) 4097100	Japan+81 (43) 213-2191
Stuttgart +49 (711) 78954-510	Japan+81 (43) 213-2191	Korea+82 (51) 636-7080
India+91 (129) 4097100	Korea+82 (51) 636-7080	The Netherlands- +31 (23) 5661111
Japan+81 (43) 213-2191	The Netherlands- +31 (23) 5661111	Poland+48 12 295 13 00
Korea+82 (51) 636-7080	United States +1 (970) 482-5811	United States +1 (970) 482-5811
Poland+48 12 295 13 00		
United States +1 (970) 482-5811		

For the most current product support and contact information, please visit our website directory at www.woodward.com/directory.

Technical Assistance

If you need to contact technical assistance, you will need to provide the following information. Please write it down here before contacting the Engine OEM, the Packager, a Woodward Business Partner, or the Woodward factory:

General	
Your Name	
Site Location	
Phone Number	
Fax Number	
Prime Mover Information	
Manufacturer	
Engine Model Number	
Number of Cylinders	
Type of Fuel (gas, gaseous, diesel, dual-fuel, etc.)	
Power Output Rating	
Application (power generation, marine, etc.)	
Control/Governor Information	
Control/Governor #1	
Woodward Part Number & Rev. Letter	
Control Description or Governor Type	
Serial Number	
Control/Governor #2	
Woodward Part Number & Rev. Letter	
Control Description or Governor Type	
Serial Number	
Control/Governor #3	
Woodward Part Number & Rev. Letter	
Control Description or Governor Type	
Serial Number	
Symptoms	
Description	

If you have an electronic or programmable control, please have the adjustment setting positions or the menu settings written down and with you at the time of the call.

Appendix A. Acronyms/Abbreviations

AUX auxiliary **EEPROM** electrically-erasable programmable read-only memory **EMC** electro-magnetic compatibility GUI graphic user interface inputs/outputs I/O Isoch isochronous ITB integrated throttle body L-Series Woodward electronic engine governor that contains both a rotary actuator and a controller circuit board MPU magnetic pick up OEM original equipment manufacturer PWM pulse-width modulated revolutions per minute rpm RS-232 a communications standard **TPS** throttle position sensor

Appendix B. L-Series Configuration Summary

Chapter 4.
tion Controller
CCW CW = = = =
PWM 0.5 V CAN Not Used PWM 0.5 V CAN = Not Used Aux 1
de Low Side =
= = J1939 CANopen =
Yes No

Discrete Out Discrete Out Normally On? Indicates Watchdog Reset? Indicates Brownout Reset? Indicates EE Prom Failure? Indicates Position Sensor Failure? Indicates Temperature Sensor Failure? Indicates Supply Voltage Fault? Indicates Relay Fault?	Yes No Yes No Yes No Yes No Yes No Yes No Yes No
Indicates Relay Fault? Indicates Position Demand Failure? Indicates Overtemperature? Indicates Position Error? Indicates Run Enable Shutdown? Indicates Analog Demand Failed? Indicates PWM Demand Failed? Indicates CAN Demand Failed? Indicates Position Tamper Fault?	Yes No Yes No
Faults (Shutdown/Alarms) Temp Sensor Failure Action Supply Voltage Fault Action Relay Fault Action Position Demand Failure Action Overtemperature Action Position Error Action Position Tamper Fault	Shutdown Alarm Shutdown Alarm Shutdown Alarm Shutdown Alarm Shutdown Alarm Shutdown Alarm
Faults are Latched? CAN Fault is Latched? Position Error Max (%) Position Error Delay (sec) CAN Tracking Error Max (%) CAN Tracking Error Delay (sec)	Yes No Yes No = = = =
Security Apply security to Configuration Reading? Apply security to Configuration Loading? Apply security to Position PID Edit? Apply security to Position Calibration? Password	Yes No Yes No Yes No Yes No

Appendix C. **L-Series Control Specifications**

Specifications

Power Supply 12/24 V systems (10-32 Vdc) reverse polarity

protection, 2.5 A max

Power Consumption 32 W maximum

Nominal: 0.34 N·m (0.25 lb-ft) at 25 °C Torque

Maximum Transient (at 105 °C): 0.20 N·m (0.15 lb-ft)

Minimum Continuous (at 105 °C): 0.14 N·m (0.10 lb-ft)

Mass/Weight 425 g (15 oz)

Power-Up to Operation Time <250 ms (< 1 s CAN versions)

Performance

±2% at 25 °C Positioning Accuracy

±4% (analog), ±3.6% (PWM), ±3% (CAN)-over temp

Slew Time 10%-90% 33 ms 1% Overshoot Settling Time 10 ms

-6 db Roll-off at ±0.5% Input 32 Hz 8 Hz -3 db Roll-off at ±2% Input

Environment

Ambient Operating Temperature -40 to +105 °C (-40 to +221 °F)

Storage Temperature -40 to +125 °C (-40 to +257 °F)

EMI/RFI EN61000-6-2: Immunity for Industrial Environments

EN61000-6-4: Emissions for Industrial Environments SAE J1113-21: Radiated Immunity (100 V/m) SAE J1113-11: Conducted Transient Immunity –

Pulse 5b

Suppressed Load Dump (45 V)

US MIL-STD 810E, Method 507.3, Procedure III Humidity Salt Spray US MIL-STD 810E, Method 509.3, Procedure I

Shock MS1-40G 11 ms sawtooth

Random Vibration Random: 0.3 G²/Hz, 10-2000 Hz (22.1 Grms) 3 h/axis

Sine: 5 G 2.5 mm peak-to-peak, 5-2000 Hz, 3 h/axis,

90 min dwells, 1 octave/min

SAE J1211, Paragraph 4.8.3 (modified) Drop

Thermal Shock SAE J1455, Paragraph 4.1.3.2

Ingress Protection IP56 per EN60529

Analog Command Input

Parameter	Value
Input Type	0–5 V, Single-Ended Input
Input Scaling	0.5 V = 0% and 4.5 V = 100% position
Max Input (Full Scale)	5 V ± 1%
Isolation	None
Transient Protection	According to EMC norm
Input Impedance	499 kΩ
Anti-Aliasing Filter	1 anti-aliasing pole at 0.001 ms (159 kHz)
Resolution	10 bits
Accuracy	±1.3% of full scale over the temperature
	range of –40 to +125 °C, including drift
I/O Latency	6.5 ms
Calibration Method	2-point linear software calibration
Out of Range Signal	< 0.2 V or > 4.8 V
Overvoltage Protection	Input protected against 32 Vdc steady
	state

PWM Command Input

Parameter	Value
Input Magnitude	5–32 V p-p
Frequency Range	300–1500 Hz
Duty Cycle Scaling	10% = fully closed and 90% = fully open
Isolation	None
Input Impedance Push-Pull Mode	44 kΩ–113 kΩ
Input Impedance Open Collector Mode,	15 kΩ
High Side or Low Side.	
Resolution	16 bits at 300 Hz, 14 bits at 1.5 kHz
Accuracy	±1% of full scale (duty cycle), over the
	temperature range of –40 to +125 °C,
	including drift
I/O Latency	6.5 ms
Calibration	Duty cycle offset adjustment is available in
	Service Tool. This will tailor the input to
	the signal source
Out of Range Frequency	None
Out of Range Duty Cycle	< 3% or > 97%

Discrete Input

Parameter	Value
Input Current	0.5 mA @ 5 Vdc
Input Type	Ground referenced discrete input
Delay Time for Shutdown	< 200 ms for system to recognize shutdown
Delay Time for Reset	< 1 s for valves to move to minimum position
Detection	
Max Voltage from +	32 V (power input voltage)
Connection	
Isolation	None, Intended for use with external relay or other dry
	contact
Input Thresholds	> 3.1 Vdc = "ON" < 0.8 Vdc = "OFF"
Input Current	0.5 mA @ 5 Vdc

Discrete Output

Diodrete Gatpat	
Parameter	Value
Output Type	Low-side output driver
Max Contact Voltage (Open)	32 V
Max Current	0.5 A
Max Contact Voltage at 0.5 A	1.5 V
(Closed)	
Max Delay Time for Opening	6.5 ms
Contact	
Default at Power Up	Configurable in software
Error Condition	Configurable in software
OK Condition	Configurable in software
Driving Inductive Loads	Yes, internally protected low-side switch
Protection	Utilizes circuitry that will open the contact when output
	contacts are short-circuited. Self-resetting when fault
	is removed

TPS Output

1F3 Output	
Parameter	Value
Output Type	0–5 V, single-ended
Output Scaling	0.75 V = full CCW position and 4.25 V = full CW
	position
Isolation	None
3 db Circuit Bandwidth	350 Hz
Transient Protection	According to EMC norm
Output Impedance	2.8 kΩ (±1%)
Accuracy	±10% of full scale, @ 25 °C
Temperature Drift	±0.4% over the full temperature range
I/O Latency	n/a – direct from position sensor
Calibration Method	Sensor-in-place factory calibration. 2-point linear
Out of Range Signal	< 0.25 V or > 4.75 V
Overvoltage Protection	Output protected against 32 Vdc, steady-state; if >28
	V is applied to pin 2, a position-related error will be
	annunciated

RS-232 Serial Communication Service Port

Parameter	Value
Isolation	None
Baud Rate	Fixed 19.2 Kbaud
Electrical Interface	Outputs are TTL level. Requires external transceiver for conversion to RS-232 levels for proper communication!!
Pinout	Tx = pin 4, $Rx = pin 6$, $Gnd = pin 3$
Maximum Cable Length	10 m (33 ft), not meant for permanent connection (for service only)
Cable Type	Straight-through (no crossover)

CAN Communications (optional)

CAN Communications (optional	/
Parameter	Value
Туре	2-wire CAN, version 2.0B
,.	software selectable CANopen or J1939
J1939	Complies with SAE J1939 but uses proprietary group
	extensions; 29-bit
CANopen	CANopen node (ref CiA DS301 Version 4.02)
Device Identifier	Service Tool software setting
Isolation	None
Baud Rate	Fixed 250 Kbaud
Pinout	Lo = pin 6 (AUX4), Hi = pin 4 (AUX3)
	(shared with RS-232 communications)
Line Limitations	40 m (130 ft)
	If an isolator is used:
	Trunk Length: 250 m (820 ft)
	Maximum Drop: 6 m (20 ft)
	Cumulative Drop: 78 m (256 ft)
Fault Detection	Service Tool setting

Electronics Temperature Sensor

Parameter	Value
Accuracy	±2 °C at 25 °C ambient ±3 °C over full range (–40 to +125 °C)
I/O Latency	6.5 ms

Software Execution Rates

Software Routine	Nominal Software Execution Rate
Position Control Algorithms	1.6 ms
Position Demand Algorithms	6.5 ms
Analog Input Logic	6.5 ms
PWM Input Logic	6.5 ms
Serial Port	background task
CAN communications	6.5 ms
Run Enable Discrete Input	6.5 ms
Discrete Output	6.5 ms
Diagnostics	6.5 ms

Reliability and Quality Goals

The L-Series control system has a reliability target of 17 500 hours MTBF. It also has a quality goal of less than 25 PPM when measuring out-of-the-box defects. This quality goal is a target based on continuous improvement.




Figure C-1. Bode Plot of L-Series Response

Revision History

Changes in Revision G—

• Added information about new derivatives (firmware part numbers 5418-3479 & 5418-6750)

Declarations

DECLARATION OF CONFORMITY

According to EN 45014

Manufacturer's Name: WOODWARD GOVERNOR COMPANY (WGC)

Industrial Controls Group

Manufacturer's Address: 1000 E. Drake Rd.

Fort Collins, CO, USA, 80525

Model Name(s)/Number(s): L-Series

8404-xxxx and similar

Conformance to Directive(s): 89/336/EEC COUNCIL DIRECTIVE of 03 May 1989 on

the approximation of the laws of the Member States relating

to electromagnetic compatibility and all applicable

amendments.

Applicable Standards: EN61000-6-4, (2001): EMC Part 6-4: Generic Standards -

Emissions for Industrial Environments

EN61000-6-2, (2001): EMC Part 6-2: Generic Standards -

Immunity for Industrial Environments

We, the undersigned, hereby declare that the equipment specified above conforms to the above Directive(s).

MANUFACTURER

Signature

Scott McWhorter

Full Name

Engineering Manager

Position

WGC, Fort Collins, CO, USA

Place

06/16/05

Date

86

Declaration of Incorporation

Woodward Governor Company 1000 E. Drake Road Fort Collins, Colorado 80525 United States of America

Product: L-Series Actuator

Part Number: 6300-1005 and similar

The undersigned hereby declares, on behalf of Woodward Governor Company of Loveland and Fort Collins, Colorado, that the above-referenced product is in conformity with the following EU Directives as they apply to a component:

98/37/EEC (Machinery)

This product is intended to be put into service only upon incorporation into an apparatus/system that itself will meet the requirements of the above Directives and bears the CE mark.

MANUFACTURER

Signature

James D. Rudolph

Full Name

Engineering Manager

Position

WGC, Fort Collins, CO, USA

Place

Date // //3/0

00240-04-EU-02-03

87

We appreciate your comments about the content of our publications.

Send comments to: icinfo@woodward.com

Please reference publication 26289G.





PO Box 1519, Fort Collins CO 80522-1519, USA 1000 East Drake Road, Fort Collins CO 80525, USA Phone +1 (970) 482-5811 • Fax +1 (970) 498-3058

Email and Website—www.woodward.com

Woodward has company-owned plants, subsidiaries, and branches, as well as authorized distributors and other authorized service and sales facilities throughout the world.

Complete address / phone / fax / email information for all locations is available on our website.