



Product Manual 26554
(Revision B, 11/2019)
Original Instructions

**IGV (Inlet Guide Vane) Actuator
for IECEx and ATEX Intrinsically Safe
Installation**

Installation and Operation Manual



General Precautions

Read this entire manual and all other publications pertaining to the work to be performed before installing, operating, or servicing this equipment.

Practice all plant and safety instructions and precautions.

Failure to follow instructions can cause personal injury and/or property damage.



Revisions

This publication may have been revised or updated since this copy was produced. To verify that you have the latest revision, check manual **26455**, *Customer Publication Cross Reference and Revision Status & Distribution Restrictions*, on the *publications* page of the Woodward website:

<http://www.woodward.com/>

The latest version of most publications is available on the *publications* page. If your publication is not there, please contact your customer service representative to get the latest copy.




Proper Use

Any unauthorized modifications to or use of this equipment outside its specified mechanical, electrical, or other operating limits may cause personal injury and/or property damage, including damage to the equipment. Any such unauthorized modifications: (i) constitute "misuse" and/or "negligence" within the meaning of the product warranty thereby excluding warranty coverage for any resulting damage, and (ii) invalidate product certifications or listings.



Translated Publications

If the cover of this publication states "Translation of the Original Instructions" please note:

The original source of this publication may have been updated since this translation was made. Be sure to check manual **26455**, *Customer Publication Cross Reference and Revision Status & Distribution Restrictions*, to verify whether this translation is up to date. Out-of-date translations are marked with . Always compare with the original for technical specifications and for proper and safe installation and operation procedures.

Revisions— A bold, black line alongside the text identifies changes in this publication since the last revision.

Woodward reserves the right to update any portion of this publication at any time. Information provided by Woodward is believed to be correct and reliable. However, no responsibility is assumed by Woodward unless otherwise expressly undertaken.

Contents

WARNINGS AND NOTICES.....	3
ELECTROSTATIC DISCHARGE AWARENESS	4
REGULATORY COMPLIANCE	5
CHAPTER 1. GENERAL INFORMATION.....	7
Introduction.....	7
IGV Actuator Functional Characteristics	8
CHAPTER 2. IGV ACTUATOR OPERATION.....	18
CHAPTER 3. STANDARD COMPONENT DETAILS	19
Triple Coil Electrohydraulic Servo Valve Assembly	19
Trip Relay Valve Assembly	19
Hydraulic Filter Assembly.....	19
LVDT Position Feedback Sensors	19
CHAPTER 4. INSTALLATION	20
General.....	20
Unpacking	20
Hydraulic Connections	21
Electrical Connections.....	21
Electronic Settings	22
CHAPTER 5. MAINTENANCE AND HARDWARE REPLACEMENT	26
Maintenance.....	26
Hardware Replacement	26
Troubleshooting Charts.....	29
CHAPTER 6. PRODUCT SUPPORT AND SERVICE OPTIONS	32
Product Support Options.....	32
Product Service Options	32
Returning Equipment for Repair	33
Replacement Parts.....	34
Engineering Services	34
Contacting Woodward's Support Organization	34
Technical Assistance	35
REVISION HISTORY	36
COMPONENT DECLARATIONS	37

Illustrations and Tables

Figure 1-1a. IGV Actuator with Hydraulic Trip (left side view)	9
Figure 1-1b. IGV Actuator with Hydraulic Trip (front and top views)	10
Figure 1-1c. IGV Actuator with Hydraulic Trip (right side view)	11
Figure 1-1d. IGV Actuator (partial cutaway with reference numbers).....	12
Figure 1-2a. 7E IGV Actuator with Hydraulic Trip (left side view)	13
Figure 1-2b. 7E IGV Actuator with Hydraulic Trip (front and top views)	14
Figure 1-2c. 7E IGV Actuator with Hydraulic Trip (right side view).....	15
Figure 1-3. IGV Hydraulic Schematic (Hydraulic Trip System).....	16
Figure 1-4. Servo Valve Electrical Schematic and Wiring Diagram.....	16
Figure 1-5. LVDT Electrical Schematic and Wiring Diagram	17
Figure 4-1. IGV Actuator Block Diagram.....	22
Figure 4-2. Moog Drawing G4400 Configuration 4	24
Figure 4-3. Sentech Drawing A607003-04.....	25
Table 1-1. IGV Actuator Functional Characteristics.....	8
Table 1-2. IGVs with Hydraulic Trip	8

Warnings and Notices

Important Definitions



This is the safety alert symbol used to alert you to potential personal injury hazards. Obey all safety messages that follow this symbol to avoid possible injury or death.

- **DANGER** - Indicates a hazardous situation, which if not avoided, will result in death or serious injury.
- **WARNING** - Indicates a hazardous situation, which if not avoided, could result in death or serious injury.
- **CAUTION** - Indicates a hazardous situation, which if not avoided, could result in minor or moderate injury.
- **NOTICE** - Indicates a hazard that could result in property damage only (including damage to the control).
- **IMPORTANT** - Designates an operating tip or maintenance suggestion.

WARNING

**Overspeed /
Overtemperature /
Overpressure**

The engine, turbine, or other type of prime mover should be equipped with an overspeed shutdown device to protect against runaway or damage to the prime mover with possible personal injury, loss of life, or property damage.

The overspeed shutdown device must be totally independent of the prime mover control system. An overtemperature or overpressure shutdown device may also be needed for safety, as appropriate.

WARNING

**Personal Protective
Equipment**

The products described in this publication may present risks that could lead to personal injury, loss of life, or property damage. Always wear the appropriate personal protective equipment (PPE) for the job at hand. Equipment that should be considered includes but is not limited to:

- Eye Protection
- Hearing Protection
- Hard Hat
- Gloves
- Safety Boots
- Respirator

Always read the proper Material Safety Data Sheet (MSDS) for any working fluid(s) and comply with recommended safety equipment.

WARNING

Start-up

Be prepared to make an emergency shutdown when starting the engine, turbine, or other type of prime mover, to protect against runaway or overspeed with possible personal injury, loss of life, or property damage.

Electrostatic Discharge Awareness

NOTICE

Electrostatic Precautions

Electronic controls contain static-sensitive parts. Observe the following precautions to prevent damage to these parts:

- Discharge body static before handling the control (with power to the control turned off, contact a grounded surface and maintain contact while handling the control).
- Avoid all plastic, vinyl, and Styrofoam (except antistatic versions) around printed circuit boards.
- Do not touch the components or conductors on a printed circuit board with your hands or with conductive devices.

To prevent damage to electronic components caused by improper handling, read and observe the precautions in Woodward manual **82715**, *Guide for Handling and Protection of Electronic Controls, Printed Circuit Boards, and Modules*.

Follow these precautions when working with or near the control.

1. Avoid the build-up of static electricity on your body by not wearing clothing made of synthetic materials. Wear cotton or cotton-blend materials as much as possible because these do not store static electric charges as much as synthetics.
2. Do not remove the printed circuit board (PCB) from the control cabinet unless absolutely necessary. If you must remove the PCB from the control cabinet, follow these precautions:
 - Do not touch any part of the PCB except the edges.
 - Do not touch the electrical conductors, the connectors, or the components with conductive devices or with your hands.
 - When replacing a PCB, keep the new PCB in the plastic antistatic protective bag it comes in until you are ready to install it. Immediately after removing the old PCB from the control cabinet, place it in the antistatic protective bag.

Regulatory Compliance

European Compliance:

ATEX Directive: Suitability is the result of ATEX compliance of the individual components as follows:

Servo valve is certified per KEMA02ATEX1015X
 Zone 0, Category 1, Group II, Ex ia IIB/IIC T4 Ga
 Zone 1, Category 2, Group II, Ex ia IIB/IIC T3 or T4 Gb
 Servo valve is certified per KEMA02ATEX1016X
 Zone 2, Category 3, Group II, Ex nA IIC T3 or T4 Gc

LVDT is certified per ITS03ATEX21023
 Zone 0, Category 1, Group II, Ex ia IIC T3 Ga
 LVDT is self-declared to
 Zone 2, Category 3, Group II, Ex nA II T3 Gc

Other European Compliance:

Compliance with the following European Directives or standards does not qualify this product for application of the CE Marking:

RoHS Directive: Restriction of Hazardous Substances 2011/65/EU:
 Woodward Turbomachinery Systems products are intended exclusively for sale and use only as a part of Large Scale Fixed Installations per the meaning of Art.2.4(e) of directive 2011/65/EU. This fulfills the requirements stated in Art.2.4(c) and as such the product is excluded from the scope of RoHS2.

ATEX Directive: Exempt from the non-electrical portion of the ATEX Directive 2014/34/EU due to no potential ignition sources per EN ISO 80079-36:2016 for Zone 2 installation.

Machinery Directive: Compliant as partly completed machinery with Directive 2006/42/EC of the European Parliament and the Council of 17 May 2006 on machinery.

Pressure Equipment Directive: Compliant as "SEP" per Article 4.3 to Pressure Equipment Directive 2014/68/EU on the harmonisation of the laws of the Member States relating to the making available on the market of pressure equipment.

Other International Compliance

IECEx: This suitability is the result of IECEx compliance of the individual components as follows:

Servo valve per IECEx KEM 10.0041X
 Ex ia IIB/IIC T4 Ga
 Ex ia IIB/IIC T3 or T4 Gb
 Ex nA IIC T3 or T4 Gc

LVDT per IECEx ITS 10.0031X
 Ex ia IIC T3 Ga
 LVDT per IECEx ITS 10.0032X
 Ex nA IIC T3 Gc

Special Conditions For Safe Use:

Wiring must be in accordance with North American Class I, Division 1 or European or other international Zone 1 Category 2 wiring methods as applicable, and in accordance with the authority having jurisdiction.

Field Wiring must be suitable for at least 121 °C.

Special Conditions for IECEx and ATEX compliance:

- If the servo valve has been used in a “nA” application, it cannot be subsequently safely used in an “ia” application
- Because the enclosure of the servo valve is made of aluminum, if it is mounted in an area where the use of Category 1G apparatus is required, it must be installed such that, even in the event of rare incidents, ignition sources due to impact and friction sparks are excluded.
- When installed in Zone 1 application, wires to the servo valve and LVDT must be installed with barriers per instructions in this manual.
- The LVDT must be installed only in locations providing adequate protection against entry of solid foreign objects or water capable of impairing safety.
- For use in an application in type of protection “n”, the screwed cable connector may only be disconnected when the circuit is de-energized or when the location is known to be non-hazardous.

**WARNING**

EXPLOSION HAZARD—Do not remove covers or connect/disconnect electrical connectors unless power has been switched off or the area is known to be non-hazardous.

Substitution of components may impair suitability for Zone 1 applications.

**AVERTISSEMENT**

RISQUE D'EXPLOSION—Ne pas enlever les couvercles, ni raccorder / débrancher les prises électriques, sans vous en assurer auparavant que le système a bien été mis hors tension; ou que vous vous situez bien dans une zone non explosive.

La substitution de composants peut rendre ce matériel inacceptable pour les emplacements de Zone 1.

Chapter 1.

General Information

Introduction

The IGV (Inlet Guide Vane) actuator controls the position of the inlet guide vanes of the GE Frame 7 industrial gas turbine system. The actuator provides highly accurate position control. The actuator is a double-acting design that will close the guide vane on loss of electrical or hydraulic signals. An on board hydraulic filter is designed into the manifold to augment the reliability of the servo valve and actuator. The servo valve is an electrically redundant triple-coil design. An ac-powered LVDT provides feedback for the actuator.

The Woodward IGV actuator (Figures 1-1 and 1-2) performs a dual function for industrial or utility gas turbines. One function rapidly closes the turbine inlet guide vane. The other function provides accurate position control of the turbine inlet guide vanes.

The IGV actuator features a modular design, and meets critical control characteristics, while allowing the same actuator design to accommodate a variety of stroke, force output, and mechanical interface arrangements. The electrical and mechanical interfaces have been designed for quick and easy assembly or removal of the actuator, at the factory or in the field. The components include an on-board hydraulic filter, electrohydraulic servo valve, trip valves, double-acting hydraulic cylinder, and dual LVDTs.

Optimum control of the inlet guide vane requires that the actuator accurately and quickly track the demand signals transmitted by the control. The IGV actuator has been designed to provide output forces that exceed the opening and closing requirements. The additional margin helps ensure that the system moves rapidly even under service conditions where the actuator has been contaminated or worn. The hydraulic trip relay valves have been selected to provide high operating force margins, and to ensure the desired closure rate of the actuator under trip conditions.

IGV Actuator Functional Characteristics

Table 1-1. IGV Actuator Functional Characteristics

Functional Requirement	IGV Actuator
Position Accuracy:	±1% full scale (over ±25 °F/±14 °C deviation from calibration)
Position Repeatability:	±0.5% of point over the range of 10 to 100%
Hydraulic Fluid Type:	Petroleum-based hydraulic fluids as well as fire resistant hydraulic fluids such as Fyrquel EHC
Maximum Operating Hydraulic Supply Pressure	1400 to 1800 psig (9653 to 12 411 kPa) (design at 1600 psig/11 032 kPa)
Proof Test Fluid Pressure Level	2700 psig (18 616 kPa) minimum per SAE J214 (Prod Test)
Minimum Burst Fluid Pressure	4500 psig (31 264 kPa) minimum per SAE J214
Fluid Filtration Required	10–15 µm at 75 Beta
Hydraulic Fluid Contamination Level	Per ISO 4406 code 18/16/13 max, code 16/14/11 preferred
Hydraulic Fluid Temperature	+50 to +160 °F (+10 to +71 °C)
Actuator Ambient Temperature	–40 to +250 °F (–40 to +121 °C)
Vibration Test Level	0.5 gp 5–100 Hz sine wave Random 0.01500 gr ² /Hz from 10 to 40 Hz ramping down to 0.00015 gr ² /Hz at 500 Hz
Shock	Limited to 30 G by servo valve
Trip Time	From 1 to 5 seconds at 1600 psi (11 032 kPa) supply pressure, 100 °F (38 °C) oil temperature and 3000–5000 lbf (13–22 kN) load (100–0% stroke)
Slew Time	0% to 100% in 4.5 ±1.5 seconds and 100% to 0% in 5 ±1.5 seconds
Trip Pressure (relative to hydraulic return)	Pick up and drop out pressures to be ≤30 psid
Hydraulic Fluid Connections for 7E Turbine	Trip Relay Pressure—0.500 SAE O-ring straight thread (-8) Supply Pressure—0.750 SAE O-ring straight thread (-12) Return Port—1.000 NPT port (-16)
Servo Input Current Rating	–7.2 to +8.8 mA (null bias 0.8 ±0.32 mA)
Paint	Two part Epoxy
Actuation Forces (opening and closing at 1600 psig/11 032 kPa)	Retract Force (open)—41 233 lb/183 404 N Extend Force—49 087 lb/218 339 N
Design Availability Objective	Better than 99.5% over an 8760 hour period

Table 1-2. IGVs with Hydraulic Trip

ACTUATOR	STROKE LENGTH	STROKE TOLERANCE	RETRACTED/OPEN	IGV OPEN	IGV CLOSED	IGV O.A.L
9904-1533	1.880"	±0.020	29.850 (758.18)	49.850 (1266.18)	51.730 (1313.93)	53.480 (1358.38)




Figure 1-1a. IGV Actuator with Hydraulic Trip (left side view)




Figure 1-1b. IGV Actuator with Hydraulic Trip (front and top views)




Figure 1-1c. IGV Actuator with Hydraulic Trip (right side view)




Figure 1-1d. IGV Actuator (partial cutaway with reference numbers)

NOTES:

1. WHEN WELDING - DO NOT USE ELECTRICAL COMPONENTS AS WELDING GROUND.
2. APPROXIMATE WEIGHT 500 LBS.
3. THIS IS AN INSTALLATION DRAWING OF 9904-989.




Figure 1-2a. 7E IGV Actuator with Hydraulic Trip (left side view)




Figure 1-2b. 7E IGV Actuator with Hydraulic Trip (front and top views)




Figure 1-2c. 7E IGV Actuator with Hydraulic Trip (right side view)




Figure 1-3. IGV Hydraulic Schematic (Hydraulic Trip System)

SERVOVALVE




Figure 1-4. Servo Valve Electrical Schematic and Wiring Diagram




Figure 1-5. LVDT Electrical Schematic and Wiring Diagram

NOTES

1. These general reference outline drawings apply to various Woodward IGV actuators. Consult Woodward for the latest outline drawing for your particular IGV actuator.
2. Installation Orientation Orientation vertical approximately as shown
See elsewhere in this manual for other installation recommendations
3. Approximate Weight:
IGV Actuator with hydraulic trip 487 lb / 221 kg
4. Service Manual Replacement Parts
Servo Valve—consult Woodward for part number
O-rings for servo valve—consult Woodward for part number
Filter element—consult Woodward for part number
Manual—consult Woodward for part number
LVDT—consult Woodward for part number
Trip relay valve—consult Woodward for part number
Seal kit for trip relay valve—consult Woodward for part number
5. Description of IGV Actuator
Process fluid hydraulic fluid
Temperature range hydraulic fluid 50 to 160 °F/10 to 71 °C
 ambient -40 to +250 °F/-40 to +121 °C

External leakage (none)
6. Actuation
Cylinder bore 6.250 inch diameter (158.75 mm)
Rod diameter 2.500 inch diameter (63.50 mm)

		TRIP		STROKE
		HYDRAULIC	ELECTRIC	
7E	9904-1533	Applicable	N/A	1.88"

- | | |
|------------------------------------|--|
| Static seals | Elastomer per US MIL-R-83248 (Viton) |
| Operating fluid | Petroleum-based hydraulic fluid as well as fire resistant hydraulic fluids such as Fyrquel EHC |
| Operating hydraulic pressure | 1400 to 1800 psig/8274 to 11 722 kPa |
| 7. Servo Valve Flow Rating | 10.0 US gal/min (38 L/min) at 1000 psid (6895 kPa) valve drop, 4-way |
| Electrical input rating | ±8 mA (sum of three coils) |
| First stage null bias | 10 ±4% Rated Flow Cylinder Port 1 to Drain and Pressure to Port 2 |
| Null Internal Leakage at 1600 psid | 0.42 US gal/min (1.6 L/min) (New)
0.75 US gal/min (2.8 L/min) (R+R) |
| Electrical connection | Mates with Bendix PYGMY Connector PT06P-12-8S |

IMPORTANT

These general reference outline drawings apply to various Woodward IGV actuators. Consult Woodward for the latest outline drawing for your particular IGV actuator.

Chapter 2.

IGV Actuator Operation

The IGV actuator is controlled by an electronic servo-control system (not included), which compares the demanded and actual actuator positions. The control system modulates the input current signal to the electrohydraulic servo valve to minimize the positioning system error. See Figure 1-3 for a functional schematic of the dual-acting actuator with hydraulic trip system. Hydraulic oil enters the actuator via a removable element filter with integral high ΔP indicator and is directed to a four-way electrohydraulic servo valve used in a three-way configuration. The PC1 control pressure output from the servo valve is directed to the upper cavity (rod end) of the hydraulic piston. When the force exerted by the hydraulic pressure exceeds the force of the opposing IGV force, the output piston retracts, rotating the Inlet Guide Vane ring in the opening direction.

The IGV actuator is available with a hydraulic trip system. A trip relay valve assembly is interposed between the electrohydraulic servo control valve and the servo output stage. In the hydraulic trip system, loss or reduction of the externally supplied trip signal pressure causes the trip relay valve to shift position. As the trip relay valve shifts position, it connects the lower cavity (head end) of the actuator piston directly to the hydraulic supply pressure. The supply pressure forces the actuation piston up to the extended position, rotating the Inlet Guide Vane ring to the closed position. Two redundant LVDT position feedback transducers are also mounted within each actuator. The LVDT sensor cores and support rods are connected to the main actuator output rod by an anti-rotation plate which is also coupled to a rod which is guided in a bushing. This guide bushing maintains LVDT alignment to minimize core damage due to sliding wear and the associated loss of sensing accuracy.

Chapter 3.

Standard Component Details

Triple Coil Electrohydraulic Servo Valve Assembly

The IGV actuator uses a two stage hydraulic servo valve to modulate the position of the output shaft and thereby control the inlet guide vane. The first stage torque motor uses a triple-wound coil, which controls the position of the first- and second-stage valves in proportion to the total electrical current applied to the three coils.

If the control system requires a rapid movement of the actuator, the total current is increased well above the null current. In such a condition, supply oil is admitted to the appropriate actuator piston cavity. The flow rate delivered to the piston cavity is proportional to the total current applied to the three coils. Thus, the actuator stroke velocity and the valve opening are also proportional to the current (above null) supplied to the torque motor above the null point.

If the control system requires a rapid movement to close the IGV actuator, the total current is reduced well below the null current. In such a condition, the actuator piston cavity is connected to the hydraulic drain circuit. The flow rate returning from the upper piston cavity of the valve is proportional to the magnitude of the total current below the null value. The flow rate and closing velocity of the valve is in this case proportional to the total current below the null point.

Near the null current, the servo valve essentially isolates the piston cavities from the hydraulic supply and drain, and the piston pressure is balanced to maintain a constant position. The control system, which regulates the amount of current delivered to the coils, modulates the current supplied to the coil to obtain proper closed loop operation of the system.

Trip Relay Valve Assembly

The IGV actuator is available with a hydraulic trip system. The IGV actuator uses two two-position, three-way, hydraulically operated valves to switch the position of the IGV actuator. One valve connects a servo port to the actuator rod end, and the other connects the other servo port to the actuator head end with pilot pressure applied. In the hydraulic trip system, pilot pressure is supplied externally by the customer. With no pilot pressure, the pump is connected to the actuator head end port, and the drain port is connected to the actuator rod end port. The valves are designed to ensure that pickup and drop-out points occur at less than 40 psid. When the trip circuit pressure increases to its pickup pressure, the three-way relay valves shift position. The servo valve control ports are then connected to the actuator ports. Depending on the command signal, one actuator port is connected to pump pressure while the other is connected to tank, allowing the actuator to function.

Hydraulic Filter Assembly

The IGV actuator is supplied with an integrated, high-capacity filter. This broad-range filter protects the internal hydraulic control components from large oil-borne contaminants that might cause the hydraulic components to stick or operate erratically. The filter is supplied with a visual indicator which indicates when the pressure differential exceeds the recommended value, indicating that replacement of the element is necessary.

LVDT Position Feedback Sensors

The IGV actuator uses dual LVDTs for position feedback. The LVDTs are factory set to give 0.7 ± 0.1 Vrms feedback in extended position.

Chapter 4. Installation

General

See the outline drawings (Figures 1-1 and 1-2) for:

- Overall dimensions
- Hydraulic connections and fitting sizes
- Electrical connections
- Lift points
- Weight of the actuator

The design of the IGV actuator requires that the output shaft be mounted vertically. Additionally, a vertical actuator position is generally preferred to conserve floor space as well as ease of making electrical, fuel, and hydraulic connections and changing the hydraulic filter element.

The IGV actuator is designed for support by an actuator base. Additional supports are neither needed nor recommended.



WARNING

Due to typical noise levels in turbine environments, hearing protection should be worn when working on or around this product.



WARNING

The surface of this product can become hot enough or cold enough to be a hazard. Use protective gear for product handling in these circumstances. Temperature ratings are included in the specification section of this manual.



WARNING

Woodward recommends lifting the IGVA by installing two lifting eyes in the 0.500 x 13 tapped holes shown in Figures 1-1b/1-2b. If the unit must be lifted by slings, Woodward recommends running a strap through the 2" (51 mm) diameter hole on the yoke. This will extend the IGV rod as the unit is lifted. If installing straps on any other location, observe the center of gravity noted in Figure 1-1b and take care that the straps do not press against other components such as the LVDTs, servo valve, or anti-rotation rod.



WARNING

External fire protection is not provided in the scope of this product. It is the responsibility of the user to satisfy any applicable requirements for their system.

Unpacking

The actuator is shipped with the turnbuckle linkage disconnected from the output shaft but included in the same shipping container along with necessary mounting hardware. Check the shipping container for all components before removing it from the area.

Hydraulic Connections

For the hydraulic trip system IGVA, there are three hydraulic connections that must be made to each actuator: supply, return, and trip. The connections to the actuator used on GE Frame 7E model turbines use SAE straight thread O-ring connections for the trip and main supply ports and a 1" NPT connection for the drain port. The tubing up to the actuator must be constructed to eliminate any transfer of vibration or other forces into the actuator.

Make provisions for proper filtration of the hydraulic fluid that will supply the actuator. The system filtration should be designed to assure a supply of hydraulic oil with a maximum ISO 4406 contamination level of 18/16/13 and a preferred level of 16/14/11. The filter element included with the actuator is not intended to provide adequate filtration over the entire life of the actuator.

The hydraulic supply to the actuator is to be 0.750 inch (19.05 mm) tubing capable of supplying 10 US gal/min (38 L/min) at 1400–1800 psig (9653–12 411 kPa).

The hydraulic drain for the 7E should be 1.00 inch (25.4 mm) tubing and must not restrict the flow of fluid from the actuator. The drain pressure must not exceed 30 psig (207 kPa) under any condition.

The trip relay valve supply should be 0.500 inch (12.70 mm) tubing. The Trip Relay Pressure should be above 40 psig (276 kPa) to enable the actuator to function.

Electrical Connections



Due to the hazardous location listings associated with this product, proper wire type and wiring practices are critical to operation.

NOTICE

Do not connect any cable grounds to “instrument ground”, “control ground”, or any non-earth ground system. Make all required electrical connections based on the wiring diagrams (Figures 1-4 and 1-5).

The use of cable with individually-shielded twisted pairs is recommended. All signal lines should be shielded to prevent picking up stray signals from nearby equipment. Installations with severe electromagnetic interference (EMI) may require shielded cable run in conduit, double-shielded wire, or other precautions. Connect the shields at the control system side or as indicated by the control system wiring practices, but never at both ends of the shield such that a ground loop is created. Wires exposed beyond the shield must be less than 2 inches (51 mm). The wiring should provide signal attenuation to greater than 60 dB.

The servo valve cable should consist of three individually shielded twisted pairs. Each pair should be connected to one coil of the servo valve as indicated in Figure 1-4 (wiring diagram). When installed in Zone 1 application, using intrinsically safe method of protection, barriers must be installed in a safe area per the wiring diagram (Figure 4-2, Moog Drawing G4400 Configuration 4). All barriers which are part of the approved system configurations must be mounted and installed in compliance with the barrier manufacturer's requirements. Barriers supplied for the servo valve circuit are dual channel AC type barrier, manufactured by MTL Instruments Ltd.

Hazard area (field) wiring must meet the requirements of the barrier manufacturer or ISA (Instrument Society of America) RP 12.6. Field wiring must be constructed using twisted, shielded pairs of at least 18 AWG wire. Shield must be connected to earth ground only at the barrier strip.

The LVDT cable must consist of four individually shielded twisted pairs. Two separate pairs should be used for each of the excitation voltages to the LVDT, and two separate pairs used for each of the feedback voltages from the LVDT, as indicated in Figure 1-5 (wiring diagram). When installing in a Zone 1 application using intrinsically safe method of protection, barriers must be installed in a safe area per the wiring diagram (Figure 4-3, Sentech Drawing A607003-04). All barriers must be mounted and installed in compliance with the barrier manufacturer's requirement. Barriers supplied for the LVDT circuit are manufactured by R. Stahl, Inc. The mains power of the control system supplying the barriers must not exceed 250 Vrms with respect to earth.

Cable parameters for the hazard area (field) wiring:

For Group IIC: C: 0.024 uF max
L: 0.17 mH max
L/R Ratio 11 max

Electronic Settings

Dynamic Tuning Parameters

It is imperative that the correct dynamic characteristics of this actuator be input into the control system to ensure that the operation of the actuator/control system is within acceptable limits.




Figure 4-1. IGV Actuator Block Diagram

- A_c Hydraulic cylinder working area (in²) 30.68 in² extend area, 25.77 in² retract area
- K_{sv} Servo valve flow gain (in³/s) = 6.1 in³/s/mA
- K_L LVDT gain (Vrms/inch). Gain = 1.0181 Vrms/inch
- ξ servo valve damping ratio = 0.7
- ω_n servo valve natural frequency (rad/s) = 520 rad/s (83 Hz)
- τ_L LVDT time constant (s) = 0.005 (depends on excitation/demodulation)
[in² = square inches; 1 in² = 645.16 mm²]
[in³ = cubic inches; 1 in³ = 16.387 mm³]

Null Current Adjustment

Every IGV actuator shipped contains documentation that gives the actual null current as measured by Woodward. It is imperative that the control system null current match the as-measured current for each IGV actuator in the system. Incorrect null current setting (with proportional control only) will result in position error.

Rigging Procedure

The actuator is shipped with documentation which contains the appropriate LVDT feedback signals for each LVDT in the fully extended and retracted positions (assuming 7.0 Vrms excitation at 3000 Hz).

Once the control system is connected to the actuator and control of the actuator is established, set the command position to 0% of full stroke. Measure the feedback voltage from each LVDT. Adjust the Offset in the feedback loop until the feedback voltage matches the documented values for that position. Adjust the command position to 100% of full stroke. Adjust the Gain of the feedback loop until the LVDT feedback voltage matches the documented values. Set the command position to close the vane (actuator extend). Visually verify that the vane (actuator) is opened and that the feedback voltage from the LVDT is 0.7 ± 0.1 Vrms. This process may have to be repeated to ensure the feedback voltages at both the 0% and 100% command positions match the documented values.

NOTICE

During field rigging of turnbuckle length, do not weld on any surface of the rod ends. Tack welds for anti-rotation should only be applied on the lock nuts and turnbuckle using the supplied weld strip, preferably more than 3.0 inches (76 mm) from the ends of the turnbuckle as shown in Figure 1-2.




Figure 4-2. Moog Drawing G4400 Configuration 4




Figure 4-3. Sentech Drawing A607003-04

Chapter 5.

Maintenance and Hardware Replacement

Maintenance

The IGV actuator requires no maintenance or adjustment in preparation for (or during) normal operation.

Woodward recommends routine checks of the DP gauge on the filter assembly to verify that the filter is not partially clogged. If the DP indicator shows red, the filter element needs to be replaced.

Woodward recommends a yearly removal and cleaning of the Trip Relay Valve Cartridges to prevent build-up of oil varnish or contaminants which may prevent proper operation of the Trip Relay Valve. Remove each valve as described below and soak in a solvent (Stoddard or kerosene based) compatible with the fluorocarbon O-rings. Actuate the valve by hand and blow clean with compressed air. Verify smooth operation of the Trip Relay Valve and ensure no sticking or binding is present.

In the event that any of the standard components of the actuator become inoperative, field replacement of components is possible. Contact a Woodward representative for assistance.

Hardware Replacement



EXPLOSION HAZARD—Do not remove covers or connect/disconnect electrical connectors unless power has been switched off or the area is known to be non-hazardous.

Substitution of components may impair suitability for Zone 1 applications.



To prevent possible serious personal injury, or damage to equipment, be sure all electric power, hydraulic pressure, and vane force have been removed from the actuator before beginning any maintenance or repairs.



Due to typical noise levels in turbine environments, hearing protection should be worn when working on or around the IGV actuator.

See the outline drawings (Figures 1-1 and 1-2) for the location of items.

Hydraulic Filter Assembly/Cartridge

The hydraulic filter is located on the hydraulic manifold, hanging directly under the top manifold directly under the servo valve.

Replacement of Filter Assembly

1. Remove four 0.312-18 UNC socket head cap screws.
2. Remove the filter assembly from the manifold block.



The filter contains a large amount of hydraulic fluid that may be spilled during filter removal.

3. Remove the two O-rings present in the interface between the filter and the manifold.
4. Obtain a new filter assembly.
5. Place two new O-rings in the new filter assembly.
6. Install the filter onto the manifold assembly. Be sure to place the filter in the correct orientation. See the outline drawings (Figures 1-1 and 1-2).
7. Install four 0.312-18 cap screws through the filter into the manifold, and torque to 20–27 lb-ft (27–37 N·m).

Replacement of Filter Cartridge

IMPORTANT

The filter contains a large amount of hydraulic fluid that may be spilled during filter removal.

1. Using a 1-5/16 inch (~33+ mm) wrench, loosen the bowl from the filter assembly.
2. Remove the filter element by pulling it downward.
3. Obtain a new filter element.
4. Lubricate the O-ring on the ID of the cartridge with hydraulic fluid.
5. Install the cartridge into the assembly by sliding the open end of the cartridge upward onto the nipple.
6. Install the filter bowl. Tighten to 25–30 lb-ft (34–41 N·m).

Trip Relay Valve Cartridges Replacement

The trip relay valve cartridges are located in the hydraulic manifold block (Figure 1-1b item 22).

IMPORTANT

Hydraulic fluid may spill during cartridge removal.

1. Using a 1.25 inch (~32– mm) wrench, loosen the trip relay valves from the hydraulic manifold.
2. Slowly remove the cartridges from the manifold.
3. Obtain new trip relay valve cartridges and verify part number and revision with the existing unit.
4. Verify that all O-rings and backup rings are present on new cartridge.
5. Lubricate the O-rings with hydraulic fluid or petroleum jelly.
6. Install the cartridge into the manifold housing.
7. Torque to 33–37 lb-ft (45–50 N·m).

Servo Valve Replacement

The servo valve is located on the hydraulic manifold directly above the filter assembly. Refer to the outline drawings (Figure 1-1b item 19).

1. Disconnect the servo valve cable from the servo valve.
2. Remove the four #10-32 UNF socket head cap screws holding the servo valve to the manifold (Figure 1-1b item 18).
3. Discard the four O-rings between the servo valve and the manifold.
4. Obtain a replacement servo valve and verify part number and revision with the existing unit.
5. Remove the protective plate from the replacement servo valve and verify that O-rings are on all four counter bores of the servo valve.
6. Place the servo valve onto the hydraulic manifold. Be sure to orient the servo valve to match the original orientation. Be sure that all four O-rings remain in their proper location during assembly.
7. Install four #10-32 UNF socket head cap screws and torque to 56–75 lb-in (6.3–8.5 N·m).

LVDT Replacement



CAUTION

Use care and follow all instructions after removal of supply pressure and blocking the actuator in extended position. Significant weight is being supported, and the potential to cause bodily injury is high if all safety precautions are not followed.

The LVDTs are located on the right side of the upper and lower manifolds when viewing the front (hydraulic port connections) of the actuator. Refer to the outline drawings (Figures 1-1b , 1-1c, 1-2b, 1-2c).

1. Shut off the hydraulic supply to the IGV actuator and ensure that the actuator is in the fully extended position. You may need to block it in this position.
2. Remove the LVDT covers (item 76 on Figures 1-1b and 42 on Figure 1-1c) by removing the four #10-32 UNF screws (items 17 on Figures 1-1b and 1-1c) holding the access covers on the top and side of the LVDTs.
3. Disconnect both sets of LVDT connectors.
4. Remove the #10-32 UNF locknuts and washers (items 29 and 30 on Figure 1-1b) from the defective LVDT rod holding the 0.250 inch flats on the rod.
5. Lower the rod from the anti-rotation plate and allow it to rest on the LVDT.
6. Remove the two 0.250-20 UNC socket head cap screws (items 37 Figure 1-1c) holding the LVDT bracket to the upper and lower manifolds.
7. Carefully remove the LVDT assembly from the actuator by vertically lowering it away from the IGV. Take care not to damage the good LVDT housing and rod.
8. Obtain a replacement LVDT and verify part number and revision with the existing unit.
9. Install the bottom #10-32 UNF locknut and washer on the replacement LVDT rod. Install the new rod into the anti-rotation plate, positioning the rod height to approximately match the other LVDT rod height.
10. Install the #10-32 UNF locknut and washer onto the LVDT rod but do not torque the nut at this time.
11. Carefully slide the replacement LVDT over the LVDT rod. ***Be very careful not to force the LVDT at any time since this could damage the LVDT rod.***
12. Install the two 0.250-20 UNC socket head cap screws holding the LVDT bracket to the upper and lower manifolds and torque to 120–160 lb-in (13.6–18.1 N·m).
13. Connect the LVDT cable to the new LVDT.
14. Reattach the hydraulic drain connection.
15. Once the LVDT is installed, it must then be calibrated as described below.
16. Covers will be attached after calibration.

LVDT Calibration

1. Whenever an LVDT is replaced, or whenever its core rod adjustment is disturbed, the LVDT output voltage must be calibrated in the following way.



CAUTION

Use care and follow all instructions after removal of supply pressure and blocking the actuator in extended position. Significant weight is being supported and the potential to cause bodily injury is high if all safety precautions are not followed.

2. If not replacing an LVDT but calibrating:
 - a. Ensure that the actuator it is in its fully extended position. Shut off the hydraulic supply to the IGV actuator and block it in this position.
 - b. Remove the LVDT covers (item 76 on Figures 1-1b and 42 on Figure 1-1c) by removing the four #10-32 UNF screws (items 17 on Figures 1-1b and 1-1c) holding the access covers on the top and side of the LVDTs.
3. Adjust the LVDT rod so that the output of the replaced LVDT is 0.7 ± 0.1 Vrms with the IGV actuator fully extended (inlet guide vane closed).
4. Tighten the #10-32 UNF locknut to 32–35 lb-in (3.6–4.0 N·m).

5. Attach an accurate stroke measurement device (dial indicator or equivalent), capable of measuring 3 inches (76 mm) of stroke, to the IGV actuator body.
6. Apply hydraulic pressure to the IGV actuator and manually command the actuator to retract stroke:

		STROKE	
		inches	mm
7E	9904-1533	1.88 ±0.02	47.8 ±0.5

Note and record the LVDT output voltages at this 1.88 inch (47.8 mm) stroke position for the 7E.

7. Remove the actuator control command, returning the actuator to its rest (inlet guide vane closed) position.
8. Shut off the IGV actuator hydraulic supply.
9. Update the IGV actuator control logic with the new LVDT output voltage value.

Troubleshooting Charts

Faults in the IGV control may be associated with speed variations of the prime mover, but such speed variations may not always indicate system faults. Therefore, when improper IGV operation occurs, check all components, including the turbine for proper operation. Refer to applicable electronic control manuals for assistance in isolating the trouble. The following steps describe troubleshooting for the IGV actuator.

Disassembly of the IGV actuator in the field is **not** recommended due to the special tools and procedures required. Under unusual circumstances where disassembly becomes necessary, all work and adjustments should be made by personnel thoroughly trained in the proper procedures and tools.

When requesting information or service help from Woodward, it is important to include the part number and serial number of the actuator assembly in your communication.

Symptom	Possible Causes	Remedies
External hydraulic leakage	Static O-ring seal(s) missing or deteriorated	Replace O-rings fitted to user-serviceable components (filter, servo valve, trip relay valve) as needed. Otherwise, return actuator to Woodward for service.
	Dynamic O-ring seal missing or deteriorated	Return actuator to Woodward for service.
Internal hydraulic leakage	Servo valve internal O-ring seal(s) missing or deteriorated	Replace servo valve.
	Servo valve metering edges worn	Replace servo valve.
	Piston seal missing or deteriorated	Return actuator to Woodward for service.

Symptom	Possible Causes	Remedies
Actuator will not open (actuator retract)	Servo valve command current incorrect. (The sum of the current through the three coils of the servo valve must be greater than the null bias of the servo valve for the actuator to open.)	Trace and verify that all wiring is in accordance with the electrical schematic (Figures 1-4 and 1-5) and the GE system wiring schematic(s). Pay special attention to the polarity of the wiring to the servo valve and LVDT.
	Servo valve failure	Replace servo valve.
	Hydraulic supply pressure inadequate	Supply pressure must be greater than 1400 psig/9653 kPa (1600 psig/11 032 kPa preferred).
	Trip relay pressure inadequate (hydraulic trip system IGVA)	Trip pressure must be greater than 40 psig (276 kPa).
Actuator will not close	Trip Relay Valve Cartridge failure	Remove the two Trip Relay Valves from the actuator as described previously. Visually inspect and actuate by hand. Check for contamination, sticky operation, or binding. Clean as described in the Maintenance section, or replace the Trip Valves.
	Servo valve command current incorrect. (The sum of the current through the three coils of the servo valve must be less than the null bias of the servo valve for the actuator to close.)	Trace and verify that all wiring is in accordance with the electrical schematic (Figure 1-4) and the GE system wiring schematic(s). Pay special attention to the polarity of the wiring to the servo valve and LVDT.
	Servo valve failure	Replace servo valve.
	LVDT failure	Replace LVDT.
	Linkage broken	Return actuator to Woodward for service.
Actuator will not respond smoothly	Trip Relay Valve Cartridge failure	Remove the two Trip Relay Valves from the actuator as described previously. Visually inspect and actuate by hand. Check for contamination, sticky operation, or binding. Clean as described in the Maintenance section, or replace the Trip Valves.
	Hydraulic filter clogged	Check the differential pressure indicator on the filter housing.
	Servo valve spool sticking	Verify hydraulic contamination levels are within recommendations of Chapter 1. The use of dither may improve performance in contaminated systems.
	Servo valve internal pilot filter clogged	Replace servo valve.
	Rod-end(s) worn out	Return actuator to Woodward for service.
	Piston seal worn out	Return actuator to Woodward for service.
	Trip Relay Valve Cartridge failure	Remove the two Trip Relay Valves from the actuator as described previously. Visually inspect and actuate by hand. Check for contamination, sticky operation, or binding. Clean as described in the Maintenance section, or replace the Trip Valves.

Symptom	Possible Causes	Remedies
Actuator seals wear out prematurely	Hydraulic contamination level is excessive	Verify hydraulic contamination levels are within recommendations of Chapter 1. The use of excessive dither may reduce life in contaminated systems.
	System is oscillating (seal life is proportional to distance traveled). Even small oscillations (on the order of $\pm 1\%$) at slow frequencies (on the order of 0.1 Hz) cause wear to accumulate rapidly.	Determine and eliminate the root cause of oscillation.

Chapter 6.

Product Support and Service Options

Product Support Options

If you are experiencing problems with the installation, or unsatisfactory performance of a Woodward product, the following options are available:

- Consult the troubleshooting guide in the manual.
- Contact the manufacturer or packager of your system.
- Contact the Woodward Full Service Distributor serving your area.
- Contact Woodward technical assistance (see “How to Contact Woodward” later in this chapter) and discuss your problem. In many cases, your problem can be resolved over the phone. If not, you can select which course of action to pursue based on the available services listed in this chapter.

OEM or Packager Support: Many Woodward controls and control devices are installed into the equipment system and programmed by an Original Equipment Manufacturer (OEM) or Equipment Packager at their factory. In some cases, the programming is password-protected by the OEM or packager, and they are the best source for product service and support. Warranty service for Woodward products shipped with an equipment system should also be handled through the OEM or Packager. Please review your equipment system documentation for details.

Woodward Business Partner Support: Woodward works with and supports a global network of independent business partners whose mission is to serve the users of Woodward controls, as described here:

- A **Full Service Distributor** has the primary responsibility for sales, service, system integration solutions, technical desk support, and aftermarket marketing of standard Woodward products within a specific geographic area and market segment.
- An **Authorized Independent Service Facility (AISF)** provides authorized service that includes repairs, repair parts, and warranty service on Woodward's behalf. Service (not new unit sales) is an AISF's primary mission.

A current list of Woodward Business Partners is available at www.woodward.com/directory.

Product Service Options

The following factory options for servicing Woodward products are available through your local Full-Service Distributor or the OEM or Packager of the equipment system, based on the standard Woodward Product and Service Warranty (5-01-1205) that is in effect at the time the product is originally shipped from Woodward or a service is performed:

- Replacement/Exchange (24-hour service)
- Flat Rate Repair
- Flat Rate Remanufacture

Replacement/Exchange: Replacement/Exchange is a premium program designed for the user who is in need of immediate service. It allows you to request and receive a like-new replacement unit in minimum time (usually within 24 hours of the request), providing a suitable unit is available at the time of the request, thereby minimizing costly downtime. This is a flat-rate program and includes the full standard Woodward product warranty (Woodward Product and Service Warranty 5-01-1205).

This option allows you to call your Full-Service Distributor in the event of an unexpected outage, or in advance of a scheduled outage, to request a replacement control unit. If the unit is available at the time of the call, it can usually be shipped out within 24 hours. You replace your field control unit with the like-new replacement and return the field unit to the Full-Service Distributor.

Charges for the Replacement/Exchange service are based on a flat rate plus shipping expenses. You are invoiced the flat rate replacement/exchange charge plus a core charge at the time the replacement unit is shipped. If the core (field unit) is returned within 60 days, a credit for the core charge will be issued.

Flat Rate Repair: Flat Rate Repair is available for the majority of standard products in the field. This program offers you repair service for your products with the advantage of knowing in advance what the cost will be. All repair work carries the standard Woodward service warranty (Woodward Product and Service Warranty 5-01-1205) on replaced parts and labor.

Flat Rate Remanufacture: Flat Rate Remanufacture is very similar to the Flat Rate Repair option with the exception that the unit will be returned to you in "like-new" condition and carry with it the full standard Woodward product warranty (Woodward Product and Service Warranty 5-01-1205). This option is applicable to mechanical products only.

Returning Equipment for Repair

If a control (or any part of an electronic control) is to be returned for repair, please contact your Full-Service Distributor in advance to obtain Return Authorization and shipping instructions.

When shipping the item(s), attach a tag with the following information:

- Return authorization number
- Name and location where the control is installed
- Name and phone number of contact person
- Complete Woodward part number(s) and serial number(s)
- Description of the problem
- Instructions describing the desired type of repair

Packing a Control

Use the following materials when returning a complete control:

- Protective caps on any connectors
- Antistatic protective bags on all electronic modules
- Packing materials that will not damage the surface of the unit
- At least 100 mm (4 inches) of tightly packed, industry-approved packing material
- A packing carton with double walls
- A strong tape around the outside of the carton for increased strength

NOTICE

To prevent damage to electronic components caused by improper handling, read and observe the precautions in Woodward manual 82715, *Guide for Handling and Protection of Electronic Controls, Printed Circuit Boards, and Modules*.

Replacement Parts

When ordering replacement parts for controls, include the following information:

- The part number(s) (XXXX-XXXX) that is on the enclosure nameplate
- The unit serial number, which is also on the nameplate

Engineering Services

Woodward offers various Engineering Services for our products. For these services, you can contact us by telephone, by email, or through the Woodward website.

- Technical Support
- Product Training
- Field Service

Technical Support is available from your equipment system supplier, your local Full-Service Distributor, or from many of Woodward's worldwide locations, depending upon the product and application. This service can assist you with technical questions or problem solving during the normal business hours of the Woodward location you contact. Emergency assistance is also available during non-business hours by phoning Woodward and stating the urgency of your problem.

Product Training is available as standard classes at many of our worldwide locations. We also offer customized classes, which can be tailored to your needs and can be held at one of our locations or at your site. This training, conducted by experienced personnel, will assure that you will be able to maintain system reliability and availability.

Field Service engineering on-site support is available, depending on the product and location, from many of our worldwide locations or from one of our Full-Service Distributors. The field engineers are experienced both on Woodward products as well as on much of the non-Woodward equipment with which our products interface.

For information on these services, please contact us via telephone, email us, or use our website:
www.woodward.com.

Contacting Woodward's Support Organization

For the name of your nearest Woodward Full-Service Distributor or service facility, please consult our worldwide directory at www.woodward.com/directory, which also contains the most current product support and contact information.

You can also contact the Woodward Customer Service Department at one of the following Woodward facilities to obtain the address and phone number of the nearest facility at which you can obtain information and service.

Products Used in Electrical Power Systems

<u>Facility</u>	<u>Phone Number</u>
Brazil -----	+55 (19) 3708 4800
China -----	+86 (512) 6762 6727
Germany:	
Kempen----	+49 (0) 21 52 14 51
Stuttgart -	+49 (711) 78954-510
India -----	+91 (124) 4399500
Japan-----	+81 (43) 213-2191
Korea-----	+82 (51) 636-7080
Poland -----	+48 12 295 13 00
United States-----	+1 (970) 482-5811

Products Used in Engine Systems

<u>Facility</u>	<u>Phone Number</u>
Brazil -----	+55 (19) 3708 4800
China -----	+86 (512) 6762 6727
Germany -----	+49 (711) 78954-510
India -----	+91 (124) 4399500
Japan-----	+81 (43) 213-2191
Korea-----	+82 (51) 636-7080
The Netherlands--	+31 (23) 5661111
United States-----	+1 (970) 482-5811

Products Used in Industrial Turbomachinery Systems

<u>Facility</u>	<u>Phone Number</u>
Brazil -----	+55 (19) 3708 4800
China -----	+86 (512) 6762 6727
India -----	+91 (124) 4399500
Japan-----	+81 (43) 213-2191
Korea-----	+82 (51) 636-7080
The Netherlands--	+31 (23) 5661111
Poland -----	+48 12 295 13 00
United States-----	+1 (970) 482-5811

Technical Assistance

If you need to contact technical assistance, you will need to provide the following information. Please write it down here before contacting the Engine OEM, the Packager, a Woodward Business Partner, or the Woodward factory:

General

Your Name _____

Site Location _____

Phone Number _____

Fax Number _____

Prime Mover Information

Manufacturer _____

Turbine Model Number _____

Type of Fuel (gas, steam, etc.) _____

Power Output Rating _____

Application (power generation, marine,
etc.) _____

Control/Governor Information

Control/Governor #1

Woodward Part Number & Rev. Letter _____

Control Description or Governor Type _____

Serial Number _____

Control/Governor #2

Woodward Part Number & Rev. Letter _____

Control Description or Governor Type _____

Serial Number _____

Control/Governor #3

Woodward Part Number & Rev. Letter _____

Control Description or Governor Type _____

Serial Number _____

Symptoms

Description _____

If you have an electronic or programmable control, please have the adjustment setting positions or the menu settings written down and with you at the time of the call.

Revision History

Changes in Revision B—

- Replaced the Regulatory Compliance section minus the warnings
- Replaced the declarations

Component Declarations

Manufacturer:

MOOG

Industrial Controls Division

East Aurora, New York 14052 USA

☎: (716) 652-2000 Fax: (716) 687-7910

www.moog.com

Importer:

MOOG

GmbH

Hanns-Klemm-Str. 28

71034 Böblingen, Germany

+49 7031 622 0

EU Declaration of Conformity



Hereby we declare the Series of Servo Valves **xx7xKxxxx** or **x7xxKxxxx**
 (Actual model & serial number is referenced on the delivery note)
 are in conformance with the provisions of directive 2014/34/EU (ATEX).

Description: Electro-hydraulic servo valve for use in hazardous areas requiring intrinsic safety or non-incendive protection.
 Intended Use: Direction, position, velocity, pressure, or force control in hydraulic control systems.

Notified body: (0344), DEKRA Certification B.V., Meander 1051, 6825 MJ Arnhem, The Netherlands

Numbers of the (EC-) Type Examination Certificates are: **KEMA 02ATEX1015 X** and **KEMA 02ATEX1016 X**

Number of the IECEx Certificate of Conformity is: **IECEx KEM 10.0041X**

Equipment marking:  II 1 G Ex ia IIB/IIC T4 Ga
 II 2 G Ex ia IIB/IIC T3 or T4 Gb
 II 3 G Ex nA IIC T3 or T4 Gc

Applied ATEX Directive harmonized standards:

<u>Cenelec</u>	<u>IECEx</u>	<u>Title</u>
EN 60079-0:2009	IEC 60079-0: 2007-10 Edition 5	Explosive atmospheres - Part 0: Equipment - General requirements
EN 60079-11:2007	IEC 60079-11: 2006 Edition 5	Explosive atmospheres - Part 11: Equipment protection by intrinsic safety "i"
EN 60079-15:2005	IEC 60079-15: 2005-03 Edition 3	Electrical apparatus for explosive gas atmospheres - Part 15: Construction, test and marking of type of protection "n" electrical apparatus
EN 60079-26:2007	IEC 60079-26: 2006 Edition: 2	Explosive atmospheres - Part 26: Equipment with equipment protection level (EPL) Ga

We hereby we self-declare that this equipment also conforms to:

Applied ATEX Directive harmonized standards:

EN 60079-0:2012/A11:2013	IEC 60079-0: 2011-06 Edition 6.0	Explosive atmospheres - Part 0: Equipment - General requirements
EN 60079-11:2012	IEC 60079-11: 2011-06 Edition 6.0	Explosive atmospheres - Part 11: Equipment protection by intrinsic safety "i"
EN 60079-15:2010	IEC 60079-15: 2010-01 Edition 4	Explosive atmospheres - Part 15: Equipment protection by type of protection "n"

Applied EMC Directive 2004/108/EC harmonized standards:


IEC 61000-6-2:2005	Electromagnetic compatibility (EMC) – Part 6-2: Generic standards – Immunity for industrial environments
IEC 61000-6-4:2006/A1:2010	Electromagnetic compatibility (EMC) – Part 6-4: Generic standards – Emission standard for industrial environments

Additional information:

The object of the declaration described above is in conformity with the relevant Union harmonization legislation: Directive 94/9/EC (until April 19th, 2016) and Directive 2014/34/EU (from April 20th, 2016).

Authorized Person: Earl T. McCullough

Title: Quality Assurance Manager

Signature: 

Date: 3/04/2016

©MOOG MOOG INC., Industrial Controls Division • East Aurora, NY 14052	CAGE CODE 94697	REVISION N
CDD6615 - x7xxK EU Declaration of Conformity		

DECLARATION OF CONFORMITY
According to EN 45014





Manufacturer's Name: SENTECH INC.

Manufacturer's Address: 2851 Limekiln Pike
North Hills, PA 19038
USA

Model Name(s)/Number(s): Linear Variable Differential Transformer (LVDT)
Models per 75AGV-xxxxC series and similar

Conformance to Directive(s): Directive 2014/34/EU of the laws of the Member States concerning equipment and protective systems intended for use in potentially explosive atmospheres

Applicable Standards: EN60079-0:2012: Electrical apparatus for potentially explosive atmospheres – General requirements
EN60079-11:2012: Electrical apparatus for potentially explosive atmospheres – Intrinsic safety “i”
EN60079-15: 2010 - Electrical apparatus for potentially explosive atmospheres - Type of protection ‘n’

Marking:  0359  II 1 G, Ex ia IIC T3 Ga
  II 3 G, Ex nA II T3 Gc, Ingress Protection IP54

3rd Party Certification: ITS03ATEX21023
EN60079 ITS06ATEX45394X

Conformity Assessment: ITS/02/028

Notified Body ITS Testing & Certification Ltd.
For ATEX Directive: ITS House, Cleeve Road
Leatherhead, Surrey, KT22 75B UK

We, the undersigned, hereby declare that the equipment specified above conforms to the above Directive(s).

MANUFACTURER: SENTECH, INC.
2851 Limekiln Pike
North Hills PA 19038 USA

Signature  **Date:** July 25, 2016

Full Name	Position	Location
Dipak Patel	V. P. Engineering	North Hills, PA USA

A607031-04

SENTECH INC.

This Page Intentionally Left Blank

This Page Intentionally Left Blank

This Page Intentionally Left Blank

We appreciate your comments about the content of our publications.

Send comments to: icinfo@woodward.com

Please reference publication **26554**.



PO Box 1519, Fort Collins CO 80522-1519, USA
1041 Woodward Way, Fort Collins CO 80524, USA
Phone +1 (970) 482-5811

Email and Website—www.woodward.com

Woodward has company-owned plants, subsidiaries, and branches, as well as authorized distributors and other authorized service and sales facilities throughout the world.

Complete address / phone / fax / email information for all locations is available on our website.