



Product Manual 26704
(Revision A, 12/2020)
Original Instructions

Gas Stop/Ratio Valve with Electric Trip for IECEx Installation

Installation and Operation Manual



General Precautions

Read this entire manual and all other publications pertaining to the work to be performed before installing, operating, or servicing this equipment.

Practice all plant and safety instructions and precautions.

Failure to follow instructions can cause personal injury and/or property damage.



Revisions

This publication may have been revised or updated since this copy was produced. To verify that you have the latest revision, check manual **26455**, *Customer Publication Cross Reference and Revision Status & Distribution Restrictions*, on the *publications* page of the Woodward website:

<http://www.woodward.com>

The latest version of most publications is available on the *publications* page. If your publication is not there, please contact your customer service representative to get the latest copy.




Proper Use

Any unauthorized modifications to or use of this equipment outside its specified mechanical, electrical, or other operating limits may cause personal injury and/or property damage, including damage to the equipment. Any such unauthorized modifications: (i) constitute "misuse" and/or "negligence" within the meaning of the product warranty thereby excluding warranty coverage for any resulting damage, and (ii) invalidate product certifications or listings.



Translated Publications

If the cover of this publication states "Translation of the Original Instructions" please note:

The original source of this publication may have been updated since this translation was made. Be sure to check manual **26455**, *Customer Publication Cross Reference and Revision Status & Distribution Restrictions*, to verify whether this translation is up to date. Out-of-date translations are marked with . Always compare with the original for technical specifications and for proper and safe installation and operation procedures.

Revisions— A bold, black line alongside the text identifies changes in this publication since the last revision.

Woodward reserves the right to update any portion of this publication at any time. Information provided by Woodward is believed to be correct and reliable. However, no responsibility is assumed by Woodward unless otherwise expressly undertaken.

Contents

WARNINGS AND NOTICES.....	2
ELECTROSTATIC DISCHARGE AWARENESS	3
REGULATORY COMPLIANCE	4
CHAPTER 1. GENERAL INFORMATION.....	5
CHAPTER 2. STOP/RATIO VALVE OPERATION	13
CHAPTER 3. STANDARD COMPONENT DETAILS	14
Triple Coil Electrohydraulic Servo Valve Assembly	14
Trip Relay Valve Assembly	14
Hydraulic Filter Assembly.....	14
CHAPTER 4. INSTALLATION	16
General.....	16
Unpacking	17
Piping Installation	17
Hydraulic Connections	18
Electrical Connections.....	18
Fuel Vent Port	19
Electronic Settings	19
CHAPTER 5. MAINTENANCE AND HARDWARE REPLACEMENT	21
Maintenance.....	21
Hardware Replacement	21
Troubleshooting Charts.....	26
CHAPTER 6. PRODUCT SUPPORT AND SERVICE OPTIONS	29
Product Support Options.....	29
Product Service Options	29
Returning Equipment for Repair	30
Replacement Parts.....	31
Engineering Services	31
Contacting Woodward's Support Organization	31
Technical Assistance	32
REVISION HISTORY	33

Illustrations and Tables

Figure 1-1a. 4" Electrical Trip Gas Stop/Ratio Valve Outline Drawing (dual conduit entry)	7
Figure 1-1b. 4" Electrical Trip Gas Stop/Ratio Valve Outline Drawing (dual conduit entry)	8
Figure 1-2. Single Acting Hydraulic Schematic.....	9
Figure 1-3. Electrical Schematic and Wiring Diagram (dual conduit valve) (except SS260).....	10
Figure 4-1. Stop/Ratio Valve Block Diagram	19
Figure 4-2. Structures for PID Control	19
Figure 5-1. Stroke Measurement Attachment Bar	26
Table 4-1. Class 300 Flange Bolt or Stud Specifications.....	17
Table 4-2. Stud / Bolt Torque Values	17
Table 4-3. Recommended Control Gain Values for Different Control Types.....	20

Warnings and Notices

Important Definitions



This is the safety alert symbol used to alert you to potential personal injury hazards. Obey all safety messages that follow this symbol to avoid possible injury or death.

- **DANGER** - Indicates a hazardous situation, which if not avoided, will result in death or serious injury.
- **WARNING** - Indicates a hazardous situation, which if not avoided, could result in death or serious injury.
- **CAUTION** - Indicates a hazardous situation, which if not avoided, could result in minor or moderate injury.
- **NOTICE** - Indicates a hazard that could result in property damage only (including damage to the control).
- **IMPORTANT** - Designates an operating tip or maintenance suggestion.

WARNING

**Overspeed /
Overtemperature /
Overpressure**

The engine, turbine, or other type of prime mover should be equipped with an overspeed shutdown device to protect against runaway or damage to the prime mover with possible personal injury, loss of life, or property damage.

The overspeed shutdown device must be totally independent of the prime mover control system. An overtemperature or overpressure shutdown device may also be needed for safety, as appropriate.

WARNING

**Personal Protective
Equipment**

The products described in this publication may present risks that could lead to personal injury, loss of life, or property damage. Always wear the appropriate personal protective equipment (PPE) for the job at hand. Equipment that should be considered includes but is not limited to:

- Eye Protection
- Hearing Protection
- Hard Hat
- Gloves
- Safety Boots
- Respirator

Always read the proper Material Safety Data Sheet (MSDS) for any working fluid(s) and comply with recommended safety equipment.

WARNING

Start-up

Be prepared to make an emergency shutdown when starting the engine, turbine, or other type of prime mover, to protect against runaway or overspeed with possible personal injury, loss of life, or property damage.

Electrostatic Discharge Awareness

NOTICE

Electrostatic Precautions

Electronic controls contain static-sensitive parts. Observe the following precautions to prevent damage to these parts:

- Discharge body static before handling the control (with power to the control turned off, contact a grounded surface and maintain contact while handling the control).
- Avoid all plastic, vinyl, and Styrofoam (except antistatic versions) around printed circuit boards.
- Do not touch the components or conductors on a printed circuit board with your hands or with conductive devices.

To prevent damage to electronic components caused by improper handling, read and observe the precautions in Woodward manual **82715**, *Guide for Handling and Protection of Electronic Controls, Printed Circuit Boards, and Modules*.

Follow these precautions when working with or near the control.

1. Avoid the build-up of static electricity on your body by not wearing clothing made of synthetic materials. Wear cotton or cotton-blend materials as much as possible because these do not store static electric charges as much as synthetics.
2. Do not remove the printed circuit board (PCB) from the control cabinet unless absolutely necessary. If you must remove the PCB from the control cabinet, follow these precautions:
 - Do not touch any part of the PCB except the edges.
 - Do not touch the electrical conductors, the connectors, or the components with conductive devices or with your hands.
 - When replacing a PCB, keep the new PCB in the plastic antistatic protective bag it comes in until you are ready to install it. Immediately after removing the old PCB from the control cabinet, place it in the antistatic protective bag.

Regulatory Compliance

International Compliance:

IECEx Suitability is the result of IECEx compliance of the individual components as follows:

Servo valve per IECEx KEM 10.0041X for Ex nA II T3

Solenoid valve per IECEx SIR 11.0102X for Ex nA IIC T4 Gc and IIIC

LVDT per IECEx ITS 10.0032 for Ex nA II T3

Junction Box per IECEx PTB 08.0006 for Ex e ia II, IIC T6, T5, T4

Contacts per IECEx KEM 06.0027U for Ex e II

Special Conditions for Safe Use—All Valves

Wiring must be in accordance with North American Class I, Division 2 or European Zone 2, Category 3 wiring methods as applicable, and in accordance with the authority having jurisdiction.

Field Wiring must be suitable for at least 100 °C.

The wiring junction box provides earth ground terminals if needed for a separate earth ground to meet wiring requirements.



WARNING

EXPLOSION HAZARD—Do not connect or disconnect while circuit is live unless area is known to be non-hazardous.

Substitution of components may impair suitability for Class I, Division 2 or Zone 2.



AVERTISSEMENT

RISQUE D'EXPLOSION—Ne pas raccorder ni débrancher tant que l'installation est sous tension, sauf en cas l'ambiance est décidément non dangereuse.

La substitution de composants peut rendre ce matériel inacceptable pour les emplacements de Classe I, Division 2 ou Zone 2.

Chapter 1.

General Information

The Woodward Gas Stop/Ratio Valve with Electric Trip performs a dual function for industrial or utility gas turbines. One function rapidly shuts off fuel to the turbine fuel control system. Another function provides accurate control of gas fuel pressure at the outlet of the stop/ratio valve. This pressure is applied to the inlets of the gas fuel control valve.

The Gas Stop/Ratio Valve features a modular design and meets critical control characteristics while allowing the same valve design to accommodate a variety of stroke, force output, and mechanical interface arrangements. The electrical and mechanical interfaces have been designed for quick and easy assembly or removal of the valve, at the factory or in the field. The components include an on-board hydraulic filter, electrohydraulic servo valve, trip valve, trip solenoid, single-acting hydraulic cylinder, and dual LVDTs.

Optimum control of the gas turbine requires that the actuator and valve accurately and quickly track the demand signals transmitted by the control. The stop/ratio valve has been designed to provide output forces that exceed the opening and closing requirements with some margin. The additional margin helps ensure that the system moves rapidly even under service conditions where the valve has been contaminated or worn. The hydraulic trip relay valve has been selected to provide high operating force margins, high flow capacity, and to ensure the desired closure rate of the valve under trip conditions.

By using a long actuation rod between the hydraulic cylinder and the valve lever arm, the side-loading forces on the actuator shaft and seals are greatly reduced, decreasing the wear between sliding parts, and increasing the useful service life of the system. The ample distance between the wetted heavy-duty linear slide rings within the stop/ratio valve accommodates any remaining side load. These provisions provide extended service life even in severe service conditions.

Gas Stop/Ratio Valve Functional Characteristics

Functional Requirement	Gas Stop/Ratio Valve		
Valve Type	Fisher Type Vee-Ball® Design V300 or V300 Series B HD Metal, TCM-Ultra, or SS-260 seals		
Position Accuracy	±1% full scale (over ±25 °F/±14 °C deviation from calibration)		
Position Repeatability	±0.5% of point over the range of 10 to 100%		
Hydraulic Fluid Type	Petroleum Based hydraulic fluids as well as fire resistant hydraulic fluids such as Fyrquel EHC		
Maximum Operating Hydraulic Supply Pressure	1200 to 1700 psig (8274 to 11 722 kPa) (design at 1600 psig/11 032 kPa)		
Proof Test Fluid Pressure Level	2550 psig (20 685 kPa) minimum per SAE J214 (Prod Test)		
Minimum Burst Fluid Pressure	4250 psig (34 475 kPa) minimum per SAE J214		
Fluid Filtration Required	10–15 µm at 75 Beta		
Hydraulic Fluid Contamination Level	Per ISO 4406 code 18/16/13 max, code 16/14/11 preferred		
Hydraulic Fluid Temperature	+80 to +170 °F (+27 to +77 °C)		
Actuator Ambient Temperature	–20 to +180 °F (–29 to +82 °C)		
Vibration Test Level	Random 0.01500 gr ² /Hz from 10 to 40 Hz ramping down to 0.00015 gr ² /Hz at 500 Hz (1.04 Grms)		
Shock	Limited to 30 g by servo valve		
Trip Time	Less than 0.200 seconds (100–0% stroke)		
Open Slew Time	5 to 95% in 0.500 ±0.15 seconds		
Close Slew Time	95 to 5% in 0.500 ±0.15 seconds		
Trip Solenoid Voltage	90–140 Vdc (125 Vdc nominal)		
Hydraulic Fluid Connections	Supply Pressure–0.750-16 UNF straight thread port (–8) Return Port–1.312-20 UNF straight thread port (–16)		
Servo Input Current Rating	–7.2 to +8.8 mA (null bias 0.8 ±0.32 mA)		
Paint	Two-part Epoxy		
Actuation Forces (opening at 1200 psig/8274 kPa) (closing via spring)	Opening Force	3, 4, & 6" valves (small actuator ¹)	8" valves (large actuator ²)
	• Fully Extended	811 lb/3607 N	1200 lb/5338 N
	• Fully Retracted	1581 lb/7032 N	3085 lb/13 722 N
	Closing Force		
	• Fully Extended	2075 lb/9230 N	4690 lb/20 861 N
	• Fully Retracted	1305 lb/5805 N	2805 lb/12 477 N
Design Availability Objective	Better than 99.5% over an 8760 hour period		
Sound Level	Per Fisher-Rosemount Catalog 12		

¹Small actuator used on 3", 4", and 6" valves with HD Metal or TCM-Ultra seals

²Large actuator used on 6" valves with SS-260 seals, as well as on 8" valves with HD Metal or TCM-Ultra seals

Note: Vee-Ball® is a trademark of Fisher-Rosemount.




Figure 1-1a. 4" Electrical Trip Gas Stop/Ratio Valve Outline Drawing (dual conduit entry)





Figure 1-1b. 4" Electrical Trip Gas Stop/Ratio Valve Outline Drawing (dual conduit entry)



FUNCTIONAL SCHEMATIC

262-030
03-4-22

Figure 1-2. Single Acting Hydraulic Schematic




Figure 1-3. Electrical Schematic and Wiring Diagram (dual conduit valve) (except SS260)

Notes for Figures 1-1 through 1-3

1. The general reference outline drawing applies to various Woodward Gas Fuel Stop/Ratio valves. Consult Woodward for the latest outline drawing for your particular stop/ratio valve.
2. Installation Orientation
Pipe supported only
Orientation vertical approximately as shown
See elsewhere in this manual for other installation recommendations
3. Approximate Weight
3" Valve—255 lbs/116 kg
4" Valve—280 lbs/127 kg,
6" Valve (except SS-260)—332 lbs/151 kg
6" Valve (SS-260)—447 lbs/203 kg
8" Valve—540 lbs/245 kg
4. Service Manual Replacement Parts
Servo Valve—consult Woodward for part number
O-rings for servo valve—consult Woodward for part number
Filter element—consult Woodward for part number
Manual—consult Woodward for part number
LVDT—consult Woodward for part number
Trip relay valve—consult Woodward for part number
Seal kit for trip relay valve—consult Woodward for part number
Trip Solenoid Valve—consult Woodward for part number
5. Description of Stop/Ratio Valve
Process fluid natural gas
Temperature range natural gas 50 to 300 °F/10 to 149 °C (unheated fuel)
 natural gas 50 to 450 °F/10 to 232 °C (heated fuel)
 ambient -20 to +180 °F/-29 to +82 °C
External leakage (2 cm³/min maximum to overboard drain)
6. Actuation
Cylinder bore Small Actuator¹: 1.750 inch diameter (44.45 mm)
 Large Actuator²: 2.500 inch diameter (63.50 mm)
Stroke 3.500 inch (88.90 mm)
Static seals Elastomer per US MIL-R-83248 (Viton)
Operating fluid Petroleum-based hydraulic fluid as well as fire resistant hydraulic fluids
 such as Fyrquel EHC
Rated hydraulic pressure 1600 psig/11 032 kPa
Operating hydraulic pressure 1200 to 1700 psig/8274 to 11 722 kPa
Ambient temperature -20 to +180 °F/-29 to +82 °C
Hydraulic fluid temperature 80 to 170 °F/27 to 77 °C
7. Servo Valve
Flow rating Small Actuator¹: 5.0 US gal/min (18.9 L/min) at 1000 psid (6895 kPa)
 valve drop, 4-way
 Large Actuator²: 10.0 US gal/min (37.8 L/min) at 1000 psid (6895 kPa)
 valve drop, 4-way
Electrical input rating ±8 mA (sum of three coils)
Null bias 10% of rated flow to close stop/ratio valve
 (= 10 ± 4% rated current at hydraulic null)
Electrical connection 0.375 O.D. tube fitting. 0.562-18 UNF-2A thread per
 MS 33656-6

¹Small actuator used on 3", 4", and 6" valves with HD Metal or TCM-Ultra seals²Large actuator used on 6" valves with SS-260 seals, as well as on 8" valves with HD Metal or TCM-Ultra seals

IMPORTANT

The general reference outline drawing applies to various Woodward Gas Fuel Stop/Ratio valves. Consult Woodward for the latest outline drawing for your particular stop/ratio valve.

Chapter 2.

Stop/Ratio Valve Operation

The Gas Stop/Ratio Valve actuator is controlled by an electronic servo-control system (not included), which compares the demanded and actual valve positions. The control system modulates the input current signal to the electrohydraulic servo valve to minimize the positioning system error. See Figure 1-2 for a functional schematic of the single-acting actuator.

Hydraulic oil enters the actuator via a removable element filter with integral high ΔP indicator and is directed to a four-way, electrohydraulic servo valve used in a three-way configuration. The PC1 control pressure output from the servo valve is directed to the top of the hydraulic piston. When the force exerted by the hydraulic pressure exceeds the force of the opposing loading springs, the output piston extends, rotating the valve in the opening direction.

A trip relay valve assembly is interposed between the electrohydraulic servo control valve and the servo output stage. Loss or reduction of the externally supplied trip signal pressure causes the trip relay valve to shift position. This connects the upper cavity of the actuator piston to the hydraulic drain. The force supplied by the return springs pushes the actuation rod up, rotating the valve to the closed position.

Two redundant LVDT position feedback transducers are also mounted within each actuator. The LVDT sensor cores and support rods are connected to the main actuator output rod by a coupling arrangement guided on a bushing. This guide bushing maintains LVDT alignment to minimize core damage due to sliding wear and the associated loss of sensing accuracy.

Chapter 3.

Standard Component Details

Triple Coil Electrohydraulic Servo Valve Assembly

The stop/ratio valve actuator utilizes a two-stage hydraulic servo valve to modulate the position of the output shaft and thereby control the stop ratio valve. The first stage torque motor utilizes a triple wound coil, which controls the position of the first and second stage valves in proportion to the total electrical current applied to the three coils.

If the control system requires a rapid movement of the valve to increase fuel pressure to the control valves, the total current is increased well above the null current. In such a condition, supply oil is admitted to the cavity above the actuator piston. The flow rate delivered to the upper piston cavity is proportional to the total current applied to the three coils. Thus, the actuator stroke velocity and the valve opening are also proportional to the current (above null) supplied to the torque motor above the null point.

If the control system requires a rapid movement to reduce fuel pressure downstream of the stop/ratio valve, the total current is reduced well below the null current. In such a condition, the actuator piston cavity is connected to the hydraulic drain circuit. The flow rate returning from the upper piston cavity of the valve is proportional to the magnitude of the total current below the null value. The flow rate and closing velocity of the valve are in this case proportional to the total current below the null point.

Near the null current, the servo valve essentially isolates the upper piston cavity from the hydraulic supply and drain, and the upper piston pressure and spring load are balanced to maintain a constant position. The control system, which regulates the amount of current delivered to the coils, modulates the current supplied to the coil to obtain proper closed loop operation of the system.

Trip Relay Valve Assembly

The stop/ratio valve uses a solenoid-operated trip relay circuit to operate a high capacity, three-way, two-position, hydraulically operated valve. This trip relay circuit consists of four functional elements: the trip relay solenoid valve, the trip relay supply orifice, the hydraulically operated trip valve, and the trip relay volume.

In the normal run mode, the trip relay solenoid valve is closed, which prevents the trip relay volume from bleeding to the hydraulic return. As a result, high-pressure oil is fed into the trip relay circuit through the supply orifice, which quickly pressurizes the trip circuit to supply pressure. When the trip circuit pressure increases above 1100 kPa (160 psig), the three-way relay valve shifts position so that the common port connects the control port of the servo valve to the lower piston cavity of the actuator, allowing the servo valve to position the throttle valve.

The solenoid valve opens when it is de-energized. Opening the solenoid valve causes the trip circuit to be connected to drain. This in turn causes the three-way relay valve to shift position so that the common port is connected to the hydraulic drain circuit, and isolated from the hydraulic supply. As the pressure falls within the lower piston cavity, the return spring rapidly returns the valve plug to the downward position, closing the control valve and shutting off fuel to the engine.

Hydraulic Filter Assembly

The stop/ratio actuator is supplied with an integrated, high capacity filter. This broad range filter protects the internal hydraulic control components from large oil-borne contaminants that might cause the hydraulic components to stick or operate erratically. The filter is supplied with a visual indicator which indicates when the pressure differential exceeds the recommended value, indicating that replacement of the element is necessary.

LVDT Position Feedback Sensors

The stop/ratio actuator uses dual LVDTs for position feedback. The LVDTs are factory set to give 0.7 ± 0.1 Vrms feedback at minimum position and 3.5 ± 0.5 Vrms feedback at maximum position. The actual voltage values for each LVDT are recorded on a label placed inside the actuator electrical box, for reference during field calibration.

Chapter 4. Installation

General

See the outline drawing (Figure 1-1) for:

- Overall dimensions
- Process piping flange locations
- Hydraulic fitting sizes
- Electrical connections
- Lift points and center of gravity
- Weight of the valve

The design of the Vee-Ball® valve requires that the rotary drive shaft be mounted horizontally. Additionally, a vertical actuator position is generally preferred to conserve floor space as well as ease of making electrical, fuel, and hydraulic connections and changing the hydraulic filter element.

The stop/ratio valve is designed for support by the piping flanges alone. Additional supports are neither needed nor recommended.

The standard stop/ratio valve is supplied with a left-hand orientation as shown in the outline drawing. The valve can be configured with a right-hand orientation; however, this request must be on the purchase order at the time the order is placed for this change to take place.



WARNING

External fire protection is not provided in the scope of this product. It is the responsibility of the user to satisfy any applicable requirements for their system.



WARNING

Due to typical noise levels in turbine environments, hearing protection should be worn when working on or around the valve.



WARNING

The surface of this product can become hot enough or cold enough to be a hazard. Use protective gear for product handling in these circumstances. Temperature ratings are included in the specification section of this manual.



WARNING

Do not lift or handle the valve by any conduit. Lift or handle the valve only by using the eyebolts.



WARNING

The surface temperature of this valve approaches the maximum temperature of the applied process media. It is the responsibility of the user to ensure that the external environment contains no hazardous gases capable of ignition in the range of the process media temperatures.

Unpacking

The valve is shipped in an airtight bag with desiccant to ensure a non-corrosive environment. We recommend that the valve be kept in its shipping container until installation. If the valve is to be stored for extended periods of time, encase the valve in an airtight container with desiccant.

Piping Installation

Refer to ANSI B16.5 for details of flange, gasket, and bolt types and dimensions.

Verify that the process piping flange-to-flange-face dimensions meet the requirements of the outline drawing (Figure 1-1) within standard piping tolerances. The valve should mount between the piping interfaces such that the flange bolts can be installed with only manual pressure applied to align the flanges. Mechanical devices such as hydraulic or mechanical jacks, pulleys, chain-falls, or similar should never be used to force the piping system to align with the valve flanges.

The stop/ratio valve is designed for support by the piping flanges alone; additional supports are neither needed nor recommended.

Grade 5 (metric class 8.8) bolts or studs should be used to install the valve into the process piping. The length and diameter for Class 300 flanges shall conform to the following table according to the valve flange size.

Table 4-1. Class 300 Flange Bolt or Stud Specifications

Nominal Pipe Size	Number of Bolts	Diameter of Bolts	Stud Length	Machine Bolt Length
1 inch/ 25 mm	4	5/8 inch/ 16 mm	3.00 inch/ 76.2 mm	2.50 inch/ 63.5 mm
2 inch/ 51 mm	8	3/4 inch/ 19 mm	3.50 inch/ 88.9 mm	3.00 inch/ 76.2 mm
3 inch/ 76 mm	8	3/4 inch/ 19 mm	4.25 inch/ 108.0 mm	3.50 inch/ 88.9 mm
4 inch/ 102 mm	8	3/4 inch/ 19 mm	4.50 inch/ 114.3 mm	3.75 inch/ 95.2 mm
6 inch/ 152 mm	8	3/4 inch/ 19 mm	4.75 inch/ 120.6 mm	4.25 inch/ 108.0 mm
8 inch/ 203 mm	12	7/8 inch/ 22 mm	5.50 inch/ 139.7 mm	4.75 inch/ 120.6 mm

Flange gasket materials should conform to ANSI B16.20. The user should select a gasket material which will withstand the expected bolt loading without injurious crushing, and which is suitable for the service conditions.

When installing the valve into the process piping, it is important to properly torque the stud/bolts in the appropriate sequence in order to keep the flanges of the mating hardware parallel to each other. A two-step torque method is recommended. Once the studs/bolts are hand tightened, torque the studs/bolts in a crossing pattern to half the torque value listed in the following table. Once all studs/bolts have been torqued to half the appropriate value, repeat the pattern until the rated torque value is obtained.

Table 4-2. Stud / Bolt Torque Values

Bolt Size	Torque
5/8 inch/16 mm	150–155 lb-ft/203–210 N·m
3/4 inch/19 mm	250–260 lb-ft/339–353 N·m
7/8 inch/22 mm	375–390 lb-ft/508–529 N·m

Hydraulic Connections

Two hydraulic connections must be made to each valve: supply and return. The connections to the valve are straight-thread O-ring style ports per SAE J514. The tubing up to the valve must be constructed to eliminate any transfer of vibration or other forces into the valve.

Make provisions for proper filtration of the hydraulic fluid that will supply the actuator. The system filtration should be designed to assure a supply of hydraulic oil with a maximum ISO 4406 contamination level of 18/16/13 and a preferred level of 16/14/11. The filter element included with the actuator is not intended to provide adequate filtration over the entire life of the actuator.

The hydraulic supply to the actuator is to be 0.500 inch (12.70 mm) tubing capable of supplying 10 US gallons/min (18 L/min) at 1200–1700 psig (8274–11 722 kPa).

The hydraulic drain should be 1.00 inch (25.4 mm) tubing and must not restrict the flow of fluid from the valve. The drain pressure must not exceed 30 psig (207 kPa) under any condition.

Electrical Connections



WARNING

EXPLOSION HAZARD—Do not connect or disconnect while circuit is live unless area is known to be non-hazardous.



WARNING

Due to the hazardous location listings associated with this valve, proper wire type and wiring practices are critical to operation.

NOTICE

Do not connect any cable grounds to “instrument ground”, “control ground”, or any non-earth ground system. Make all required electrical connections based on the wiring diagram (Figure 1-3).

The use of cable with individually shielded twisted pairs is recommended. All signal lines should be shielded to prevent picking up stray signals from nearby equipment. Installations with severe electromagnetic interference (EMI) may require shielded cable run in conduit, double-shielded wire, or other precautions. Connect the shields at the control system side or as indicated by the control system wiring practices, but never at both ends of the shield such that a ground loop is created. Wires exposed beyond the shield must be less than 2 inches (51 mm). The wiring should provide signal attenuation to greater than 60 dB.

Servo Valve Electrical Connection

Servo valve cable must consist of three individually shielded twisted pairs. Each pair should be connected to one coil of the servo valve as indicated in Figure 1-12 (Wiring Diagram).

LVDT Electrical Connection

The LVDT cable must consist of four individually shielded twisted pairs. Two separate pairs should be used for each of the excitation voltages to the LVDT, and two separate pairs used for each of the feedback voltages from the LVDT.

Electric Trip Solenoid Connection

The electric trip solenoid valve must use wire suitable for at least 300 V.

Fuel Vent Port

The fuel vent port must be vented to a safe location. In normal operation, this vent should have zero leakage. However, if excessive leakage is detected from this vent port, contact a Woodward representative for assistance.

Electronic Settings

Dynamic Tuning Parameters

It is imperative that the correct dynamic characteristics of this valve be input into the control system to ensure that the operation of the valve/control system is within acceptable limits.




Figure 4-1. Stop/Ratio Valve Block Diagram

Ksv nominal = 3.0 in³/sec/mA at 1600 psi supply (small actuator¹);
 6.0 in³/sec/mA at 1600 psi supply (large actuator¹);
 Ksv is proportional to square root of supply, and constant with position.

ZetaSV = 0.7

WnSV = 680 rad/s (108 Hz); WnSV is proportional to square root of supply

Ac = 2.4 in² (small actuator¹); 4.9 in² (large actuator¹)

KL = 0.80 Vrms/inch

Servo Travel = 3.5 inches

TauL = 0.005 seconds (depends on excitation/demodulation)

¹See page 2 for usage of small and large actuators




Figure 4-2. Structures for PID Control

Table 4-3. Recommended Control Gain Values for Different Control Types

Control Gain Settings	Proportional Control	Proportional Integral	Proportional Integral Derivative
	Kp=5;	Kp=3; Ki=5;	Kp=3; Ki=5; Kd=0.01 or Tau Lead = 0.01

Null Current Adjustment

Every valve shipped contains documentation that gives the actual Null Current as measured by Woodward. It is imperative that the control system null current match the as-measured current for each valve in the system. Incorrect null current setting, with proportional control only, will result in position error.

Rigging Procedure

Inside the electrical enclosure of the valve, there is an adhesive label that contains the appropriate valve position (as a percent of full stroke), the physical stroke (inches), and the corresponding LVDT feedback signals for each LVDT (assuming 7.0 Vrms excitation at 3000 Hz).

Once the control system is connected to the valve and control of the valve is established, set the valve command position to 0% of full stroke. Measure the feedback voltage from each LVDT. Adjust the Offset in the feedback loop until the feedback voltage matches the documented values (see the label inside the electrical enclosure) for that position. Adjust the command position to 100% of full stroke. Adjust the Gain of the feedback loop until the LVDT feedback voltage matches the documented values. Set the command position to close the valve. Verify that the valve is closed visually and that the feedback voltage from the LVDT is 0.7 ± 0.1 Vrms. This process may have to be repeated to ensure the feedback voltages at both the 0% and 100% command positions match the documented values.

Chapter 5.

Maintenance and Hardware Replacement

Maintenance

The Gas Stop/Ratio Valve requires no maintenance or adjustment in preparation for or during normal operation.

Woodward recommends routine checks of the DP gauge on the filter assembly to verify that the filter is not partially clogged. If the DP indicator shows red, the filter element needs to be replaced.

In the event that any of the standard components of the valve become inoperative, field replacement of certain components is possible. Contact a Woodward representative for assistance.

Hardware Replacement

WARNING

EXPLOSION HAZARD—Do not connect or disconnect while circuit is live unless area is known to be non-hazardous.

Substitution of components may impair suitability for Class I, Division 2 or Zone 2.

WARNING

To prevent possible serious personal injury, or damage to equipment, be sure all electric power, hydraulic pressure, and gas pressure have been removed from the valve and actuator before beginning any maintenance or repairs.

WARNING

External fire protection is not provided in the scope of this product. It is the responsibility of the user to satisfy any applicable requirements for their system.

WARNING

Due to typical noise levels in turbine environments, hearing protection should be worn when working on or around the Gas Stop/Ratio valve.

WARNING

The surface of this product can become hot enough or cold enough to be a hazard. Use protective gear for product handling in these circumstances. Temperature ratings are included in the specification section of this manual.

WARNING

Do not lift or handle the valve by any conduit. Lift or handle the valve only by using the eyebolts.

See the outline drawing (Figure 1-1) for the location of items.

Hydraulic Filter Assembly/Cartridge

The hydraulic filter is located on the hydraulic manifold, hanging directly under the servo valve.

Replacement of Filter Assembly

1. Remove four 0.312-18 UNC socket head cap screws.
2. Remove the filter assembly from manifold block.

IMPORTANT

The filter contains a large amount of hydraulic fluid that may be spilled during filter removal.

3. Remove the two O-rings present in the interface between the filter and the manifold.
4. Obtain a new filter assembly.
5. Place two new O-rings in the new filter assembly.
6. Install filter onto manifold assembly. Be sure to place the filter in the correct orientation. See the outline drawing (Figure 1-1).
7. Install four 0.312-18 cap screws through filter and torque into manifold to 106–146 lb-in (12.0–16.5 N·m).

Replacement of Filter Cartridge

IMPORTANT

The filter contains a large amount of hydraulic fluid that may be spilled during filter removal.

1. Using a 1-5/16 inch (~33+ mm) wrench, loosen the bowl from the filter assembly.
2. Remove the filter element by pulling it downward.
3. Obtain a new filter element.
4. Lubricate the O-ring on the ID of the cartridge with hydraulic fluid.
5. Install the cartridge into the assembly by sliding the open end of the cartridge upward onto the nipple.
6. Install the filter bowl. Tighten only by hand.

Trip Relay Valve Cartridge

The trip relay valve cartridge is located in the hydraulic manifold block.

IMPORTANT

Hydraulic fluid may spill during cartridge removal.

1. Using a 1.5 inch (~38+ mm) wrench, loosen the trip relay valve from the hydraulic manifold.
2. Slowly remove the cartridge from the manifold.
3. Obtain new trip relay valve cartridge and verify part number and revision with existing unit.
4. Verify that all O-rings and backup rings are present on new cartridge.
5. Lubricate O-rings with hydraulic fluid or petroleum jelly.
6. Install cartridge into manifold housing.
7. Torque to 80–90 lb-ft (108–122 N·m).

Trip Relay Solenoid Valve

The trip relay solenoid valve is located on the side of the hydraulic manifold opposite the trip relay cartridge valve. See the outline drawing (Figure 1-1).

1. Remove the cover to the electrical junction box.
2. Disconnect the solenoid valve wires from the connector block labeled 17 and 18.
3. Loosen the conduit fittings from the electrical box, the solenoid valve, and the tee fitting in between.
4. Carefully remove the conduit from the solenoid valve and pull the wiring out of the conduit.
5. Using a 1-1/4 inch wrench (~32– mm), loosen the solenoid valve from the hydraulic manifold.
6. Slowly remove the solenoid valve from the manifold. ***There could be some hydraulic fluid upon removal. Be cautious when handling.***

7. Obtain a new solenoid valve from Woodward.
8. Verify that both O-rings and back-up ring are present on the new valve.
9. Lubricate the O-rings with hydraulic fluid or petroleum jelly.
10. Install the new solenoid valve into the hydraulic manifold.
11. Torque the solenoid valve to 40–58 lb-ft (54–79 N·m).
12. Install wiring through the conduit and into the electrical box.
13. Connect the conduit to the solenoid valve and torque to 450–550 lb-in (51–62 N·m).
14. Torque the conduit to the electrical box and to the tee fitting to 450–550 lb-in (51–62 N·m).
15. Install wires into the solenoid valve connector blocks labeled 17 and 18. If it is necessary to cut the wires for installation, be sure to retain at least one service loop of wiring.
16. Replace the cover onto the junction box and tighten the screws.

Check for external leakage upon pressurizing the hydraulic system.

Servo Valve

The servo valve is located on the hydraulic manifold directly above the filter assembly. Refer to the outline drawing (Figure 1-1).

IMPORTANT

There could be a substantial amount of hydraulic fluid upon removal.

1. Remove the cover to the electrical junction box.
2. Disconnect the servo valve wires from the connector blocks labeled 1–6.
3. Loosen the conduit fittings from the electrical box and the servo valve.
4. Carefully remove the conduit from the servo valve and pull the wiring out of the conduit.
5. Remove the four #10-32 UNF socket head cap screws holding the servo valve to the manifold.
6. Discard the eight O-rings between the servo valve, the adapter plate, and the manifold.
7. Obtain replacement servo valve and verify part number and revision with existing unit.
8. Place four new O-rings on the adapter plate.
9. Reposition adapter plate onto hydraulic manifold ensuring hydraulic passages and bolt holes are aligned correctly. Be sure that all four O-rings remain in their proper location during assembly on the lower side of the adaptor plate facing the manifold.
10. Remove protective plate from replacement servo valve and verify that O-rings are on all four counter bores of the servo valve.
11. Place the servo valve onto the adapter plate that has been positioned on the hydraulic manifold. Be sure to orient the servo valve to match the original orientation. Be sure that all four O-rings remain in their proper location during assembly.
12. Install four #10-32 UNF socket head cap screws and torque to 55-57 lb-in (6.2-6.4 N·m).
13. Install the servo valve wiring through conduit and into electrical box.
14. Connect conduit to servo valve and torque to 450–550 lb-in (51–62 N·m).
15. Torque conduit to electrical box to 450–550 lb-in (51–62 N·m).
16. Install wires into servo valve connector blocks labeled 1–6 as shown in the wiring diagram (Figure 1-3). If it is necessary to cut wires for installation, be sure to retain at least one service loop of wiring.
17. Replace cover onto junction box and tighten screws.

! WARNING

To prevent possible personal injury, do NOT remove the spring cover (which is spring-loaded to over 1000 lbs/4448 N).

The LVDTs are located on the upper mounting plate located on the top of the large spring cylinder and below the hydraulic manifold. Refer to the outline drawing (Figure 1-1).

1. Remove the cover to the electrical junction box.
2. Disconnect both sets of LVDT wires from the connector blocks labeled 7–14.
3. Loosen the conduit fittings from the electrical box and from both LVDTs.
4. Carefully remove the conduit from the LVDTs and pull the wiring out of the conduit.

5. Disconnect the hydraulic drain connection for improved working space.

IMPORTANT

There could be a substantial amount of hydraulic fluid upon removal.

6. Remove the 0.500-20 UNF mounting nut from the defective LVDT only.
7. Remove the two 0.250-20 UNC socket head cap screws holding the LVDT bracket to the upper mounting plate.
8. Carefully remove the LVDT assembly from the valve by lifting vertically upwards. Take care not to damage the good LVDT housing and rod.
9. Remove the four #10-32 UNF screws holding the access cover on the side of the spring cylinder to gain access to the LVDT rods.
10. Remove 0.375-24 UNF jam nut from defective LVDT rod.
11. Remove the defective LVDT rod using the 0.250 inch flats at the top of the threads. The rod will be difficult to unscrew due to the thread-locking feature incorporated into the spring plate.
12. Obtain replacement LVDT and verify part number and revision with existing unit.
13. Install replacement LVDT rod into spring plate, positioning the rod height to approximately match the other LVDT rod height.
14. Install the 0.375-24 UNF jam nut onto the LVDT rod but do not torque nut at this time.

15. Carefully slide replacement LVDT through upper mounting plate and over the LVDT rod. Be very careful not to force the LVDT at any time since this could damage the LVDT rod.
16. Carefully reinstall the good LVDT and bracket assembly through upper mounting plate and over the LVDT rod. Be very careful not to force the LVDT at any time since this could damage the LVDT rod.
17. Install the two 0.250-20 UNC socket head cap screws holding the LVDT bracket to the upper mounting plate and torque to 58–78 lb-in (6.6–8.8 N·m).
18. Install replacement LVDT into mounting bracket and torque 0.500-20 UNF mounting nut to 400–500 lb-in (45–56 N·m).
19. Mark one of the LVDT wire sets so that the two sets of LVDT wires are distinct. Once the LVDT wires are installed into the electrical box, it will be difficult to distinguish the two sets if they are not marked.
20. Install wiring through conduit and into electrical box.
21. Connect conduit to LVDTs and torque to 450–550 lb-in (51–62 N·m).
22. Torque conduit to electrical box to 450–550 lb-in (51–62 N·m).
23. Install wires into LVDT connector blocks labeled 7–14 as shown in the wiring diagram (Figure 1-3). If it is necessary to cut wires for installation, be sure to retain at least one service loop of wiring.
24. Reattach the hydraulic drain connection.
25. Once the LVDT is installed, it must then be calibrated as described below.

LVDT Calibration

1. Whenever an LVDT is replaced, or whenever its core rod adjustment is disturbed, the LVDT output voltage must be calibrated in the following way.



WARNING

Use care and follow all instructions after removal of the spring access cover. Internal components can potentially crush fingers, and some components are held under significant force.

2. Shut off the hydraulic supply to the stop/ratio actuator.
3. Remove the access cover from the side of the stop/ratio actuator housing by removing the four #10-32 UNF screws and washers, exposing the LVDT core rod adjustment.
4. Adjust the LVDT rod so that the output of the replaced LVDT is 0.7 ± 0.1 Vrms with the stop/ratio actuator fully retracted (gas valve fully closed).
5. Tighten the 1.375-24 UNF LVDT rod jam nut to 270–320 lb-in (31–36 N·m).
6. Install the stroke measurement attachment bar (Woodward part number 1327-945 provided with the stop/ratio actuator) to the moving plate of the actuator as shown in Figure 5-1.
7. Attach an accurate stroke measurement device (dial indicator or equivalent), capable of measuring 4 inches (100 mm) of stroke, to the stop/ratio actuator body. Position the indicator plunger tip on the measurement bar, as shown in Figure 5-1.
8. Apply hydraulic pressure to the stop/ratio actuator and manually command the actuator to stroke 3.500 ± 0.005 inches (88.90 ± 0.13 mm) by manipulating the electronic controller.
9. Note and record the LVDT output voltages at this 3.5 inch stroke position.
10. Remove the actuator control command, returning the actuator to its rest (gas valve closed) position.
11. Shut off the stop/ratio actuator hydraulic supply.
12. Update the stop/ratio control logic with the new LVDT output voltage value.
13. Remove the cover on the stop/ratio actuator electrical junction box.
14. Replace the original LVDT max output voltage value on the label in the stop/ratio actuator electrical junction box with the newly measured value.
15. Replace the cover on the junction box and tighten the screws.
16. Remove the dial indicator and measurement bar.



Figure 5-1. Stroke Measurement Attachment Bar

17. Reinstall the access cover with four #10-32 UNF screws, adjusting the closed indicator mark to align with the position indicator screw slot. Tighten the four cover attaching screws to 30–40 lb-in (3.4–4.5 N·m).

Troubleshooting Charts

Faults in the fuel control or governing system are often associated with speed variations of the prime mover, but such speed variations do not always indicate fuel control or governing system faults. Therefore, when improper speed variations occur, check all components including the engine or turbine for proper operation. Refer to applicable electronic control manuals for assistance in isolating the trouble. The following steps describe troubleshooting for the gas fuel stop/ratio valve.

Disassembly of the gas fuel stop/ratio valve in the field is not recommended due to the dangerous forces contained in the springs. Under unusual circumstances where disassembly becomes necessary, all work and adjustments should be made by personnel thoroughly trained in the proper procedures.

When requesting information or service help from Woodward, it is important to include the part number and serial number of the valve assembly in your communication.

Manual 26704

Gas Stop/Ratio Valve with Electric Trip / IECEx

Symptom	Possible Causes	Remedies
External hydraulic leakage	Static O-ring seal(s) missing or deteriorated	Replace O-rings fitted to user-serviceable components (filter, servo valve, trip relay valve) as needed. Otherwise, return actuator to Woodward for service.
	Dynamic O-ring seal missing or deteriorated	Return actuator to Woodward for service.
Internal hydraulic leakage	Servo valve internal O-ring seal(s) missing or deteriorated	Replace servo valve.
	Servo valve metering edges worn	Replace servo valve.
	Piston seal missing or deteriorated	Return actuator to Woodward for service.
External gas fuel leakage	Piping flange gaskets missing or deteriorated	Replace gaskets.
	Piping flanges improperly aligned	Rework piping as needed to achieve alignment requirements detailed in Chapter 4.
	Piping flange bolts improperly torqued	Rework bolts as needed to achieve torque requirements detailed in Chapter 4.
	Packing follower needs adjustment	Adjust follower per Fisher manual Form 5290, Type Vee-Ball.
	Packing missing or deteriorated	Service packing per Fisher manual Form 5290, Type Vee-Ball.
Internal gas fuel leakage	Vee-Ball seal missing or deteriorated	Service seal per Fisher manual Form 5290, Type Vee-Ball, and Fisher Errata Sheet Type Vee-Ball SS-260.
Valve will not open	Servo valve command current incorrect. (The sum of the current through the three coils of the servo valve must be greater than the null bias of the servo valve for the gas valve to open.)	Trace and verify that all wiring is in accordance with the electrical schematic (Figure 1-3) and the GE system wiring schematic(s). Pay special attention to the polarity of the wiring to the servo valve and LVDT.
	Servo valve failure	Replace servo valve.
	Hydraulic supply pressure inadequate	Supply pressure must be greater than 1200 psig/8274 kPa (1600 psig/11 032 kPa preferred).
	Trip solenoid valve failure	Replace solenoid valve.
	Vee-Ball jammed	Service Vee-Ball per Fisher manual Form 5290, Type Vee-Ball.
Valve will not close	Servo valve command current incorrect. (The sum of the current through the three coils of the servo valve must be less than the null bias of the servo valve for the gas valve to close.)	Trace and verify that all wiring is in accordance with the electrical schematic (Figure 1-3) and the GE system wiring schematic(s). Pay special attention to the polarity of the wiring to the servo valve and LVDT.
	Servo valve failure	Replace servo valve.
	LVDT failure	Replace LVDT.
	Springs broken	Return actuator to Woodward for service.
	Linkage broken	Return actuator to Woodward for service.
	Vee-Ball jammed	Service Vee-Ball per Fisher manual Form 5290, Type Vee-Ball.

Symptom	Possible Causes	Remedies
Valve will not respond smoothly	Hydraulic filter clogged	Check the differential pressure indicator on the filter housing.
	Servo valve spool sticking	Verify hydraulic contamination levels are within recommendations of Chapter 1. The use of dither may improve performance in contaminated systems.
	Servo valve internal pilot filter clogged	Replace servo valve.
	Excessive friction in Vee-Ball assembly	Service Vee-Ball per Fisher manual Form 5290, Type Vee-Ball, and Fisher Errata Sheet Type Vee-Ball SS-260.
	Rod-end(s) worn out	Return actuator to Woodward for service.
Actuator seals wear out prematurely	Piston seal worn out	Return actuator to Woodward for service.
	Hydraulic contamination level is excessive	Verify hydraulic contamination levels are within recommendations of Chapter 1. The use of excessive dither may reduce life in contaminated systems.
	System is oscillating (seal life is proportional to distance traveled). Even small oscillations (on the order of $\pm 1\%$) at slow frequencies (on the order of 0.1 Hz) cause wear to accumulate rapidly.	Determine and eliminate the root cause of oscillation.

Chapter 6.

Product Support and Service Options

Product Support Options

If you are experiencing problems with the installation, or unsatisfactory performance of a Woodward product, the following options are available:

- Consult the troubleshooting guide in the manual.
- Contact the manufacturer or packager of your system.
- Contact the Woodward Full-Service Distributor serving your area.
- Contact Woodward technical assistance (see “How to Contact Woodward” later in this chapter) and discuss your problem. In many cases, your problem can be resolved over the phone. If not, you can select which course of action to pursue based on the available services listed in this chapter.

OEM or Packager Support: Many Woodward controls and control devices are installed into the equipment system and programmed by an Original Equipment Manufacturer (OEM) or Equipment Packager at their factory. In some cases, the programming is password-protected by the OEM or packager, and they are the best source for product service and support. Warranty service for Woodward products shipped with an equipment system should also be handled through the OEM or Packager. Please review your equipment system documentation for details.

Woodward Business Partner Support: Woodward works with and supports a global network of independent business partners whose mission is to serve the users of Woodward controls, as described here:

- A **Full-Service Distributor** has the primary responsibility for sales, service, system integration solutions, technical desk support, and aftermarket marketing of standard Woodward products within a specific geographic area and market segment.
- An **Authorized Independent Service Facility (AISF)** provides authorized service that includes repairs, repair parts, and warranty service on Woodward's behalf. Service (not new unit sales) is an AISF's primary mission.

A current list of Woodward Business Partners is available at www.woodward.com/directory.

Product Service Options

The following factory options for servicing Woodward products are available through your local Full-Service Distributor or the OEM or Packager of the equipment system, based on the standard Woodward Product and Service Warranty (5-01-1205) that is in effect at the time the product is originally shipped from Woodward or a service is performed:

- Replacement/Exchange (24-hour service)
- Flat Rate Repair
- Flat Rate Remanufacture

Replacement/Exchange: Replacement/Exchange is a premium program designed for the user who is in need of immediate service. It allows you to request and receive a like-new replacement unit in minimum time (usually within 24 hours of the request), providing a suitable unit is available at the time of the request, thereby minimizing costly downtime. This is a flat-rate program and includes the full standard Woodward product warranty 5-01-1205 North American Terms and Conditions of Sale (Industrial Business Segment).

This option allows you to call your Full-Service Distributor in the event of an unexpected outage, or in advance of a scheduled outage, to request a replacement control unit. If the unit is available at the time of the call, it can usually be shipped out within 24 hours. You replace your field control unit with the like-new replacement and return the field unit to the Full-Service Distributor.

Charges for the Replacement/Exchange service are based on a flat rate plus shipping expenses. You are invoiced the flat rate replacement/exchange charge plus a core charge at the time the replacement unit is shipped. If the core (field unit) is returned within 60 days, a credit for the core charge will be issued.

Flat Rate Repair: Flat Rate Repair is available for the majority of standard products in the field. This program offers you repair service for your products with the advantage of knowing in advance what the cost will be. All repair work carries the standard Woodward service warranty 5-01-1205 North American Terms and Conditions of Sale (Industrial Business Segment) on replaced parts and labor.

Flat Rate Remanufacture: Flat Rate Remanufacture is very similar to the Flat Rate Repair option with the exception that the unit will be returned to you in "like-new" condition and carry with it the full standard Woodward product warranty 5-01-1205 North American Terms and Conditions of Sale (Industrial Business Segment). This option is applicable to mechanical products only.

Returning Equipment for Repair

If a control (or any part of an electronic control) is to be returned for repair, please contact your Full-Service Distributor in advance to obtain Return Authorization and shipping instructions.

When shipping the item(s), attach a tag with the following information:

- Return authorization number
- Name and location where the control is installed
- Name and phone number of contact person
- Complete Woodward part number(s) and serial number(s)
- Description of the problem
- Instructions describing the desired type of repair

Packing a Control

Use the following materials when returning a complete control:

- Protective caps on any connectors
- Antistatic protective bags on all electronic modules
- Packing materials that will not damage the surface of the unit
- At least 100 mm (4 inches) of tightly packed, industry-approved packing material
- A packing carton with double walls
- A strong tape around the outside of the carton for increased strength

NOTICE

To prevent damage to electronic components caused by improper handling, read and observe the precautions in Woodward manual 82715, *Guide for Handling and Protection of Electronic Controls, Printed Circuit Boards, and Modules*.

Replacement Parts

When ordering replacement parts for controls, include the following information:

- The part number(s) (XXXX-XXXX) that is on the enclosure nameplate
- The unit serial number, which is also on the nameplate

Engineering Services

Woodward offers various Engineering Services for our products. For these services, you can contact us by telephone, by email, or through the Woodward website.

- Technical Support
- Product Training
- Field Service

Technical Support is available from your equipment system supplier, your local Full-Service Distributor, or from many of Woodward's worldwide locations, depending upon the product and application. This service can assist you with technical questions or problem solving during the normal business hours of the Woodward location you contact. Emergency assistance is also available during non-business hours by phoning Woodward and stating the urgency of your problem.

Product Training is available as standard classes at many of our worldwide locations. We also offer customized classes, which can be tailored to your needs and can be held at one of our locations or at your site. This training, conducted by experienced personnel, will assure that you will be able to maintain system reliability and availability.

Field Service engineering on-site support is available, depending on the product and location, from many of our worldwide locations or from one of our Full-Service Distributors. The field engineers are experienced both on Woodward products as well as on much of the non-Woodward equipment with which our products interface.

For information on these services, please contact us via telephone, email us, or use our website:
www.woodward.com.

Contacting Woodward's Support Organization

For the name of your nearest Woodward Full-Service Distributor or service facility, please consult our worldwide directory at www.woodward.com/directory, which also contains the most current product support and contact information.

You can also contact the Woodward Customer Service Department at one of the following Woodward facilities to obtain the address and phone number of the nearest facility at which you can obtain information and service.

Products Used in Electrical Power Systems

<u>Facility</u>	<u>Phone Number</u>
Brazil -----	+55 (19) 3708 4800
China -----	+86 (512) 6762 6727
Germany:	
Kempen----	+49 (0) 21 52 14 51
Stuttgart -	+49 (711) 78954-510
India -----	+91 (124) 4399500
Japan-----	+81 (43) 213-2191
Korea-----	+82 (51) 636-7080
Poland -----	+48 12 295 13 00
United States-----	+1 (970) 482-5811

Products Used in Engine Systems

<u>Facility</u>	<u>Phone Number</u>
Brazil -----	+55 (19) 3708 4800
China -----	+86 (512) 6762 6727
Germany -----	+49 (711) 78954-510
India -----	+91 (124) 4399500
Japan-----	+81 (43) 213-2191
Korea-----	+82 (51) 636-7080
The Netherlands--	+31 (23) 5661111
United States-----	+1 (970) 482-5811

Products Used in Industrial Turbomachinery Systems

<u>Facility</u>	<u>Phone Number</u>
Brazil -----	+55 (19) 3708 4800
China -----	+86 (512) 6762 6727
India -----	+91 (124) 4399500
Japan-----	+81 (43) 213-2191
Korea-----	+82 (51) 636-7080
The Netherlands--	+31 (23) 5661111
Poland -----	+48 12 295 13 00
United States-----	+1 (970) 482-5811

Technical Assistance

If you need to contact technical assistance, you will need to provide the following information. Please write it down here before contacting the Engine OEM, the Packager, a Woodward Business Partner, or the Woodward factory:

General

Your Name _____

Site Location _____

Phone Number _____

Fax Number _____

Prime Mover Information

Manufacturer _____

Turbine Model Number _____

Type of Fuel (gas, steam, etc.) _____

Power Output Rating _____

Application (power generation, marine,
etc.) _____

Control/Governor Information

Control/Governor #1

Woodward Part Number & Rev. Letter _____

Control Description or Governor Type _____

Serial Number _____

Control/Governor #2

Woodward Part Number & Rev. Letter _____

Control Description or Governor Type _____

Serial Number _____

Control/Governor #3

Woodward Part Number & Rev. Letter _____

Control Description or Governor Type _____

Serial Number _____

Symptoms

Description _____

If you have an electronic or programmable control, please have the adjustment setting positions or the menu settings written down and with you at the time of the call.

Revision History

Changes in Revision A—

- Revised torque values in the Servo Valve section, Line 12, on pg. 23

We appreciate your comments about the content of our publications.

Send comments to: icinfo@woodward.com

Please reference publication **26704**.



PO Box 1519, Fort Collins CO 80522-1519, USA
1041 Woodward Way, Fort Collins CO 80524, USA
Phone +1 (970) 482-5811

Email and Website—www.woodward.com

Woodward has company-owned plants, subsidiaries, and branches, as well as authorized distributors and other authorized service and sales facilities throughout the world.

Complete address / phone / fax / email information for all locations is available on our website.