

Product Manual 35210 (Revision 2, 11/2022)
Original Instructions

Woodward Gas Fuel Skid with GS Series Metering Valves

For GE DLE Turbines: LM2500+ DLE, LM2500+ G4 DLE, PGT25+ DLE, PGT25+ G4 DLE LM6000PF

Installation, Operation, and Maintenance Manual



General Precautions Read this entire manual and all other publications pertaining to the work to be performed before installing, operating, or servicing this equipment.

Practice all plant safety instructions and precautions.

Failure to follow instructions can cause personal injury and/or property damage.



Revisions

This publication may have been revised or updated since this copy was produced. To verify that you have the latest revision, check manual 26455, *Customer Publication Cross Reference and Revision Status & Distribution Restrictions*, on the publications page of the Woodward website:

http://www.woodward.com

The latest version of most publications is available on the publications page. If your publication is not there, please contact your customer service representative to receive the latest copy.



Proper Use

Any unauthorized modifications to, or use of this equipment outside of its specified mechanical, electrical, or other operating limits may cause personal injury and/or property damage, including damage to the equipment. Any such unauthorized modifications: (i) constitute "misuse" and/or "negligence" within the meaning of the product warranty, thereby excluding warranty coverage for any resulting damage, and (ii) invalidate product certifications or listings.



If the cover of this publication states "Translation of the Original Instructions" please note:

Translated Publications

The original source of this publication may have been updated since this translation was made. Be sure to check manual 26455, *Customer Publication Cross Reference and Revision Status & Distribution Restrictions*, to verify whether this translation is up to date. Out-of-date translations are marked with ⚠. Always compare with the original for technical specifications and for proper and safe installation and operation procedures.

Revisions— A bold, black line alongside the text identifies changes in this publication since the last revision.

Woodward reserves the right to update any portion of this publication at any time. Information provided by Woodward is believed to be correct and reliable. However, no responsibility is assumed by Woodward unless otherwise expressly undertaken.

Table of Contents

Warnings and Notices	
ELECTROSTATIC DISCHARGE AWARENESS	4
REGULATORY COMPLIANCE	5
CONTROL SPECIFICATIONS	7
CHAPTER 1. GENERAL INFORMATION	8
CHAPTER 2. INSTALLATION	9
Introduction	9
Mechanical Installation	
Electrical Installation	
GS Series Valve Setup/Configuration	
Water Ingress Protection	12
CHAPTER 3. MAINTENANCE	19
Introduction	
GS Series Maintenance	
GSOV25 HT Maintenance	21
CHAPTER 4. PRODUCT SUPPORT AND SERVICE OPTIONS	24
Product Support Options	
Product Service Options	
Returning Equipment for Repair	25
Replacement Parts	
Engineering Services	
Contacting Woodward's Support Organization	
Technical Assistance	27
REVISION HISTORY	28

Table of Figures

Figure 2-1. Bolt Tightening Sequence	
Figure 2-2a. Standard Woodward GS40 (Stainless Steel Body) Gas Fuel Skid Detailed View 13	
Figure 2-2b. Standard Woodward GS40 (Stainless Steel Body) Gas Fuel Skid Isometric View	14
Figure 2-3a. Standard Woodward GS40 (Aluminum Body) Gas Fuel Skid Detailed View 15	
Figure 2-3b. Standard Woodward GS40 (Aluminum Body) Gas Fuel Skid Isometric View 16	
Figure 2-4a. Standard Woodward GS50 (Stainless Steel Body) Gas Fuel Skid Detailed View 17	
Figure 2-4b. Standard Woodward GS50 (Stainless Steel Body) Gas Fuel Skid Isometric View	18

Warnings and Notices

Important Definitions



This is the safety alert symbol used to alert you to potential personal injury hazards. Obey all safety messages that follow this symbol to avoid possible injury or death.

- DANGER Indicates a hazardous situation, which if not avoided, will result in death or serious injury.
- WARNING Indicates a hazardous situation, which if not avoided, could result in death or serious injury.
- CAUTION Indicates a hazardous situation, which if not avoided, could result in minor or moderate
 injury.
- NOTICE Indicates a hazard that could result in property damage only (including damage to the control).
- **IMPORTANT** Designates an operating tip or maintenance suggestion.

<u>^</u>WARNING

Overspeed /
Overtemperature /
Overpressure

The engine, turbine, or other type of prime mover should be equipped with an overspeed shutdown device to protect against runaway or damage to the prime mover with possible personal injury, loss of life, or property damage.

The overspeed shutdown device must be totally independent of the prime mover control system. An overtemperature or overpressure shutdown device may also be needed for safety, as appropriate.



Personal Protective Equipment

The products described in this publication may present risks that could lead to personal injury, loss of life, or property damage. Always wear the appropriate personal protective equipment (PPE) for the job at hand. Equipment that should be considered includes, but is not limited to:

- Eye Protection
- Hearing Protection
- Hard Hat
- Gloves
- Safety Boots
- Respirator

Always read the proper Material Safety Data Sheet (MSDS) for any working fluid(s) and comply with recommended safety equipment.



Start-up

Be prepared to make an emergency shutdown when starting the engine, turbine, or other type of prime mover, to protect against runaway or overspeed with possible personal injury, loss of life, or property damage.

Electrostatic Discharge Awareness

NOTICE

Electrostatic Precautions

Electronic controls contain static-sensitive parts. Observe the following precautions to prevent damage to these parts:

- Discharge body static before handling the control (with power to the control turned off, contact a grounded surface, and maintain contact while handling the control).
- Avoid all plastic, vinyl, and Styrofoam (except antistatic versions) around printed circuit boards.
- Do not touch the components or conductors on a printed circuit board with your hands or with conductive devices.

To prevent damage to electronic components caused by improper handling, read and observe the precautions in Woodward manual 82715, Guide for Handling and Protection of Electronic Controls, Printed Circuit Boards, and Modules.

Follow these precautions when working with or near the control.

- Avoid the build-up of static electricity on your body by not wearing clothing made of synthetic materials. Wear cotton or cotton-blend materials as much as possible since they do not store as much static electric charges as synthetics.
- 2. Do not remove the printed circuit board (PCB) from the control cabinet unless absolutely necessary. If you must remove the PCB from the control cabinet, follow these precautions:
 - Do not touch any part of the PCB except the edges.
 - Do not touch the electrical conductors, the connectors, or the components with conductive devices or with your hands.
 - When replacing a PCB, keep the new PCB in the plastic antistatic protective bag it comes in until you are ready to install it. After removing the old PCB from the control cabinet, immediately place it in the antistatic protective bag.

Regulatory Compliance

European Compliance for CE Marking:

These listings are limited only to those units bearing the CE Marking.

EMC Directive: Declared to Directive 2014/30/EU of the European Parliament and of the

Council of 26 February 2014 on the harmonization of the laws of the Member

States relating to electromagnetic compatibility (EMC).

Pressure Directive 2014/68/EU on the harmonisation of the laws of the Member States

Equipment

relating to the making pressure equipment available on the market.

Directive PED Category II

(Valve Assembly): PED Module H – Full Quality Assurance,

CE-0062-PED-H-WDI 001-20-USA-rev-A

ATEX - Potentially

Explosive Atmospheres Directive: Directive 2014/34/EU on the harmonisation of the laws of the Member States relating to equipment and protective systems intended for use in potentially

explosive atmospheres. GS Series Valve:

Go Series valve.

Conduit (without flying leads) Versions:

Zone 1: II 2 G Ex db IIB T3 Gb, CSANe 20ATEX1196X

All Versions:

Zone 2: II 3 G Ex ec IIC T3 Gc

Note: ATEX EU-Type Certificate is limited to Category 2 (Zone 1) and only for

conduit entry versions. See Declaration of Conformity for clarification.

Other European Compliance:

Compliance with the following European Directives or standards does not qualify this product for application of the CE Marking:

Machinery Compliant as partly completed machinery with DIRECTIVE 2006/42/EC of the

Directive: European Parliament and the Council of 17 May 2006 on machinery.

IECEx: All skid components have IECEx certification.

Skid is certified for use in explosive atmospheres

GS Series Valve: IECEx CSA 19.0038X Conduit (without flying leads) Version:

Zone 1: Ex db IIB T3 Gb

All Versions:

Zone 2: Ex ec IIC T3 Gc

Special Conditions for Safe Use:

The Woodward GS Series Gas Fuel Skid must be installed in an area protected from exposure to water and falling debris.

The end user must provide electrical emergency switch-off and means for electrical isolation of the equipment.

Refer to manual 35136 for complete wiring, installation, operation, and maintenance instructions for the GS Series valve.

Refer to manual 26080 for complete wiring, installation, operation, and maintenance instructions for the Smart Pressure Transducer.

Refer to manual 26190 for complete wiring, installation, operation, and maintenance instructions for the GSOV25 HT valve.

Compliance with the Machinery Directive 2006/42/EC noise measurement and mitigation requirements is the responsibility of the manufacturer of the machinery into which this product is incorporated.



EXPLOSION HAZARD—Do not remove covers or connect/disconnect electrical connectors unless power has been switched off or the area is known to be non-hazardous.

Substitution of components may impair suitability for Zone 1, Zone 2, or Class 1 Division 2 applications.



RISQUE D'EXPLOSION— Ne pas enlever les couvercles, ni raccorder / débrancher les prises électriques, sans vous en assurez auparavant que le système a bien été mis hors tension; ou que vous situez bien dans une zone non explosive.

La substitution de composants peut rendre ce matériel inacceptable pour les emplacements de applications Zone 1, Zone 2, ou Classe 1 Division 2



Due to typical noise levels in turbine environments, hearing protection should be worn when working on or around the GS Series gas fuel skid.



The surface of this product can become hot or cold enough to be a hazard. Use protective gear for product handling in these circumstances. Temperature ratings are included in the specification section of this manual.



External fire protection is not provided in the scope of this product. It is the responsibility of the user to satisfy any applicable requirements for their system.

Control Specifications

Electrical Characteristics

GS Series Electrical Refer to GS Series manual 35136

Information:

Smart Pressure Transducer Refer to Smart Pressure Transducer manual 26080

Electrical Information:

GSOV25 HT Electrical Refer to GSOV25 HT manual 26190

Information:

Mechanical Characteristics

Weight:

Valve	Material	3-valve (lb)	3-valve (kg)
GS40	Aluminum	1095	497
	Stainless Steel	1215	551
GS50	Aluminum	1125	510
	Stainless Steel	1233	559

Valve	Material	5-valve (lb)	5-valve (kg)
GS40	Aluminum	1525	692
	Stainless Steel	1725	782
GS50	Aluminum	1575	714
	Stainless Steel	1755	796

Mounting: See installation drawings Fuel Connections: See installation drawings

Temperature

Ambient Operating (-20 to +80) °C / (-4 to +176) °F

Temperature:

Fuel Temperature: Aluminum: (-40 to +93) C / (-40 to +200) F

Stainless Steel: (-40 to +177) C / (-40 to +350) F

Pressure

Maximum Fuel Pressure: Aluminum: 51.7 bar(g) / 750 psig

Stainless Steel: 99.3 bar(g) / 1440 psig

Proof Pressure: Aluminum: 77.6 bar(g) / 1125 psig

Stainless Steel: 148.9 bar(g) / 2160 psig

Pipe Flange - Inlet

ASME Designation: 2 inch, Class 600, RFWN per ASME B16.5 (flanges internally

threaded)

Bolting: 8 x 0.625-11" UNC

Pipe Flanges - Discharge

GS40:

Aluminum body: 1.50 inch SAE Code 61, 3000 pound flat faced flanges Stainless steel body: 1.50 inch Class 600, RFWN per ASME B16.5

GS50:

Aluminum body: 2.00 inch SAE Code 61, 3000 pound flat faced flanges Stainless steel body: 2.00 inch Class 600, RFWN per ASME B16.5

Chapter 1. General Information

The Woodward GS Series gas fuel skid is an integrated valve, driver, and pressure- sensing assembly with the ability to meter gas fuel accurately for low-emissions turbines. To achieve accurate gas fuel metering, a digital position demand signal from the supervisory control must be used. The GS Series valve is capable of CANopen digital communications protocols. The GS Series valve flow characteristics are kept within the valve driver onboard the unit. The position demand from the supervisory control is generated by a calculation based on the pressures, temperature, and other properties of the gas fuel. The pressures are received from the Woodward Smart Pressure Transducer manifold affixed to the fuel skid. The pressure transmitter sends the pressure data digitally via a RS-422 protocol to the supervisory control.

Refer to manual 35136 for complete wiring, installation, operation, and maintenance instructions for the GS Series valve.

Refer to manual 26080 for complete wiring, installation, operation, and maintenance instructions for the Smart Pressure Transducer.

Refer to manual 26190 for complete wiring, installation, operation, and maintenance instructions for the GSOV25 HT valve.

Chapter 2. Installation

Introduction



The Woodward GS Series gas fuel skid weighs 559 kg / 1233 lb. for 3-valve configurations and 796 kg / 1755 lb. for 5-valve configurations. To prevent injury, use a lifting strap when handling the fuel skid. Do not lift or handle the unit by any conduit, cable, or tubing.



Due to typical noise levels in the turbine environments, hearing protection should be worn when working on or around the Woodward GS Series gas fuel skid.



The surface of this product can become hot or cold enough to be a hazard. Use protective gear for product handling in these circumstances. Temperature ratings are included in the specification section of this manual.



External fire protection is not provided in the scope of this product. It is the responsibility of the user to satisfy any applicable requirements for their system.



The engine, turbine, or other type of prime mover should be equipped with an overspeed, misfire, detonation detection shutdown device(s), that operate totally independently of the prime mover control device(s) to protect against runaway or damage to the engine, turbine, or other type of prime mover with possible personal injury or loss of life should the system fail.

Mechanical Installation

Take care when unpacking the gas fuel skid. Check the assembly for signs of damage, such as bent or dented covers, scratches, and loose or broken parts. Notify the shipper and Woodward if damage is found.

The Woodward GS Series gas fuel skid ships with covers on the inlet and discharge pipe flanges as well as the vent lines. The shipping covers ensure that debris is unable to enter the fuel skid before final assembly into the turbine baseplate. The shipping covers must be removed before installation into the piping system.

Vent Lines

The Woodward GS Series gas fuel skid contains customer connections for three vent lines. Each line must be connected by rigid steel piping to a fuel connection, purge, vent, or flare-off system so as not to be exposed to obstruction or physical damage. The GS Series overboard vent line must not be exposed

to back pressure in excess of 689 kPa / 100 psig. Vent line locations and descriptions are provided in Figures 2-2 and 2-3.

Skid Mounting

See Figures 2-2 and 2-3 for overall dimensions, mounting hole locations, lifting eyes, and any fitting or plumbing connections. The gas fuel skid is mounted to the turbine baseplate through the four mounting feet located at the bottom of the gas fuel skid. Mechanical devices such as hydraulic or mechanical jacks, pulleys, chain-falls, or similar should never be used to force the piping system to align with the valve flanges.


Pipe Installation



For 3-valve systems, two of the flow legs have blanking flanges that should not be removed. These flanges have been pressure tested with the fuel skid.

ANSI/ASME Flanges—Inlet Connection

Inlet connection fastener material must meet or exceed ASTM A193 Grade B7 per ASME B16.5. The use of thread anti-galling lubricant is required on all bolted connections. The use of helical split washers is recommended. Flange gasket materials should conform to ASME B16.20. Type CGI gaskets must be used on the inlet connection. The user should select a gasket material which will withstand the expected bolt loading without injurious crushing, and which is suitable for the service conditions. When installing the skid into the process piping, it is important to properly torque the studs/bolts in the appropriate sequence to keep the flanges of the mating hardware parallel to each other. A two-step torque method is recommended. Rated torque for the inlet connection is (108 to 122) N·m / (80 to 90) lb.-ft. Once the studs/bolts are hand-tightened, torque the fasteners in a crossing pattern illustrated in Figure 2-1, to half the required torque value. Once all studs/bolts have been torqued to half the appropriate value, repeat the pattern until the rated torque value is obtained.






Figure 2-1. Bolt Tightening Sequence

SAE Flanges—Discharge Connections

The gas fuel skid shall be mounted into the piping system using the 1.5 inch (38 mm) SAE flanges per J518 Code 61. Discharge connection fastener material shall be of SAE Grade 5 material or better as specified in SAE J429. The use of thread anti-galling lubricant is required on all bolted connections. The use of helical split washers is recommended. O-rings for the SAE flange connections are Viton, size 225 (Woodward part number 1355-423). Rated torque for the discharge connections is (28 to 33) N·m / (21 to 24) lb.-ft.



Leak check all gaseous fuel connections. Leaking gaseous fuel can cause explosion hazards, property damage, or loss of life.

Electrical Installation



EXPLOSION HAZARD—Do not remove covers or connect/disconnect electrical connectors unless power has been switched off or the area is known to be non-hazardous. Substitution of components may impair suitability for Class I, Division 2, Zone 2 or Zone 1 applications.



Take care not to damage the GS Series driver cover seal or flamepath surfaces while removing or replacing the cover on conduit versions. Damage to this joint may result in moisture ingress, fire, or explosion. Inspect the surfaces of the cover and housing to ensure they are not damaged or contaminated. Clean the surface with rubbing alcohol if necessary.



For Division 1/Zone 1 products: Proper torque is critical to ensure that the unit is sealed properly. When reinstalling the GS Series driver cover, torque all (14x) M8 fasteners to 18-22 lb.-ft (24.4-29.8 N·m).



Detailed specifications, requirements, and warnings are included in each component's respective manual.

Refer to manual 35136 for complete wiring, operation, installation, and maintenance instructions for the GS Series valve.

Refer to manual 26080 for complete wiring, operation, installation, and maintenance instructions for the Smart Pressure Transducer.

Refer to manual 26190 for complete wiring, installation, operation, and maintenance instructions for the GSOV25 HT valve.

GS Series Valve Setup/Configuration

Refer to manual 35136 for complete Service Tool setup instructions.

Water Ingress Protection

The following are considerations for protecting the Woodward GS Series gas fuel skid from water damage.

Turbine Water Wash Process: Some customers perform a water wash of the turbine compressor section, which can result in incidental water spray directed onto the gas fuel skid. The gas fuel skid should be properly protected from water spray.

Power Wash: The gas fuel skid should NOT be pressure/power washed. If there is other equipment in the vicinity that is being pressure washed, the gas fuel skid should be adequately protected from incidental water spray.




Figure 2-2a. Standard Woodward GS40 (Stainless Steel Body) Gas Fuel Skid Detailed View




Figure 2-2b. Standard Woodward GS40 (Stainless Steel Body) Gas Fuel Skid Isometric View




Figure 2-3a. Standard Woodward GS40 (Aluminum Body) Gas Fuel Skid Detailed View




Figure 2-3b. Standard Woodward GS40 (Aluminum Body) Gas Fuel Skid Isometric View




Figure 2-4a. Standard Woodward GS50 (Stainless Steel Body) Gas Fuel Skid Detailed View




Figure 2-4b. Standard Woodward GS50 (Stainless Steel Body) Gas Fuel Skid Isometric View

Chapter 3. Maintenance

Introduction

This product is designed for continuous operation in a typical industrial environment and does not include components that require periodic service. The following maintenance checks should be completed to ensure the correct operation of the gas fuel skid. Refer to the individual component manuals for detailed information and drawings of the individual fuel skid components.

To take advantage of related product software and hardware improvements, it is recommended that your product be sent back to Woodward or to a Woodward authorized service facility after every five to ten years of continuous service for inspection and component upgrades. Please refer to the service options chapter when returning products.



Substitution of components may impair suitability for Zone 1, Zone 2, or Class 1 Division 2 applications.

Refer to manual 35136 for complete troubleshooting and maintenance instructions for the GS Series valve.

Refer to manual 26080 for complete field servicing and maintenance instructions for the Smart Pressure Transducer.

Refer to manual 26190 for complete field servicing and maintenance instructions for the GSOV25 HT valve.

GS Series Maintenance

Maintenance is not required for the GS Series valve; however, periodic cleaning may be performed. A petrochemical solvent is recommended to clean the valve by washing and brushing. High-pressure power washing is not recommended. When cleaning the metering element and the inside of the valve body, do not use sharp objects that may scrape or dent the metering element, as this could degrade the accuracy of the valve.

When using solvent or water to clean the valve, be certain that all access points into the enclosure are closed or covered (electronics cover, conduit entry, OBVD port).



REMOVE INPUTS—To prevent possible serious personal injury, or damage to equipment, be sure that all electric power, hydraulic pressure, and gas pressure have been removed from the valve before beginning any maintenance or repairs.

LIFTING—The aluminum GS Series valves weigh approximately 54 kg / 120 lb. and stainless-steel GS Series valves weigh approximately 71 kg / 156 lb. To prevent injury, use a lifting strap when handling the GS Series valve. Do not lift or handle the valve by any conduit or cable.

NOISE—Due to typical noise levels in turbine environments, hearing protection should be worn when working on or around the GS Series valve.

BURN HAZARD—The surface of this product can become hot or cold enough to be a hazard. Use protective gear for product handling in these circumstances. Temperature ratings are included in the specification section of this manual.



Explosion Hazard—Do not remove covers or connect/disconnect electrical connectors unless power has been switched off or the area is known to be non-hazardous.

When re-installing the electrical enclosure cover, it should be tightened to 18-22 lb.-ft (24.4-29.8 N·m).



COVER—Take care not to damage the threads when removing or replacing the cover. Damage to these threads may result in moisture ingress, fire, or explosion. Clean the surface with rubbing alcohol if necessary. Inspect the threads to ensure they are not damaged or contaminated. Proper torque is critical to ensure the unit is sealed properly. When re-installing the electrical enclosure cover, it should be tightened to 18-22 lb.-ft (24.4-29.8 N·m). For conduit versions, refer to manual 35136 for complete cover removal and re-installation instructions.

WIRING—Due to the hazardous location listings associated with this product, proper wire type and wiring practices are critical to operation.

GSOV25 HT Maintenance



Prior to performing any maintenance on the GSOV25 HT, inlet and outlet gas pressure must be relieved. Failure to remove gas pressure from the inlet and discharge of the valve may result in equipment damage, personal injury, or death.



EXPLOSION HAZARD—Do not connect or disconnect while circuit is live unless area is known to be non-hazardous.

Electrical power must be removed from the GSOV25 HT whenever working on or near the solenoid or proximity switch.

Pilot Filter

To ensure optimum performance of the valve, remove and clean the pilot-section filter at least once per year, or more often if system contamination levels are higher than normal. Remove the pilot filter by turning counterclockwise on the 1.000 inch (25.40 mm) hex head nut. The filter may be cleaned ultrasonically or back-flushed with a light solvent. Inspect the O-ring seals and replace as necessary. The upper O-ring is Woodward part number 1355-169, and the lower O-ring is part number is 1355-111. Lightly lubricate the O-rings with petroleum jelly and torque pilot filter nut to 23 N·m / 200 lb.-in after reassembly.

Vent Leakage

Diligent monitoring of the vent connection leakage can provide early warning of seal degradation or internal contamination of the valve, which may result in unreliable valve operation.

If vent leakage exceeds 1000 cm³/min when the valve is closed, either the solenoid, the second stage ball seat, or the internal seals are leaking. If a spare solenoid is available, replace it to determine its effect on leakage. If replacing the solenoid does not correct the leakage problem, return the valve to Woodward for repair.

If vent leakage exceeds 1000 cm³/min when the valve is open, the most likely cause is a damaged second-stage face seal. Remove this face seal and invert 180 degrees to provide a new sealing surface. See the maintenance section on the second stage seal for this procedure. The solenoid is a possible secondary cause and can be replaced to determine its effect.

Solenoid Valve

Although there is no regular maintenance required on the solenoid valve, use the following information to troubleshoot problems related to the solenoid valve.



Currently there are two solenoid voltages available: 24 VDC and 125 VDC. Be sure to specify the correct part number for the top-level valve when ordering a replacement solenoid.

The typical dc resistance of the 24 VDC coil is 56 Ω and 1.5 k Ω for the 125 VDC version. Nominal current draw of the 24 VDC coil is 400 mA and 80 mA for the 125 VDC coil.

The solenoid valve can be replaced in the field if necessary. Remove the solenoid from the GSOV25 HT by unscrewing the two 0.250-28 Allen head screws that hold the solenoid to the valve housing. Replace the three O-ring seals if necessary (Woodward part number 1355-101). The poppet section of the

solenoid can be disassembled further and cleaned if necessary, but this action is beyond the scope of this manual. If further disassembly is undertaken, take extreme care to insure proper re-assembly. Lightly lubricate the O-rings with petroleum jelly and torque the solenoid mounting screws to 9.2 N·m / 81 lb.-in after re-assembly.

Routinely check the shutdown switches or relays to be sure that they are capable of terminating the electrical supply to the solenoid. Use the shutoff valve whenever possible to be sure it is operating satisfactorily.

Second Stage Face Seal

The second stage piston face seal is only actively sealing when the valve is in the open position. If excessive vent leakage is observed while the valve is open, the second stage face seal may be damaged. The face seal can be inverted inside its housing to allow a new sealing surface to be used.

- 1. Remove piping from the overboard vent connection.
- 2. Remove only two of the 0.250-28 screws from the overboard vent cap. With the help of another person, slowly unscrew the remaining two screws, which will unload the spring force beneath the cap. The other person should preload the cap and spring slightly to prevent the cap from popping off at the end of the screw's engagement with the housing.
- 3. Turn the vent cap over and remove the circular face seal retainer. Remove the face seal from its groove, invert it to expose the new sealing surface, and re-install it in the groove.
- 4. Re-install the face seal retainer in the body housing, not in the vent cap. The face seal retainer should sit firmly in a counter bore in the top of the body housing.
- 5. Re-install the vent cap onto the housing. With the help of another person, slightly compress the spring to allow initial screw engagement. It may be necessary to lightly lubricate the underside of the face seal to keep it secure in its groove during this step. Pay close attention while the vent cap is engaging the face seal retainer to assure proper fit. Torque the four screws in a cross pattern to 9.2 N·m / 81 lb.-in.
- 6. Re-install the vent piping connections.

Proximity Switch

There is no regular maintenance required on the proximity switch, but the following information can be used to troubleshoot problems related to the proximity switch.

The switch contains a Form C contact with four leads extending from the switch. Red is the normally closed contact, blue is the normally open contact, black is common, and green is the case ground.

When the valve is closed, the dc resistance across the contacts should read:

- Normally Closed (NC): open circuit
- Normally Open (NO): 0.1 to 1.0 Ω

When the valve is open, the dc resistance across the contacts should read:

- Normally Closed (NC): 0.1 to 1.0 Ω
- Normally Open (NO): open circuit

If an erroneous or intermittent switch indication is observed, check the continuity of each switch contact as described above. Lightly tap the proximity switch with a wrench or small hammer. The proximity switch should not be affected by these small mechanical disturbances. If the contacts change state with a light tap or do not read the correct dc resistance as given above, replace the switch.

Replace the proximity switch in the field if necessary. The valve must be in the closed position to replace and set the new switch position.

- 1. Disconnect any wiring or conduit attached to the proximity switch.
- 2. Use an adjustable wrench on the 1.000-inch (25.40 mm) hex of the proximity switch head and back the switch out of the body by turning counterclockwise.

- 3. Remove thread seal, washer, and jam nuts from the old switch and install them on the new switch. The Woodward part number for the thread seal is 1386-181.
- 4. Apply a small amount of Loctite 242 (removable) to the new switch threads and thread into the valve body until in bottoms out against main piston.
- 5. Mark the position of the switch relative to the body and then back the switch out 1/2 to 5/8 of a turn.
- 6. Torque the first jam nut to 20 N·m / 15 lb.-ft while holding the hex head on the end of the proximity switch. Apply Loctite 242 on the threads just after the first jam nut. Torque the second jam nut against the first to 20 N·m / 15 lb.-ft, again while holding the switch hex head.
- 7. Re-assemble the switch wiring and conduit connections.

Component Replacement

Woodward has prepared detailed guides and installation kits to ease the replacement of skid component hardware. Contact Woodward for gas fuel skid component replacement kits, including detailed instruction.

Chapter 4. Product Support and Service Options

Product Support Options

If you are experiencing problems with the installation, or unsatisfactory performance of a Woodward product, the following options are available:

- Consult the troubleshooting guide in the manual.
- Contact the manufacturer or packager of your system.
- Contact the Woodward Full Service Distributor serving your area.
- Contact Woodward technical assistance (see "How to Contact Woodward" later in this chapter)
 and discuss your problem. In many cases, your problem can be resolved over the phone. If not,
 you can select which course of action to pursue based on the available services listed in this
 chapter.

OEM or Packager Support: Many Woodward controls and control devices are installed into the equipment system and programmed by an Original Equipment Manufacturer (OEM) or Equipment Packager at their factory. In some cases, the programming is password-protected by the OEM or packager, and they are the best source for product service and support. Warranty service for Woodward products shipped with an equipment system should also be handled through the OEM or Packager. Please review your equipment system documentation for details.

Woodward Business Partner Support: Woodward works with and supports a global network of independent business partners whose mission is to serve the users of Woodward controls, as described here:

A **Full Service Distributor** has the primary responsibility for sales, service, system integration solutions, technical desk support, and aftermarket marketing of standard Woodward products within a specific geographic area and market segment.

An **Authorized Independent Service Facility (AISF)** provides authorized service that includes repairs, repair parts, and warranty service on Woodward's behalf. Service (not new unit sales) is an AISF's primary mission.

A **Recognized Turbine Retrofitter (RTR)** is an independent company that does both steam and gas turbine control retrofits and upgrades globally, and can provide the full line of Woodward systems and components for the retrofits and overhauls, long term service contracts, emergency repairs, etc.

A current list of Woodward Business Partners is available at www.woodward.com/directory.

Product Service Options

The following factory options for servicing Woodward products are available through your local Full-Service Distributor or the OEM or Packager of the equipment system, based on the standard Woodward Product and Service Warranty (5-01-1205) that is in effect at the time the product is originally shipped from Woodward, or a service is performed:

- Replacement/Exchange (24-hour service)
- Flat Rate Repair
- Flat Rate Remanufacture

Replacement/Exchange: Replacement/Exchange is a premium program designed for the user who is in need of immediate service. It allows you to request and receive a like-new replacement unit in minimum time (usually within 24 hours of the request), providing a suitable unit is available at the time of the request, thereby minimizing costly downtime. This is a flat-rate program and includes the full standard Woodward product warranty 5-01-1205 North American Terms and Conditions of Sale (Industrial Business Segment).

This option allows you to call your Full-Service Distributor in the event of an unexpected outage, or in advance of a scheduled outage, to request a replacement control unit. If the unit is available at the time of the call, it can usually be shipped out within 24 hours. You replace your field control unit with the like-new replacement and return the field unit to the Full-Service Distributor.

Charges for the Replacement/Exchange service are based on a flat rate plus shipping expenses. You are invoiced the flat rate replacement/exchange charge plus a core charge at the time the replacement unit is shipped. If the core (field unit) is returned within 60 days, a credit for the core charge will be issued.

Flat Rate Repair: Flat Rate Repair is available for the majority of standard products in the field. This program offers you repair service for your products with the advantage of knowing in advance what the cost will be. All repair work carries the standard Woodward service warranty 5-01-1205 North American Terms and Conditions of Sale (Industrial Business Segment) on replaced parts and labor.

Flat Rate Remanufacture: Flat Rate Remanufacture is very similar to the Flat Rate Repair option with the exception that the unit will be returned to you in "like-new" condition and carry with it the full standard Woodward product warranty 5-01-1205 North American Terms and Conditions of Sale (Industrial Business Segment). This option is applicable to mechanical products only.

Returning Equipment for Repair

If a control (or any part of an electronic control) is to be returned for repair, please contact your Full-Service Distributor in advance to obtain Return Authorization and shipping instructions.

When shipping the item(s), attach a tag with the following information:

- Return authorization number
- Name and location where the control is installed
- Name and phone number of contact person
- Complete Woodward part number(s) and serial number(s)
- Description of the problem
- Instructions describing the desired type of repair

Packing a Control

Use the following materials when returning a complete control:

- Protective caps on any connectors
- Antistatic protective bags on all electronic modules
- · Packing materials that will not damage the surface of the unit
- At least 100 mm (4 inches) of tightly packed, industry-approved packing material
- A packing carton with double walls
- A strong tape around the outside of the carton for increased strength



To prevent damage to electronic components caused by improper handling, read and observe the precautions in Woodward manual 82715, Guide for Handling and Protection of Electronic Controls, Printed Circuit Boards, and Modules.

Replacement Parts

When ordering replacement parts for controls, include the following information:

- The part number(s) (XXXX-XXXX) that is on the enclosure nameplate
- The unit serial number, which is also on the nameplate

Engineering Services

Woodward offers various Engineering Services for our products. For these services, you can contact us by telephone, by email, or through the Woodward website.

- Technical Support
- Product Training
- Field Service

Technical Support is available from your equipment system supplier, your local Full-Service Distributor, or from many of Woodward's worldwide locations, depending upon the product and application. This service can assist you with technical questions or problem solving during the normal business hours of the Woodward location you contact. Emergency assistance is also available during non-business hours by phoning Woodward and stating the urgency of your problem.

Product Training is available as standard classes at many of our worldwide locations. We also offer customized classes, which can be tailored to your needs and can be held at one of our locations or at your site. This training, conducted by experienced personnel, will assure that you will be able to maintain system reliability and availability.

Field Service engineering on-site support is available, depending on the product and location, from many of our worldwide locations or from one of our Full-Service Distributors. The field engineers are experienced both on Woodward products as well as on much of the non-Woodward equipment with which our products interface.

For information on these services, please contact one of the Full-Service Distributors listed at www.woodward.com/local-partner.

Contacting Woodward's Support Organization

For the name of your nearest Woodward Full-Service Distributor or service facility, please consult our worldwide directory at https://www.woodward.com/support, which also contains the most current product support and contact information.

You can also contact the Woodward Customer Service Department at one of the following Woodward facilities to obtain the address and phone number of the nearest facility at which you can obtain information and service.

Products Used in Electrical Power Systems Product Engine Engine

Engine Systems		
FacilityPhone Number		
Brazil+55 (19) 3708 4800		
China+86 (512) 8818 5515		
Germany +49 (711) 78954-510		
India+91 (124) 4399500		
Japan+81 (43) 213-2191		
Korea+ 82 (32) 422-5551		
The Netherlands+31 (23) 5661111		
United States+1 (970) 482-5811		

Products Used in

r roudcis Osea ili ilidustriai
Turbomachinery Systems
FacilityPhone Number
Brazil+55 (19) 3708 4800
China+86 (512) 8818 5515
India+91 (124) 4399500
Japan+81 (43) 213-2191
Korea+ 82 (32) 422-5551
The Netherlands+31 (23) 5661111
Poland+48 (12) 295 13 00
United States+1 (970) 482-5811

Products Used in Industrial

Technical Assistance

If you need to contact technical assistance, you will need to provide the following information. Please write it down here before contacting the Engine OEM, the Packager, a Woodward Business Partner, or the Woodward factory:

General	
Your Name	
Site Location	
Phone Number	
Fax Number	
Prime Mover Information	
Manufacturer	
Turbine Model Number	
Type of Fuel (gas, steam, etc.)	
Power Output Rating	
Application (power generation, marine, etc.)	
Control/Governor Information	
Control/Governor #1	
Woodward Part Number & Rev. Letter	
Control Description or Governor Type	
Serial Number	
Control/Governor #2	
Woodward Part Number & Rev. Letter	
Control Description or Governor Type	
Serial Number	
Control/Governor #3	
Woodward Part Number & Rev. Letter	
Control Description or Governor Type	
Serial Number	
Symptoms	
Description	

If you have an electronic or programmable control, please have the adjustment setting positions or the menu settings written down and with you at the time of the call.

Revision History

This Page Left Intentionally Blank

We appreciate your comments about the content of our publications.

Send comments to: industrial.support@woodward.com

Please reference publication 35210.





PO Box 1519, Fort Collins CO 80522-1519, USA 1041 Woodward Way, Fort Collins CO 80524, USA Phone +1 (970) 482-5811

Email and Website—www.woodward.com

Woodward has company-owned plants, subsidiaries, and branches, as well as authorized distributors and other authorized service and sales facilities throughout the world.

Complete address / phone / fax / email information for all locations is available on our website.