

Product Manual 36631 (Revision B) Original Instructions

Two-slope Manifold Pressure Bias Load Control & Fuel Limiter for PG Governor with Torque Advance at Idle Speed

Operation Manual



Read this entire manual and all other publications pertaining to the work to be performed before installing, operating, or servicing this equipment.

Practice all plant and safety instructions and precautions.

Failure to follow instructions can cause personal injury and/or property damage.



Revisions

This publication may have been revised or updated since this copy was produced. To verify that you have the latest revision, check manual 26311, *Revision Status & Distribution Restrictions of Woodward Technical Publications*, on the *publications page* of the Woodward website:

www.woodward.com/publications

The latest version of most publications is available on the *publications page*. If your publication is not there, please contact your customer service representative to get the latest copy.



Any unauthorized modifications to or use of this equipment outside its specified mechanical, electrical, or other operating limits may cause personal injury and/or property damage, including damage to the equipment. Any such unauthorized modifications: (i) constitute "misuse" and/or "negligence" within the meaning of the product warranty thereby excluding warranty coverage for any resulting damage, and (ii) invalidate product certifications or listings.



Woodward reserves the right to update any portion of this publication at any time. Information provided by Woodward is believed to be correct and reliable. However, no responsibility is assumed by Woodward unless otherwise expressly undertaken.

Warnings and Notices

Important Definitions



This is the safety alert symbol. It is used to alert you to potential personal injury hazards. Obey all safety messages that follow this symbol to avoid possible injury or death.

- **DANGER**—Indicates a hazardous situation which, if not avoided, will result in death or serious injury.
- **WARNING**—Indicates a hazardous situation which, if not avoided, could result in death or serious injury.
- **CAUTION**—Indicates a hazardous situation which, if not avoided, could result in minor or moderate injury.
- **NOTICE**—Indicates a hazard that could result in property damage only (including damage to the control).
- **IMPORTANT**—Designates an operating tip or maintenance suggestion.

WARNINGOverspeed /
Overtemperature /
OverpressureOverspeed /
overspeed /
overspeed shutdown device must be totally independent of the
prime mover control system. An overtemperature or overpressure
overpressure
overspeed for safety, as appropriate.

| WARNING Personal Protective Equipment | The products described in this publication may present risks that could lead to personal injury, loss of life, or property damage. Always wear the appropriate personal protective equipment (PPE) for the job at hand. Equipment that should be considered includes but is not limited to: • Eye Protection • Hearing Protection • Hard Hat • Gloves • Safety Boots |
|--|---|
| | Respirator |
| | Always read the proper Material Safety Data Sheet (MSDS) for any working fluid(s) and comply with recommended safety equipment. |



WARNING Automotive Applications On- and off-highway Mobile Applications: Unless Woodward's control functions as the supervisory control, customer should install a system totally independent of the prime mover control system that monitors for supervisory control of engine (and takes appropriate action if supervisory control is lost) to protect against loss of engine control with possible personal injury, loss of life, or property damage.

NOTICE

To prevent damage to a control system that uses an alternator or battery-charging device, make sure the charging device is turned off before disconnecting the battery from the system.

Battery Charging Device

Electrostatic Discharge Awareness

| NOTICE | Electronic controls contain static-sensitive parts. Observe the following precautions to prevent damage to these parts: | |
|------------------------------|---|--|
| Electrostatic Precautions | Discharge body static before handling the control (with power to the control turned off, contact a grounded surface and maintain contact while handling the control). Avoid all plastic, vinyl, and Styrofoam (except antistatic versions) around printed circuit boards. Do not touch the components or conductors on a printed circuit board with your hands or with conductive devices. To prevent damage to electronic components caused by improper handling, read and observe the precautions in Woodward manual 82715, Guide for Handling and Protection of Electronic Controls, Printed Circuit Boards, and Modules. | |

Follow these precautions when working with or near the control.

- 1. Avoid the build-up of static electricity on your body by not wearing clothing made of synthetic materials. Wear cotton or cotton-blend materials as much as possible because these do not store static electric charges as much as synthetics.
- 2. Do not remove the printed circuit board (PCB) from the control cabinet unless absolutely necessary. If you must remove the PCB from the control cabinet, follow these precautions:
 - Do not touch any part of the PCB except the edges.
 - Do not touch the electrical conductors, the connectors, or the components with conductive devices or with your hands.
 - When replacing a PCB, keep the new PCB in the plastic antistatic protective bag it comes in until you are ready to install it. Immediately after removing the old PCB from the control cabinet, place it in the antistatic protective bag.

Two-slope Manifold Pressure Bias Load Control

Description

The basic load control system adjusts the load on an engine as a function of governor speed setting and fuel. Governors used on turbocharged engines are often equipped with more intricate load control systems. One such system, employed in a governor with pneumatically controlled speed setting, schedules load as a function of speed setting control air pressure, fuel, and the absolute pressure* of the manifold charging air.

*—"Absolute pressure" is the sum of the pressure indicated in an ordinary pressure gauge plus the atmospheric pressure outside of the gauge.

The schematic arrangement of this type of load control system is shown in Figure 1.

Manifold charging air pressure is brought into the upper bellows and tends to push the output case end down. The lower bellows is of the same size and has been evacuated. The force at the output case end is thus unaffected by atmospheric pressure changes and is, therefore, proportional to the absolute manifold charging air pressure.

The force produced by the absolute manifold charging air pressure is transmitted, through the output case end and bellows-to-valve lever, to the cone valve. This force is opposed at the cone valve by the force of the spring between the cone valve and the sensor piston.

The unrestricted flow of pressure oil applies constant pressure to the upper-side of the sensor piston. A series of orifices restricts the flow of pressure oil to the underside of the piston. Except while changes are occurring in the manifold charging air pressure, the bellows force tending to push the cone valve up is balanced or equaled by the spring force from the opposite direction. Thus, the cone valve normally "floats" just off its seat and continually bypasses to sump the oil admitted through the orifice stack to the underside of the piston. (This accounts for the continuous "bubbling" of oil from the top of the sensor when it is operating.)

If the bellows force is greater than the opposing spring force, the cone valve is forced upward, and oil flows out from under the piston at an increased rate. The pressure oil above the piston forces it down, compressing the spring until the spring force again equals the bellows force. If the absolute manifold charging air pressure is decreased, the bellows output force is reduced, and the spring pushes the cone valve onto its seat. The oil pressure under the piston will move the piston up and reduce the spring load on the cone valve until the opposing forces are again equal.

The load control pilot valve plunger is suspended from the floating lever. When the pilot valve plunger is "centered" (with its control lands exactly covering the control ports in the plunger bushing), no oil flows to or from the load regulator. If the pilot valve plunger is lifted above its centered position, pressure oil is directed to the load regulator to decrease engine load. If the pilot valve plunger is lowered below its centered position, pressure oil is directed to the load regulator to increase engine load.





One end of the floating lever is connected to the power piston tailrod; the other end is attached to linkage from the governor speed-setting mechanism. The floating lever and pilot valve plunger are nominally positioned as functions of speed setting and fuel. However, attached to the floating lever at a point between the pilot valve plunger and the connection to the speed setting linkage is a slotted pick-up link which takes a position proportional to the sensor piston position. The pick-up link can, after the free movement in the slot is taken up, raise the left end of the floating lever by moving the pivot link up away from the pivot link cup assembly. At the same time, the load control pilot valve plunger is also raised. Thus, the pressure sensor decreases engine load and fuel as charging pressure decreases.

The slot in the pick-up link will allow a loss in the absolute value of the charging air pressure particularly at low speed and load settings without any resulting derating. This feature is useful for applications for which the engine and turbocharger combination have been rated for altitude operation.

The ratio or proportion of pick-up link movement for a given sensor piston movement depends on which of the two pivot screws on the top end of the pick-up link is in contact with the pick-up arm.

The two pivot screws, each of which is adjustable, permit establishment of a twoslope derating curve which enables close matching of the system with the normal blower characteristics while still derating sufficiently, in the extreme case of complete loss of turbocharger, to allow continued running of the engine without exceeding exhaust temperature limitations.

The closing of the extensible pivot link cup assembly determines the point beyond which an increase in absolute manifold charging air pressure no longer affects the load control system. This assists good acceleration, while allowing for some scatter in manifold pressures between engines.

A typical two-slope derating curve, plotting fuel versus absolute manifold charging air pressure at constant engine speed, is shown in Figure 2. The "flat" at the top of the curve is reached when the pivot link cup assembly closes or, in some cases, when the adjustable stop screw in the pick-up arm touches ground.



ABS. MAN. CHARGING AIR PRESSURE

Figure 2. Typical Two-slope Derating Curve

The curve shows graphically the effect of the alternate pivot points on the pick-up link. Such a system acts to prevent excessive exhaust temperatures by reducing the rack setting of the engine at load balance during periods of low turbocharger discharge.

A typical load control curve (with the turbine blowers operating normally) resulting from the absolute manifold pressure is shown in Figure 3. The vertical rise at the start of the curve shows the effect of changing the control air signal below the pressure required to advance speed above the minimum speed level (i.e., the period of torque advance at idle speed).



Figure 3. Typical Load Control Curve

Thus, a combination of three signals determines the engine load: (1) the control air pressure, (2) the governor fuel setting, and (3) the absolute pressure of the manifold charging air.

If is of interest to note that, though the speed setting servo piston shown in Figure 1 takes a position proportional to control air pressure, the governor speed setting is unaffected by control air pressure changes below a certain level. The upper spring seat can move up (decreasing governor speed) as the servo piston moves up (due to lower control air pressure signals) only until the large diameter shoulder of the spring seat hits its stop. This will be equivalent to idle speed. Above the control air pressure corresponding to idle speed, the upper spring seat moves down to increase the governor speed setting as the servo piston moves down.

Figure 4 shows a typical load control curve (plotting fuel versus control air pressure) which might be obtained in a governor with a yield linkage assembly attached to the floating lever.



CONTROL AIR PRESSURE



Absolute Manifold Pressure Fuel Limiter

The normal lag of the turbo-supercharger speed to the engine speed during periods of acceleration makes it possible to supply, on large increases in load, more fuel to the engine than can be burned with the air available from the supercharger. The resulting unbalance of fuel and air leads to poor combustion and excessive smoke, and often retards the ability of the engine to return to normal speed after a load change. Restricting the governor power piston in the opening direction—and hence, limiting engine fuel—as a function of absolute manifold charging air pressure ensures that sufficient air is available for proper combustion of fuel.

The fuel limiter consists essentially of a pressure sensor, a cam, and a connecting beam. If the fuel limiter is incorporated in a governor which also has a form of pressure bias load control, a single pressure sensor can serve to fill the needs of each system. Such an arrangement is shown in Figure 1.

One end of the connecting beam is attached to the tailrod of the governor power piston; the other end is positioned as a function of the cam position. The beam passes under the shutdown block so that if the beam is raised sufficiently far, it will raise the shutdown block and with it the shutdown rod. The shutdown rod is an extension of the governor pilot valve plunger. Thus, lifting the shutdown rod lifts the pilot valve plunger and causes the power piston to move down and thereby decrease fuel to the engine.

Fuel may be increased until the upward movement of the power piston causes the connecting beam to lift the shutdown block. The cam position establishes the height to which the power piston may rise before the connecting beam lifts the shutdown block. Thus, the cam position determines the maximum fuel allowed the engine at any instant.

As shown in Figure 1, the cam is attached to the hydraulically operated piston in the pressure sensor. As explained above, the piston takes a position which is proportional to the absolute charging air pressure. The fuel limit at any instant is, therefore, a function of the absolute charging air pressure.

It should be noted that, though using common signals (sensor piston position and power piston position), the fuel limiter and pressure bias load control scheme are separate and independent systems.

Information and Parts Replacement

When requesting additional information concerning governor operation or when ordering parts, the following information must accompany the request:

- Governor serial number (shown on nameplate). The serial number is needed since the reference numbers shown in this manual do not identity the exact part number required for any one governor
- Manual number (this is manual 36631)
- Part reference number, name of part, or description of part

Parts List for Figures 5, 6, 7

| Ref. No. | Part Name | Ref. No. | Part Name |
|----------|--------------------------------|-----------|-------------------------------------|
| 36631-1 | Washer | 36631-61 | Power Piston Tailrod |
| 36631-2 | Power Piston Lever | 36631-62 | Pilot Valve Link |
| 36631-3 | Stop Nut | 36631-63 | Hex. Hd. Bolt |
| 36631-4 | Floating Lever Link | 36631-64 | Socket Hd. Cap Screw |
| 36631-5 | Adjustable Fulcrum Pin | 36631-65 | Eccentric Assv. |
| 36631-6 | Link Adjusting Spring | 36631-66 | Eccentric |
| 36631-7 | Washer | 36631-67 | Pilot Valve Nut |
| 36631-8 | Straight Pin | 36631-68 | Spring Retainer |
| 36631-9 | Speeder Spring Power Cylinder | 36631-69 | Snan Ring |
| 36631-10 | Connector Clamp Plate | 36631-70 | Load Control Valve Spring |
| 36631-11 | Gasket | 36631-71 | Spring Collar |
| 36631-12 | Control Lever Slide | 36631-72 | Overriding Piston |
| 36631-13 | Dianhragm Link Assembly | 36631-73 | Load Control Spacer |
| 36631-14 | Diaphragm Spring | 36631-74 | Oil Seal Gasket |
| 36631-15 | Floating Lever Link Assy | 36631-75 | L C Pilot Valve Bushing Spring |
| 36631-16 | Speeder Spring Servo Spring | 36631-75 | Load Control Pilot Valve Plunger |
| 36631-17 | Spring Seat | 36631-77 | Load Control Pilot Valve Bushing |
| 36631-18 | Diaphragm Spring | 36631-78 | Retaining Ring |
| 26621 10 | Diaphragm Washer | 26621 70 | |
| 26624 20 | Keyed Weeher | 26621-79 | Divet Link Din |
| 30031-20 | Neyeu washer Dianbroam Nut | 30031-00 | PIVOL LINK PIN |
| 30031-21 | | 30031-81 | Spacer |
| 36631-22 | Cotter Pin | 36631-82 | PISTON |
| 36631-23 | | 36631-83 | wasner |
| 36631-24 | Floating Lever Assembly | 36631-84 | Washer |
| 36631-25 | Washer | 36631-85 | Pivot Pin |
| 36631-26 | Thrust Bearing | 36631-86 | Set Screw |
| 36631-27 | Pin | 36631-87 | Speed Control Bracket Cap |
| 36631-28 | Regulating Bushing | 36631-88 | Nut |
| 36631-29 | Floating Lever Link Spring | 36631-89 | Needle Bearing |
| 36631-30 | Pilot Bushing | 36631-90 | Speed Control Lever |
| 36631-31 | Pilot Bushing Spring | 36631-91 | Hex Jam Nut |
| 36631-32 | Spring | 36631-92 | Idle Speed Setting Screw |
| 36631-33 | Speeder Spring Stop Clamp Ring | 36631-93 | Washer |
| 36631-34 | Speeder Spring Stop Sleeve | 36631-94 | Screw |
| 36631-35 | Bushing Spacer | 36631-95 | Nut (#10-32) |
| 36631-36 | Soc. Hd. Screw | 36631-96 | Adjustable Fulcrum Pin |
| 36631-37 | Screw | 36631-97 | Headed Pin |
| 36631-38 | Washer | 36631-98 | Speed Setting Stud |
| 36631-39 | Shutdown Rod | 36631-99 | Set Screw |
| 36631-40 | Speeder Spring Seat | 36631-100 | Power Piston Fulcrum Assy. |
| 36631-41 | Power Piston | 36631-101 | Speeder Spring Power Cylinder Assy. |
| 36631-42 | Power Piston Stop Screw | 36631-102 | Load Control Scale |
| 36631-43 | Power Piston Fulcrum Assy. | 36631-103 | Washer |
| 36631-44 | Pivot Link Cap Assembly | 36631-104 | Screw |
| 36631-45 | Pin | 36631-105 | Washer |
| 36631-46 | Latch Spring | 36631-106 | Headed Pin |
| 36631-47 | Nut | 36631-107 | Washer |
| 36631-48 | Adjusting Screw | 36631-108 | Pickup Lever |
| 36631-49 | Shutdown Block Assembly | 36631-109 | Pin |
| 36631-50 | Power Piston Lever | 36631-110 | Pickup Lever Adjusting Screw |
| 36631-51 | Pin | 36631-111 | Screw |
| 36631-52 | Pivot Pin Link | 36631-112 | Pickup Link Assy |
| 36631-53 | Adjusting Screw Pin | 36631-113 | Cotter Pin |
| 36631-54 | Adjusting Screw Knob | 36631-114 | Hosting Lever Assy |
| 36631-55 | Link Adjusting Spring | 36631-115 | Male Connector |
| 36631-56 | Adjusting Screw Pin | 36631-116 | Screw |
| 36631-57 | Movable Fulcrum Pin | 36631-117 | Lockwasher |
| 36631-58 | Adjusting Screw | 36631-118 | Bracket Assy |
| 36631-50 | Lower Fulcrum Pin | 36631-110 | Washer |
| 36631-59 | | 36631-119 | Cotter Pin |
| 00001-00 | | 30031-120 | |

| Ref. No. | Part Name |
|-----------|--------------------------|
| 36631-121 | Tailrod Pin |
| 36631-122 | Connecting Beam |
| 36631-123 | Cam Guide Bracket |
| 36631-124 | Fuel Limit Body |
| 36631-125 | Shim |
| 36631-126 | Bearing |
| 36631-127 | Headed Pin |
| 36631-128 | Spring Anchor Screw |
| 36631-129 | Fulcrum Pin |
| 36631-130 | Spring |
| 36631-131 | Bellows Locknut |
| 36631-132 | Banjo Pitting Body |
| 36631-133 | Banjo Fitting Screw |
| 36631-134 | Banjo Seal |
| 36631-135 | Nut |
| 36631-136 | Sleeve |
| 36631-137 | O-ring |
| 36631-138 | Bellows Assembly |
| 36631-139 | Lockwasher |
| 36631-140 | Nylok Screw |
| 36631-141 | Lever Support Lock Block |
| 36631-142 | Socket Hd. Screw |
| 36631-143 | Retaining Ring |
| 36631-144 | Lever Support And Plug |
| 36631-145 | Hex. Hd. Cap Screw |
| 36631-146 | Washer |
| 36631-147 | Lockwasher |
| 36631-148 | Pin |
| 36631-149 | Pipe Plug |

| Ref. No. | Part Name |
|-----------|-------------------------------|
| 36631-150 | Rocker Arm Assembly |
| 36631-151 | Valve Seat |
| 36631-152 | Valve Plunger |
| 36631-153 | Piston Spring |
| 36631-154 | Spring Seat |
| 36631-155 | Piston Sleeve |
| 36631-156 | Retaining Ring |
| 36631-157 | Spacer |
| 36631-158 | Cylinder Head |
| 36631-159 | Screw |
| 36631-160 | Washer |
| 36631-161 | Pointer Spring |
| 36631-162 | Load Control Scale |
| 36631-163 | Pointer Pivot |
| 36631-164 | Load Control Pointer |
| 36631-165 | Load Control Indicator Washer |
| 36631-166 | Washer Type Spring |
| 36631-167 | Orifice Case |
| 36631-168 | Washer |
| 36631-169 | Snap Ring |
| 36631-170 | Check Valve Assy. |
| 36631-171 | O-ring |
| 36631-172 | Snap Ring |
| 36631-173 | Plug and Screen Assy. |
| 36631-174 | Spring |
| 36631-175 | Washer |
| 36631-176 | Orifice Plate |
| 36631-177 | Gasket |



Figure 5. Parts Identification



Figure 6. Parts Identification



SECTION D-D



Figure 7. Parts Identification

We appreciate your comments about the content of our publications.

Send comments to: icinfo@woodward.com

Please reference publication 36631B.



PO Box 1519, Fort Collins CO 80522-1519, USA 1000 East Drake Road, Fort Collins CO 80525, USA Phone +1 (970) 482-5811 • Fax +1 (970) 498-3058

Email and Website—www.woodward.com

Woodward has company-owned plants, subsidiaries, and branches, as well as authorized distributors and other authorized service and sales facilities throughout the world.

Complete address / phone / fax / email information for all locations is available on our website.