




easYgen-1000 Genset Control



Configuration

Software Version 2.0xxx



**WARNING**

Read this entire manual and all other publications pertaining to the work to be performed before installing, operating, or servicing this equipment. Practice all plant and safety instructions and precautions. Failure to follow instructions can cause personal injury and/or property damage.

The engine, turbine, or other type of prime mover should be equipped with an overspeed (overtemperature, or overpressure, where applicable) shutdown device(s), that operates totally independently of the prime mover control device(s) to protect against runaway or damage to the engine, turbine, or other type of prime mover with possible personal injury or loss of life should the mechanical-hydraulic governor(s) or electric control(s), the actuator(s), fuel control(s), the driving mechanism(s), the linkage(s), or the controlled device(s) fail.

Any unauthorized modifications to or use of this equipment outside its specified mechanical, electrical, or other operating limits may cause personal injury and/or property damage, including damage to the equipment. Any such unauthorized modifications: (i) constitute "misuse" and/or "negligence" within the meaning of the product warranty thereby excluding warranty coverage for any resulting damage, and (ii) invalidate product certifications or listings.

**CAUTION**

To prevent damage to a control system that uses an alternator or battery-charging device, make sure the charging device is turned off before disconnecting the battery from the system.

Electronic controls contain static-sensitive parts. Observe the following precautions to prevent damage to these parts.

- Discharge body static before handling the control (with power to the control turned off, contact a grounded surface and maintain contact while handling the control).
- Avoid all plastic, vinyl, and Styrofoam (except antistatic versions) around printed circuit boards.
- Do not touch the components or conductors on a printed circuit board with your hands or with conductive devices.

**OUT-OF-DATE PUBLICATION**

This publication may have been revised or updated since this copy was produced. To verify that you have the latest revision, be sure to check the Woodward website:

<http://www.woodward.com/pubs/current.pdf>

The revision level is shown at the bottom of the front cover after the publication number. The latest version of most publications is available at:

<http://www.woodward.com/publications>

If your publication is not there, please contact your customer service representative to get the latest copy.

Important definitions**WARNING**

Indicates a potentially hazardous situation that, if not avoided, could result in death or serious injury.

**CAUTION**

Indicates a potentially hazardous situation that, if not avoided, could result in damage to equipment.

**NOTE**

Provides other helpful information that does not fall under the warning or caution categories.

Woodward reserves the right to update any portion of this publication at any time. Information provided by Woodward is believed to be correct and reliable. However, Woodward assumes no responsibility unless otherwise expressly undertaken.

© Woodward
All Rights Reserved.

Revision History

Rev.	Date	Editor	Changes
NEW	05-04-29	TP	Release based on manual 37204
A	05-07-06	TP	Language revision, minor corrections, Technical Data added, ground fault protection revision

Content

CHAPTER 1. GENERAL INFORMATION.....	8
CHAPTER 2. CONFIGURATION.....	9
Configuration Via The Front Panel.....	9
Configuration Using The PC	10
Function Of The Inputs And Outputs	11
CHAPTER 3. PARAMETERS	14
Password	15
Event History	16
Measuring	17
Measuring: Rated Values	17
Measuring: Transformers.....	20
Application.....	22
Application: Application Mode.....	22
Application: Start In AUTOMATIC Operating Mode (LogicsManager)	23
Application: Stop In AUTOMATIC Operating Mode (LogicsManager)	23
Application: Operating Mode	23
Application: Liquid Crystal Display (LC Display)	24
Application: Critical Mode (Sprinkler Operation, LogicsManager).....	25
Engine	27
Engine: Start /Stop Sequence	27
Engine: Diesel Engine	27
Engine: Gas Engine.....	30
Engine: Pickup.....	32
Engine: Start/Stop Automatic.....	33
Engine: Firing Speed And Engine Delayed Monitoring	34
Breaker.....	37
Breaker: Operation Of The Circuit Breakers	37
Breaker: GCB Settings	39
Breaker: MCB Settings {2oc}.....	41
Breaker: GCB/MCB Settings {2oc}.....	41
Emergency Power (AMF).....	42
Protection	44
Protection: Alarm Acknowledgement.....	44
Protection: Generator Protection	44
Protection: Generator, Overfrequency (Limits 1 & 2) ANSI# 81O	45
Protection: Generator, Underfrequency (Limits 1 & 2) ANSI# 81U	47
Protection: Generator, Overvoltage (Limits 1 & 2) ANSI# 59.....	49
Protection: Generator, Undervoltage (Limits 1 & 2) ANSI# 27	51
Protection: Generator, Time-Overcurrent Monit. (Limits 1, 2 & 3) ANSI# 50/51	53
Protection: Generator, Reverse/Reduced Power (Limits 1 & 2) ANSI# 32R/F	55
Protection: Engine/Generator, Overload (Limits 1 & 2) ANSI# 32	58
Protection: Generator, Unbalanced Load (Limits 1 & 2) ANSI# 46.....	60
Protection: Generator, Voltage Asymmetry	63

Protection: Generator, Ground Fault (Limits 1 & 2)	65
Protection: Generator, Voltage Phase Rotation	67
Protection: Generator, Inverse Time-Overcurrent Monitoring ANSI# IEC 255	70
Protection: Mains Protection {2oc}	73
Protection: Mains, Voltage Phase Rotation - {2oc}	74
Protection: Mains, Mains Failure Detection {2oc}	75
Protection: Breaker, Circuit Breaker Monitoring	77
Protection: Engine, Overspeed (Limits 1 & 2) ANSI# 12	80
Protection: Engine, Underspeed (Limits 1 & 2)	82
Protection: Engine/Generator, Speed/Frequency Mismatch (Speed Detection)	84
Protection: Engine, Start Failure	86
Protection: Engine, Shutdown Malfunction	87
Protection: Engine, Unintended Stop	87
Protection: Engine, Dead Bus Operation	88
Protection: Battery, Overvoltage (Limits 1 & 2)	89
Protection: Battery, Undervoltage (Limits 1 & 2)	91
Protection: CAN Open Interface, Monitoring	93
Protection: J1939 Interface, Monitoring	94
Protection: J1939 Interface, Amber Warning Lamp DM1	95
Protection: J1939 Interface, Red Stop Lamp DM1	96
Discrete Inputs	97
Discrete Outputs (<i>LogicsManager</i>)	100
Analog Inputs (<i>FlexIn</i>)	101
Analog Inputs: Display	102
Analog Inputs: Type	102
Analog Inputs: Monitoring Limits	106
Analog Inputs: Wire Break Monitoring	107
Analog Inputs: Characteristics "Linear" (2 Point Scaling)	108
Analog Inputs: Configure Flexible Thresholds	109
Analog Inputs: Characteristics "Table A" And "Table B" (9 Point Scaling)	111
Counters	112
Counters: Maintenance Call	112
Counters: Running Hours, kWh And kvarh	113
Counters: Start Counter	113
<i>LogicsManager</i>	114
<i>LogicsManager</i> : Limit Switch (Load)	114
<i>LogicsManager</i> : Internal Flags	115
<i>LogicsManager</i> : Timer	116
Interfaces	118
Interfaces: CAN Bus (<i>FlexCAN</i>)	118
Interfaces: J1939	118
Interfaces: Serial Interface	120
System	121
System: Password System	121
System: Factory Settings	122
System: Real-Time Clock	123
System: Versions	124
APPENDIX A. COMMON	125
Alarm Classes	125
Conversion Factors	126
Temperature	126
Pressure	126

<u>APPENDIX B. LOGICSMANAGER</u>	<u>127</u>
Logical Symbols	129
Logical Outputs	130
Logical Outputs: Internal Flags	130
Logical Outputs: Internal functions	130
Logical Outputs: Relay Outputs	131
Logical Command Variables	132
Logical Command Variables: [00.00] - Internal Flags	132
Logical Command Variables: [01.00] - Alarm Classes	133
Logical Command Variables: [02.00] - System Status	134
Logical Command Variables: [03.00] - Engine Control	135
Logical Command Variables: [04.00] - Operating Status	136
Logical Command Variables: [05.00] - Alarms Of The Engine	137
Logical Command Variables: [06.00] - Alarms Of The Generator	138
Logical Command Variables: [07.00] - Alarms Of The Mains	139
Logical Command Variables: [08.00] - Alarms Of The System	140
Logical Command Variables: [09.00] - Discrete Inputs	140
Logical Command Variables: [10.00] - Analog Inputs	141
Logical Command Variables: [11.00] - Time Functions	141
Logical Command Variables: [12.00] - External Discrete Inputs (Expansion Board)	142
Logical Command Variables: [13.00] - Status Of The Internal Relay Outputs	142
Logical Command Variables: [14.00] - Status Of The External Relay Outputs	143
Factory Setting	144
Factory Setting: Functions	144
Factory Setting: Relay Outputs	148
Factory Setting: Internal Flags	151
Discrete Inputs	154
<u>APPENDIX C. CHARACTERISTICS OF THE VDO INPUTS</u>	<u>155</u>
VDO Input "Pressure" (0 to 5 bar / 0 to 72 psi) - Index "III"	155
VDO Input "Pressure" (0 to 10 bar / 0 to 145 psi) - Index "IV"	156
VDO Input "Temperature" (40 to 120 °C / 104 to 248 °F) - Index "92-027-004"	157
VDO Input "Temperature" (50 to 150 °C / 122 to 302 °F) - Index "92-027-006"	158
<u>APPENDIX D. LIST OF PARAMETERS</u>	<u>159</u>
<u>APPENDIX E. TECHNICAL DATA</u>	<u>178</u>
<u>APPENDIX F. ENVIRONMENTAL DATA</u>	<u>181</u>
<u>APPENDIX G. SERVICE OPTIONS</u>	<u>182</u>
Product Service Options	182
Returning Equipment For Repair	182
Packing A Control	183
Return Authorization Number RAN	183
Replacement Parts	183
How To Contact Woodward	184
Engineering Services	185
Technical Assistance	186

Illustrations And Tables

Illustrations

Figure 3-1: Event history- display	16
Figure 3-3: Start /stop sequence - diesel engine.....	28
Figure 3-4: Start /stop sequence - gas engine.....	31
Figure 3-5: Engine - firing speed and engine delayed monitoring.....	34
Figure 3-6: Operating / closed circuit current.....	39
Figure 3-8: Monitoring - generator overfrequency	45
Figure 3-10: Monitoring - generator underfrequency	47
Figure 3-12: Monitoring - generator overvoltage	49
Figure 3-14: Monitoring - generator undervoltage	51
Figure 3-16: Monitoring - generator time-overcurrent.....	53
Figure 3-18: Monitoring - generator reverse / reduced power	56
Figure 3-20: Monitoring - generator overload	58
Figure 3-22: Monitoring - generator unbalanced load	60
Figure 3-24: Monitoring - generator voltage asymmetry	63
Figure 3-26: Monitoring - calculated generator ground fault.....	65
Figure 3-27: Monitoring - calculated generator ground current - vector diagram	66
Figure 3-30: Monitoring - generator inverse time-overcurrent - characteristic "Normal"	70
Figure 3-31: Monitoring - generator inverse time-overcurrent - characteristic "High"	71
Figure 3-32: Monitoring - generator inverse time-overcurrent - characteristic "Extreme"	71
Figure 3-35: Monitoring - engine overspeed	80
Figure 3-37: Monitoring - engine underspeed.....	82
Figure 3-39: Monitoring - plausibility check n/f.....	84
Figure 3-41: Monitoring - battery overvoltage	89
Figure 3-43: Monitoring - battery undervoltage	91
Figure 3-46: N.O./N.C.	98
Figure 3-49: Analog inputs - possibilities of combinations (<i>FlexIn</i>)	101
Figure 3-50: Analog input scaling - linear characteristics	108
Figure 3-51: Analog input scaling - table (example)	111
Figure 3-53: <i>LogicsManager</i> - function overview	128
Figure 3-55: <i>LogicsManager</i> - display in LeoPC.....	129
Figure 3-56: <i>LogicsManager</i> - display in LCD.....	129
Figure 3-58: Analog inputs - characteristics diagram VDO 0 to 5 bar, Index "III"	155
Figure 3-59: Analog inputs - characteristics diagram VDO 0 to 10 bar, Index "IV"	156
Figure 3-60: Analog inputs - characteristics diagram VDO 40 to 120 °C, Index "92-027-004"	157
Figure 3-61: Analog inputs - characteristics diagram VDO 50 to 150 °C, Index "92-027-006"	158

Tables

Table 1-1: Manual - overview	8
Table 3-2: Event history - operation states	16
Table 3-7: Permissible limits	42
Table 3-9: Monitoring - standard values - generator overfrequency	45
Table 3-11: Monitoring - Standard values - generator underfrequency	47
Table 3-13: Monitoring - standard values - generator overvoltage	49
Table 3-15: Monitoring - standard values - generator undervoltage	51
Table 3-17: Monitoring - standard values - generator time-overcurrent	53
Table 3-19: Monitoring - standard values - generator reverse / reduced power	56
Table 3-21: Monitoring - standard values - generator overload	58
Table 3-23: Monitoring - standard values - generator unbalanced load	60
Table 3-25: Monitoring - standard values - generator voltage asymmetry	63
Table 3-28: Monitoring - standard values - generator ground fault	66
Table 3-29: Monitoring - standard values - generator voltage phase rotation	68
Table 3-33: Monitoring - standard values - generator inverse time-overcurrent	72
Table 3-34: Monitoring - standard values - mains voltage phase rotation	74
Table 3-36: Monitoring - standard values - engine overspeed	80
Table 3-38: Monitoring - standard values - engine underspeed	82
Table 3-40: Monitoring - standard values - plausibility control n/f	85
Table 3-42: Monitoring - standard values - battery overvoltage	89
Table 3-44: Monitoring - standard values - battery undervoltage	91
Table 3-45: Discrete inputs - assignment	97
Table 3-47: Relay outputs - assignment	100
Table 3-48: Analog inputs - possibilities of configuration (<i>FlexIn</i>)	101
Table 3-52: Relay outputs - Assignment	127
Table 3-54: <i>LogicsManager</i> - command overview	128
Table 3-57: <i>LogicsManager</i> - logical symbols	129

Chapter 1.

General Information

Type	English	German
easYgen-1000 Series		
easYgen-1000 - Installation	37320	GR37320
easYgen-1000 - Configuration	this manual ⇌	GR37321
easYgen-1000 - Operation	37322	GR37322
easYgen-1000 - Application	37205	GR37205
easYgen-1000 - Interfaces	37262	GR37262
Additional Manuals		
IKD 1 - Manual Discrete expansion board with 8 discrete inputs and 8 relay outputs that can be coupled via the CAN bus to the control unit. Evaluation of the discrete inputs as well as control of the relay outputs is done via the control unit.	37135	GR37135
IKN 1 - Manual 20-channel NiCrNi temperature scanner that monitors the temperature values for exceeding or falling below a threshold value, measured through senders on the IKN 1. A configured relay on the board of the IKN 1 will trip. The IKN 1 can be coupled with the control unit using the CAN bus to display measuring values as well as alarms.	37136	GR37136
LeoPC1 - User Manual PC program for visualization, configuration, remote control, data logging, language upload, alarm and user management, and management of the event recorder. This manual describes the set up of the program and interfacing with the control unit.	37146	GR37146
LeoPC1 - Engineering Manual PC program for visualization, configuration, remote control, data logging, language upload, alarm and user management, and management of the event recorder. This manual describes the configuration and customization of the program.	37164	GR37164
GW 4 - Manual Gateway for transferring the CAN bus to any other interface or bus.	37133	GR37133
ST 3 - Manual Control to govern the Lambda value of a gas engine. The Lambda value will be directly measured through a Lambda probe and controlled to a configured value.	37112	GR37112

Table 1-1: Manual - overview

Intended Use The unit must only be operated for the uses described in this manual. The prerequisite for a proper and safe operation of the product is correct transportation, storage, and installation as well as careful operation and maintenance.



NOTE

This manual has been developed for a unit fitted with all available options. Inputs/outputs, functions, configuration screens and other details described, which do not exist on your unit may be ignored.

The present manual has been prepared to enable the installation and commissioning of the unit. On account of the large variety of parameter settings, it is not possible to cover every possible combination. The manual is therefore only a guide. In case of incorrect entries or a total loss of functions, the default settings can be taken from the enclosed list of parameters at the rear of this manual.

Chapter 2. Configuration

Configuration Via The Front Panel



How to operate the unit via the front panel is explained in manual "37322". Please familiarize yourself with the unit, the buttons and their meaning/operation and the display monitoring using this manual. The display of parameters via the front panel will differ from the display of the parameters via the LeoPC1 program described in this manual. The sequence, the meaning and the setting limits are identical.

Configuration Using The PC



CAUTION

For the configuration of the unit via the PC please use the LeoPC1 software with the following software version:

LeoPC1 from 3.1.xxx



NOTE

Please note that configuration using the direct configuration cable DPC (product number 5417-557) is possible starting with revision B of the DPC (first delivered July 2003). If you have an older model please contact our sales department.

For configuration of the unit via PC program please proceed as follows:

- Install the PC program on your laptop/PC according to the installation manual.
- Before the end of the installation you are requested to select the language with which you want to start the PC program. You can change the language at any time. The selection of the language refers only to language with which the menus and subprograms of the PC program works. This setting will not change the language of the control unit being configured.
- After the installation of the PC program reboot your laptop/PC.
- Establish the connection between your laptop/PC and the unit via the DPC. Plug one side to the configuration plug of the unit and the other side to the COM1 port of your laptop/PC (other possibilities are described in the installation manual).
- You may start the PC program as follows:
 - by "Start/Program/Woodward/LeoPC" (starting at version 3.1.xxx), or
 - by a double click on a file ending ".cfg" in the subdirectory "/LeoPC".
- After the PC program was started, establish the communication by pressing the "F2" button. This will establish a data link between the unit and the laptop/PC.
- Start the sub program "Device Parameterization" and adjust the parameter of the unit to your application using this manual.



NOTE

The connection cables delivered with the DPC must be used to connect to the easYgen to ensure that the controller functions properly. An extension or utilization of different cable types for the connection between easYgen and DPC may result a malfunction of the easYgen. This may possibly result in damage to components of the system. If an extension of the data connection line is required, only the serial cable between DPC and laptop/PC may be extended.



NOTE

If the laptop/PC fails to communicate with the control unit being configured, refer to LeoPC1 manual 37146.



NOTE

Depending on the used computer and the installed operation system, problems with the communication via an infrared connection may occur.



NOTE

If you want to read or write parameters using a [LeoPC1 Gateway-RS-232 via GW4] connection, you must configure the parameter "Visualization" to "not active" in LeoPC1. The parameter "Visualization" may be configured back to "active" after reading and/or writing.

Function Of The Inputs And Outputs



Discrete inputs

The discrete inputs may be grouped into two categories:

- **programmable**
The programmable discrete input has been programmed with a factory default function using the *LogicsManager*. The following text describes how these functions may be changed using the *LogicsManager*.
- **fixed**
The discrete input has a specific function that cannot be changed. The discrete input cannot be used in the *LogicsManager*.



NOTE

Depending on the configured application mode (Parameter 20), the discrete inputs can be "*programmable*" or "*fixed*". Please refer to the table on page 97.

Emergency stop

programmable to discrete input [D1], terminal 51/50

This discrete input is configured as alarm class F and it is not delayed by the engine.

Automatic {all}

programmable to discrete input [D2], terminal 52/50

Activated in the operation mode AUTOMATIC

logic "1" If the unit is in the operating mode AUTOMATIC (selected with the operating mode selection push button on the front foil) the controlled engine is automatically started.

logic "0" The engine will be stopped.

Enable MCB {2oc}

fixed to discrete input [D6], terminals 56/50

⇒ **Note: Only if parameter Enable MCB via DI6 is enabled (refer to page 41)!**

logic "1" The MCB is enabled.

logic "0" The MCB is not enabled and switching back to mains supply following an emergency power operation will be blocked.

Reply: MCB is open{2oc}

fixed to discrete input [D7], terminals 57/50

⇒ **Note: Negative logic function!**

This discrete input indicates to the control that the MCB is open if it is energized (logic "1"). This operating status will be displayed in the LCD.

Reply: GCB is open {1oc}+{2oc}

fixed to discrete input [D8], terminals 58/50

⇒ **Note: Negative function logic!**

This discrete input (logic "1") signalizes the control that the GCB is open. This operating status will be displayed in the LCD.

Alarm inputs {all}

All discrete inputs which are not assigned a function can be used as alarm inputs. The alarm or control inputs can be configured freely. Please refer to Discrete Inputs on page 97.

Relay outputs

The discrete outputs can be grouped into two categories:

- **programmable**
The relay output has been pre-defined (programmed) with this function using the *LogicsManager* (which are described in the following text). The function may be changed by using the *LogicsManager*.
- **fixed**
The relay output has a specific function that cannot be changed. The relay output is not visible at the unit in the *LogicsManager*.



NOTE

The relay outputs can be "**programmable**" or "**fixed**" depending on the application mode (refer to Parameter 20). Also refer to Table 3-47: Relay outputs - assignment on page 100.

Centralized alarm {all}

programmable to relay [R1], terminals 30/35

By energizing this relay a centralized alarm is issued. A horn or a buzzer can be activated. By pressing the button next to the symbol "✓", the relay can be reset. It will be energized again if a new fault condition occurs. The centralized alarm is activated by alarms class B or higher.

Stopping alarm {all}

programmable to relay [R2], terminals 31/35

By energizing this relay a stopping alarm (alarms of alarm classes C and higher) is issued. It will be reset if all stopping alarms have been acknowledged.

Starter {all}

fixed to relay [R3], terminals 32/35

By energizing this relay the starter motor is engaged. When reaching ignition speed (Parameter 52) or the maximum starter time (Parameter 47), this relay will be de-energized again.

Fuel solenoid / gas valve (Diesel / gas engine) {all}

fixed to relay [R4], terminals 33/35

Fuel solenoid: By energizing this relay the fuel solenoid for the diesel engine is energized. If the engine should be shut down or engine-firing speed drops below the set speed, this relay de-energizes immediately.

Gas valve: By energizing this relay the gas valve for the engine is enabled. If the engine should be shut down or the engine speed drops below the set ignition speed, this relay de-energizes immediately.

Pre-glow (Diesel engine) {all}

programmable to relay [R5], terminals 34/35

By energizing this relay preheating of the diesel engine is carried out. Refer to parameter "Preglow mode" in section "Engine".

Ignition ON (Gas engine) {all}

programmable on relay [R5], terminals 34/35

By energizing this relay the ignition of the gas engine is enabled.

Auxiliary services*programmable* to relay [R6], terminals 36/37Prior to engine start (pre-run):

Before each starting sequence this relay may be energized for an adjustable time (i.e. opening louvers). By energizing the relay output an additional message is displayed in the control screen. This relay is always energized if speed is detected. In the "MANUAL" operating mode this relay output is always energized. The signal remains ON until the operating mode is changed.

During engine run:

The relay remains energized while the engine is running or as long as speed is detected.

Following an engine stop (post-operation):

After each engine stop (speed is no longer detected) this relay may remain energized for an adjustable time (i.e. operate a cooling pump). If the operating mode is changed from MANUAL to STOP or AUTOMATIC without a start command the relay remains energized for this period of time. The message "post run services" will be displayed on the control unit screen.

Command: open GCB {1o} or {1oc} or {2oc}*fixed* to relay [R7], terminals 38/39

{1o}: This relay remains de-energized until the GCB is manually closed. The relay will de-energize when a fault condition or an engine shut down occurs.

{1oc} or {2oc}: This relay will be energized by the control unit to perform the GCB switching operation. If "Reply: GCB is open" occurs, the relay will de-energize.

Command: close MCB {2oc}*fixed* to relay [R8], terminals 40/41

By energizing this relay the MCB will be closed. This output is always a closing pulse. This requires the MCB have a holding coil and sealing contacts, which are external to the control unit.

Command: open MCB {2oc}*fixed* to relay [R9], terminals 42/43

By energizing this relay the MCB will be opened. If "Reply MCB is open" occurs the relay output will be terminated.

Command: close GCB {1oc} or {2oc}*fixed* to relay [R10], terminals 44/45

Configured maintaining output: Energizing this relay will close the GCB. If the GCB is configured as a maintaining output the relay will remain energized as long as the discrete input "Reply: GCB is open" is not active. If an alarm class C or higher occurs or the GCB is opened, this relay de-energizes.

Configured momentary output: If the relay is configured in this manner a holding coil and sealing contacts must be installed externally to the control unit.

Ready for operation {all}*fixed* to relay [R11], terminals 46/47


This relay energizes when the control unit is powered up and the control unit does not detect any internal fault conditions within the CPU. If the relay de-energizes safe operation of the control unit cannot be ensured. This is a watchdog relay for the control unit CPU. It is recommended this relay should be wired to an emergency stop function (i.e. open GCB and stop engine). Additionally, it is possible to configure further events, which cause the relay to de-energize, using the *LogicsManager*.

***LogicsManager* Relay {all}**

All relays not assigned a defined function, may be configured via the *LogicsManager*.

Chapter 3. Parameters

The description of the parameters is confined to the illustration via the PC-program. The parameters are thereby described as follows.



Password



The unit is equipped with a multi-level code and configuration hierarchy, which allows different user access to the control. A distinction is made between:

Code level CS0 (User Level)

This code level allows for monitoring of the system and does not permit access to the parameters. Configuration is blocked. Only the time may be adjusted.

Standard password = none

Code level CS1 (Basis Service Level)

This code level entitles the user to change selected parameters, like setting Bar/PSI, °C/°F, and horn reset time. Changing a password is not permitted at this level. This password expires two hours after entering the password and the user is returned to the CS0 level.

Standard password = "0 0 0 1"

Code level CS3 (Commissioning Level)

Allows direct access to all parameters (displaying and changing). In addition, the user may also set the password for levels CS1 and CS3. This password expires two hours after entering the password and the user is returned to the CS0 level.

Standard password = "0 0 0 3"



NOTE

Once the code level is entered, access to the configuration menus will be allowed for two hours or until another password is entered into the control. If a user needs to exit a code level then code level CS0 should be entered. This will block any configuration of the control. A user may return to CS0 by allowing the entered password to expire after two hours or by changing any one digit on the random number generated on the password screen and entering it into the unit.

By entering "0000" the current password level remains active until another password is entered into the control unit. Otherwise, the code level would expire when loading the standard values (default 0000) via LeoPC1.

DE	Password				0000 to 9999
EN	Password				
CS0	{0}	{10}	{10c}	{20c}	To configure the control via the front panel bus enter the password.
	✓	✓	✓	✓	
DE	Password CAN				0000 to 9999
EN	Password CAN				
L	{0}	{10}	{10c}	{20c}	To configure the control via CAN bus enter "password CAN".
1	✓	✓	✓	✓	
DE	Password DPC				0000 to 9999
EN	Password RS232 /DPC				
L	{0}	{10}	{10c}	{20c}	To configure the control via DPC please enter "password DPC".
2	✓	✓	✓	✓	

Event History



The event history is a FIFO (First In/First Out) memory for logging alarm events and operation states of the unit. The capacity of the event history is 300 entries. As new event messages are entered into the history, the oldest messages are deleted once 300 events have occurred.

The individual alarm messages, which are stored in the event history, are described in detail in Appendix A: Operation of manual 37322. The operation states, which are stored in the event history, are listed in the table below.

The event history display is password-protected.




Figure 3-1: Event history- display

A date/time stamp is added to each entry. Additional characters (+ and -) indicate the state of the alarm. The "+" character indicates an alarm condition that is still active. If the alarm conditions are no longer present anymore, the "+" character will be changed to "-".

DE | EN
CS3

Event history display

Ereignisspeicher anzeigen

{0} ✓

{10} ✓

{10c} ✓

{20c} ✓

Event history: Display event history

Individual entries can be selected with the **↑** or **↓** keys and deleted from the event history with the **↵** key.

Auto mode
Stop mode
Manual mode
MCB open
MCB close
GCB open
GCB close
Mains failure
Emergency run
Engine is running
Critical mode

Info

Table 3-2: Event history - operation states

DEFINITION		Clear event log				Event history: Clear event history	YES / NO
		Ereignisspeicher löschen					
CS3		{0}	{10}	{10c}	{20c}	YES	The complete event history will be deleted. After the event history has been deleted, this parameter changes back to "NO" automatically.
		✓	✓	✓	✓	NO	The event history will not be deleted.

Measuring



NOTE

There are two versions of hardware, which are described in this manual: A current transformer ../1 A-version [../1] and a current transformer ../5 A-version [../5]. The setting limits for these two versions are different.



NOTE

It is absolutely necessary for correct rated voltage values to be entered, as many measurement and monitoring functions refer to these values.

Measuring: Rated Values

EN	Rated system frequency				Rated system frequency	50/60 Hz
DE	Nennfrequenz im System					
CS0	{0}	{10}	{100}	{200}	The rated frequency of the system.	
3	✓	✓	✓	✓		

EN	Rated voltage generator				Rated generator voltage	50 to 650,000 V
DE	Nennspannung Generator					
CS0	{0}	{10}	{100}	{200}	ⓘ This value is the primary voltage of the generator PTs (generator voltage on data plate).	
4	✓	✓	✓	✓		

The rated voltage of the generator. The secondary generator PT voltages and their terminals are given below:

- Secondary voltage: 120 Vac
- Generator voltage: Terminals 22/24/26/28
- Secondary voltage: 480 Vac
- Generator voltage: Terminals 23/25/27/29

EN	Rated voltage mains				Rated mains voltage	50 to 650,000 V
DE	Nennspannung Netz					
CS0	{0}	{10}	{100}	{200}	ⓘ This value is the primary voltage of the connected mains PTs.	
5	---	---	---	✓		

The rated voltage of the mains. The secondary mains PT voltages and their terminals are given below:

- Secondary voltage: 120 Vac
- Mains voltage: Terminals 14/16/18/20
- Secondary voltage: 480 Vac
- Mains voltage: Terminals 15/17/19/21

EN	Generator voltage measuring			
DE	Gen.Spannungsmessung			
CS0	{0}	{1o}	{1oc}	{2oc}
6	✓	✓	✓	✓

Measurement principle: Generator

3Ph 4W / 3Ph 3W / 1Ph 2W / 1Ph 3W

① Please refer to the comments on measuring principles in the installation manual (37320).

3Ph 4WMeasurement is performed Line-Neutral (WYE connected system). Phase voltages and the neutral must be connected for proper calculation. The measurement, display and protection are adjusted according to the rules for WYE connected systems. Monitoring refers to the following voltages:

- V_{L12} , V_{L23} , and V_{L31} , or
- V_{L1N} , V_{L2N} and V_{L3N} .

3Ph 3WMeasurement is performed Line-Line (Delta connected system). Phase voltages must be connected for proper calculation. The measurement, display and protection are adjusted according to the rules for Delta connected systems. Monitoring refers to the following voltages:

- V_{L12} , V_{L23} , V_{L31} .

1Ph 2WMeasurement is performed for single-phase systems. The measurement, display and protection are adjusted according to the rules for single-phase systems. Monitoring refers to the following voltages:

- V_{L1N} .

1Ph 3WMeasurement is performed Line-Neutral (WYE connected system). The measurement, display, and protection are adjusted according to the rules for single-phase systems. Monitoring refers to the following voltages:

- V_{L1N} , V_{L3N} .

EN	Generator current measuring			
DE	Gen.Strommessung			
CS0	{0}	{1o}	{1oc}	{2oc}
7	✓	✓	✓	✓

Measurement principle: Generator

L1 L2 L3 / Phase L1 / Phase L2 / Phase L3

① Please refer to the comments on measuring principles in the installation manual (37320).

L1 L2 L3All three phases are monitored. The measurement, display and protection are adjusted according to the rules for 3-phase measurement. Monitoring refers to the following currents:

- I_{L1} , I_{L2} , I_{L3} .

Phase L{1/2/3} Only one phase is monitored. The measurement, display and protection are adjusted according to the rules for single-phase measurement. Monitoring refers to the selected phase.

EN	Mains voltage measuring			
DE	Netzspannungsmessung			
CS0	{0}	{1o}	{1oc}	{2oc}
8	---	---	---	✓

Measurement principle: Mains

3Ph 4W / 3Ph 3W / 1Ph 2W / 1Ph 3W

① Please refer to the comments on measuring principles in the installation manual (37320).

3Ph 4W Measurement is performed Line-Neutral (WYE connected system). Phase voltages and the neutral must be connected for proper calculation. The measurement, display and protection are adjusted according to the rules for WYE connected systems. Monitoring refers to the following voltages:

- VL12, VL23, and VL31, or
- VL1N, VL2N and VL3N.

3Ph 3W Measurement is performed Line-Line (Delta connected system). Phase voltages must be connected for proper calculation. The measurement, display and protection are adjusted according to the rules for Delta connected systems. Monitoring refers to the following voltages:

- VL12, VL23, VL31.

1Ph 2W Measurement is performed for single-phase systems. The measurement, display and protection are adjusted according to the rules for single-phase systems. Monitoring refers to the following voltages:

- VL1N.

1Ph 3W Measurement is performed Line-Neutral (WYE connected system). The measurement, display, and protection are adjusted according to the rules for single-phase systems. Monitoring refers to the following voltages:

- VL1N, VL3N.

EN	Mains current measuring			
DE	NetzStrommessung			
CS0	{0}	{1o}	{1oc}	{2oc}
9	---	---	---	✓

Measurement principle: Mains

Phase L1 / Phase L2 / Phase L3

① Please refer to the comments on measuring principles in the installation manual (37320).

Phase L{1/2/3} Measurement is performed for the selected phase only. The measurement and display refer to the selected phase. The configured phase CT must be connected to perform current measurement.

**NOTE**

It is absolutely necessary for correct rated power and current values to be entered, as many measurement and monitoring functions refer to these values.

EN	Rated active power[kW]			
DE	Nennwirkleistung[kW]			
CS0	{0}	{1o}	{1oc}	{2oc}
10	✓	✓	✓	✓

Rated active power

0.5 to 99,999.9 kW

This value specifies the generator rated power.

EN	Rated current			
DE	Nennstrom Generator			
CS0	{0}	{1o}	{1oc}	{2oc}
11	✓	✓	✓	✓

Rated current

5 to 32,000 A

This value specifies the generator rated current.

Measuring: Transformers

Voltage Transformer

EN	Gen. voltage transf. primary	Voltage transformer, generator, primary	50 to 650,000 V
----	------------------------------	---	-----------------

DE	Gen.Spg.Wandler primär			
CS0	{0}	{1o}	{1oc}	{2oc}
12	✓	✓	✓	✓

The primary generator voltage in V.

EN	Gen. voltage transf. secondary	Voltage transformer, generator, secondary	50 to 480 V
----	--------------------------------	---	-------------

DE	Gen.Spg.Wandler sekundär			
CS0	{0}	{1o}	{1oc}	{2oc}
13	✓	✓	✓	✓

① The control is equipped with two rated voltage range inputs, which are determined via different terminals (see below). This value refers to the secondary voltages of the potential transformers, which are directly connected to the control.

The secondary generator voltage in V.

- Rated voltage: 120 Vac (for PT's up to 120 Vac)
 - Generator voltage: Terminals 22/24/26/28
- Rated voltage: 480 Vac
 - Generator voltage: Terminals 23/25/27/29

EN	Mains.volt. transf. primary	Voltage transformer, mains, primary	50 to 650,000 V
----	-----------------------------	-------------------------------------	-----------------

DE	Netz.Spg.Wandler primär			
CS0	{0}	{1o}	{1oc}	{2oc}
14	---	---	---	✓

The primary mains voltage in V.

EN	Mains.volt. transf. secondary	Voltage transformer, mains, secondary	50 to 480 V
----	-------------------------------	---------------------------------------	-------------

DE	Netz.Spg.Wandler sekundär			
CS0	{0}	{1o}	{1oc}	{2oc}
15	---	---	---	✓

① The control is equipped with two rated voltage range inputs, which are determined via different terminals (see below). This value refers to the secondary voltages of the potential transformers, which are directly connected to the control.

The secondary mains voltage in V.

- Rated voltage: 120 Vac (for PT's up to 120 Vac)
 - Mains voltage: Terminals 14/16/18/20
- Rated voltage: 480 Vac
 - Mains Voltage: Terminals 15/17/19/21

Current Transformer

EN	Generator current transformer	Current transformer, generator	1 to 32,000/{x} A
DE	Generator Stromwandler		
CS0	{0} {1o} {1oc} {2oc}	① Current transformer ratio for the generator.	
16	✓ ✓ ✓ ✓		
<p>The control can be optionally equipped with ../1 A or with ../5 A current transformer inputs. Depending on the version there are two different specifications of the parameter, which control the same memory location. You can find this value at the unit either on the data plate or via the software.</p> <p>{x} = 1 easYgen-1xxx-51B = Current transformer with ../1 A rated current, {x} = 5 easYgen-1xxx-55B = Current transformer with ../5 A rated current.</p>			
EN	Input mains current as	Current transformer, input	Mains current / ground current
DE	Eingang Netzstrom als		
CS3	{0} {1o} {1oc} {2oc}	Mains cur. ... Mains current input is used for measuring the mains current. The ground current is only provided as calculated ground current.	
17	✓ ✓ ✓ ✓	① The ground current monitoring refers to the rated generator current!	
<p>Ground cur. Mains current input is used for the directly measured ground current. The calculated ground current is not evaluated anymore.</p> <p>① The ground current monitoring refers to the rated transformer current configured at the unit!</p>			



NOTE


It depends on the setting of the above parameter, which of the following screens is displayed.

EN	Mains current transformer	Current transformer, mains	1 to 32,000/{x} A
DE	Netz-Stromwandler		
CS0	{0} {1o} {1oc} {2oc}	① Current transformer ratio for the mains.	
18	--- --- --- ✓		
<p>The control can be optionally equipped with ../1 A or with ../5 A current transformer inputs. Depending on the version there are two different specifications of the parameter, which control the same memory location. You can find this value at the unit either on the data plate or via the software.</p> <p>{x} = 1 easYgen-1xxx-51B = Current transformer with ../1 A rated current, {x} = 5 easYgen-1xxx-55B = Current transformer with ../5 A rated current.</p>			
EN	Ground current transformer	Current transformer, ground	1 to 32,000/{x} A
DE	Erd-Stromwandler		
CS0	{0} {1o} {1oc} {2oc}	① Ground current transformer ratio.	
19	✓ ✓ ✓ ✓		
<p>The control can be optionally equipped with ../1 A or with ../5 A current transformer inputs. Depending on the version there are two different specifications of the parameter. You can find this value either on the data plate or via the software.</p> <p>{x} = 1 easYgen-1xxx-51B = Current transformer with ../1 A rated current, {x} = 5 easYgen-1xxx-55B = Current transformer with ../5 A rated current.</p>			

Application




Application: Application Mode



NOTE

All functions which are described in the following text may be assigned by the [LogicsManager](#) to any relay which is available via the [LogicsManager](#) and not assigned to another function. The assignment of the defined relays to defined functions occurs by selection of the application mode (i.e. function "Command: Close GCB" on relay [R10], this relay can no longer be operated via the [LogicsManager](#)). The same way some relays are designated to specific functions, others may be assigned to different functions. These are listed as "programmed" relays. If a relay is "programmable" the function may be assigned to other relays via the [LogicsManager](#) by configuration.



NOTE

Changing the application mode will not change other configured values in the parameters. The application mode parameter is the only mode that will be affected.

		Application mode	Application modes		"None" / "GCB open" / "GCB" / "GCB/MCB"
		Betriebsmodus			
EN	CS0	{0}	{1o}	{1oc}	{2oc}
DE	20	✓	✓	✓	✓

The unit may be configured for four different application modes. The discrete inputs and relay outputs are pre-defined dependent upon the selected application mode. Only the screens and functions that pertain to the application mode selected are displayed. Refer to the "Operation manual" (37322) for additional information.

None[Application mode {0} "Engine Control" \[BM\]](#)
The control unit will function as an engine control. All necessary inputs and outputs are assigned and pre-defined.

GCB open[Application mode {1o} "Protection" \[open GCB\]](#)
The control unit will function as an engine control with generator and engine protection. The control unit can only open the GCB. All necessary inputs and outputs are assigned and pre-defined.

GCB[Application mode {1oc} "1-CB control" \[open/close GCB\]](#)
The control unit will function as a 1 CB unit. The control unit can open and close the GCB. All necessary inputs and outputs are assigned and pre-defined.

GCB/MCB ...[Application mode {2oc} "2 CB control" \[open/close GCB/MCB\]](#)
The control unit will function as a 2 CB unit. The control unit can open and close the GCB and the MCB. All necessary inputs and outputs are assigned and pre-defined.

Application: Start In AUTOMATIC Operating Mode (*LogicsManager*)

The start of the engine can be performed via different logical conditions. This can be:

- a discrete input,
- a temperature level
- an interface
- a timer
- any logical combination

If this logical output becomes TRUE in AUTOMATIC operating mode, the generator starts and the GCB will be closed. The simultaneous activation of other *LogicsManager* outputs (e.g. Stop req. in Auto, Start w/o load) may affect this function.

Only {1oc}, {2oc}: If this logical output becomes FALSE again, the GCB will be opened again and the generator will be stopped after the cool-down phase.

		Start req. in Auto				Start request in operation mode AUTOMATIC	LogicsManager
DE	EN	Startanf. in Auto					
CS0		{0}	{1o}	{1oc}	{2oc}	The LogicsManager and its default settings are explained on page 127 in Appendix B: "LogicsManager".	
21	✓	✓	✓	✓	✓		

Application: Stop In AUTOMATIC Operating Mode (*LogicsManager*)

If this logical output becomes TRUE, it inhibits all other start processes (e.g. Start req. in Auto, emergency power, etc.). Stopping of the engine can be initiated externally via a discrete input or any logical combination.

DE	EN	Stop req. in Auto				Stop request in operation mode AUTOMATIC	<i>LogicsManager</i>
		Stopanf. in Auto					
CS0		{0}	{1o}	{1oc}	{2oc}	The <i>LogicsManager</i> and its default settings are explained on page 127 in Appendix B: " <i>LogicsManager</i> ".	
22		✓	✓	✓	✓		

Application: Operating Mode

DE	EN	Start w/o load				Start without assuming load	<i>LogicsManager</i>
		Start ohne Übernahme					
		{0}	{1o}	{1oc}	{2oc}	If this <i>LogicsManager</i> condition is TRUE switching from mains to generator supply following an engine start is prevented (the GCB operation is blocked). This function may be used to perform a test operation. If an emergency power case occurs meanwhile, it is still possible to change to generator operation. The <i>LogicsManager</i> and its default settings are explained on page 127 in Appendix B: " <i>LogicsManager</i> ".	
CS0	23	---	---	✓	✓		

DE EN	Startup in mode				Operating mode after applying the power supply	Stop / Auto / Manual / last
	Einschalten in Betriebsart					
CS0	{0}	{1o}	{1oc}	{2oc}	If the controller is powered down, the unit will start in the following configured mode when it is powered up again.	
24	---	---	✓	✓		

Stop..... The unit starts in the STOP operating mode.

Auto..... The unit starts in the AUTOMATIC operating mode.

Manual..... The unit starts in the MANUAL operating mode.

last..... The unit starts in the last operating mode the control was in prior to being de-energized.

**NOTE**

For the selection of the operating mode via the *LogicsManager* (if two different operating modes have been selected simultaneously) the control unit will prioritize the modes as follows:

1. STOP,
2. MANUAL
3. AUTOMATIC

EN	Operation mode AUTO			
DE	Betriebsart AUTO			
CS0	{0}	{1o}	{1oc}	{2oc}
25	✓	✓	✓	✓

Activate operating mode AUTOMATIC*LogicsManager*

Once the conditions of the *LogicsManager* have been fulfilled the unit will change into operating mode AUTOMATIC. If AUTOMATIC mode is selected via the *LogicsManager* it is not possible to change operating modes via the front panel. The *LogicsManager* and its default settings are explained on page 127 in Appendix B: "*LogicsManager*".

EN	Operation mode MAN			
DE	Betriebsart MAN			
CS0	{0}	{1o}	{1oc}	{2oc}
26	✓	✓	✓	✓

Activate operating mode MANUAL*LogicsManager*

Once the conditions of the *LogicsManager* have been fulfilled the unit will change into operating mode MANUAL. If MANUAL mode is selected via the *LogicsManager* it is not possible to change operating modes via the front panel. The *LogicsManager* and its default settings are explained on page 127 in Appendix B: "*LogicsManager*".

EN	Operation mode STOP			
DE	Betriebsart STOP			
CS0	{0}	{1o}	{1oc}	{2oc}
27	✓	✓	✓	✓

Activate operating mode STOP*LogicsManager*

Once the conditions of the *LogicsManager* have been fulfilled the unit will change into operating mode STOP. If STOP mode is selected via the *LogicsManager* it is not possible to change operating modes via the front panel. The *LogicsManager* and its default settings are explained on page 127 in Appendix B: "*LogicsManager*".

Application: Liquid Crystal Display (LC Display)

EN	Alternative screen			
DE	Alternative Anzeigemasken			
CS0	{0}	{1o}	{1oc}	{2oc}
28	✓	✓	✓	✓

Show alternative screens**YES / NO**

YESThe alternative screens are shown in the LC display. Refer to manual 37322.

NOThe standard screens are shown in the LC display. Refer to manual 37322.

EN	Show mains data			
DE	Netzdaten anzeigen			
CS0	{0}	{1o}	{1oc}	{2oc}
29	---	---	---	✓

Show mains data**YES / NO**

YESThe alternative screens are shown in the LC display. Refer to manual 37322.

NOThe standard screens are shown in the LC display. Refer to manual 37322.

Application: Critical Mode (Sprinkler Operation, *LogicsManager*)

The critical mode may be externally initiated via a discrete input. The *LogicsManager* is used to define the conditions that will enable the critical mode (for conditions and explanation of programming refer to *LogicsManager* on page 114).

Alarm Classes

When critical mode is enabled the alarm classes are reclassified as follows:

	Alarm classes					
Normal operation	A	B	C	D	E	F
Critical mode	A	B	B	B	B	B

Critical mode "ON"

A critical mode will be initiated/started once the critical mode operation *LogicsManager* output becomes TRUE (logic "1"). The critical mode message is displayed on the LC screen. If the engine is not already running, the controller will attempt to start the engine up to 10 times (unless configured for less). All shutdown alarms become warning messages (see above).

Critical mode "OFF"

A critical mode will be interrupted/stopped once critical mode operation *LogicsManager* output becomes FALSE (logic "0"). The critical mode operation is continued for the configured critical mode postrun time. If the operation mode changes to STOP, this time will be considered as expired. With termination of the critical mode, a normal cool down is performed.

Critical mode and emergency power {2oc}

The emergency power operation has priority. If there is a mains failure during the critical mode, the generator will supply the busbar. The MCB will be opened and the GCB will be closed. The critical mode message is displayed on the LC screen and all shutdown alarms become warning alarms.

- ⇒ Critical mode ends before mains recovery: The emergency power operation will be continued and all shutdown alarms become active again. If the mains return, the unit transfers the load from generator supply to mains supply after the mains settling delay expires.
- ⇒ Emergency power operation ends before the end of the critical mode: The critical mode is maintained and the load is transferred from generator supply to mains supply after the mains settling delay expires. The engine remains running until the conditions for the critical mode are no longer existent.

Critical mode and start request

The critical mode operation has priority. If there is a critical mode request while the generator is running, the GCB will be opened (in application mode {2oc} there will be a change from generator supply to mains supply of the busbar). The critical mode message is displayed on the LC screen and all shutdown alarms become warning alarms.

- ⇒ Critical mode ends before the start request is terminated: The engine continues running (in application mode {2oc} there will be a change from mains supply to generator supply of the busbar). All shutdown alarms will become active again. By resetting the start request the GCB will be opened and the engine will be stopped.
- ⇒ Start request will be terminated before the critical mode is terminated: The critical mode operation is continued. The engine keeps running until the conditions for the critical mode are no longer fulfilled.

Parameters

If this logical output becomes TRUE in AUTOMATIC operating mode, it starts the critical mode.

	EN	Critical mode				Critical mode request	<i>LogicsManager</i>
	DE	Sprinklerbetrieb					
30		{0}	{1o}	{1oc}	{2oc}	The <i>LogicsManager</i> and its default settings are explained on page 127 in Appendix B: " <i>LogicsManager</i> ".	
	EN	Critical mode postrun				Critical mode postrun time	0 to 6000
	DE	Sprinkler Nachlaufzeit					
31		{0}	{1o}	{1oc}	{2oc}	The critical mode operation is continued for the time configured here after the critical mode request has been terminated.	
	EN	Close GCB in override				Close GCB in critical mode	YES / N
	DE	GLS schließen bei Sprinkler					
32		{0}	{1o}	{1oc}	{2oc}	YES If a critical mode operation is detected the GCB will close. NO The GCB cannot be closed during a critical mode operation.	
	EN	Override alarm cl. also in MAN				Critical mode alarm classes active in MANUAL operating mode	YES / N
	DE	Sprinkler Alarmkl. in MAN					
33		{0}	{1o}	{1oc}	{2oc}	YES The critical mode alarm classes will override the normal operation alarm classes when in MANUAL operation mode if enable via the <i>LogicsManager</i> . NO The alarm classes will not be changed in the MANUAL operating mode.	
	EN	Break emergency in override				Critical mode override emergency operations ...	2 to 999
	DE	Pause Notstrom bei Sprinkler					
34		{0}	{1o}	{1oc}	{2oc}	The emergency power operations are overridden for the configured time when the critical mode starts to supply the complete generator power to the sprinkler pump.	

Engine



Engine: Start /Stop Sequence



NOTE

All functions which are described in the following text, may be assigned by the **LogicsManager** to any relay that is available via the **LogicsManager** and not assigned another function.

EN DE	Start/Stop mode				Engine: Type of engine	Diesel / Gas / External
	Start/Stop Modus					
	{0}	{1o}	{1oc}	{2oc}	Diesel or gas engine start/stop logic must be selected. The starting sequences are described in the following chapters. If this parameter is configured to "External" the start/stop sequence must be done externally.	
35	✓	✓	✓	✓		

Engine: Diesel Engine

Start sequence

The relay "Pre-glow" will be energized for the preheating time period. Following preheating, the fuel solenoid is first energized and then the starter is engaged. When the configured firing speed is exceeded, the starter is disengaged and the fuel solenoid remains energized via the firing speed. If the engine fails to start, the starting sequence is blocked for a configurable time period ("Time for engine stop"), and the message "Crank protect" is displayed if starting of the engine is attempted. If the number of unsuccessful start attempts reaches the configured value, an alarm message will be issued.

Stop sequence

After opening the GCB, the coasting time starts and the engine runs without load. On termination of the coasting time, the fuel solenoid is de-energized, and the engine is stopped. If starting of the engine is attempted. If the engine cannot be stopped via the fuel solenoid, the alarm message "stop failure" appears.

Start/stop diagram

The formula signs and indices mean:

t _{HVL}	Lead time auxiliary operation	[s]
t _{VG}	Preheating time	[s]
t _{SV}	Engagement time	[s]
t _{SP}	Interval between 2 start attempts	[s]
t _{MV}	Engine delayed monitoring	[s]
t _{HNL}	Coasting time auxiliary operation	[s]
t _{NL}	Coasting time	[s]




Figure 3-3: Start /stop sequence - diesel engine

Parameter

EN	Fuel relay: close to stop	Diesel engine: Fuel relay for close to stop	YES / NO
DE	Kraftstoffmagnet: Stopmag.		
	{0} {1o} {1oc} {2oc}		
36	✓ ✓ ✓ ✓	<p>YES Stop solenoid</p> <p>To stop the engine the stop solenoid is energized. The stop solenoid remains energized for an additional 30 s after speed is no longer detected from the engine.</p> <p>NO Operating solenoid</p> <p>Before each starting sequence the operating solenoid is energized. To stop the engine the operating solenoid is de-energized.</p>	
EN	Preglow time	Diesel engine: Preglow time [t _{VG}]	0 to 300 s
DE	Vorglühzeit		
	{0} {1o} {1oc} {2oc}		
37	✓ ✓ ✓ ✓	Before each starting the diesel engine is preheated for this time (if a "0" has been configured here the engine will be started without preglow).	
EN	Preglow mode	Diesel engine: Preglow mode	NO / Always / An.input [Tx]
DE	Vorglühmodus		
	{0} {1o} {1oc} {2oc}		
38	✓ ✓ ✓ ✓	<p>This parameter dictates if and under what conditions a diesel engine is preheated.</p> <p>NO The diesel engine is never preheated before a start attempt.</p> <p>Always Before a start attempt the "Preheating" relay is always energized for the pre-glow time (previous screen). After that a start attempt is initiated.</p> <p>An.in.{x} Preheating of the engine is initiated by a temperature transducer through the analog input [T1] = "Temp.1" or the analog input [T2] = "Temp.2". A requirement here is that the selected analog input is configured as a temperature measuring input. The limit of the temperature is set in the following screen.</p>	
EN	Preglow temp. threshold	Diesel engine: Preheating temperature set point value	-10 to 60 °C
DE	Vorglühen wenn T<		
	{0} {1o} {1oc} {2oc}		
39	✓ ✓ ✓ ✓	If the transducer temperature falls below the value entered here and the previous parameter ("temp 1" or "temp 2") is enabled and the diesel engine will be preheated.	

Engine: Gas Engine

Start sequence

Function: The starter is engaged. Following the expiration of the firing delay time and if the engine is rotating with at least the configured "minimum start speed", the ignition is switched on. Following the expiration of the gas valve delay, the gas valve is then enabled. If the starting attempt is successful (i.e. the configured firing speed is exceeded) the starter is disengaged. The gas valve and the ignition remain enabled via the firing speed. If the engine fails to start, the starting sequence is blocked for a configurable time period ("Time for engine stop"), and the message "Crank protect" is displayed if starting of the engine is attempted.

Stop sequence

Function: After opening the GCB, the coasting time starts and the engine runs without load. On termination of the coasting time, the gas valve is closed or de-energized, and the engine is stopped. If the engine cannot be stopped, the alarm message "stop failure" appears. If no speed is detected anymore, the ignition remains active for 5 seconds so that the remaining gas is able to combust.

Start/stop diagram

The formula signs and indices mean:

t_{HVL}	Lead time auxiliary operation	[s]
t_{SV}	Start delay	[s]
t_{SP}	Interval between 2 start attempts....	[s]
t_{ZV}	Ignition delay	[s]
t_{GV}	Gas delay.....	[s]
t_{MV}	Engine delayed monitoring	[s]
t_{HNL}	Coasting time auxiliary operation ..	[s]
t_{NL}	Coasting time	[s]
t_{ZN}	Ignition coasting ("post burning")..	[s]




Figure 3-4: Start /stop sequence - gas engine

Parameter

EN	Ignition delay				Gas engine: Ignition delay [t _{ZV}]	0 to 999 s
	Zündverzögerung					
DE	{0}	{10}	{100}	{200}	With gas engines often a purging operation is desired before starting. With the engaging of the starter the ignition delay is started. If the "Minimum speed for ignition" is reached after the expiration of this time, the ignition is energized.	
40	✓	✓	✓	✓		
EN	Gas valve delay				Gas engine: Gas valve delay [t _{GV}]	0 to 999 s
	Gasverzögerung					
DE	{0}	{10}	{100}	{200}	By energizing the ignition relay the gas valve delay is started. After the expiration of the time set here and the number of revolutions per minute (RPM) is higher than the minimum ignition speed, the gas valve is enabled. Once the ignition speed has been reached, the gas valve remains opened. If the speed falls below ignition speed, the gas valve will be closed and the "Ignition" relay is de-energized 5 seconds later.	
41	✓	✓	✓	✓		
EN	Min.speed for ignition				Gas engine: Minimum ignition speed	10 to 1.800 RPM
	Mindestdrehz. für Zündung					
DE	{0}	{10}	{100}	{200}	After expiration of the ignition delay the number of revolutions set here must be reached, so the "Ignition" relay will be energized.	
42	✓	✓	✓	✓		

Engine: Pickup

To configure the pickup input, the following values must be configured:

- Nominal speed (RPM)
- Number of teeth on the flywheel detected by the magnetic pick up (MPU) or the number of pickup pulses per revolution of the engine.

EN	Speed Pickup				Pickup	ON / OFF
DE	Pickup					
43	{0}	{10}	{100}	{200}	ONSpeed monitoring of the engine is carried out by the MPU. OFFSpeed/frequency monitoring of the generator set (the engine) is performed by measuring the frequency of the generator. There is no MPU wired to this unit.	
	✓	✓	✓	✓		
EN	Nominal speed				Nominal speed	500 to 4,000 RPM
DE	Nenndrehzahl					
44	{0}	{10}	{100}	{200}	Number of revolutions per minute of the engine at rated engine speed.	
	✓	✓	✓	✓		
EN	Number of gear teeth				Number of pickup teeth	2 to 260
DE	Anzahl Pickup-Zähne					
45	{0}	{10}	{100}	{200}	Number of pulse per revolution/teeth on the flywheel.	
	✓	✓	✓	✓		

Engine: Start/Stop Automatic

		Aux. services prerun				Engine: Pre-run auxiliary operation (start preparation) [t _{HVL}]		0 to 999 s	
		Hilfsbetriebe Vorlauf				<div>CAUTION:</div> <div>During an emergency start this delay time "auxiliary pre-run" is not initialized. The engine will be started immediately.</div> <div>① In the MANUAL operation mode the relay "auxiliary pre-run" is permanently ON.</div>			
		{0}	{1o}	{1oc}	{2oc}				
46		✓	✓	✓	✓				
						Before each starting sequence this relay may be energized for an adjustable time (i.e. opening louvers). By energizing the relay output an additional message is displayed in the control screen. This relay is always energized if speed is detected. In the "MANUAL" operating mode this relay output is always energized. The signal remains ON until the operating mode is changed.			
		Starter time				Engine: Maximum starter delay [t _{sv}]		1 to 99 s	
		Einrückzeit Anlasser				<div>This is the maximum time that the starter relay will remain energized. If the discrete input for the <i>LogicsManager</i> function "Ignition speed reached" = TRUE, the speed/frequency have reached the minimum level, or the time has expired the relay is then de-energized.</div>			
		{0}	{1o}	{1oc}	{2oc}				
47		✓	✓	✓	✓				
		Start pause time				Engine: Start pause time [t _{sp}]		1 to 99 s	
		Startpausenzeit				<div>This is the delay time between the individual starting attempts. This time also is used to protect the starter relay.</div>			
		{0}	{1o}	{1oc}	{2oc}				
48		✓	✓	✓	✓				
		Cool down time				Engine: Cool down time [t _{NL}]		1 to 999 s	
		Motor Nachlaufzeit				<div>Regular stop:</div> <div>If the engine performs a normal stop (start request is disabled or change into STOP operating mode) or a stop caused by an alarm of alarm class C/D, a cool down with an opened GCB is carried out. This time is programmable.</div> <div>Stop by a class 'C' or 'D' alarm:</div> <div>If the engine is stopped by an alarm of this alarm class, a cool down is carried out with an opened GCB. This time is programmable.</div> <div>Stop by a class 'E' or 'F' alarm:</div> <div>If the engine is stopped by an alarm of this alarm class, the engine is shutdown without a cool down immediately.</div>			
		{0}	{1o}	{1oc}	{2oc}				
49		✓	✓	✓	✓				
		Auxiliary services postrun				Engine: Coasting auxiliary operation (post operation) [t _{HNL}]		0 to 999 s	
		Hilfsbetriebe Nachlauf				<div>After each engine stop (speed is no longer detected) this relay may remain ener-</div> <div>gized for an adjustable time (i.e. operate a cooling pump). If the operating mode is</div> <div>changed from MANUAL to STOP or AUTOMATIC without a start command the</div> <div>relay remains energized for this period of time. The message "post run services"</div> <div>will be displayed on the control unit screen.</div>			
		{0}	{1o}	{1oc}	{2oc}				
50		✓	✓	✓	✓				
		Time of motor stop				Engine: Engine blocking		0 to 99 s	
		Zeit für Motorstop				<div>During this time a restart of the engine is blocked. This time should be configured</div> <div>so that the engine is total shutdown to protect the starting circuit. Once speed from</div> <div>the engine is no longer detected the time configured in this parameter is initiated.</div>			
		{0}	{1o}	{1oc}	{2oc}				
51		✓	✓	✓	✓				

Engine: Firing Speed And Engine Delayed Monitoring




Figure 3-5: Engine - firing speed and engine delayed monitoring

**NOTE**

When the ignition speed is reached, the starter is disengaged under one of the following conditions:

- The measurement via **MPU is enabled** (ON):
 - ⇒ Ignition speed is detected
 - ⇒ Ignition speed (measured via the generator voltage) is detected
 - ⇒ Conditions for discrete input "Ignition speed" (see *LogicsManager*) equal true.
- The measurement via **MPU is disabled** (OFF):
 - ⇒ Ignition speed (measured via the generator voltage) is detected
 - ⇒ Conditions for discrete input "Ignition speed" (see *LogicsManager*) equal true.

Pickup	Generator frequency	Engine speed	<i>LogicsManager</i>
OFF	YES	NO	YES (if programmed)
ON	YES	YES	YES (if programmed)

Engine: Firing/Ignition Speed

EN	Firing speed	Engine: Firing speed	5 to 60 Hz
DE	Ziinddrehzahl		
52	{0} {10} {100} {200}	After firing speed has been reached, the starter is disengaged and the time counter for the engine delayed monitoring is activated.	

Note: Frequency measurement via the generator voltage input is possible beginning with 15 Hz or higher. If the MPU measurement is enabled, values down to 5 Hz can be measured.

EN	Logism. for firing speed	Engine: Firing speed via <i>LogicsManager</i>	YES / NO
DE	Logism. für Ziinddrehzahl		
53	{0} {10} {100} {200}	YES The engine firing speed is monitored by the <i>LogicsManager</i> instead of the MPU. NO The firing speed is measured by the speed/frequency input (MPU), not via the <i>LogicsManager</i> .	

EN	Ignition speed	Engine: Firing speed reached via <i>LogicsManager</i>	<i>LogicsManager</i>
DE	Ziinddrehz. erreicht		
54	{0} {10} {100} {200}	Once the conditions of the <i>LogicsManager</i> have been fulfilled the ignition speed will be recognized as above minimum limit (e.g. via an oil pressure switch). The <i>LogicsManager</i> and its default settings are explained on page 127 in Appendix B: " <i>LogicsManager</i> ".	

Engine: Engine Delayed Monitoring

After reaching the minimum ignition speed a timer is started. Upon expiration of this timer all "engine delayed monitoring" configured alarms and discrete inputs will be enabled. This timer should be configured in such a manner that it corresponds to the starting time of the engine plus any possible startup transients. A GCB closure may take place after the expiration of this timer. Note: The GCB closure can be initiated prior to engine delayed monitoring by configuring the *LogicsManager*; see "Breaker" starting page 36).

EN	Engine monit. delay time	Engine: Engine delayed monitoring [t _{MV}]	0 to 99 s
DE	Verzög. Motorüberwach.		
55	{0} {10} {100} {200}	Delay between reaching the firing speed and activation of the monitoring of engine speed delayed alarms (i.e. underspeed).	

Engine: Idle Mode

When the engine is operated at idle speed, undervoltage, underfrequency, and underspeed monitoring are not performed. The analog input monitoring uses the alternative limits, which may be configured for the idle mode (Parameter 255). The GCB cannot be closed in idle mode. This function allows for a controlled operation of an engine without alarm messages at a lower speed (lower than the configured monitoring values e.g. warm-up of an engine). Note: The idle mode is blocked when the GCB is closed. A message may be output to a relay here using the *LogicsManager* (Idle mode is active, command variable 4.15), e.g. as a signal for a speed controller.

EN	Constant idle run				Engine: <i>LogicsManager</i> continuous idle mode	<i>LogicsManager</i>
DE	Dauernd Idle Modus					
56	{0}	{1o}	{1oc}	{2oc}	Once the conditions of the <i>LogicsManager</i> have been fulfilled the engine will be continuously operated in idle mode. Undervoltage, underfrequency, and underspeed monitoring are not performed. A key switch via a DI may be configured here for example. The <i>LogicsManager</i> and its default settings are explained on page 127 in Appendix B: " <i>LogicsManager</i> ".	
	✓	✓	✓	✓		
EN	Idle mode automatic				Engine: <i>LogicsManager</i> automatic idle mode	<i>LogicsManager</i>
DE	Automatic Idle Modus					
57	{0}	{1o}	{1oc}	{2oc}	Once the conditions of the <i>LogicsManager</i> have been fulfilled the engine will be operated in idle mode automatically for the configured time during start-up. Undervoltage, underfrequency, and underspeed monitoring are not performed. This function may always be configured to "1" for example. The <i>LogicsManager</i> and its default settings are explained on page 127 in Appendix B: " <i>LogicsManager</i> ".	
	✓	✓	✓	✓		
EN	Time for automatic idle run				Engine: Time for automatic idle mode	1 to 9999 s
DE	Zeit für Automatic Idle Modus					
58	{0}	{1o}	{1oc}	{2oc}	The automatic idle mode is active for the time configured here. Undervoltage, underfrequency, and underspeed monitoring are not performed during this time.	
	✓	✓	✓	✓		
EN	During emerg/critical				Engine: Idle mode possible during AMF / critical operation	YES / NON
DE	Während Notstrom/Sprinkler					
59	{0}	{1o}	{1oc}	{2oc}	YES If an AMF or sprinkler operation is enabled, the engine will go to rated speed only after completing the configured idle mode. NO If an AMF or critical operation is enabled, the idle mode will be overridden and the engine will go directly to rated speed.	
	✓	✓	✓	✓		



NOTE

The idle mode will be deactivated and normal operation monitoring limits (Parameter 254) will be enabled again, if one of the following conditions is fulfilled:

- Generator frequency and voltage are within the dead bus start limits (Parameter 65 and 66).
- Engine delayed monitoring (Parameter 55) has expired after the idle mode has ended.



NOTE

The analog inputs alternate limit of the analog inputs for the idle mode is configured with Parameter 255.

Breaker



Breaker: Operation Of The Circuit Breakers

Switching the pulses takes place in the following screen and has the described effect on the signal sequence (the MCB cannot be controlled by the continuous pulse for security reasons, because otherwise, the MCB would be opened in case of a failure/exchange of the easYgen). If the parameter "Auto unlock" is configured to YES, an open pulse will be issued prior to each close pulse. The parameter "Enable MCB" prevents the closing of the MCB. A closed MCB will not be opened.

Dead bus start GCB {1oc} or {2oc}

The GCB is closed, if the following conditions are met simultaneously:

Automatic operation

- The operating mode AUTOMATIC has been selected
- No class C alarm or higher is present
- The engine is running
- The engine delayed monitoring (Parameter 55) as well as the GCB breaker delay (Parameter 67) have been expired or the *LogicsManager* function "Undelayed close of GCB" (Parameter 64) is enabled
- The generator voltage and frequency are within the configured limits (Parameters 65 and 66)
- The MCB has been opened for at least the time configured in "Transfer time GCB↔MCB" (Parameter 72) ({2oc} only)
- The function "Start without load" (Parameter 23) has been disabled through the *LogicsManager*
- Only in critical mode: the parameter "Close GCB in override" (Parameter 32) is configured to YES

Manual operation

- The operating mode MANUAL has been selected.
- No class C alarm or higher is present
- The engine is running
- The engine delayed monitoring (Parameter 55) as well as the GCB breaker delay (Parameter 67) have been expired
- The generator voltage and frequency are within the configured limits (Parameters 65 and 66)
- The MCB has been open for at least the time configured in "Transfer time GCB↔MCB" (Parameter 72) ({2oc} only)
- The button "Close GCB" has been pressed

Dead bus start MCB {2oc}

The MCB is closed, if the following conditions are met simultaneously:

Automatic operation

- The operating mode AUTOMATIC has been selected
- The mains voltage is available and within the configured limits (Parameters 65 and 66)
- The GCB is open or has been opened for at least the "Transfer time GCB \leftarrow →MCB" (Parameter 72)
- "Enable MCB" (Parameter 71) is configured as ALWAYS or discrete input 6 is energized if configured as DI 6

Manual operation

- Operating mode MANUAL has been selected
- The mains voltage is available and within the configured limits (Parameters 65 and 66)
- The GCB is open or has been opened for at least the "Transfer time GCB \leftarrow →MCB" (Parameter 72)
- "Enable MCB" (Parameter 71) is configured as ALWAYS or discrete input 6 is energized if configured as DI 6
- The button "Close MCB" has been pressed

Open GCB {1o} or {1oc} or {2oc}

The GCB is opened when the relay "Command: GCB close" de-energizes (only if Parameter **62** "GCB close pulse" is configured as NO) and when the relay "Command GCB open" energizes. The GCB will be opened under the following circumstances.

- In STOP operating mode
- In case of a class C alarm or higher
- By pressing the button "GCB open" or "MCB close" (depending on the CB logic which has been set) in MANUAL operating mode
- By pressing the button "stop engine" in MANUAL operating mode
- In the event of an automatic stopping in the AUTOMATIC operating mode (the start request has been terminated or a stop request has been initiated)
- Prior to the MCB closing onto the dead busbar
- In critical mode (Sprinkler operation), provided that an emergency power operation is not active, and "Close GCB in override" (Parameter 32) has been configured to NO
- If "Start without load" has been enabled through the *LogicsManager*

Open MCB {2oc}

The MCB is opened when the relay "Command: MCB open" is energized. The MCB will be opened under the following circumstances.

- If an emergency power operation is initiated (mains failure) once the generator voltage is within the permissible limits
- Prior to the closure of the GCB
- Upon pressing the "MCB OPEN" or "GCB CLOSE" push-button (dependent upon the configured CB logic) in MANUAL operating mode

Breaker: GCB Settings



NOTE

Operating current (NO): The relay is enabled (i.e. in the operating state) when current flows through the coil. If a loss of the supply voltage occurs, the relay contacts will not transfer and a fault condition will not be monitored. In this mode of operation the state of the system should be monitored through other means than the state of the relay.

Closed circuit current (NC): The relay is disabled (i.e. in idle state) when current flows through the coil. The relay is energized in idle state. If a loss of the supply voltage occurs, the relay contacts will transfer and a fault condition will be monitored.




Figure 3-6: Operating / closed circuit current

EN	GCB open relay			
DE	GLS Öffnen-Kontakt			
60	{0}	{1o}	{1oc}	{2oc}
	---	✓	✓	✓

Breaker: "Command: GCB open" relay

N.O. / N.C.

N.O. (normally open) If the GCB is to be opened, the relay "command: GCB open" is energized. When the control receives the message "Reply: GCB is open", the relay is de-energized.

N.C. (normally closed) If the GCB is to be opened, the relay "command: GCB open" de-energizes. When the control receives the message "Reply: GCB is open", the relay is energized again.

EN	GCB time pulse			
DE	GLS Impulsdauer			
61	{0}	{1o}	{1oc}	{2oc}
	---	✓	✓	✓

Breaker: Pulse duration to close the GCB

0.04 to 1.00 s

The time of the pulse output may be adjusted to the breaker being utilized.

EN	GCB close pulse			
DE	GLS Schließen Impuls			
62	{0}	{1o}	{1oc}	{2oc}
	---	---	✓	✓

Breaker: "Command: GCB close" issue as pulse

YES / NO

YES..... Configured momentary output: The relay "Command: GCB close" issues an add-on pulse. If the relay is configured in this manner a holding coil and sealing contacts must be installed externally to the control unit. The DI "Reply: GCB closed" is used to identify closed contacts.

NO..... Configured maintaining output: The relay "Command: close GCB" may be wired directly into the holding circuit for the power circuit breaker. If this method is utilized it is recommended that isolation relays be used. After the connect pulse has been issued and the reply of the power circuit breaker has been received, the relay "Command: close GCB" remains energized. If a class C alarm or higher occurs or the GCB is opened, this relay de-energizes.

In both cases the relay "Command: GCB open" energizes to open the GCB.

		GCB auto unlock				Breaker: Breaker unblocking GCB		YES / NO	
		GLS auto entriegeln							
		{0}	{1o}	{1oc}	{2oc}				
63		---	---	✓	✓	<p>This is used for special circuit breakers to put the breaker into a defined initial state or to enable closing at all.</p> <p>YESBefore every close-pulse, an open-pulse is issued for 1 second. A CB close pulse is enabled only after the open pulse is issued.</p> <p>NOThe CB close pulse is enabled without being preceded by a CB open pulse.</p>			
		Undelayed close GCB				Breaker: Undelayed closing of the GCB		LogicsManager	
		GLS unverzögert							
		{0}	{1o}	{1oc}	{2oc}				
64		---	---	✓	✓	<p>Once the conditions of the <i>LogicsManager</i> have been fulfilled the GCB will be closed immediately (without waiting for the delayed by engine speed timer to expire). When using the standard setting, the GCB will be closed without delay in AMF operation. The <i>LogicsManager</i> and its default settings are explained on page 127 in Appendix B: "<i>LogicsManager</i>".</p>			
		GCB frequency window				Breaker: "Command: GCB close": maximum frequency deviation		0.2 to 10.0 %	
		GLS Frequenzabweichung							
		{0}	{1o}	{1oc}	{2oc}				
65		---	---	✓	✓	<p>① This value refers to the Rated system frequency (Parameter 3, see page 17).</p> <p>This is the maximum amount that the frequency will be allowed to deviate from the rated frequency and the "Command: GCB close" may be issued. This is to prevent the prime mover from going into an underfrequency condition due to overloading.</p>			
		GCB voltage window				Breaker: "Command: GCB close": maximum voltage deviation		1 to 100 %	
		GLS Spannungsabweichung							
		{0}	{1o}	{1oc}	{2oc}				
66		---	---	✓	✓	<p>① This value refers to the Rated generator voltage (Parameter 4, see page 17).</p> <p>This is the maximum amount that the voltage will be allowed to deviate from the rated voltage and the "Command: GCB close" may be issued.</p>			
		Gen. settling time				Breaker: "Command: GCB close": Breaker delay		0 to 99 s	
		GLS Schalterverzögerung							
		{0}	{1o}	{1oc}	{2oc}				
67		---	---	✓	✓	<p>The time configured here begins to count down once the engine monitoring delay timer has expired. This permits for an additional delay time before the breaker is closed in order to ensure that none of the engine delayed watchdogs trips. It is possible to bypass this delay time through the <i>LogicsManager</i> (see Parameter 64) in the event an emergency operation condition (mains failure) occurs.</p> <p>Background: This additional delay time, which starts upon expiration of the "delayed engine monitoring" is used to prevent unnecessary interruptions of the voltage supply of the consumers. This condition occurs during switching operations from the mains to the generator. Every time a switching operation occurs the bus is without voltage for a short time. The consumers can be supplied once the "GCB settling time" has been expired. If the GCB would be closed prior to expiration of the delayed engine monitoring (by enabling this via the <i>LogicsManager</i>) and an alarm would become active after expiration of the delayed engine monitoring, the GCB would have to be opened and the consumers would be without voltage again. Unnecessary CB switching operations and voltage interruptions should be avoided by utilizing this parameter.</p>			

Breaker: MCB Settings {2oc}

	DE	EN	MCB auto unlock				Breaker: Switch unblocking MCB	YES / NO
			NLS auto entriegeln					
			{0}	{1o}	{1oc}	{2oc}		
68			---	---	---	✓	<p>This is used for special circuit breakers to put the breaker into a defined initial state or to enable closing at all.</p> <p>This is used for special circuit breakers to put the breaker into a defined initial state or to enable closing at all.</p> <p>YES..... Before every close-pulse, an open-pulse is issued for 1 second. A CB close pulse is enabled only after the open pulse is issued.</p> <p>NO..... The CB close pulse is enabled without being preceded by a CB open pulse.</p>	
	DE	EN	Close MCB in stop mode				Breaker: Close MCB in STOP mode	YES / NO
			NLS schließen im Stopmodus					
			{0}	{1o}	{1oc}	{2oc}		
69			---	---	---	✓	<p>YES..... The MCB may be closed in the STOP operation mode as long as the closing conditions are fulfilled.</p> <p>NO..... The MCB cannot be closed in the STOP operation mode.</p>	
	DE	EN	MCB time impulse				Breaker: Impulse duration to close the MCB	0.04 to 1.00 s
			NLS Impulsdauer					
			{0}	{1o}	{1oc}	{2oc}		
70			---	✓	✓	✓	<p>The time of the pulse output may be adjusted to the breaker being utilized.</p>	
	DE	EN	Enable MCB				Breaker: Enable MCB	ALWAYS / DI6
			Freigabe NLS					
			{0}	{1o}	{1oc}	{2oc}		
71			---	---	---	✓	<p>ALWAYS The MCB is always enabled and the discrete input 6 may be configured freely.</p> <p>DI6 Enabling the MCB is performed by energizing discrete input 6 (Enable MCB).</p>	

Breaker: GCB/MCB Settings {2oc}

DE	Transfer time GCB↔MCB				Breaker: Transfer time GCB ↔ MCB	0.10 to 99.99 s
	Pausenzeit GLS↔NLS					
72	{0}	{1o}	{1oc}	{2oc}	Switching from generator supply to mains supply or from mains supply to generator supply occurs automatically if the operating conditions have been met. The time between the reply "power circuit breaker is open" and a close pulse is set by this parameter. This time applies for both directions. During this time the consumers are de-energized.	
	---	---	---	✓		

Emergency Power (AMF)



NOTE

The emergency power operation is possible only in application mode {20c} (2 power circuit breakers). If the function 'Stop in AUTO' or 'inhibit emergency power' has been assigned to a discrete input, an emergency power operation may be prevented or interrupted from an external source.

Prerequisite: The emergency power function can only be activated in the case of synchronous generators by the configuration screen "Emergency power ON". Emergency power is carried out in operating mode AUTOMATIC regardless of the status of the discrete input 'Start in AUTO' (*LogicsManager*).

Activation of emergency power: If a mains power fault is detected on at least one or more of terminals 14-21 for the duration of the time set in the "Emergency power delay time ON" screen, an emergency power operation is activated. A mains voltage fault is defined using the following limits:

Permissible predetermined limits

Mains	
Voltage	Parameter values (refer to "Protection/Mains failure detection "; page 75)
Frequency	Parameter values (refer to "Protection/Mains failure detection"; page 75)
Rotation	Parameter values (refer to "Protection/Mains phase rotation"; page 74)

Table 3-7: Permissible limits

The following principles are observed in the case of emergency power:

- If an emergency power operation is initiated, the engine is started under all circumstances, unless the start sequence is interrupted via an alarm or prevented via the *LogicsManager* or the operating mode is changed.
- The GCB can be closed regardless of the engine delay time after the dead bus starting limits have been reached if the parameter 64 has been set accordingly.
- If the mains return during an emergency power operation (GCB is closed), the mains settling time must expire before the load is transferred from the generator to mains operation.

MCB malfunction: The following is the protocol the unit follows when the control unit is in the AUTOMATIC operating mode, there has not been a start request, and the control unit is configured as emergency power standby. If the MCB opens, the control system attempts to reclose the breaker. If this is not possible (due to an MCB alarm), the engine is started due to the "MCB malfunction" if the parameter "Emergency power" is configured to "ON". Emergency power subsequently supplies the busbar. Only following the successful acknowledgment of the "MCB malfunction" alarm, is the GCB opened and the MCB closed and the engine shuts off again. Emergency power is also triggered via the detection of a switch fault when the MCB is switched on regularly. In order to achieve this, the "Emergency start with MCB failure" (Parameter 76) and "MCB monitoring" (Parameter 167) must be configured as "ON" .

Mains rotation field alarm: If the mains returns after a mains failure with a reversed rotation direction the generator remains in emergency power operation until the mains rotation matches the rotation of the generator set.

Protection



Protection: Alarm Acknowledgement

DE	Time until horn reset				Self acknowledgment of the centralized alarm (horn)	0 to 1,000 s
	Zeit Hupenreset					
78	{0}	{1o}	{1oc}	{2oc}	Alarm class A - Alarm class A messages are acknowledged using the "✓" button on the front panel. Alarm class B to F - After each alarm of this alarm class occurs, the alarm LED flashes and the command variable 03.05 (horn) is issued. After the delay time 'time until horn reset' has expired, the flashing LED changes into a steady light and the command variable 03.05 (horn) is reset. The alarm LED flashes until the alarm has been acknowledged either via the push button, the <i>LogicsManager</i> , or the interface. Note: If this parameter is configured to 0, the horn will remain active until it will be acknowledged.	
	✓	✓	✓	✓		

DE EN	External acknowledge				Protection: External acknowledgment of alarms	<i>LogicsManager</i>
	Ext. Quittierung					
79	{0}	{1o}	{1oc}	{2oc}	<p>It is possible to acknowledge all alarms simultaneously from remote, e.g. with a discrete input. The command variables of the <i>LogicsManager</i> have to become TRUE twice. The first time is for acknowledging the horn, the second for all alarm messages. The On-delay time is the minimum time the input signals have to be "1". The OFF-delay time is the time how long the input conditions have to be "0" before the next high signal is accepted. Once the conditions of the <i>LogicsManager</i> have been fulfilled the alarms will be acknowledged.</p>	
	✓	✓	✓	✓		

① The first high signal into the discrete input acknowledges the command variable 03.05 (horn). The second high signal acknowledges all inactive alarm messages.

The *LogicsManager* and its default settings are explained on page 127 in Appendix B: "*LogicsManager*".

Protection: Generator Protection

DE EN	Voltage monitoring generator				Generator protection: Type of monitoring	3 phase / 4 phase
	Spg.Überwachung Generator					
80	{0}	{1o}	{1oc}	{2oc}	The unit can either monitor the wye voltages (phase-neutral: 3ph-4w, 1ph-3w and 1ph-2w) or the delta voltages (phase-phase: 3ph-3w and 3ph-4w). Usually, for the low-voltage system the phase voltages are monitored, while for the medium to high voltage systems the delta voltages are monitored. The monitoring of the wye voltage is above all necessary to avoid earth-faults in a compensated or isolated network resulting in the tripping of the voltage protection.	
	---	✓	✓	✓		

WARNING:
This parameter influences the protective functions.

- 3 phase**The phase-phase voltage will be measured and all subsequent parameters concerning voltage monitoring "generator" are referred to this value (V_{L-L}).
- 4 phase**The phase-neutral voltage will be measured and all subsequent parameters concerning voltage monitoring "generator" are referred to this value (V_{L-N}).

Protection: Generator, Overfrequency (Limits 1 & 2) ANSI# 810

There are two overfrequency alarm levels available in the control. Both alarms are definite time alarms and are illustrated in the figure below. The figure diagrams a frequency trend and the associated pickup times and length of the alarms. It should be noted that this figure illustrates a limit 1 alarm that is self-acknowledged. Limit 2 alarms cannot be self-acknowledged. Monitoring of the frequency is accomplished in two steps. Three-phase measurement of the frequency is carried out, if all voltages are greater than 15 % of the rated value (120 V or 480 V). This permits a very rapid and accurate frequency measurement. The frequency however will be measured properly even if voltage is applied to one phase only.




Figure 3-8: Monitoring - generator overfrequency

Parameter table

The parameters represented in this table are specified in the following, whereas the description is identical for all limits; the limits may only differ in their setting ranges.

Limit	Text	Setting range	Default value
Overfrequency (The hysteresis is 0.05 Hz.)			
Limit 1	Monitoring	ON / OFF	ON
	Limit	50.0 to 130.0 %	110.0 %
	Delay	0.02 to 99.99 s	1.50 s
	Alarm class	A/B/C/D/E/F	B
	Self-acknowledgment	YES / NO	NO
Limit 2	Monitoring	ON / OFF	ON
	Limit	50.0 to 130.0 %	115.0 %
	Delay	0.02 to 99.99 s	0.30 s
	Alarm class	A/B/C/D/E/F	F
	Self-acknowledgment	YES / NO	NO

Table 3-9: Monitoring - standard values - generator overfrequency

EN	Monitoring			
DE	Überwachung			
	{0}	{1o}	{1oc}	{2oc}
81	---	✓	✓	✓

Gen.Overfrequency: Monitoring (limit 1/limit 2)**ON / OFF**

ONOverfrequency monitoring is carried out according to the following parameters. Monitoring is performed at two levels. Both values may be configured independent from each other (prerequisite: limit 1 < limit 2).

OFFMonitoring is disabled for limit 1 and/or limit 2.

EN	Limit			
DE	Limit			
	{0}	{1o}	{1oc}	{2oc}
82	---	✓	✓	✓

Gen.Overfrequency: Threshold value (limit 1/limit 2)**50.0 to 130.0 %**

❗ This value refers to the Rated system frequency (Parameter 3, see page 17).

The percentage values that are to be monitored for each threshold limit are defined here. If this value is reached or exceeded for at least the delay time without interruption, the action specified by the alarm class is initiated.

EN	Delay			
DE	Verzögerung			
	{0}	{1o}	{1oc}	{2oc}
83	---	✓	✓	✓

Gen.Overfrequency: Delay (limit 1/limit 2)**0.02 to 99.99 s**

If the monitored generator frequency value exceeds the threshold value for the delay time configured here, an alarm will be issued. If the monitored generator frequency falls below the threshold (minus the hysteresis) before the delay expires the time will be reset.

EN	Alarm class			
DE	Alarmklasse			
	{0}	{1o}	{1oc}	{2oc}
84	---	✓	✓	✓

Gen.Overfrequency: Alarm class (limit 1/limit 2)**Class A/B/C/D/E/F**

❗ See chapter "Alarm" on page 125.

The alarm class assigned to each limit alarm.

EN	Self acknowledge			
DE	Selbstquittierend			
	{0}	{1o}	{1oc}	{2oc}
85	---	✓	✓	✓

Gen. overfrequency: Self acknowledgment (limit 1/limit 2)**YES / NO**

YESThe control automatically clears the alarm if it is no longer valid.

NOAn automatic reset of the alarm does not occur. The reset occurs manually by pressing the appropriate buttons, by activating the *LogicsManager* output "External acknowledgement" via an discrete input, or via an interface.

Protection: Generator, Underfrequency (Limits 1 & 2) ANSI# 81U

There are two underfrequency alarm levels available in the control. Both alarms are definite time alarms and are illustrated in the figure below. The figure diagrams a frequency trend and the associated pickup times and length of the alarms. It should be noted that this figure illustrates a limit 1 alarm that is self-acknowledged. Limit 2 alarms cannot be self-acknowledged. Monitoring of the frequency is performed in two steps. Measuring of the frequency occurs three-phase, if all voltages are larger than 15 % of the rated frequency (120 V or 480 V). This permits quick and exact frequency measuring. The frequency however will be measured correctly even if voltage is applied only to one phase.




Figure 3-10: Monitoring - generator underfrequency

Parameter table

The parameters represented in this table are specified in the following, whereas the description is identical for all limits; the limits may only differ in their setting ranges.

Limit	Text	Setting range	Standard value
Underfrequency (The hysteresis is 0.05 Hz.)			
Limit 1	Monitoring	ON / OFF	ON
	Limit	50.0 to 130.0 %	90.0 %
	Delay	0.02 to 99.99 s	5.00 s
	Alarm class	A/B/C/D/E/F	B
	Self-acknowledgment	YES / NO	NO
	Delayed by engine speed	YES / NO	NO
Limit 2	Monitoring	ON / OFF	ON
	Limit	50.0 to 130.0 %	84.0 %
	Delay	0.02 to 99.99 s	0.30 s
	Alarm class	A/B/C/D/E/F	F
	Self-acknowledgment	YES / NO	NO
	Delayed by engine speed	YES / NO	NO

Table 3-11: Monitoring - Standard values - generator underfrequency

EN	Monitoring			
DE	Überwachung			
	{0}	{1o}	{1oc}	{2oc}
86	---	✓	✓	✓

Gen. underfrequency: Monitoring (Limit 1/Limit 2)**ON / OFF**

ON Underfrequency monitoring is carried out according to the following parameters. Monitoring is performed at two levels. Both values may be configured independent from each other (prerequisite: Limit 1 > Limit 2).

OFF Monitoring is disabled for limit 1 and/or limit 2.

EN	Limit			
DE	Limit			
	{0}	{1o}	{1oc}	{2oc}
87	---	✓	✓	✓

Gen. underfrequency: Threshold value (Limit 1/Limit 2)**50.0 to 130.0 %**

❗ This value refers to the Rated system frequency (Parameter 3, see page 17).

The percentage values that are to be monitored for each threshold limit are defined here. If this value is reached or fallen below for at least the delay time without interruption, the action specified by the alarm class is initiated.

EN	Delay			
DE	Verzögerung			
	{0}	{1o}	{1oc}	{2oc}
88	---	✓	✓	✓

Gen. underfrequency: Delay (Limit 1/Limit 2)**0.02 to 99.99 s**

If the monitored generator frequency value falls below the threshold value for the delay time configured here, an alarm will be issued. If the monitored generator frequency exceeds the threshold (plus the hysteresis) again before the delay expires the time will be reset.

EN	Alarm class			
DE	Alarmklasse			
	{0}	{1o}	{1oc}	{2oc}
89	---	✓	✓	✓

Gen. underfrequency: Alarm class (Limit 1/Limit 2)**Class A/B/C/D/E/F**

❗ See chapter "Alarm" on page 125.

The alarm class assigned to each limit alarm.

EN	Self acknowledge			
DE	Selbstquittierend			
	{0}	{1o}	{1oc}	{2oc}
90	---	✓	✓	✓

Gen. underfrequency: Self acknowledgment (Limit 1/Limit 2)**YES / NO**

YES The control automatically clears the alarm if it is no longer valid.

NO An automatic reset of the alarm does not occur. The reset occurs manually by pressing the appropriate buttons, by activating the LogicsManager output "External acknowledgement" via an discrete input, or via an interface.

EN	Delayed by engine speed			
DE	Verzögert durch Motordrehz.			
	{0}	{1o}	{1oc}	{2oc}
91	---	✓	✓	✓

Gen. underfrequency Engine delayed monitoring (Limit 1/Limit 2)**YES / NO**

YES The alarm is delayed until engine monitoring is enabled. Therefore the conditions of Parameter 55 "Engine delayed monitoring" must be fulfilled.

NO The alarm is not delayed until engine monitoring is enabled. Fault conditions are immediately analyzed.

**NOTE**

This monitoring function is disabled in idle mode (see page 36).

Protection: Generator, Overvoltage (Limits 1 & 2) ANSI# 59

Power is monitored depending on Parameter 6 "Gen.voltage measuring" and Parameter 7 "Gen.current measuring". There are two overvoltage alarm levels available in the control. Both alarms are definite time alarms and are illustrated in the below figure. The figure diagrams a frequency trend and the associated pickup times and length of the alarms. It should be noted that this figure illustrates a limit 1 alarm that is self-acknowledged. Limit 2 alarms cannot be self-acknowledged. Monitoring of the voltage is done in two steps.




Figure 3-12: Monitoring - generator overvoltage

Parameter table

The parameters represented in this table are specified in the following, whereas the description is identical for all limits; the limits may only differ in their setting ranges.

Limit	Text	Setting range	Standard value
Overvoltage (The hysteresis is 0.7 % of the rated value)			
Limit 1	Monitoring	ON / OFF	ON
	Limit	50.0 to 125.0 %	108.0 %
	Delay	0.02 to 99.99 s	5.00 s
	Alarm class	A/B/C/D/E/F	B
	Self-acknowledgment	YES / NO	NO
	Engine delayed monitoring	YES / NO	NO
Limit 2	Monitoring	ON / OFF	ON
	Limit	50.0 to 125.0 %	112.0 %
	Delay	0.02 to 99.99 s	0.30 s
	Alarm class	A/B/C/D/E/F	F
	Self-acknowledgment	YES / NO	NO
	Engine delayed monitoring	YES / NO	NO

Table 3-13: Monitoring - standard values - generator overvoltage

EN	Monitoring			
DE	Überwachung			
	{0}	{1o}	{1oc}	{2oc}
92	---	✓	✓	✓

Gen. overvoltage: Monitoring (Limit 1/Limit 2)**ON / OFF**

ON Overvoltage monitoring is carried out according to the following parameters. Monitoring is performed at two levels. Both values may be configured independent from each other (prerequisite: limit 1 < limit 2).

OFF Monitoring is disabled for limit 1 and/or limit 2.

EN	Limit			
DE	Limit			
	{0}	{1o}	{1oc}	{2oc}
93	---	✓	✓	✓

Gen. overvoltage: Threshold value (Limit 1/Limit 2)**50.0 to 125.0 %**

❗ This value refers to the Rated generator voltage (Parameter 4, see page 17).

The percentage values that are to be monitored for each threshold limit are defined here. If this value is reached or exceeded for at least the delay time without interruption, the action specified by the alarm class is initiated.

EN	Delay			
DE	Verzögerung			
	{0}	{1o}	{1oc}	{2oc}
94	---	✓	✓	✓

Gen. overvoltage: Delay (Limit 1/Limit 2)**0.02 to 99.99 s**

If the monitored generator voltage exceeds the threshold value for the delay time configured here, an alarm will be issued. If the monitored generator voltage falls below the threshold (minus the hysteresis) before the delay expires the time will be reset.

EN	Alarm class			
DE	Alarmklasse			
	{0}	{1o}	{1oc}	{2oc}
95	---	✓	✓	✓

Gen. overvoltage: Alarm class (Limit 1/Limit 2)**Class A/B/C/D/E/F**

❗ See chapter "Alarm" on page 125.

The alarm class assigned to each limit alarm.

EN	Self acknowledge			
DE	Selbstquittierend			
	{0}	{1o}	{1oc}	{2oc}
96	---	✓	✓	✓

Gen. overvoltage: Self acknowledgment (Limit 1/Limit 2)**YES / NO**

YES The control automatically clears the alarm if it is no longer valid.

NO An automatic reset of the alarm does not occur. The reset occurs manually by pressing the appropriate buttons, by activating the LogicsManager output "External acknowledgement" via an discrete input, or via an interface.

EN	Delayed by engine speed			
DE	Verzögert durch Motordrehz.			
	{0}	{1o}	{1oc}	{2oc}
97	---	✓	✓	✓

Gen. overvoltage: Engine delayed monitoring (Limit 1/Limit 2)**YES / NO**

YES The alarm is delayed until engine monitoring is enabled. Therefore the conditions of Parameter 55 "Engine delayed monitoring" must be fulfilled.

NO The alarm is not delayed until engine monitoring is enabled. Fault conditions are immediately analyzed.

Protection: Generator, Undervoltage (Limits 1 & 2) ANSI# 27

Voltage is monitored depending on Parameter 6 "Gen.voltage measuring". There are two undervoltage alarm levels available in the control. Both alarms are definite time alarms and are illustrated in the below figure. The figure diagrams a frequency trend and the associated pickup times and length of the alarms. It should be noted that this figure illustrates a limit 1 alarm that is self-acknowledged. Limit 2 alarms cannot be self-acknowledged. Monitoring of the voltage is done in two steps.




Figure 3-14: Monitoring - generator undervoltage

Parameter table

The parameters represented in this table are specified in the following, whereas the description is identical for all limits; the limits may only differ in their setting ranges.

Limit	Text	Setting range	Standard value
Undervoltage (The hysteresis is 0.7 % of the rated value)			
Limit 1	Monitoring	ON / OFF	ON
	Limit	50.0 to 125.0 %	92.0 %
	Delay	0.02 to 99.99 s	5.00 s
	Alarm class	A/B/C/D/E/F	B
	Self-acknowledgment	YES / NO	NO
	Engine delayed monitoring	YES / NO	YES
Limit 2	Monitoring	ON / OFF	ON
	Limit	50.0 to 125.0 %	88.0 %
	Delay	0.02 to 99.99 s	3.00 s
	Alarm class	A/B/C/D/E/F	F
	Self-acknowledgment	YES / NO	NO
	Engine delayed monitoring	YES / NO	YES

Table 3-15: Monitoring - standard values - generator undervoltage

EN	Monitoring			
DE	Überwachung			
	{0}	{1o}	{1oc}	{2oc}
98	---	✓	✓	✓

Gen. undervoltage: Monitoring (Limit 1/Limit 2)**ON / OFF**

ON Undervoltage monitoring is carried out according to the following parameters. Monitoring is performed at two levels. Both values may be configured independent from each other (prerequisite: limit 1 < limit 2).

OFF Monitoring is disabled for limit 1 and/or limit 2.

EN	Limit			
DE	Limit			
	{0}	{1o}	{1oc}	{2oc}
99	---	✓	✓	✓

Gen. undervoltage: Threshold value (Limit 1/Limit 2)**50.0 to 125.0 %**

❗ This value refers to the Rated generator voltage (Parameter 4, see page 17).

The percentage values that are to be monitored for each threshold limit are defined here. If this value is reached or fallen below for at least the delay time without interruption, the action specified by the alarm class is initiated.

EN	Delay			
DE	Verzögerung			
	{0}	{1o}	{1oc}	{2oc}
100	---	✓	✓	✓

Gen. undervoltage: Delay (Limit 1/Limit 2)**0.02 to 99.99 s**

If the monitored generator voltage falls below the threshold value for the delay time configured here, an alarm will be issued. If the monitored generator voltage exceeds the threshold (plus the hysteresis) again before the delay expires the time will be reset.

EN	Alarm class			
DE	Alarmklasse			
	{0}	{1o}	{1oc}	{2oc}
101	---	✓	✓	✓

Gen. undervoltage: Alarm class (Limit 1/Limit 2)**Class A/B/C/D/E/F**

❗ See chapter "Alarm" on page 125.

The alarm class assigned to each limit alarm.

EN	Self acknowledge			
DE	Selbstquittierend			
	{0}	{1o}	{1oc}	{2oc}
102	---	✓	✓	✓

Gen. undervoltage: Self acknowledgment (Limit 1/Limit 2)**YES / NO**

YES The control automatically clears the alarm if it is no longer valid.

NO An automatic reset of the alarm does not occur. The reset occurs manually by pressing the appropriate buttons, by activating the LogicsManager output "External acknowledgement" via an discrete input, or via an interface.

EN	Delayed by engine speed			
DE	Verzögert durch Motordrehz.			
	{0}	{1o}	{1oc}	{2oc}
103	---	✓	✓	✓

Gen. undervoltage: Delayed engine speed (Limit 1/Limit 2)**YES / NO**

YES The alarm is delayed until engine monitoring is enabled. Therefore the conditions of Parameter 55 "Engine delayed monitoring" must be fulfilled.

NO The alarm is not delayed until engine monitoring is enabled. Fault conditions are immediately analyzed.

**NOTE**

This monitoring function is disabled in idle mode (see page 36).

Protection: Generator, Time-Overcurrent Monit. (Limits 1, 2 & 3) ANSI# 50/51

Current is monitored depending on Parameter 7 "Gen.current measuring". The generator overcurrent alarm contains three limits and can be setup as a step definite time overcurrent alarm as illustrated in the figure below. Monitoring of the maximum phase current is performed in three steps. Every step can be provided with a delay time independent of the other steps.




Figure 3-16: Monitoring - generator time-overcurrent

Parameter table

The parameters represented in this table are specified in the following, whereas the description is identical for all limits; the limits may only differ in their setting ranges.

Limit	Text	Setting range	Standard value
Overcurrent (The hysteresis is 1 % of the rated value)			
Limit 1	Monitoring	ON / OFF	ON
	Limit	50.0 to 300.0 %	110.0 %
	Delay	0.02 to 99.99 s	30.00 s
	Alarm class	A/B/C/D/E/F	E
	Self-acknowledgment	YES / NO	NO
Limit 2	Monitoring	ON / OFF	ON
	Limit	50.0 to 300.0 %	150.0 %
	Delay	0.02 to 99.99 s	1.00 s
	Alarm class	A/B/C/D/E/F	F
	Self-acknowledgment	YES / NO	NO
Limit 3	Monitoring	ON / OFF	ON
	Limit	50.0 to 300.0 %	250.0 %
	Delay	0.02 to 99.99 s	0.40 s
	Alarm class	A/B/C/D/E/F	F
	Self-acknowledgment	YES / NO	NO

Table 3-17: Monitoring - standard values - generator time-overcurrent

EN	Monitoring			
DE	Überwachung			
	{0}	{1o}	{1oc}	{2oc}
104	---	✓	✓	✓

Gen. overcurrent, TOC: Monitoring (Limit 1/Limit 2/Limit 3)**ON / OFF**

ONOvercurrent monitoring is carried out according to the following parameters. Monitoring is performed at three levels. All three values may be configured independent from each other (prerequisite: Limit 1 < Limit 2 < Limit 3).

OFFMonitoring is disabled for limit 1, limit 2, and/or limit 3.

EN	Limit			
DE	Limit			
	{0}	{1o}	{1oc}	{2oc}
105	---	✓	✓	✓

Gen. overcurrent, TOC: Threshold value (Limit 1/Limit 2/Limit 3)**50.0 to 300.0 %**

❗ This value refers to the Rated current (Parameter 11, see page 17).

The percentage values that are to be monitored for each threshold limit are defined here. If this value is reached or exceeded for at least the delay time without interruption, the action specified by the alarm class is initiated.

EN	Delay			
DE	Verzögerung			
	{0}	{1o}	{1oc}	{2oc}
106	---	✓	✓	✓

Gen. overcurrent, TOC: Delay (Limit 1/Limit 2/Limit 3)**0.02 to 99.99 s**

If the monitored generator current exceeds the threshold value for the delay time configured here, an alarm will be issued. If the monitored generator current falls below the threshold (minus the hysteresis) before the delay expires the time will be reset.

EN	Alarm class			
DE	Alarmklasse			
	{0}	{1o}	{1oc}	{2oc}
107	---	✓	✓	✓

Gen. overcurrent, TOC: Alarm class (Lim.1/Lim.2/Lim.3)**Class A/B/C/D/E/F**

❗ See chapter "Alarm" on page 125.

The alarm class assigned to each limit alarm.

EN	Self acknowledge			
DE	Selbstquittierend			
	{0}	{1o}	{1oc}	{2oc}
108	---	✓	✓	✓

Gen. overcurrent, TOC: Self acknowledgment (Limit 1/Limit 2/Limit 3)**ON / OFF**

YESThe control automatically clears the alarm if it is no longer valid.

NOAn automatic reset of the alarm does not occur. The reset occurs manually by pressing the appropriate buttons, by activating the LogicsManager output "External acknowledgement" via an discrete input, or via an interface.

Protection: Generator, Reverse/Reduced Power (Limits 1 & 2) ANSI# 32R/F

Power is monitored depending on Parameter 6 "Gen.voltage measuring" and Parameter 7 "Gen.current measuring". The generator power limits may be setup as reduced power and/or reverse power depending on the threshold value configured in the control. The note below explains how a reduced or reverse power limit is configured. If the single- or three-phase measured real power is below the adjusted limit of the reduced load or below the adjusted value of the reverse power the alarm will be issued.



NOTE

Definition

- **Reduced power**
Tripping if the real power has fallen below the (positive) limit..
- **Reverse power**
Tripping if the direction of the real power reverses and the (negative) limit is exceeded.

The values for reverse /reduced power monitoring can be configured as follows:

- Limit 1 (Limit 1) = **Positive** and
Limit 2 (Limit 2) = **Positive** (whereas Limit 2 > Limit 1 > 0 %):
⇒ Both limits are reduced power monitoring.
- Limit 1 (Limit 1) = **Negative** and
Limit 2 (Limit 2) = **Negative** (whereas Limit 2 < Limit 1 < 0%):
⇒ Both limits are reverse power monitoring.
- Limit 1 (Limit 1) = **Positive** and
Limit 2 (Limit 2) = **Negative** (whereas Limit 1 > 0 % > Limit 2):
⇒ Limit 1 is reduced power monitoring and
⇒ Limit 2 is reverse power monitoring.




Figure 3-18: Monitoring - generator reverse / reduced power

Parameter table

The parameters represented in this table are specified in the following, whereas the description is identical for all limits; the limits may only differ in their setting ranges.

Limit	Text	Setting range	Standard value
Reverse / reduced power (The hysteresis is 1 % of the rated value)			
Limit 1	Monitoring	ON / OFF	ON
	Limit	-99.9 to 99.0 %	-3.0 %
	Delay	0.02 to 99.99 s	5.00 s
	Alarm class	A/B/C/D/E/F	B
	Self-acknowledgment	YES / NO	NO
Limit 1 > 0 % Red. power	Engine delayed monitoring	YES / NO	NO
	Rev. power	YES / NO	NO
Limit 2	Monitoring	ON / OFF	ON
	Limit	-99.9 to 99.0 %	-5.0 %
	Delay	0.02 to 99.99 s	3.00 s
	Alarm class	A/B/C/D/E/F	E
	Self-acknowledgment	YES / NO	NO
Limit 2 > 0 % Red. power	Engine delayed monitoring	YES / NO	NO
	Rev. power	YES / NO	NO

Table 3-19: Monitoring - standard values - generator reverse / reduced power

<div>DE</div> <div>EN</div>					Monitoring				Gen. reverse/reduced power: Monitoring (Limit 1/Limit 2)		ON / OFF			
					Überwachung									
					{0}	{1o}	{1oc}	{2oc}						
109					---	✓	✓	✓	ON..... Reverse/reduced power monitoring is carried out according to the following parameters. Both values may be configured independent from each other (prerequisite for {1oc}, {2oc}: GCB must be closed).					
									OFF..... Monitoring is disabled for limit 1 and/or limit 2.					
<div>DE</div> <div>EN</div>					Limit				Gen. reverse/reduced power: Threshold value (Limit 1/Limit 2)				-99.9 to 99.0 %	
					Limit									
					{0}	{1o}	{1oc}	{2oc}	ⓘ This value refers to the Rated active power (Parameter 10, see page 17).					
110					---	✓	✓	✓	The percentage values that are to be monitored for each threshold limit are defined here. If this value is reached or fallen below for at least the delay time without interruption, the action specified by the alarm class is initiated.					
<div>DE</div> <div>EN</div>					Delay				Gen. reverse/reduced power: Delay (Limit 1/Limit 2)				0.02 to 99.99 s	
					Verzögerung									
					{0}	{1o}	{1oc}	{2oc}	If the monitored generator power falls below the threshold value for the delay time configured here, an alarm will be issued. If the monitored generator power exceeds or falls below the threshold (plus/minus the hysteresis) again before the delay expires the time will be reset.					
111					---	✓	✓	✓						
<div>DE</div> <div>EN</div>					Alarm class				Gen. reverse/reduced power: Alarm cl.(Lim.1/Lim.2)				Class A/B/C/D/E/F	
					Alarmklasse									
					{0}	{1o}	{1oc}	{2oc}	ⓘ See chapter "Alarm" on page 125.					
112					---	✓	✓	✓	The alarm class assigned to each limit alarm.					
<div>DE</div> <div>EN</div>					Self acknowledge				Gen. reverse/reduced power: Self acknowledgment (Limit 1/Limit 2)				YES / NO	
					Selbstquittierend									
					{0}	{1o}	{1oc}	{2oc}	YES..... The control automatically clears the alarm if it is no longer valid.					
113					---	✓	✓	✓	NO..... An automatic reset of the alarm does not occur. The reset occurs manually by pressing the appropriate buttons, by activating the LogicsManager output "External acknowledgement" via an discrete input, or via an interface.					
<div>DE</div> <div>EN</div>					Delayed by engine speed				Gen. reverse/reduced power: Engine delayed monitoring (Limit 1/Limit 2)				YES / NO	
					Verzögert durch Motordrehz.									
					{0}	{1o}	{1oc}	{2oc}	YES..... The alarm is delayed until engine monitoring is enabled. Therefore the conditions of Parameter 55 "Engine delayed monitoring" must be fulfilled.					
114					---	✓	✓	✓	NO..... The alarm is not delayed until engine monitoring is enabled. Fault conditions are immediately analyzed.					

Protection: Engine/Generator, Overload (Limits 1 & 2) ANSI# 32

Power is monitored depending on Parameter 6 "Gen.voltage measuring" and Parameter 7 "Gen.current measuring". If the real power is above the configured limit an alarm will be issued.




Figure 3-20: Monitoring - generator overload

Parameter table

The parameters represented in this table are specified in the following, whereas the description is identical for all limits; the limits may only differ in their setting ranges.

Limit	Text	Setting range	Standard value
Overload (The hysteresis is 1 % of the rated value)			
Limit 1	Monitoring	ON / OFF	ON
	Limit	50.0 to 300.0 %	110.0 %
	Delay	0.02 to 99.99 s	11.00 s
	Alarm class	A/B/C/D/E/F	B
	Self-acknowledgment	YES / NO	NO
Limit 2	Monitoring	ON / OFF	ON
	Limit	50.0 to 300.0 %	120.0 %
	Delay	0.02 to 99.99 s	0.10 s
	Alarm class	A/B/C/D/E/F	E
	Self-acknowledgment	YES / NO	NO

Table 3-21: Monitoring - standard values - generator overload

EN	Monitoring
DE	Überwachung
	{0} {1o} {1oc} {2oc}

115 --- ✓ ✓ ✓

Gen. overload: Monitoring (Limit 1/Limit 2)

ON / OFF

ON..... Overload monitoring is carried out according to the following parameters. Monitoring is performed at two levels. Both values may be configured independent from each other (prerequisite: limit 1 < limit 2).

OFF..... Monitoring is disabled for limit 1 and/or limit 2.

EN	Limit
DE	Limit
	{0} {1o} {1oc} {2oc}

116 --- ✓ ✓ ✓

Gen. overload: Threshold value (Limit 1/Limit 2)

50.0 to 300.00 %

① This value refers to the Rated active power (Parameter 10, see page 17).

The percentage values that are to be monitored for each threshold limit are defined here. If this value is reached or exceeded for at least the delay time without interruption, the action specified by the alarm class is initiated.

EN	Delay
DE	Verzögerung
	{0} {1o} {1oc} {2oc}

117 --- ✓ ✓ ✓

Gen. overload: Delayed (Limit 1/Limit 2)

0.02 to 99.99 s

If the monitored generator load exceeds the threshold value for the delay time configured here, an alarm will be issued. If the monitored generator load falls below the threshold (minus the hysteresis) before the delay expires the time will be reset.

EN	Alarm class
DE	Alarmklasse
	{0} {1o} {1oc} {2oc}

118 --- ✓ ✓ ✓

Gen. overload: Alarm class (Limit 1/Limit 2)

Class A/B/C/D/E/F

① See chapter "Alarm" on page 125.

The alarm class assigned to each limit alarm.-

EN	Self acknowledge
DE	Selbstquittierend
	{0} {1o} {1oc} {2oc}

119 --- ✓ ✓ ✓

Gen. overload: Self acknowledgment (Limit 1/Limit 2)

YES / NO

YES..... The control automatically clears the alarm if it is no longer valid.

NO..... An automatic reset of the alarm does not occur. The reset occurs manually by pressing the appropriate buttons, by activating the LogicsManager output "External acknowledgement" via an discrete input, or via an interface.

Protection: Generator, Unbalanced Load (Limits 1 & 2) ANSI# 46

Power is monitored depending on Parameter 6 "Gen.voltage measuring" and Parameter 7 "Gen.current measuring". The generator unbalanced load alarm is a phase imbalance alarm. The percentage threshold value indicates the permissible variation of phase current from the arithmetic mean value of all three-phase currents.




Figure 3-22: Monitoring - generator unbalanced load

Parameter table

The parameters represented in this table are specified in the following, whereas the description is identical for all limits; the limits may only differ in their setting ranges.

Limit	Text	Setting range	Standard value
Unbalanced load (The hysteresis is 1 % of the rated value)			
Limit 1	Monitoring	ON / OFF	ON
	Limit	0.0 to 100.0 %	10.0 %
	Delay	0.02 to 99.99 s	10.00 s
	Alarm class	A/B/C/D/E/F	B
	Self-acknowledgment	YES / NO	NO
	Delayed by engine speed	YES / NO	NO
Limit 2	Monitoring	ON / OFF	ON
	Limit	0.0 to 100.0 %	15.0 %
	Delay	0.02 to 99.99 s	1.00 s
	Alarm class	A/B/C/D/E/F	E
	Self-acknowledgment	YES / NO	NO
	Delayed by engine speed	YES / NO	NO

Table 3-23: Monitoring - standard values - generator unbalanced load

Formulas for calculation

	Phase L1	Phase L2	Phase L3
Exceeding	$I_{L1} \geq \frac{3 \times I_N \times P_A + I_{L2} + I_{L3}}{2}$	$I_{L2} \geq \frac{3 \times I_N \times P_A + I_{L1} + I_{L3}}{2}$	$I_{L3} \geq \frac{3 \times I_N \times P_A + I_{L1} + I_{L2}}{2}$
Undershooting	$I_{L1} \leq \frac{I_{L2} + I_{L3} - 3 \times I_N \times P_A}{2}$	$I_{L2} \leq \frac{I_{L1} + I_{L3} - 3 \times I_N \times P_A}{2}$	$I_{L3} \leq \frac{I_{L1} + I_{L2} - 3 \times I_N \times P_A}{2}$

Example 1 - exceeding of a limit value

Current in phase L1 = current in phase L3

Current in phase L2 has been **exceeded** P_A percentage tripping value (here 10 %) I_N rated current (here 300 A)

Tripping value for phase L2:

$$I_{L2} \geq \frac{3 \times I_N \times P_A + I_{L1} + I_{L3}}{2} = \frac{3 \times 300A \times 10\% + 300A + 300A}{2} = \frac{\frac{3 \times 300A \times 10}{100} + 300A + 300A}{2} = 345A$$

Example 2 - undershooting of a limit value

Current in phase L2 = current in phase L3

Current in phase L1 has been **undershot** P_A percentage tripping value (here 10 %) I_N rated current (here 300 A)

Tripping value for phase L1:

$$I_{L1} \geq \frac{I_{L2} + I_{L3} - 3 \times I_N \times P_A}{2} = \frac{300A + 300A - 3 \times 300A \times 10\%}{2} = \frac{300A + 300A - \frac{3 \times 300A \times 10}{100}}{2} = 255A$$

Parameters

	DE	EN	Monitoring				Gen. unbalanced load: Monitoring (Limit 1/Limit 2)		ON / OFF
			Überwachung						
			{0}	{1o}	{1oc}	{2oc}			
120		---	✓	✓	✓	✓	ONUnbalanced load monitoring is carried out according to the following parameters. Monitoring is performed at two levels. Both values may be configured independent from each other (condition: Limit 1 < Limit 2).		
							OFFNo monitoring is carried out for either limit 1 or limit 2.		
	DE	EN	Limit				Gen. unbalanced load: Threshold value (Limit 1/Limit 2)		0.0 to 100.0 %
			Limit						
			{0}	{1o}	{1oc}	{2oc}			
121		---	✓	✓	✓	✓	ⓘ This value refers to the Rated current (Parameter 11, see page 19).		
The percentage values that are to be monitored for each threshold limit are defined here. If this value is reached or exceeded for at least the delay time without interruption, the action specified by the alarm class is initiated.									
	DE	EN	Delay				Gen. unbalanced load: Delay (Limit 1/Limit 2)		0.02 to 99.99 s
			Verzögerung						
			{0}	{1o}	{1oc}	{2oc}			
122		---	✓	✓	✓	✓	If the monitored load exceeds the threshold value for the delay time configured here, an alarm will be issued. If the monitored load exceeds or falls below the threshold (minus the hysteresis) before the delay expires the time will be reset.		
	DE	EN	Alarm class				Gen. unbalanced load: Alarm class (Limit 1/Limit 2)		Class A/B/C/D/E/F
			Alarmklasse						
			{0}	{1o}	{1oc}	{2oc}			
123		---	✓	✓	✓	✓	ⓘ See chapter "Alarm" on page 125.		
The alarm class assigned to each limit alarm.									
	DE	EN	Self acknowledge				Gen. unbalanced load: Self acknowledgment (Limit 1/Limit 2)		YES / NO
			Selbstquittierend						
			{0}	{1o}	{1oc}	{2oc}			
124		---	✓	✓	✓	✓	YESThe control automatically clears the alarm if it is no longer valid.		
NOAn automatic reset of the alarm does not occur. The reset occurs manually by pressing the appropriate buttons, by activating the LogicsManager output "External acknowledgement" via an discrete input, or via an interface.									
	DE	EN	Delayed by engine speed				Gen. unbalanced load: Engine delayed monitoring (Limit 1/Limit 2)		YES / NO
			Verzögert durch Motordrehz.						
			{0}	{1o}	{1oc}	{2oc}			
125		---	✓	✓	✓	✓	YESThe alarm is delayed until engine monitoring is enabled. Therefore the conditions of Parameter 55 "Engine delayed monitoring" must be fulfilled.		
NOThe alarm is not delayed until engine monitoring is enabled. Fault conditions are immediately analyzed.									

**NOTE**

An alarm will only be issued for 3Ph-3W or 3Ph-4W applications and monitored 3-phase generator current.

Protection: Generator, Voltage Asymmetry

The generator voltage asymmetry alarm measures voltage differences between the phases of the generator. The voltage is measured three-phase. If the phase-to-phase voltage difference between the three phases exceeds the configured asymmetry limit the alarm will be issued.




Figure 3-24: Monitoring - generator voltage asymmetry

Parameter table

The parameters represented in this table are specified in the following, whereas the description is identical for all limits; the limits may only differ in their setting ranges.

Limit	Text	Setting range	Standard value
Generator voltage asymmetry (The hysteresis is 0.7 % of the rated value).			
	Monitoring	ON / OFF	ON
	Limit	0.5 to 99.9 %	10.0 %
	Delay	0.02 to 99.99 s	5.00 s
	Alarm class	A/B/C/D/E/F	F
	Self-acknowledgment	YES / NO	NO
	Engine delayed monitoring	YES / NO	YES

Table 3-25: Monitoring - standard values - generator voltage asymmetry

EN	Monitoring
DE	Überwachung
	{0} {1o} {1oc} {2oc}
126	--- ✓ ✓ ✓

Gen. voltage asymmetry: Monitoring**ON / OFF**

ON Voltage asymmetry monitoring is carried out according to the following parameters.

OFF Monitoring is disabled.

EN	Limit
DE	Limit
	{0} {1o} {1oc} {2oc}
127	--- ✓ ✓ ✓

Gen. voltage asymmetry: Threshold value**0.5 to 99.9 %**

❗ This value refers to Rated generator voltage (Parameter 4, see page 17).

The percentage values that are to be monitored for each threshold limit are defined here. If this value is reached or exceeded for at least the delay time without interruption, the action specified by the alarm class is initiated.

EN	Delay
DE	Verzögerung
	{0} {1o} {1oc} {2oc}
128	--- ✓ ✓ ✓

Gen. voltage asymmetry: Delay**0.02 to 99.99 s**

If the monitored generator voltage asymmetry exceeds the threshold value for the delay time configured here, an alarm will be issued. If the monitored generator voltage asymmetry falls below the threshold (minus the hysteresis) before the delay expires the time will be reset.

EN	Alarm class
DE	Alarmklasse
	{0} {1o} {1oc} {2oc}
129	--- ✓ ✓ ✓

Gen. voltage asymmetry: Alarm class**Class A/B/C/D/E/F**

❗ See chapter "Alarm" on page 125.

The alarm class assigned to each limit alarm.

EN	Self acknowledge
DE	Selbstquittierend
	{0} {1o} {1oc} {2oc}
130	--- ✓ ✓ ✓

Gen. voltage asymmetry: Self acknowledgment**YES / NO**

YES The control automatically clears the alarm if it is no longer valid.

NO An automatic reset of the alarm does not occur. The reset occurs manually by pressing the appropriate buttons, by activating the LogicsManager output "External acknowledgement" via an discrete input, or via an interface.

EN	Delayed by engine speed
DE	Verzögert durch Motordrehz.
	{0} {1o} {1oc} {2oc}
131	--- ✓ ✓ ✓

Gen. voltage asymmetry: Engine delayed monitoring**YES / NO**

YES The alarm is delayed until engine monitoring is enabled. Therefore the conditions of Parameter 55 "Engine delayed monitoring" must be fulfilled.

NO The alarm is not delayed until engine monitoring is enabled. Fault conditions are immediately analyzed.

**NOTE**

An alarm will only be issued for 3Ph-3W applications and monitored 3Ph-4W voltage systems.

Protection: Generator, Ground Fault (Limits 1 & 2)

Mains current transformer is configured to mains current

(Please refer to Current Transformer on page 21)

Current is monitored depending on Parameter 7 "Gen.current measuring". The configured three conductor currents $I_{\text{Gen-L1}}$, $I_{\text{Gen-L2}}$ and $I_{\text{Gen-L3}}$ are vectorially summated ($I_S = I_{\text{Gen-L1}} + I_{\text{Gen-L2}} + I_{\text{Gen-L3}}$) and compared with the response value (the calculated actual value is indicated in the display). If the actual value rises over the response value, a ground fault is present, and an alarm is issued.



NOTE

Please consider that the installation location of the generator current transformers determines the protection area of the ground fault monitoring.




Figure 3-26: Monitoring - calculated generator ground fault

Test: If one of the current transformers is short-circuited while the others have rated current the actual value amounts to 100 %.

The ground current calculation does not consider the current in a possibly existing neutral conductor. In order to be able to consider the calculation result as ground current, the neutral conductor must not conduct an appreciable operating current.

The threshold value is indicated as a percentage. It refers likewise to the generator rated current and should be adjusted in practice because of asymmetries, which cannot be avoided, to at least 10 %.

Calculation




Figure 3-27: Monitoring - calculated generator ground current - vector diagram

The **sum current** I_s is calculated e.g. (after previous complex dismantling) geometrically/vectorially, as the pointers of the **phase currents** I_{L1} and I_{L2} are parallel shifted and lined up. The pointer, that between the neutral point and the point of the shifted **pointer** I_{L2}' results is the **sum current** I_s . In order to be able to add the pointers vectorially, these must be divided into their X- and Y-coordinates (I_{L2X} , I_{L2Y} , I_{L3X} and I_{L3Y}). Afterwards all X- and all Y-coordinates can be added by an addition and a subtraction.

Results of a calculation example:

Phase current $I_{L1} = I_{Rated} = 7 \text{ A}$

Phase current $I_{L2} = 6.5 \text{ A}$

Phase current $I_{L3} = 6 \text{ A}$

Sum current (ground fault current) $I_s = 0.866 \text{ A}$.

Mains current transformer is configured to ground current

(Please refer to Current Transformer on page 21)

In this case, the value measured at the mains/ground current input is monitored. The configured percentage refers to the rated transformer current value of the mains/ground current input.



NOTE

Please consider that the installation location of the ground current measurement determines the protection area of the ground fault monitoring.

Parameter table

The parameters represented in this table are specified in the following, whereas the description is identical for all limits; the limits may only differ in their setting ranges.

Limit	Text	Setting range	Standard value
Generator ground fault (The hysteresis is 0.7 % of the rated value)			
Limit 1	Monitoring	ON / OFF	OFF
	Limit	0 to 300 %	10 %
	Delay	0.02 to 99.99 s	0.20 s
	Alarm class	A/B/C/D/E/F	B
	Self-acknowledgment	YES / NO	NO
	Engine delayed monitoring	YES / NO	NO
Limit 2	Monitoring	ON / OFF	OFF
	Limit	0 to 300 %	30 %
	Delay	0.02 to 99.99 s	0.10 s
	Alarm class	A/B/C/D/E/F	F
	Self-acknowledgment	YES / NO	NO
	Engine delayed monitoring	YES / NO	NO

Table 3-28: Monitoring - standard values - generator ground fault

Parameter

		Gen. ground fault: Monitoring (Limit 1/Limit 2)				ON / OFF
		Überwachung				
		{0}	{1o}	{1oc}	{2oc}	
132	---	✓	✓	☑		
ON..... Ground current monitoring is carried out according to the following parameters. Monitoring is performed at two levels. Both values may be configured independent from each other (prerequisite: Limit 1 < Limit 2).						
OFF..... Monitoring is disabled for limit 1 and/or limit 2.						
		Gen. ground fault: Threshold value (Limit 1/Limit 2)				0 to 300 %
		Limit				
		Limit				
		{0}	{1o}	{1oc}	{2oc}	
133	---	✓	✓	☑		
① This value refers to the Rated current of the generator (Parameter 11, see page 19), if the ground current is calculated from the generator current values. It refers to the transformer rated current (Parameter 19, see page 21), if the ground current is measured directly.						
The percentage values that are to be monitored for each threshold limit are defined here. If this value is reached or exceeded for at least the delay time without interruption, the action specified by the alarm class is initiated.						
		Gen. ground fault: Delay (Limit 1/Limit 2)				0.02 to 99.99 s
		Verzögerung				
		{0}	{1o}	{1oc}	{2oc}	
134	---	✓	✓	☑		
If the monitored ground fault exceeds the threshold value for the delay time configured here, an alarm will be issued. If the monitored ground fault falls below the threshold (minus the hysteresis) before the delay expires the time will be reset.						
		Gen. ground fault: Alarm class (Limit 1/Limit 2)				Class A/B/C/D/E/F
		Alarmklasse				
		{0}	{1o}	{1oc}	{2oc}	
135	---	✓	✓	☑		
① See chapter "Alarm" on page 125.						
The alarm class assigned to each limit alarm.						
		Gen. ground fault: Self acknowledgment (Limit 1)				YES / NO
		Self acknowledge				
		Selbstquittierend				
		{0}	{1o}	{1oc}	{2oc}	
136	---	✓	✓	☑		
YES..... The control automatically clears the alarm if it is no longer valid.						
NO..... An automatic reset of the alarm does not occur. The reset occurs manually by pressing the appropriate buttons, by activating the LogicsManager output "External acknowledgement" via an discrete input, or via an interface.						
		Gen. ground fault: Engine delayed monitoring (Limit 1)				YES / NO
		Delayed by engine speed				
		Verzögert durch Motordrehz.				
		{0}	{1o}	{1oc}	{2oc}	
137	---	✓	✓	☑		
YES..... The alarm is delayed until engine monitoring is enabled. Therefore the conditions of Parameter 55 "Engine delayed monitoring" must be fulfilled.						
NO..... The alarm is not delayed until engine monitoring is enabled. Fault conditions are immediately analyzed.						

Protection: Generator, Voltage Phase Rotation



CAUTION

Please ensure during installation that all voltages applied to this unit are wired correctly to both sides of the circuit breaker. Failure to do so may result in damage to the control unit and/or generation equipment due to closing the breaker asynchronous or with mismatched phase rotations and phase rotation monitoring enabled at all connected components (engine, generator, breakers, cable, busbars, etc.).

This function may block a connection of systems with mismatched phases systems only under the fol-

lowing conditions:

- The voltages being measured are wired correctly with respect to the phase rotation at the measuring points (i.e. the voltage transformer in front and behind the circuit breaker)
- The measuring voltages are wired without angular phase shift or interruption from the measuring point to the control unit
- The measuring voltages are wired to the correct terminals of the control unit (i.e. L1 of the generator is connected with the terminal of the control unit which is intended for the L1 of the generator)

Correct phase rotation of the phase voltages ensures that damage will not occur during an open transition breaker closure to either the mains or the generator. The voltage phase rotation alarm checks the phase rotation of the voltages and the configured phase rotation to ensure they are identical. The directions of rotation are differentiated as "clockwise" and "counter clockwise". With a clockwise field the direction of rotation is "L1-L2-L3"; with a counter clockwise field the direction of rotation is "L1-L3-L2". If the control is configured for a clockwise rotation and the voltages into the unit are calculated as counterclockwise the alarm will be initiated. The direction of configured rotation being monitored by the control unit is displayed in the LCD.

Parameter table

The parameters represented in this table are specified in the following, whereas the description is identical for all limits; the limits may only differ in their setting ranges.

Limit	Text	Setting range	Standard value
Generator voltage phase direction fault (The hysteresis is 0.7 % of the rated value)			
	Direction	CW / CCW	CW
	Monitoring	ON / OFF	ON
	Alarm class	A/B/C/D/E/F	F
	Self acknowledgment	YES / NO	NO
	Engine delayed monitoring	YES / NO	YES

Table 3-29: Monitoring - standard values - generator voltage phase rotation

		Generator phase rotation				Gen.voltage phase rotation: Direction		CW / CCW	
		Generatordrehfeld							
		{0}	{1o}	{1oc}	{2oc}				
138	---	✓	✓	✓	CW The three-phase measured generator voltage is rotating CW (clock-wise; that means the voltage rotates in direction L1-L2-L3; standard setting). CCW The three-phase measured generator voltage is rotating CCW (counter clock-wise; that means the voltage rotates in direction L1-L3-L2).				
		Monitoring				Gen.voltage phase rotation: Monitoring		ON / OFF	
		Überwachung							
		{0}	{1o}	{1oc}	{2oc}				
139	---	✓	✓	✓	ON Phase rotation monitoring is carried out according to the following parameters. OFF Monitoring is disabled.				
		Alarm class				Gen.voltage phase rotation: Alarm class		Class A/B/C/D/E/F	
		Alarmklasse							
		{0}	{1o}	{1oc}	{2oc}				
140	---	✓	✓	✓	① See chapter "Alarm" on page 125. The alarm class assigned to each limit alarm.				
		Self acknowledge				Gen.voltage phase rotation: Self-acknowledgment		YES / NO	
		Selbstquittierend							
		{0}	{1o}	{1oc}	{2oc}				
141	---	✓	✓	✓	YES The control automatically clears the alarm if it is no longer valid. NO An automatic reset of the alarm does not occur. The reset occurs manually by pressing the appropriate buttons, by activating the LogicsManager output "External acknowledgement" via an discrete input, or via an interface.				
		Delayed by engine speed				Gen.voltage phase rotation: Engine delayed monitoring		YES / NO	
		Verzögert durch Motordrehz.							
		{0}	{1o}	{1oc}	{2oc}				
142	---	✓	✓	✓	YES The alarm is delayed until engine monitoring is enabled. Therefore the conditions of Parameter 55 "Engine delayed monitoring" must be fulfilled. NO The alarm is not delayed until engine monitoring is enabled. Fault conditions are immediately analyzed.				

Protection: Generator, Inverse Time-Overcurrent Monitoring ANSI# IEC 255

Current is monitored depending on Parameter 7 "Gen.current measuring". The tripping time depends on the measured current. The higher the current is the faster the tripping time according to a defined curve. According to IEC 255 three different characteristics are available.

"Normal inverse" characteristic:
$$t = \frac{0.14}{(I/I_p)^{0.02} - 1} * t_p [s]$$

"Highly inverse" characteristic:
$$t = \frac{13.5}{(I/I_p) - 1} * t_p [s]$$

"Extremely inverse" characteristic:
$$t = \frac{80}{(I/I_p)^2 - 1} * t_p [s]$$

Data meaning:

t:	tripping time
t_p	setting value time
I	fault current; here measured current
I_p	setting value current

Please take into account during configuration:

for I start: $I_{start} > I_n$ and $I_{start} > I_p$

for I_p the smaller I_p is, the steeper is the slope of the tripping curve



NOTE

The maximum tripping time is 327s. If a higher tripping time is configured, no tripping will be performed.




Figure 3-30: Monitoring - generator inverse time-overcurrent - characteristic "Normal"




Figure 3-31: Monitoring - generator inverse time-overcurrent - characteristic "High"




Figure 3-32: Monitoring - generator inverse time-overcurrent - characteristic "Extreme"

Parameter table

The parameters represented in this table are specified in the following, whereas the description is identical for all limits; the limits may only differ in their setting ranges.

Limit	Text	Setting range	Standard value
Inverse time-overcurrent (The hysteresis is 1 % of the rated value)			
	Monitoring	ON / OFF	ON
	Overcurrent characteristic	Normal / High / Extreme	Normal
	Inv. time overcurrent Tp	0.01 to 1.99 s	0.06 s
	Inv. time overcurrent Ip	10.0 to 300.0 %	100.0 %
	Inv. time overcurrent I start	100.0 to 300.0 %	115.0 %
	Alarm class	A/B/C/D/E/F	F
	Self-acknowledgment	YES / NO	NO
	Engine delayed monitoring	YES / NO	NO

Table 3-33: Monitoring - standard values - generator inverse time-overcurrent

EN	Monitoring			
DE	Überwachung			
	{0}	{1o}	{1oc}	{2oc}
143	---	✓	✓	✓

Gen. overcurrent, inverse: Monitoring

ON / OFF

ONOvercurrent monitoring is carried out according to the following parameters.

OFFMonitoring is disabled.

EN	Inverse time characteristic			
DE	Überstrom Charakteristik			
	{0}	{1o}	{1oc}	{2oc}
144	---	✓	✓	✓

Gen. overcurrent, inverse: Tripping characteristic

Normal / High / Extreme

Selection of the used overcurrent characteristic.

NormalThe characteristic "normal inverse" will be used

HighThe characteristic "highly inverse" will be used

ExtremeThe characteristic "extremely inverse" will be used.

EN	Inv. time overcurrent			
DE	Überstrom (AMZ) Tp=			
	{0}	{1o}	{1oc}	{2oc}
145	---	✓	✓	✓

Gen. overcurrent, inverse: Time constant Tp

0.01 to 1.99 s

Time constant Tp to calculate the characteristics.

EN	Inv. time overcurr. Ip=			
DE	Überstrom (AMZ) Ip=			
	{0}	{1o}	{1oc}	{2oc}
146	---	✓	✓	✓

Gen. overcurrent, inverse: Current constant Ip

10.0 to 300.0 %

Current constant Ip to calculate the characteristics.

EN	Inv. time overcurr. I start=			
DE	Überstrom (AMZ) I-Start=			
	{0}	{1o}	{1oc}	{2oc}
147	---	✓	✓	✓

Gen. overcurrent, inverse: I start

100.0 to 300.0 %

Lower tripping value for inverse time-overcurrent protection. If the monitored current is below

I_{start} , the inverse time-overcurrent protection does not trip. If $I_{start} < I_p$, I_p is used as the lower tripping value.

DE	EN	Alarm class				Gen. overcurrent, inverse: Alarm class	Class A/B/C/D/E/F
		Alarmklasse					
148		{0}	{1o}	{1oc}	{2oc}	<div><div></div><div>① See chapter "Alarm" on page 125.</div></div>	
	---	✓	✓	✓			
The alarm class assigned to each limit alarm.							
DE	EN	Self acknowledge				Gen. overcurrent, inverse: Self acknowledgment	YES / NO
		Selbstquittierend					
149		{0}	{1o}	{1oc}	{2oc}	<div><div>YES.....</div><div>The control automatically clears the alarm if it is no longer valid.</div><div>NO.....</div><div>An automatic reset of the alarm does not occur. The reset occurs manually by pressing the appropriate buttons, by activating the LogicsManager output "External acknowledgement" via an discrete input, or via an interface.</div></div>	
	---	✓	✓	✓			
DE	EN	Delayed by engine speed				Gen. overcurrent, inverse: Engine delayed monitoring	YES / NO
		Verzögert durch Motordrehz.					
150		{0}	{1o}	{1oc}	{2oc}	<div><div>YES.....</div><div>The alarm is delayed until engine monitoring is enabled. Therefore the conditions of Parameter 55 "Engine delayed monitoring" must be fulfilled.</div><div>NO.....</div><div>The alarm is not delayed until engine monitoring is enabled. Fault conditions are immediately analyzed.</div></div>	
	---	✓	✓	✓			

Protection: Mains Protection {2oc}

DE	EN	Voltage monitoring mains				Mains protection: Type of monitoring	3 phase / 4 phase
		Spg.-Überwachung Netz					
151	{0}	{1o}	{1oc}	{2oc}	The unit can either monitor the wye voltages (phase-neutral: 3ph-4w, 1ph-3w and 1ph-2w) or the delta voltages (phase-phase: 3ph-3w and 3ph-4w). Usually, for the low-voltage system the wye voltages are monitored, while for the medium to high-voltage systems the delta voltages are monitored. The monitoring of the wye voltage is above all necessary to avoid earth-faults in a compensated or isolated network resulting in the tripping of the voltage protection.		
	---	✓	✓	✓			

WARNING:

This parameter influences the protective functions.

3 phase

.....

The delta (phase-phase) voltage will be measured and all subsequent parameters concerning voltage monitoring "generator" are referred to this value (V_{L-L}).

4 phase

.....

The wye (phase-neutral) voltage will be measured and all subsequent parameters concerning voltage monitoring "generator" are referred to this value (V_{L-N}).

Protection: Mains, Voltage Phase Rotation - {2oc}



CAUTION

Please ensure during installation that all voltages applied to this unit are wired correctly to both sides of the circuit breaker. Failure to do so may result in damage to the control unit and/or generation equipment due to closing the breaker asynchronous or with mismatched phase rotations and phase rotation monitoring enabled at all connected components (engine, generator, breakers, cable, busbars, etc.).

This function may block a connection of systems with mismatched phases systems only under the following conditions:

- The voltages being measured are wired correctly with respect to the phase rotation at the measuring points (i.e. the voltage transformer in front and behind the circuit breaker)
- The measuring voltages are wired without angular phase shift or interruption from the measuring point to the control unit
- The measuring voltages are wired to the correct terminals of the control unit (i.e. L1 of the generator is connected with the terminal of the control unit which is intended for the L1 of the generator)

Correct phase rotation of the phase voltages ensures that damage will not occur during an open transition breaker closure to either the mains or the generator. The voltage phase rotation alarm checks the phase rotation of the voltages and the configured phase rotation to ensure they are identical. The directions of rotation are differentiated as "clockwise" and "counter clockwise". With a clockwise field the direction of rotation is "L1-L2-L3"; with a counter clockwise field the direction of rotation is "L1-L3-L2". If the control is configured for a clockwise rotation and the voltages into the unit are calculated as counterclockwise the alarm will be initiated. The direction of configured rotation being monitored by the control unit is displayed in the LCD.

Parameter table

The parameters represented in this table are specified in the following, whereas the description is identical for all limits; the limits may only differ in their setting ranges.

Limit	Text	Setting range	Standard value
Mains voltage phase direction fault (The hysteresis is 0.7 % of the rated value)			
	Direction	CW / CCW	CW
	Monitoring	ON / OFF	ON
	Alarm class	A/B	B
	Self-acknowledgment	YES / NO	YES
	Engine delayed monitoring	YES / NO	NO

Table 3-34: Monitoring - standard values - mains voltage phase rotation

EN	Mains phase rotation			
DE	Netzdrehfeld			
	{0}	{1o}	{1oc}	{2oc}
152	---	---	---	✓

Mains voltage phase rotation: Direction

CW / CCW

CWThe three-phase measured mains voltage is rotating CW (clock-wise; that means the voltage rotates in direction L1-L2-L3; standard setting).

CCWThe three-phase measured mains voltage is rotating CCW (counter clock-wise; that means the voltage rotates in direction L1-L3-L2).

**NOTE**

A mains voltage rotation fault is carried out as mains failure (if the monitoring "mains voltage rotation fault" is enabled). One of the following actions is carried out:

- **Emergency power operation is enabled (ON):**
⇒ The MCB will not be closed and an emergency power operation is carried out.
- **Emergency power operation is disabled (OFF):**
⇒ The MCB will not be closed and an emergency power operation is NOT carried out.

		Monitoring					Mains voltage phase rotation: Monitoring	ON / OFF
		{0}	{1o}	{1oc}	{2oc}			
EN								
DE								
153		---	---	---	✓		ON..... Phase rotation monitoring is carried out according to the following parameters	
							OFF..... Monitoring is disabled.	

		Alarm class					Mains voltage phase rotation: Alarm class	Class A/B/C/D/E/F
		{0}	{1o}	{1oc}	{2oc}			
EN								
DE								
154		---	---	---	✓		→ CAUTION: If an alarm class that leads to an engine shutdown (alarm class C or higher) is configured into this parameter, a main phase rotation alarm may lead to an interruption of power.	
							ⓘ See chapter "Alarm" on page 125.	

The alarm class assigned to each limit alarm.

		Self acknowledge					Mains voltage phase rotation: Self-acknowledgment	YES / NO
		{0}	{1o}	{1oc}	{2oc}			
EN								
DE								
155		---	---	---	✓		YES..... The control automatically clears the alarm if it is no longer valid. NO..... An automatic reset of the alarm does not occur. The reset occurs manually by pressing the appropriate buttons, by activating the LogicsManager output "External acknowledgement" via a discrete input, or via an interface.	

		Delayed by engine speed					Mains voltage phase rotation: Engine delayed monitoring	YES / NO
		{0}	{1o}	{1oc}	{2oc}			
EN								
DE								
156		---	---	---	✓		YES..... The alarm is delayed until engine monitoring is enabled. Therefore the conditions of Parameter 55 "Engine delayed monitoring" must be fulfilled. NO..... The alarm is not delayed until engine monitoring is enabled. Fault conditions are immediately analyzed.	

Protection: Mains, Mains Failure Detection {2oc}

Voltage is monitored depending on Parameter 8 "Mains voltage measuring".

		High voltage threshold					Mains failure detection: Threshold value overvoltage	50.0 to 130.0 %
		{0}	{1o}	{1oc}	{2oc}			
EN								
DE								
157		---	---	---	✓		ⓘ This value refers to the Rated mains voltage (Parameter 5, see page 17).	
							This is the percentage of the rated voltage that determines if there has been a mains failure. If the value exceeds the configured limit, a mains failure is detected and an emergency power operation is initiated.	

EN	Low voltage threshold			
DE	Untere Grenzspannung			
	{0}	{1o}	{1oc}	{2oc}
158	---	---	---	✓

Mains failure detection: Threshold value undervoltage**50.0 to 130.0 %**

① This value refers to the Rated mains voltage (Parameter 5, see page 17).

The percentage threshold value that is to be monitored. If this value is reached or fallen below for at least the delay time without interruption, the action specified by the alarm class is initiated.

EN	Voltage hysteresis			
DE	Spannungshysterese			
	{0}	{1o}	{1oc}	{2oc}
159	---	---	---	✓

Mains failure detection: Hysteresis: Voltage**0.0 to 50.0 %**

① This value refers to the Rated mains voltage (Parameter 5, see page 17).

The percentage value configured in this parameter defines the upper and lower limits that permit for an assessment of the mains and if a failure has occurred. If the monitored value exceeds the configured limit, a mains failure has occurred and the emergency power operation is initiated. If the measured value is close to the configured limits (positive or negative deviation) the hysteresis value must be exceeded on negative deviations or fallen below on positive deviations for a mains failure to be assessed as having ended. This operation must occur for the configured mains settling time (Parameter 75). If the measured values fall below or exceed the limits before the failure delay time has expired, the failure delay timer is reset.

EN	High frequency threshold			
DE	Obere Grenzfrequenz			
	{0}	{1o}	{1oc}	{2oc}
160	---	---	---	✓

Mains failure detection: Threshold value overfrequency**70.0 to 160.0 %**

① This value refers to the Rated system frequency (Parameter 3, see page 17).

The percentage value configured in this parameter defines the upper limit threshold for the controller to monitor the mains and determine if a failure has occurred. If the monitored value exceeds the configured limit, a mains failure has occurred and an emergency power operation is initiated.

EN	Low frequency threshold			
DE	Untere Grenzfrequenz			
	{0}	{1o}	{1oc}	{2oc}
161	---	---	---	✓

Mains failure detection: Threshold value underfrequency**70.0 to 160.0 %**

① This value refers to the Rated system frequency (Parameter 3, see page 17).

The percentage value configured in this parameter defines the lower limit threshold for the controller to monitor the mains and determine if a failure has occurred. If the monitored value falls below the configured limit, a mains failure has occurred and an emergency power operation is initiated.

EN	Frequency hysteresis			
DE	Frequenzhysterese			
	{0}	{1o}	{1oc}	{2oc}
162	---	---	---	✓

Mains failure detection: Hysteresis: Frequency**0.0 to 50.0 %**

① This value refers to the Rated system frequency (Parameter 3, see page 17).

The percentage value configured in this parameter defines the upper and lower limits that permit for an assessment of the mains and if a failure has occurred. If the monitored value exceeds the configured limit, a mains failure has occurred and the emergency power operation is initiated. If the measured value is close to the configured limits (positive or negative deviation) the hysteresis value must be exceeded on negative deviations or fallen below on positive deviations for a mains failure to be assessed as having ended. This operation must occur for the configured mains settling time (Parameter 75). If the measured values fall below or exceed the limits before the failure delay time has expired, the failure delay timer is reset.

Protection: Breaker, Circuit Breaker Monitoring

Monitoring of the GCB

Circuit breaker monitoring contains two alarms: A breaker reclose alarm and a breaker open alarm.

Reclose Alarm: If the control initiates a close of the breaker and the breaker fails to close after the configured number of attempts the monitoring CB alarm will be initiated.

(See parameter Breaker monitoring GCB: Max. "GCB close" attempts).

Breaker Open Alarm: If the control is attempting to open the circuit breaker and it fails to see that the CB is open within the configured time in seconds after issuing the breaker open command then the monitoring CB alarm will be initiated.

(See parameter Breaker monitoring GCB: Max. time until reply "GCB has been opened").

Application mode {2oc}: The alarm classes have the following influence to the function of the unit.

Fault at 'closing the GCB'

- Alarm class A = no consequence
- Alarm class B: If the GCB can not be closed, the control is switched to mains operation if:
 - The mains voltage is within the necessary limits
 - The mains settling time has expired
 - The "Enable MCB" is set
 - If it is not possible to switch to mains operation the GCB attempts to continuously close.
- Alarm class C-F: If the GCB can not be closed, the engine is stopped and the unit switches to mains operation if:
 - The mains voltage is within the configured limits
 - The mains settling time has expired
 - The "Enable MCB" is set
 - If it is not possible to switch to mains operation the busbar remains de-energized (dead) until the GCB fault is acknowledged.

Fault at 'opening the GCB'

This alarm is operated according to the description of the alarm classes. During the reply that the GCB is still closed the MCB cannot be closed.

EN	GCB monitoring			
DE	GLS Überwachung			
	{0}	{1o}	{1oc}	{2oc}
163	---	✓	✓	✓

Circuit breaker monitoring GCB: Monitoring**ON / OFF**

ONMonitoring of the GCB is carried out according to the following parameters.

OFFMonitoring is disabled.

EN	GCB alarm class			
DE	GLS Alarmklasse			
	{0}	{1o}	{1oc}	{2oc}
164	---	✓	✓	✓

Circuit breaker monitoring GCB: Alarm class**Class A/B/C/D/E/F**

| ⓘ See chapter "Alarm" on page 125. |

The alarm class assigned to each limit alarm.

EN	GCB max. closing attempts			
DE	GLS ZU max. Schaltversuche			
	{0}	{1o}	{1oc}	{2oc}
165	---	---	✓	✓

Breaker monitoring GCB: Max. "GCB close" attempts**1 to 10**

The number of breaker closing attempts is configured in this parameter (relay output "Command: close CB"). When the breaker reaches the configured number of attempts, a GCB failure alarm is issued if the breaker is still open and the GCB open monitoring timer (Parameter 166) has expired.

EN	GCB open monitoring			
DE	GLS AUF Überwachung			
	{0}	{1o}	{1oc}	{2oc}
166	---	✓	✓	✓

Breaker monitoring GCB: Max. time until reply "GCB has been opened" 0.10 to 5.00 s

If the "Relay: GCB is open" is not energized once this timer expires, a GCB failure alarm is issued. This timer initiates as soon as the "open breaker" sequence begins. The alarm configured in Parameter 164 is issued.

Monitoring of the MCB {2oc}**NOTE**

If an alarm is detected when attempting to close the MCB, an emergency power operation will be carried out if the "Emergency power with MCB failure" is ON.

If an alarm class higher than 'B' class has been selected it will not be possible to start the engine with the setting "Emergency power with MCB failure" (Parameter 76) = configured as ON in an emergency power condition.

Circuit breaker monitoring contains two alarms: A breaker reclose alarm and a breaker open alarm.

Reclose Alarm: If the control initiates a close of the breaker and the breaker fails to close after the configured number of attempts the monitoring CB alarm will be initiated.

(See Parameter 165 Breaker monitoring MCB: Max. "MCB close" attempts).

Breaker Open Alarm: If the control is attempting to open the circuit breaker and it fails to see that the CB is open within the configured time in seconds after issuing the breaker open command then the monitoring CB alarm will be initiated.

(See Parameter 166 Breaker monitoring MCB: Max. time until reply "MCB has been opened").

The alarm classes have the following influence to the function of the unit.

Fault at 'closing the MCB'

- Alarm class A = no consequence
- Alarm class B

Parameter 73 "Emergency power" = OFF

If the MCB cannot be closed, the busbar remains without voltage, until the MCB breaker fault is acknowledged. The control continues attempting to close the MCB.

- Alarm class B

Parameter 73 "Emergency power" = ON, Parameter 76 "Emergency operation by MCB failure" = OFF

If the MCB cannot be closed, the busbar remains without voltage, until the MCB breaker fault is acknowledged. The control continues attempting to close the MCB.

- Alarm class B

Parameter 73 "Emergency power" = ON, Parameter 76 "Emergency operation by MCB failure" = ON

If the MCB cannot be closed, an emergency power operation is initiated after the emergency power delay time has expired (the engine is started and the GCB is closed; the busbar is supplied by the generator). If the alarm is acknowledged and if the MCB can be closed, the load is switched to mains supply and the emergency power operation terminates. Attempts to close the MCB are still performed until the generator has reached the dead bus start limits.

Fault at 'opening the MCB'

This fault is processed according to the action described within the alarm classes. As long as the reply is present that the MCB is still closed, the GCB cannot be closed.

		MCB monitoring				Circuit breaker monitoring MCB: Monitoring	ON / OFF
DE	N	NLS Überwachung					
		{0}	{1o}	{1oc}	{2oc}		
167		---	---	---	✓	ON..... Monitoring of the MCB is carried out according to the following parameters.	
						OFF..... Monitoring is disabled.	
		MCB alarm class				Circuit breaker monitoring MCB: Alarm class	Class A/B
DE	EN	NLS Alarmklasse					
		{0}	{1o}	{1oc}	{2oc}		
168		---	---	---	✓	❗ See chapter "Alarm" on page 125.	
The alarm class assigned to each limit alarm.							
		MCB max. closing attempts				Breaker monitoring MCB: Max. "GCB close" attempts	1 to 10
DE	EN	NLS ZU max. Schaltversuche					
		{0}	{1o}	{1oc}	{2oc}		
169		---	---	---	✓	The number of breaker closing attempts is configured in this parameter (relay output "Command: close CB"). When the breaker reaches the configured number of attempts, a MCB failure alarm is issued if the breaker is still open and the MCB open monitoring timer (Parameter 166) has expired.	
		MCB open monitoring				Breaker monitoring MCB: Max. time until reply "GCB has been opened" 0.10 to 5.00 s	
DE	EN	NLS AUF Überwachung					
		{0}	{1o}	{1oc}	{2oc}		
170		---	---	---	✓	If the "Relay: GCB is open" is not energized once this timer expires, a GCB failure alarm is issued. This timer initiates as soon as the "open breaker" sequence begins. The alarm configured in Parameter 164 is issued.	

Protection: Engine, Overspeed (Limits 1 & 2) ANSI# 12

The engine speed is monitored by a magnetic pickup unit (MPU) or by the frequency of the generator voltage. If the speed exceeds the overspeed limits the configured alarms will be initiated.




Figure 3-35: Monitoring - engine overspeed

Parameter table

The parameters represented in this table are specified in the following, whereas the description is identical for all limits; the limits may only differ in their setting ranges.

Limit	Text	Setting range	Standard value
Engine overspeed (The hysteresis is 50 min ⁻¹).			
Limit 1	Monitoring	ON / OFF	ON
	Limit	0 to 9,999 RPM	1,850 RPM
	Delay	0.02 to 99.99 s	1.00 s
	Alarm class	A/B/C/D/E/F	B
	Self-acknowledgment	YES / NO	NO
	Engine delayed monitoring	YES / NO	NO
Limit 2	Monitoring	ON / OFF	ON
	Limit	0 to 9,999 RPM	1,900 RPM
	Delay	0.02 to 99.99 s	0.10 s
	Alarm class	A/B/C/D/E/F	F
	Self-acknowledgment	YES / NO	NO
	Engine delayed monitoring	YES / NO	NO

Table 3-36: Monitoring - standard values - engine overspeed

EN	Monitoring				DE	Überwachung			
	{0}	{1o}	{1oc}	{2oc}		{0}	{1o}	{1oc}	{2oc}
171	---	✓	✓	✓					
Engine overspeed: Monitoring (Limit 1/Limit 2)					ON / OFF				
ON Overspeed monitoring of the engine speed is carried out according to the following parameters.									
OFF Monitoring is disabled for limit 1 and/or limit 2.									
EN	Limit				DE	Limit			
	{0}	{1o}	{1oc}	{2oc}		{0}	{1o}	{1oc}	{2oc}
172	---	✓	✓	✓					
Engine overspeed: Threshold value (Limit 1/Limit 2)					0 to 9,999 RPM				
The threshold values that are to be monitored are defined here. If the monitored engine speed reaches or exceeds this value for at least the delay time without interruption, the action specified by the alarm class is initiated.									
EN	Delay				DE	Verzögerung			
	{0}	{1o}	{1oc}	{2oc}		{0}	{1o}	{1oc}	{2oc}
173	---	✓	✓	✓					
Engine overspeed: Delay (Limit 1/Limit 2)					0.02 to 99.99 s				
If the monitored engine speed exceeds the threshold value for the delay time configured here, an alarm will be issued. If the monitored engine speed falls below the threshold (minus the hysteresis) before the delay expires the time will be reset.									
EN	Alarm class				DE	Alarmklasse			
	{0}	{1o}	{1oc}	{2oc}		{0}	{1o}	{1oc}	{2oc}
174	---	✓	✓	✓					
Engine overspeed: Alarm class (Limit 1/Limit 2)					Class A/B/C/D/E/F				
ⓘ See chapter "Alarm" on page 125.									
The alarm class assigned to each limit alarm.									
EN	Self acknowledge				DE	Selbstquittierend			
	{0}	{1o}	{1oc}	{2oc}		{0}	{1o}	{1oc}	{2oc}
175	---	✓	✓	✓					
Engine overspeed: Self acknowledgment (Limit 1/Limit 2)					YES / NO				
YES The control automatically clears the alarm if it is no longer valid.									
NO An automatic reset of the alarm does not occur. The reset occurs manually by pressing the appropriate buttons, by activating the LogicsManager output "External acknowledgement" via an discrete input, or via an interface.									
EN	Delayed by engine speed				DE	Verzögert durch Motordrehz.			
	{0}	{1o}	{1oc}	{2oc}		{0}	{1o}	{1oc}	{2oc}
176	---	✓	✓	✓					
Engine overspeed: Engine delayed monitoring (Limit 1/Limit 2)					YES / NO				
YES The alarm is delayed until engine monitoring is enabled. Therefore the conditions of Parameter 55 "Engine delayed monitoring" must be fulfilled.									
NO The alarm is not delayed until engine monitoring is enabled. Fault conditions are immediately analyzed.									

Protection: Engine, Underspeed (Limits 1 & 2)

The engine speed is monitored by a magnetic pickup unit (MPU) or by the frequency of the generator voltage. If the speed exceeds the underspeed limits the configured alarms will be initiated.




Figure 3-37: Monitoring - engine underspeed

Parameter table

The parameters represented in this table are specified in the following, whereas the description is identical for all limits; the limits may only differ in their setting ranges.

Limit	Text	Setting range	Standard value
Engine underspeed (The hysteresis is 50 min ⁻¹)			
Limit 1	Monitoring	ON / OFF	ON
	Limit	0 to 9,999 RPM	1,300 RPM
	Delay	0.02 to 99.99 s	1.00 s
	Alarm class	A/B/C/D/E/F	B
	Self-acknowledgment	YES / NO	NO
	Engine delayed monitoring	YES / NO	YES
Limit 2	Monitoring	ON / OFF	ON
	Limit	0 to 9,999 RPM	1,250 RPM
	Delay	0.02 to 99.99 s	0.10 s
	Alarm class	A/B/C/D/E/F	F
	Self-acknowledgment	YES / NO	NO
	Engine delayed monitoring	YES / NO	YES

Table 3-38: Monitoring - standard values - engine underspeed

		Monitoring				Engine underspeed: Monitoring (Limit 1/Limit 2)										ON / OFF	
		Überwachung															
		{0}	{1o}	{1oc}	{2oc}												
177		---	✓	✓	✓											ON..... Underspeed monitoring of the engine speed is carried out according to the following parameters. OFF..... Monitoring is disabled for limit 1 and/or limit 2.	
		Limit				Engine underspeed: Threshold value (Limit 1/Limit 2)										0 to 9,999 RPM	
		Limit															
		{0}	{1o}	{1oc}	{2oc}												
178		---	✓	✓	✓											The threshold values that are to be monitored are defined here. If the monitored engine speed reaches or falls below this value for at least the delay time without interruption, the action specified by the alarm class is initiated.	
		Delay				Engine underspeed: Delay (Limit 1/Limit 2)										0.02 to 99.99 s	
		Verzögerung															
		{0}	{1o}	{1oc}	{2oc}												
179		---	✓	✓	✓											If the monitored engine speed falls below the threshold value for the delay time configured here, an alarm will be issued. If the monitored engine speed exceeds the threshold (plus the hysteresis) again before the delay expires the time will be reset.	
		Alarm class				Engine underspeed: Alarm class (Limit 1/Limit 2)										Class A/B/C/D/E/F	
		Alarmklasse															
		{0}	{1o}	{1oc}	{2oc}												
180		---	✓	✓	✓											ⓘ See chapter "Alarm" on page 125.	
		The alarm class assigned to each limit alarm.															
		Self acknowledge				Engine underspeed: Self acknowledgment (Limit 1/Limit 2)										YES / NO	
		Selbstquittierend															
		{0}	{1o}	{1oc}	{2oc}												
181		---	✓	✓	✓											YES..... The control automatically clears the alarm if it is no longer valid. NO..... An automatic reset of the alarm does not occur. The reset occurs manually by pressing the appropriate buttons, by activating the LogicsManager output "External acknowledgement" via an discrete input, or via an interface.	
		Delayed by engine speed				Engine underspeed: Engine delayed monitoring (Limit 1/Limit 2)										YES / NO	
		Verzögert durch Motordrehz.															
		{0}	{1o}	{1oc}	{2oc}												
182		---	✓	✓	✓											YES..... The alarm is delayed until engine monitoring is enabled. Therefore the conditions of Parameter 55 "Engine delayed monitoring" must be fulfilled. NO..... The alarm is not delayed until engine monitoring is enabled. Fault conditions are immediately analyzed.	

ON..... Underspeed monitoring of the engine speed is carried out according to the following parameters.

OFF..... Monitoring is disabled for limit 1 and/or limit 2.

The threshold values that are to be monitored are defined here. If the monitored engine speed reaches or falls below this value for at least the delay time without interruption, the action specified by the alarm class is initiated.

If the monitored engine speed falls below the threshold value for the delay time configured here, an alarm will be issued. If the monitored engine speed exceeds the threshold (plus the hysteresis) again before the delay expires the time will be reset.

④ See chapter "Alarm" on page 125.

The alarm class assigned to each limit alarm.

YES..... The control automatically clears the alarm if it is no longer valid.

NO..... An automatic reset of the alarm does not occur. The reset occurs manually by pressing the appropriate buttons, by activating the LogicsManager output "External acknowledgement" via an discrete input, or via an interface.

YES..... The alarm is delayed until engine monitoring is enabled. Therefore the conditions of Parameter 55 "Engine delayed monitoring" must be fulfilled.

NO..... The alarm is not delayed until engine monitoring is enabled. Fault conditions are immediately analyzed.

Protection: Engine/Generator, Speed/Frequency Mismatch (Speed Detection)

Speed/frequency mismatch (n/f mismatch) checks if the generator voltage frequency f (determined from the measured generator voltage) differs from the measured engine speed n (determined from the Pickup signal) ($\Delta f-n$). If the two frequencies are not identical ($\Delta f-n \neq 0$), an alarm is output. Additionally the *LogicsManager* output "Firing speed" is checked upon its logical status with respect to the measuring values "generator frequency" and "Pickup speed".



NOTE

Speed/frequency mismatch (n/f mismatch) is carried out only if an MPU is connected to the control and Parameter 43, "Pickup", is configured ON. The following is valid:

- The measurement via **Pickup is enabled** (ON):
 ⇒ Mismatch monitoring is carried out using the engine speed from the Pickup and the generator frequency. If the speed/frequency mismatch or the *LogicsManager* is enabled and the frequency is outside of the configured limit, an alarm will be issued.
- The measurement via **Pickup is disabled** (OFF):
 ⇒ Mismatch monitoring is carried out using the generator frequency and the *LogicsManager*. If the *LogicsManager* output is enabled and the frequency is outside of the configured limit, an alarm will be issued.




Figure 3-39: Monitoring - plausibility check n/f

Parameter table

The parameters represented in this table are specified in the following, whereas the description is identical for all limits; the limits may only differ in their setting ranges.

Limit	Text	Setting range	Standard value
Speed/frequency mismatch (n/f mismatch) (The hysteresis is 50 RPM).			
	Monitoring	ON/OFF	ON
	Limit	1.5 to 8.5 Hz	5.0 Hz
	Delay	0.02 to 99.99 s	2.00 s
	Monitoring frequency	15 to 85 Hz	20 Hz
	Alarm class	A/B/C/D/E/F	E
	Self-acknowledgment	YES/NO	NO

Table 3-40: Monitoring - standard values - plausibility control n/f

EN	Monitoring	n/f/ <i>LogicsManager</i> mismatch: Monitoring	ON / OFF
DE	Überwachung		
183	{0} {1o} {1oc} {2oc}	ON..... Monitoring of the speed/frequency/ <i>LogicsManager</i> mismatch (n/f/ <i>LM</i> mismatch) is carried out according to the following parameters. OFF..... Monitoring is disabled.	
EN	Mismatch limit	n/f/ <i>LogicsManager</i> mismatch: Threshold value	1.5 to 8.5 Hz
DE	Zulässige Differenz		
184	{0} {1o} {1oc} {2oc}	The frequency mismatch that is to be monitored is defined here. If the monitored frequency mismatch reaches or exceeds this value for at least the delay time without interruption, the action specified by the alarm class is initiated. The <i>LogicsManager</i> is monitored with respect to his status.	
EN	Delay	n/f/ <i>LogicsManager</i> mismatch: Delay	0.02 to 99.99 s
DE	Verzögerung		
185	{0} {1o} {1oc} {2oc}	If the monitored frequency mismatch exceeds the threshold value for the delay time configured here, an alarm will be issued. If the monitored frequency mismatch falls below the threshold (minus the hysteresis) before the delay expires the time will be reset.	
EN	Activation frequency	n/f/ <i>LogicsManager</i> mismatch: Start-up frequency	15 to 85 Hz
DE	Überwachung ab		
186	{0} {1o} {1oc} {2oc}	The speed/frequency mismatch monitoring is enabled at this generator frequency.	
EN	Alarm class	n/f/ <i>LogicsManager</i> mismatch: Alarm class	Class A/B/C/D/E/F
DE	Alarmklasse		
187	{0} {1o} {1oc} {2oc}	① See chapter "Alarm" on page 125.	
		The alarm class assigned to each limit alarm.	
EN	Self acknowledge	n/f/ <i>LogicsManager</i> mismatch: Self acknowledgment	YES / NO
DE	Selbstquittierend		
188	{0} {1o} {1oc} {2oc}	YES..... The control automatically clears the alarm if it is no longer valid. NO..... An automatic reset of the alarm does not occur. The reset occurs manually by pressing the appropriate buttons, by activating the <i>LogicsManager</i> output "External acknowledgement" via an discrete input, or via an interface.	

Protection: Engine, Start Failure

EN	Monitoring				Start alarm: Monitoring	ON / OFF
DE	Überwachung					
189	{0}	{1o}	{1oc}	{2oc}	ONMonitoring of the start sequence is carried out according to the following parameters.	
	✓	✓	✓	✓	OFFMonitoring is disabled.	
EN	Start attempts				Start alarm: Number of starting attempts	1 to 20
DE	Anzahl Startversuche					
190	{0}	{1o}	{1oc}	{2oc}	The control will attempt to start the engine with this number of start attempts. If the engine fails to start after the configured number of attempts, an alarm will be initiated. An engine has been successfully started if the ignition speed reaches the configured firing speed within the start delay time.	
	✓	✓	✓	✓		
EN	Start attempts override				Start alarm: Number of starting attempts for override	1 to 20
DE	Anzahl Startvers. Sprinkler					
191	{0}	{1o}	{1oc}	{2oc}	If a critical operation mode is initiated, the engine will continue to attempt to start as an override function. The engine will continue to attempt to start for the additional number of starts configured here. An engine has been successfully started if the ignition speed reaches the configured firing speed within the start delay time.	
	✓	✓	✓	✓		
EN	Alarm class				Start alarm: Alarm class	Class A/B/C/D/E/F
DE	Alarmklasse					
192	{0}	{1o}	{1oc}	{2oc}	 ⓘ See chapter "Alarm" on page 125.	
	✓	✓	✓	✓	The alarm class assigned to each limit alarm.	
EN	Self acknowledge				Start alarm: Self acknowledgment	YES / NO
DE	Selbstquittierend					
193	{0}	{1o}	{1oc}	{2oc}	YESThe control automatically clears the alarm if it is no longer valid.	
	✓	✓	✓	✓	NOAn automatic reset of the alarm does not occur. The reset occurs manually by pressing the appropriate buttons, by activating the LogicsManager output "External acknowledgement" via an discrete input, or via an interface.	

Protection: Engine, Shutdown Malfunction

	Monitoring				Stop failure: Monitoring	ON / OFF
DE	Überwachung					
194	{0}	{1o}	{1oc}	{2oc}	ON..... Monitoring of the stop sequence is carried out according to the following parameters. OFF..... Monitoring is disabled.	
	✓	✓	✓	✓		
	Max. stop delay				Stop failure: Delay	3 to 999 s
DE	Verzögerung Abstellstörung					
195	{0}	{1o}	{1oc}	{2oc}	The time between the output of a stop command and the reply that the engine is stopped successfully is defined here. If the engine cannot be stopped within this time (this means speed via the Pickup, frequency via the generator voltage, or the <i>LogicsManager</i> is detected) the action specified by the alarm class is initiated.	
	✓	✓	✓	✓		
	Alarm class				Stop failure: Alarm class	Class A/B/C/D/E/F
DE	Alarmklasse					
196	{0}	{1o}	{1oc}	{2oc}	① See chapter "Alarm" on page 125.	
	✓	✓	✓	✓		
					The alarm class assigned to each limit alarm.	
	Self acknowledge				Stop failure: Self acknowledgment	YES / NO
DE	Selbstquittierend					
197	{0}	{1o}	{1oc}	{2oc}	YES..... The control automatically clears the alarm if it is no longer valid. NO..... An automatic reset of the alarm does not occur. The reset occurs manually by pressing the appropriate buttons, by activating the LogicsManager output "External acknowledgement" via an discrete input, or via an interface.	
	✓	✓	✓	✓		

Protection: Engine, Unintended Stop

DE	EN	Monitoring				Unintended stop: Monitoring	ON / OFF
		Überwachung					
198		{0}	{1o}	{1oc}	{2oc}	ON..... If the engine stops without a stop command the action specified by the alarm class is initiated. This monitoring is enabled with expiration of the engine delayed monitoring. OFF..... Stop alarm will not be evaluated.	
	✓	✓	✓	✓			
DE	EN	Alarm class				Unintended stop: Alarm class	Class A/B/C/D/E/F
		Alarmklasse					
199		{0}	{1o}	{1oc}	{2oc}	ⓘ See chapter "Alarm" on page 125.	
	✓	✓	✓	✓			
The alarm class assigned to each limit alarm.							

Protection: Engine, Dead Bus Operation

The dead bus operation monitoring issues an alarm if ignition speed is exceeded and the limits for closing the GCB (Parameters 65 and 66) are not exceeded within the configured delay. No alarm will be issued in idle mode.

DE	EN	Monitoring				Dead bus operation: Monitoring		ON / OFF	
		Überwachung							
		{0}	{1o}	{1oc}	{2oc}				
200		✓	✓	✓	✓	ON		Monitoring of the dead bus operation is carried out according to the following parameters.	
						OFF		Monitoring is disabled.	
DE	EN	Delay				Dead bus operation: Delay		1 to 999 s	
		Verzögerung							
		{0}	{1o}	{1oc}	{2oc}				
201		✓	✓	✓	✓	If the frequency deviation (Parameter 65) and/or the voltage deviation (Parameter 66) exceed the configured limits for the time defined here, an alarm will be issued. If both deviations return within the limits before the delay time expires, the delay time will be reset.			
DE	EN	Alarm class				Dead bus operation: Alarm class		Class A/B/C/D/E/F	
		Alarmklasse							
		{0}	{1o}	{1oc}	{2oc}				
202		✓	✓	✓	✓	ⓘ See chapter "Alarm" on page 125.			
						The alarm class assigned to each limit alarm.			
DE	EN	Self acknowledge				Dead bus operation: Self acknowledge		YES / NO	
		Selbstquittierend							
		{0}	{1o}	{1oc}	{2oc}				
203		✓	✓	✓	✓	YES		The control automatically clears the alarm if it is no longer valid.	
						NO		An automatic reset of the alarm does not occur. The reset occurs manually by pressing the appropriate buttons, by activating the LogicsManager output "External acknowledgement" via an discrete input, or via an interface.	

Protection: Battery, Overvoltage (Limits 1 & 2)




Figure 3-41: Monitoring - battery overvoltage

Parameter table

The parameters represented in this table are specified in the following, whereas the description is identical for all limits; the limits may only differ in their setting ranges.

Limit	Text	Setting range	Standard value
Battery overvoltage (The hysteresis is 0,7 % of the rated value.)			
Limit 1	Monitoring	ON/OFF	ON
	Limit	8.0 to 42.0 V	32.0 V
	Delay	0.02 to 99.99 s	5.00 s
	Alarm class	A/B/C/D/E/F/Control	B
	Self-acknowledgment	YES/NO	NO
	Engine delayed monitoring	YES/NO	NO
Limit2	Monitoring	ON/OFF	OFF
	Limit	8.0 to 42.0 V	35.0 V
	Delay	0.02 to 99.99 s	1.00 s
	Alarm class	A/B/C/D/E/F/Control	B
	Self-acknowledgment	YES/NO	NO
	Engine delayed monitoring	YES/NO	NO

Table 3-42: Monitoring - standard values - battery overvoltage

EN	Monitoring			
DE	Überwachung			
	{0}	{1o}	{1oc}	{2oc}
204	✓	✓	✓	✓

Battery overvoltage: Monitoring (Limit 1/Limit 2)**ON / OFF**

ON Overvoltage monitoring of the battery voltage is carried out according to the following parameters.

OFF Monitoring is disabled for limit 1 and/or limit 2.

EN	Limit			
DE	Limit			
	{0}	{1o}	{1oc}	{2oc}
205	✓	✓	✓	✓

Battery overvoltage: Threshold value (Limit 1/Limit 2)**8.0 to 42.0 V**

The threshold values that are to be monitored are defined here. If the monitored battery voltage reaches or exceeds this value for at least the delay time without interruption, the action specified by the alarm class is initiated.

EN	Delay			
DE	Verzögerung			
	{0}	{1o}	{1oc}	{2oc}
206	✓	✓	✓	✓

Battery overvoltage: Delay time (Limit 1/Limit 2)**0.02 to 99.99 s**

If the monitored battery voltage exceeds the threshold value for the delay time configured here, an alarm will be issued. If the monitored battery voltage falls below the threshold (minus the hysteresis) before the delay expires the time will be reset.

EN	Alarm class			
DE	Alarmklasse			
	{0}	{1o}	{1oc}	{2oc}
207	✓	✓	✓	✓

Battery overvoltage: Alarm class (Limit 1/Limit 2)**Class A/B/C/D/E/F/Control**

[❏ See chapter "Alarm" on page 125.](#)

The alarm class assigned to each limit alarm.

EN	Self acknowledge			
DE	Selbstquittierend			
	{0}	{1o}	{1oc}	{2oc}
208	✓	✓	✓	✓

Battery overvoltage: Self acknowledgment (Limit 1/Limit 2)**YES / NO**

YES The control automatically clears the alarm if it is no longer valid.

NO An automatic reset of the alarm does not occur. The reset occurs manually by pressing the appropriate buttons, by activating the LogicsManager output "External acknowledgement" via an discrete input, or via an interface.

EN	Delayed by engine speed			
DE	Verzögert durch Motordrehz.			
	{0}	{1o}	{1oc}	{2oc}
209	✓	✓	✓	✓

Battery overvoltage: Engine delayed monitoring (Limit 1/Limit 2)**YES / NO**

YES The alarm is delayed until engine monitoring is enabled. Therefore the conditions of Parameter 55 "Engine delayed monitoring" must be fulfilled.

NO The alarm is not delayed until engine monitoring is enabled. Fault conditions are immediately analyzed.

Protection: Battery, Undervoltage (Limits 1 & 2)




Figure 3-43: Monitoring - battery undervoltage

Parameter table

The parameters represented in this table are specified in the following, whereas the description is identical for all limits; the limits may only differ in their setting ranges.

Limit	Text	Setting range	Standard value
Battery undervoltage (The hysteresis is 0,7 % of the rated value).			
Limit 1	Monitoring	ON/OFF	ON
	Limit	8.0 to 42.0 V	24.0 V
	Delay	0.02 to 99.99 s	60.00 s
	Alarm class	A/B/C/D/E/F/Control	B
	Self-acknowledgment	YES/NO	NO
Limit2	Engine delayed monitoring	YES/NO	NO
	Monitoring	ON/OFF	ON
	Limit	8.0 to 42.0 V	20.0 V
	Delay	0.02 to 99.99 s	10.00 s
	Alarm class	A/B/C/D/E/F/Control	B
Limit2	Self-acknowledgment	YES/NO	NO
	Engine delayed monitoring	YES/NO	NO

Table 3-44: Monitoring - standard values - battery undervoltage

EN	Monitoring			
DE	Überwachung			
	{0}	{1o}	{1oc}	{2oc}
210	✓	✓	✓	✓

Battery undervoltage: Monitoring (Limit 1/Limit 2)**ON / OFF**

ONUndervoltage monitoring of the battery voltage is carried out according to the following parameters.

OFFMonitoring is disabled for limit 1 and/or limit 2.

EN	Limit			
DE	Limit			
	{0}	{1o}	{1oc}	{2oc}
211	✓	✓	✓	✓

Battery undervoltage: Threshold value (Limit 1/Limit 2)**8.0 to 42.0 V**

The threshold values that are to be monitored are defined here. If the monitored battery voltage reaches or falls below this value for at least the delay time without interruption, the action specified by the alarm class is initiated.

Note

The default monitoring limit for battery undervoltage is 24 Vdc after 60 seconds. This is because in normal operation the terminal voltage is approximately 26 Vdc (alternator charged battery).

EN	Delay			
DE	Verzögerung			
	{0}	{1o}	{1oc}	{2oc}
212	✓	✓	✓	✓

Battery undervoltage: Delay time (Limit 1/Limit 2)**0.02 to 99.99 s**

If the battery voltage falls below the threshold value for the delay time configured here, an alarm will be issued. If the battery voltage exceeds the threshold (plus the hysteresis) again before the delay expires the time will be reset.

EN	Alarm class			
DE	Alarmklasse			
	{0}	{1o}	{1oc}	{2oc}
213	✓	✓	✓	✓

Battery undervoltage: Alarm class (Limit 1/Limit 2)**Class A/B/C/D/E/F/Control**

| ⓘ See chapter "Alarm" on page 125. |

The alarm class assigned to each limit alarm.

EN	Self acknowledge			
DE	Selbstquittierend			
	{0}	{1o}	{1oc}	{2oc}
214	✓	✓	✓	✓

Battery undervoltage: Self acknowledgment (Limit 1/Limit 2)**YES / NO**

YESThe control automatically clears the alarm if it is no longer valid.

NOAn automatic reset of the alarm does not occur. The reset occurs manually by pressing the appropriate buttons, by activating the LogicsManager output "External acknowledgement" via an discrete input, or via an interface.

EN	Delayed by engine speed			
DE	Verzögert durch Motordrehz.			
	{0}	{1o}	{1oc}	{2oc}
215	✓	✓	✓	✓

Battery undervoltage: Engine delayed monitoring (Limit 1/Limit 2)**YES / NO**

YESThe alarm is delayed until engine monitoring is enabled. Therefore the conditions of Parameter 55 "Engine delayed monitoring" must be fulfilled.

NOThe alarm is not delayed until engine monitoring is enabled. Fault conditions are immediately analyzed.

Protection: CAN Open Interface, Monitoring

		Monitoring				CAN Open Interface: Monitoring		ON / OFF			
		Überwachung									
		{0}	{1o}	{1oc}	{2oc}						
216		✓	✓	✓	✓	ON Monitoring of the CAN open interface is carried out according to the following parameters. OFF Monitoring is disabled.					
		Delay				CAN Open Interface: Delay				0.1 to 650.0 s	
		Verzögerung									
		{0}	{1o}	{1oc}	{2oc}						
217		✓	✓	✓	✓	The delay is configured with this parameter. If the interface does not receive a CAN Open protocol message before the delay expires, the action specified by the alarm class is initiated. The delay timer is re-initialized after every message is received.					
		Alarm class				CAN Open Interface: Alarm class				Class A/B/C/D/E/F	
		Alarmklasse									
		{0}	{1o}	{1oc}	{2oc}						
218		✓	✓	✓	✓	① See chapter "Alarm" on page 125.					
						The alarm class assigned to each limit alarm.					
		Self acknowledge				CAN Open Interface: Self acknowledgment				YES / NO	
		Selbstquittierend									
		{0}	{1o}	{1oc}	{2oc}						
219		✓	✓	✓	✓	YES The control automatically clears the alarm if it is no longer valid. NO An automatic reset of the alarm does not occur. The reset occurs manually by pressing the appropriate buttons, by activating the LogicsManager output "External acknowledgement" via an discrete input, or via an interface.					
		Delayed by engine speed				CAN Open Interface: Engine delayed				YES / NO	
		Verzögert durch Motordrehz.									
		{0}	{1o}	{1oc}	{2oc}						
220		✓	✓	✓	✓	YES The alarm is delayed until engine monitoring is enabled. Therefore the conditions of Parameter 55 "Engine delayed monitoring" must be fulfilled. NO The alarm is not delayed until engine monitoring is enabled. Fault conditions are immediately analyzed.					



NOTE

This protection is only available if an external digital I/O board (e.g. IKD 1) is connected.

Protection: J1939 Interface, Monitoring

This watchdog triggers if the easYgen is configured to receive J1939 data from an ECU (Parameter 307) connected to the CAN bus, and evaluate these data.

		Monitoring				J1939 Interface: Monitoring		ON / OFF	
		Überwachung							
221		{0}	{1o}	{1oc}	{2oc}	ONMonitoring of the J1939 interface is carried out according to the following parameters.			
		✓	✓	✓	✓	OFFMonitoring is disabled.			
		Delay				J1939 Interface: Delay		0.1 to 650.0 s	
		Verzögerung							
222		{0}	{1o}	{1oc}	{2oc}	The delay is configured with this parameter. If the interface does not receive a CAN SAE J1939 protocol message before the delay expires, the action specified by the alarm class is initiated. The delay timer is re-initialized after every message is received.			
		✓	✓	✓	✓				
		Alarm class				J1939 Interface: Alarm class		Class A/B/C/D/E/F	
		Alarmklasse							
223		{0}	{1o}	{1oc}	{2oc}	① See chapter "Alarm" on page 125.			
		✓	✓	✓	✓				
						The alarm class assigned to each limit alarm.			
		Self acknowledge				J1939 Interface: Self acknowledgment		YES / NO	
		Selbstquittierend							
224		{0}	{1o}	{1oc}	{2oc}	YESThe control automatically clears the alarm if it is no longer valid.			
		✓	✓	✓	✓	NOAn automatic reset of the alarm does not occur. The reset occurs manually by pressing the appropriate buttons, by activating the LogicsManager output "External acknowledgement" via an discrete input, or via an interface.			
		Delayed by engine speed				J1939 Interface: Engine delayed		YES / NO	
		Verzögert durch Motordrehz.							
225		{0}	{1o}	{1oc}	{2oc}	YESThe alarm is delayed until engine monitoring is enabled. Therefore the conditions of Parameter 55 "Engine delayed monitoring" must be fulfilled.			
		✓	✓	✓	✓	NOThe alarm is not delayed until engine monitoring is enabled. Fault conditions are immediately analyzed.			



NOTE

This protection is only available if an engine control is connected which communicates with the easYgen using the J1939 protocol.

Protection: J1939 Interface, Amber Warning Lamp DM1

This watchdogs monitors, whether a specific alarm bit is received from the CAN J1939 interface. This enables to configure the easYgen in a way that a reaction is caused by this bit (e.g. warning, shutdown).

DE

EN

Monitoring

Überwachung

{0}

{1o}

{1oc}

{2oc}

226

✓

✓

✓

✓

ON.....

Monitoring of the Amber Warning Lamp message from the ECU is carried out according to the following parameters.

OFF.....

Monitoring is disabled.

DE

EN

Delay

Verzögerung

{0}

{1o}

{1oc}

{2oc}

227

✓

✓

✓

✓

The amber warning lamp delay is configured with this parameter. If the ECU sends the Amber Warning Lamp ON message, the action specified by the alarm class is initiated after the delay configured here expires.

DE

EN

Alarm class

Alarmklasse

{0}

{1o}

{1oc}

{2oc}

228

✓

✓

✓

✓

| ⓘ See chapter "Alarm" on page 125.

The alarm class assigned to each limit alarm.

DE

EN

Self acknowledge

Selbstquittierend

{0}

{1o}

{1oc}

{2oc}

229

✓

✓

✓

✓

YES.....

The control automatically clears the alarm if it is no longer valid.

NO.....

An automatic reset of the alarm does not occur. The reset occurs manually by pressing the appropriate buttons, by activating the LogicsManager output "External acknowledgement" via an discrete input, or via an interface.

DE

EN

Delayed by engine speed

Verzögert durch Motordrehz.

{0}

{1o}

{1oc}

{2oc}

230

✓

✓

✓

✓

YES.....

The alarm is delayed until engine monitoring is enabled. Therefore the conditions of Parameter 55 "Engine delayed monitoring" must be fulfilled.

NO.....

The alarm is not delayed until engine monitoring is enabled. Fault conditions are immediately analyzed.



NOTE

This protection is only available if an engine control is connected which communicates with the easY-gen using the J1939 protocol.

Protection: J1939 Interface, Red Stop Lamp DM1

This watchdogs monitors, whether a specific alarm bit is received from the CAN J1939 interface. This enables to configure the easYgen in a way that a reaction is caused by this bit (e.g. warning, shutdown).

		Monitoring				J1939 Interface: Red stop lamp DM1: Monitoring		ON / OFF	
		Überwachung							
		{0}	{1o}	{1oc}	{2oc}				
231		✓	✓	✓	✓	ONMonitoring of the Red Stop Lamp message from the ECU is carried out according to the following parameters. OFFMonitoring is disabled.			
		Delay				J1939 Interface: Red stop lamp DM1: Delay		0.1 to 650.0 s	
		Verzögerung							
		{0}	{1o}	{1oc}	{2oc}				
232		✓	✓	✓	✓	The red stop lamp delay is configured with this parameter. If the ECU sends the Red Stop Lamp ON message, the action specified by the alarm class is initiated after the delay configured here expires.			
		Alarm class				J1939 Interface: Red stop lamp DM1: Alarm class		Class A/B/C/D/E/F/Control	
		Alarmklasse							
		{0}	{1o}	{1oc}	{2oc}				
233		✓	✓	✓	✓	① See chapter "Alarm" on page 125.			
						The alarm class assigned to each limit alarm.			
		Self acknowledge				J1939 Interface: Red stop lamp DM1: Self acknowledgment		YES / NO	
		Selbstquittierend							
		{0}	{1o}	{1oc}	{2oc}				
234		✓	✓	✓	✓	YESThe control automatically clears the alarm if it is no longer valid. NOAn automatic reset of the alarm does not occur. The reset occurs manually by pressing the appropriate buttons, by activating the LogicsManager output "External acknowledgement" via an discrete input, or via an interface.			
		Delayed by engine speed				J1939 Interface: Red stop lamp DM1: Engine delayed		YES / NO	
		Verzögert durch Motordrehz.							
		{0}	{1o}	{1oc}	{2oc}				
235		✓	✓	✓	✓	YESThe alarm is delayed until engine monitoring is enabled. Therefore the conditions of Parameter 55 "Engine delayed monitoring" must be fulfilled. NOThe alarm is not delayed until engine monitoring is enabled. Fault conditions are immediately analyzed.			



NOTE

This protection is only available if an engine control is connected which communicates with the easYgen using the J1939 protocol.

Discrete Inputs



Number	Terminal	Application mode			
		{0}	{1o}	{1oc}	{2oc}
Internal discrete inputs					
[D1]	51	Alarm input (<i>LogicsManager</i>), pre-assigned with EMERGENCY OFF			
[D2]	52	Alarm input (<i>LogicsManager</i>), pre-assigned with Start in AUTO			
[D3]	53	Alarm input (<i>LogicsManager</i>)			
[D4]	54	Alarm input (<i>LogicsManager</i>)			
[D5]	55	Alarm input (<i>LogicsManager</i>)			
[D6]	56	Alarm input (<i>LogicsManager</i>)			Enable MCB ^{#1}
[D7]	57	Alarm input (<i>LogicsManager</i>)			Reply: MCB is open
[D8]	58	Alarm input (<i>LogicsManager</i>)		Reply: GCB is open	Reply: GCB is open
External discrete inputs (via CANopen; not included in easYgen delivery; can be e.g. IKD1, etc.)					
[DEx01]	---	Alarm input (<i>LogicsManager</i>)			
[DEx02]	---	Alarm input (<i>LogicsManager</i>)			
[DEx03]	---	Alarm input (<i>LogicsManager</i>)			
[DEx04]	---	Alarm input (<i>LogicsManager</i>)			
[DEx05]	---	Alarm input (<i>LogicsManager</i>)			
[DEx06]	---	Alarm input (<i>LogicsManager</i>)			
[DEx07]	---	Alarm input (<i>LogicsManager</i>)			
[DEx08]	---	Alarm input (<i>LogicsManager</i>)			
[DEx09]	---	Alarm input (<i>LogicsManager</i>)			
[DEx10]	---	Alarm input (<i>LogicsManager</i>)			
[DEx11]	---	Alarm input (<i>LogicsManager</i>)			
[DEx12]	---	Alarm input (<i>LogicsManager</i>)			
[DEx13]	---	Alarm input (<i>LogicsManager</i>)			
[DEx14]	---	Alarm input (<i>LogicsManager</i>)			
[DEx15]	---	Alarm input (<i>LogicsManager</i>)			
[DEx16]	---	Alarm input (<i>LogicsManager</i>)			

#1..If the parameter Enable MCB is configured to ALWAYS, this DI may be used as alarm input (*LogicsManager*)

Table 3-45: Discrete inputs - assignment



NOTE

Alarm inputs may also be configured as control inputs and then be used as command variables in the *LogicsManager*.

i

NOTE

Operating current (NO): The relay is enabled (i.e. in the operating state) when current flows through the coil. If a loss of the supply voltage occurs, the relay contacts will not transfer and a fault condition will not be monitored. In this mode of operation the state of the system should be monitored through other means than the state of the relay.

Closed circuit current (NC): The relay is disabled (i.e. in idle state) when current flows through the coil. The relay is energized in idle state. If a loss of the supply voltage occurs, the relay contacts will transfer and a fault condition will be monitored.




Figure 3-46: N.O./N.C.

i

NOTE

If the discrete input is used as a reply message for the breaker position, the discrete input must be configured as N.C. All reply messages from breakers are evaluated as N.C.

DE	EN	DI {x} operation				Discrete input: Operation	N.O. / N.C.
		DI {x} Funktion					
		{0}	{1o}	{1oc}	{2oc}		
236		✓	✓	✓	✓	<p>The discrete inputs may be operated by an operating current contact or an idle circuit current contact. The idle circuit current input can be used to monitor for a wire-break. A positive or negative voltage polarity referred to the reference point of the DI may be applied.</p> <p>N.O.The discrete input is analyzed as "enabled" by energizing the input (N.O. / operating current).</p> <p>N.C.The discrete input is analyzed as "enabled" by de-energizing the input (N.C. / idle current).</p>	

DE	EN	DI {x} delay				Discrete input: Delay	0.08 to 650.00 s
		DI {x} Verzögerung					
		{0}	{1o}	{1oc}	{2oc}		
237		✓	✓	✓	✓	<p>A delay time in seconds can be assigned to each alarm input. The discrete input must be enabled without interruption for the delay time before a fault is recognized. If the discrete input is used within the <i>LogicsManager</i> this delay is taken into account as well.</p> <p>Note: This parameter may only be configured using LeoPC1.</p>	

EN	DI {x} alarm class				Discrete input: Alarm class	Class A/B/C/D/E/F/Control
DE	DI {x} Alarmklasse					
	{0}	{1o}	{1oc}	{2oc}	① see chapter "Alarm Classes" on page 125.	
238	✓	✓	✓	✓		

An alarm class may be assigned to the discrete input. The alarm class is executed when the discrete input is enabled.

If "control" has been configured as alarm class a function out of the *LogicsManager* (description at page 126) can be assigned to the discrete inputs. There will be no entry in the event logger in case of an alarm.

EN	DI {x} delayed by eng.speed				Discrete input: Engine delayed monitoring	YES / NO
DE	DI {x} verzög. d. Motordrehz.					
	{0}	{1o}	{1oc}	{2oc}		
239	✓	✓	✓	✓		

YES..... The alarm is delayed until engine monitoring is enabled. Therefore the conditions of Parameter 55 "Engine delayed monitoring" must be fulfilled.

NO..... The alarm is not delayed until engine monitoring is enabled. Fault conditions are immediately analyzed.



NOTE

If a discrete input has been configured with a shut-down alarm that has been enabled to self-acknowledge, and has been configured as engine delayed the following scenario may happen:

- The discrete input shuts down the engine because of its alarm class.
- Due to the engine stopping, all engine delayed alarms are ignored.
- The alarm class is acknowledged automatically.
- The alarm will self-acknowledge and clear the fault message that shut the engine down. This prevents the fault from being analyzed. After a short delay, the engine will restart.
- After the engine monitoring delay expires, the fault that originally shut down the engine will do so again. This cycle will continue to repeat until corrected.

EN	DI {x} self acknowledge				Discrete input: Self acknowledgment	YES / NO
DE	DI {x} Selbstquittierend					
	{0}	{1o}	{1oc}	{2oc}		
240	✓	✓	✓	✓		

YES..... The control automatically clears the alarm if it is no longer valid.

NO..... An automatic reset of the alarm does not occur. The reset occurs manually by pressing the appropriate buttons, by activating the LogicsManager output "External acknowledgement" via an discrete input, or via an interface.

If the DI is configured with the alarm class "Control", self acknowledgement is always active.

EN	DI {x} text				Discrete input: Message text	user-defined
DE	DI {x} Text					
	{0}	{1o}	{1oc}	{2oc}		
L 241	✓	✓	✓	✓		

If the discrete input is enabled, this text is displayed on the control unit screen. The event log will store this text message as well.

Note: This parameter may only be configured using LeoPC1.

Note: If the DI is used as control input with the alarm class "Control", you may enter here its function (e.g. external acknowledgement) for a better overview within the configuration.

Discrete Outputs (*LogicsManager*)



The discrete outputs are controlled via the *LogicsManager*.

⇒ Please note the description of the *LogicsManager* starting on page 127.

Some outputs are assigned a function according to the application mode (see following table).

Relay Number	Term.	Basic {0}	GCB open {1o}	Application mode GCB open/close {1oc}	GCB/MCB open/close {2oc}
Internal relay outputs					
[R1]	30/35	LogicsManager			
[R2]	31/35	LogicsManager			
[R3]	32/35	Crank			
[R4]	33/35	Diesel: Fuel solenoid Gas: Gas valve			
[R5]	34/35	LogicsManager; pre-assigned with 'Diesel: Pre-glow, Gas: Ignition'			
[R6]	36/37	LogicsManager; pre-assigned with 'Auxiliary services'			
[R7]	38/39	LogicsManager	Command: open GCB		
[R8]	40/41	LogicsManager			Command: close MCB
[R9]	42/43	LogicsManager			Command: open MCB
[R10]	44/45	LogicsManager		Command: close GCB	
[R11]	46/47	Ready for operation / LogicsManager			
External relay output (via CANopen; not included in easYgen delivery; can be an expansion card like IKD1)					
[REx01]	---	LogicsManager			
[REx02]	---	LogicsManager			
[REx03]	---	LogicsManager			
[REx04]	---	LogicsManager			
[REx05]	---	LogicsManager			
[REx06]	---	LogicsManager			
[REx07]	---	LogicsManager			
[REx08]	---	LogicsManager			
[REx09]	---	LogicsManager			
[REx10]	---	LogicsManager			
[REx11]	---	LogicsManager			
[REx12]	---	LogicsManager			
[REx13]	---	LogicsManager			
[REx14]	---	LogicsManager			
[REx15]	---	LogicsManager			
[REx16]	---	LogicsManager			

#1..The relay has superimposed the "Ready for operation" information and operates as idle current relay (N.C.)

Table 3-47: Relay outputs - assignment

Analog Inputs (*FlexIn*)



The table of analog inputs lists the various types of inputs that may be utilized with this control unit. The inputs to be used on the control unit are [T1] and [T2]. The free definable characteristic curves located in tables A and B may be assigned as user defined to each analog input. The linear characteristic curves of [T1] and [T2] may only be assigned to the current analog inputs. The following assignment configurations are possible:

Table of analog inputs	Table of characteristic curves (type)									
	OFF	VDO, Pressure 0 to 5 bar (0 to 72 psi)	VDO, Pressure 0 to 10 bar (0 to 145 psi)	VDO, Temperature 40 to 120 °C (104 to 248 °F)	VDO, Temperature 50 to 150 °C (122 to 302 °F)	Pt100	Linear, 2-Points Characteristics for [T1]	Linear, 2-Points Characteristics for [T2]	Table, 9-Points Characteristics A	Table, 9-Points Characteristics B

Analog input [T1]										
0 to 20 mA	✓	---	---	---	---	---	✓	---	✓	✓
4 to 20 mA	✓	---	---	---	---	---	✓	---	✓	✓
0 to 500 Ohm	✓	✓	✓	✓	✓	✓	✓	---	✓	✓

Analog input [T2]										
0 to 20 mA	✓	---	---	---	---	---	---	✓	✓	✓
4 to 20 mA	✓	---	---	---	---	---	---	✓	✓	✓
0 to 500 Ohm	✓	✓	✓	✓	✓	✓	---	✓	✓	✓

Table 3-48: Analog inputs - possibilities of configuration (*FlexIn*)




Figure 3-49: Analog inputs - possibilities of combinations (*FlexIn*)

Analog Inputs: Display

DE	EN	Display temperature in	Temperature display in	°C / °F
		Temperaturanzeige in		
242	✓	{0}	°C.....	The temperature is displayed in °C (Celsius).
		{1o}	°F.....	The temperature is displayed in °F (Fahrenheit).
		{1oc}		
		{2oc}		
DE	EN	Display pressure in	Pressure display in	bar / psi
		Druckanzeige in		
243	✓	{0}	bar.....	The pressure is displayed in Bar.
		{1o}	psi.....	The pressure is displayed in psi.
		{1oc}		
		{2oc}		

Analog Inputs: Type

DE	EN	Type	Analog input {x} [x = 1 or 2]: Type	OFF / VDO 5bar / VDO 10bar / VDO 120°C / VDO 150°C / Pt100 / linear / Table A / Table B
		Typ		
244	✓	{0}	<p>① The characteristic curves of the inputs can be found in Appendix C (page 155).</p>	
		{1o}		
		{1oc}		
		{2oc}		

According to the following parameters different measuring ranges are possible at the analog inputs. The selectable ranges are:

- OFF** The analog input is switched off.
- VDO 5bar** The value of the analog input is interpreted with the VDO characteristics 0 to 5 bar.
- VDO 10bar** The value of the analog input is interpreted with the VDO characteristics 0 to 10 bar.
- VDO 120°C** The value of the analog input is interpreted with the VDO characteristics 40 to 120 °C.
- VDO 150°C** The value of the analog input is interpreted with the VDO characteristics 50 to 150 °C.
- Pt100** The value of the analog input is interpreted with a Pt100 characteristic.
- linear** Each analog input may be assigned to a linear characteristic curve, which can be only used for the respective defined input [T{x}] (x = 1 to 2). The minimum (0 %) and maximum (100 %) value refers to the total measuring range of the analog input (i.e. 0 to 500 Ohm, 0 to 20 mA or 4 to 20 mA). Both benchmark limits of the linear characteristic curves must be defined only in case they are used.
- Table A / B** The analog input is assigned to a characteristic curve which is defined over 9 points (stored in a table). Two independent tables (table A and table B) may be allocated to the analog inputs. Note that if these tables are to be used with the analog inputs, the defined points of these tables must be programmed into the control unit.

DE	EN	Select hardware	Analog input {x} [x = 1 or 2]: Hardware	0 to 500 Ohm / 0 to 20 mA / 4 to 20 mA
		Auswahl Hardware		
245	✓	{0}	<p>The software in the control unit may be configured for various types of sensors. The configurable ranges apply to the linear analog input. Configurable ranges are:</p> <p>0 to 500 Ohm The measuring range of the analog input is 0- to 500 Ohm. 0 Ohm = 0 %, 500 Ohm = 100 %.</p> <p>0 to 20 mA The measuring range of the analog input is 0 to 20 mA. 0 mA = 0 %, 20 mA = 100 %.</p> <p>4 to 20 mA The measuring range of the analog input is 4 to 20 mA. 4 mA = 0 %, 20 mA = 100 %.</p>	
		{1o}		
		{1oc}		
		{2oc}		

		Offset				Analog input {x} [x = 1 or 2]: Offset	-20.0 to 20.0 Ohm
		Offset					
DE	EN	{0}	{1o}	{1oc}	{2oc}		
		✓	✓	✓	✓		
246							

The resistive input (the "0-500Ohm" analog input) may be calculated with a permanent offset to adjust for inaccuracies. If the offset feature is utilized, the value configured in this parameter will be added to/subtracted from the measured resistive value. This has the following effect to the measured values (please note tables starting on page 155):

-20.0 to 0.1 Ohm
VDO temperature: The displayed value will decrease.
VDO pressure: The displayed value will increase.

+0.1 to 20.0 Ohm
VDO temperature: The displayed value will increase.
VDO pressure: The displayed value will decrease.

		Bargraph minimum				Analog input {x} [x = 1 or 2]: Bar graph minimum value	-9999 to 9999
		Bargraph Minimum					
DE	EN	{0}	{1o}	{1oc}	{2oc}		
		✓	✓	✓	✓		
247							

The start value for the bar graph display of the analog input is defined here. The value must be entered according to the display format, which refers to the analog input type (Parameter 244).

Note: This parameter is only effective if Parameter 244 is configured to Linear or Table A/B.

		Bargraph maximum				Analog input {x} [x = 1 or 2]: Bar graph maximum value	-9999 to 9999
		Bargraph Maximum					
DE	EN	{0}	{1o}	{1oc}	{2oc}		
		✓	✓	✓	✓		
248							

The end value for the bar graph display of the analog input is defined here. The value must be entered according to the display format, which refers to the analog input type (Parameter 244).

Note: This parameter is only effective if Parameter 244 is configured to Linear or Table A/B.

		Description				Analog input {x} [x = 1 or 2]: Message text	user-defined
		Beschreibung					
DE	EN	{0}	{1o}	{1oc}	{2oc}		
		✓	✓	✓	✓		
249							

If the programmed limit value of the analog input has been reached or exceeded this text is displayed in the control unit screen. The event log will store this text message and it is also used for the visualization screen.

Note: This parameter may only be configured using LeoPC1.

DE EN	Value format			
	Zahlenformat			
L	{0}	{1o}	{1oc}	{2oc}
250	✓	✓	✓	✓

Analog input {x} [x = 1 or 2]: Value format

user-defined

① If a sign to denote a negative measured value (i.e. -10) is required, then the first "0" of the numeric display is utilized for this symbol.

To display the measuring value of the analog input for the analog input types linear as well as Table A and Table B (Parameter 244) correctly this parameter is to be used to define the format. The zeros in the numeric display are used for the measuring values and are configurable. The placeholders for the digits may have symbols (i.e. commas).

Note

- This parameter may only be configured using LeoPC1.
- This parameter only applies to the linear and the user defined Table A and Table B (Parameter 244) analog input types.
- The displayed value should be configured with the same number of digits as the desired value to be measured.
- The measured value will be displayed from right to left. If the measured value is larger than the number of digits in the display, only a portion of the measured value will be shown. An example of this would be a display of three digits is configured when four digits will be needed. Instead of the number "1234" being displayed only "234" will be shown.
- If the parameter being displayed has a numeral "0" in the name, the letter "O" must be used instead. If a numeral is used, a numeric value will display in its place.

ExamplesFuel level

- value at 0 % 0
- value at 100 % 1000
- desired display up to 1,000mm
- this parameter **0,000mm**

Angle

- value at 0 % -1799
- value at 100 % 1800
- desired display -179.9° to 180.0°
- this parameter **0000.0°**

Pressure

- value at 0 % 0
- value at 100 % 100
- desired display up to 10.0bar
- this parameter **00.0bar**

DE	EN	Filter time constant			
		Filter			
		{0}	{1o}	{1oc}	{2oc}
251		✓	✓	✓	✓

Analog input {x} [x = 1 or 2]: Filter time constant

OFF / 1 / 2 / 3 / 4 / 5

A filter time constant may be used to reduce the fluctuation of an analog input reading. This filter time constant assesses the average of the signal according to the following formula:

$$\text{Cut-off frequency} = \frac{1}{20ms \times 2 \times \pi \times 2^{N-1}}$$
, whereby "N" is the parameter.

- OFF**..... The analog input is displayed without filtering.
- 1**..... Cut-off-frequency = 7.96 Hz (filter time constant = 0.02 s)
- 2**..... Cut-off-frequency = 3.98 Hz (filter time constant = 0.04 s)
- 3**..... Cut-off-frequency = 1.99 Hz (filter time constant = 0.08 s)
- 4**..... Cut-off-frequency = 0.99 Hz (filter time constant = 0.16 s)
- 5**..... Cut-off-frequency = 0.50 Hz (filter time constant = 0.32 s)

DE	EN	Hysteresis			
		Hysteresis			
		{0}	{1o}	{1oc}	{2oc}
252		✓	✓	✓	✓

Scaling linear {x} [x = A/B]: Hysteresis

0 to 999

If the analog input is used for monitoring/protection the actual value must exceed or fall below one of the limits defined in Parameter 254 and/or 255 to be recognized as out of parameters. For a value to register as having returned to be within parameters, the monitored value must rise above or fall below this value for the hysteresis.



NOTE

The setting of the hysteresis is only valid for the fixed assigned thresholds.

When using flexible thresholds, an own hysteresis (Parameter 274) must be defined. The setting of this parameter has no effect with flexible thresholds.

Analog Inputs: Monitoring Limits

<div>EN</div> <div>DE</div> <div>Monitoring level {y}</div> <div>Überwachung Stufe {y}</div> <div>{0} {1o} {1oc} {2oc}</div> <div>253</div>	<div>Analog input {x} [x = 1 or 2]: Monitoring threshold value {y} [y = 1/2] ON / OFF</div>
	<div>ONLimit(s) 1 and/or 2 are enabled and monitoring of following parameter is limits carried out. Both limits can be enabled independent of each other.</div> <div>OFFMonitoring is disabled.</div>
<div>EN</div> <div>DE</div> <div>Limit level {y}</div> <div>Limit Stufe {y}</div> <div>{0} {1o} {1oc} {2oc}</div> <div>254</div>	<div>Analog input {x} [x = 1 or 2]: Threshold value {y} [y = 1/2] -9,999 to 9,999</div>
	<div>The limit of the value to be monitored is defined by this parameter. If this value is reached or exceeded / fallen below (dependent on Parameter 257) for at least the delay time configured in Parameter 256 the action ispecified by the alarm class is initiated after the configured delay expires.</div>
<div>EN</div> <div>DE</div> <div>Limit level {y} Idle Run</div> <div>Limit Stufe {y} Idle Modus</div> <div>{0} {1o} {1oc} {2oc}</div> <div>255</div>	<div>Analog input {x} [x = 1 or 2]: Idle mode threshold value {y} [y = 1/2] -9,999 to 9,999</div>
	<div>① See Engine: Idle Mode on page 36.</div> <div>If the engine idle mode is enabled, an alternative threshold value is configured here. This threshold is used instead of the threshold defined in Parameter 254 while the idle mode is active.</div>
<div>EN</div> <div>DE</div> <div>Delay level {y}</div> <div>Verzögerung Stufe {y}</div> <div>{0} {1o} {1oc} {2oc}</div> <div>256</div>	<div>Analog input {x} [x = 1 or 2]: Delay time threshold value {y} [y = 1/2] 0.02 to 99.99 s</div>
	<div>If the monitored analog input value exceeds or falls below the threshold value for the delay time configured here, an alarm will be issued. If the monitored analog input value falls below or exceeds (dependent on Parameter 257) the threshold (plus/minus the hysteresis) before the delay expires the time will be reset.</div>
<div>EN</div> <div>DE</div> <div>Monitoring level {y} at</div> <div>Überwachung Stufe {y} auf</div> <div>{0} {1o} {1oc} {2oc}</div> <div>257</div>	<div>Analog input {x} [x = 1 or 2]: Monitoring limit {y} [y = 1/2] on Overrun / Underrun</div>
	<div>OverrunSo that the actual value is identified as reached it must have risen over the limit.</div> <div>UnderrunSo that the actual value is identified as reached it must have fallen below the limit.</div>
<div>EN</div> <div>DE</div> <div>Alarm class level {y}</div> <div>Alarmklasse Stufe {y}</div> <div>{0} {1o} {1oc} {2oc}</div> <div>258</div>	<div>Analog in.{x} [x = 1 or 2]: Alarm cl.. limit {y} [y = 1/2] Class A/B/C/D/E/F</div>
	<div>① See chapter "Alarm" on page 125.</div> <div>The alarm class assigned to each limit alarm.</div>
<div>EN</div> <div>DE</div> <div>Self acknowledge level {y}</div> <div>Selbstquittierend Stufe {y}</div> <div>{0} {1o} {1oc} {2oc}</div> <div>259</div>	<div>Analog input {x} [x = 1 or 2]: Self acknowledged limit {y} [y = 1/2] YES / NO</div>
	<div>YESThe control automatically clears the alarm if it is no longer valid.</div> <div>NOAn automatic reset of the alarm does not occur. The reset occurs manually by pressing the appropriate buttons, by activating the LogicsManager output "External acknowledgement" via an discrete input, or via an interface.</div>
<div>EN</div> <div>DE</div> <div>Delayed by engine level {y}</div> <div>Verzögert d. Motordr. St. {y}</div> <div>{0} {1o} {1oc} {2oc}</div> <div>260</div>	<div>Analog input {x} [x = 1 or 2]: Engine delayed monitoring {y} [y = 1/2] YES / NO</div>
	<div>YESThe alarm is delayed until engine monitoring is enabled. Therefore the conditions of Parameter 55 "Engine delayed monitoring" must be fulfilled.</div> <div>NOThe alarm is not delayed until engine monitoring is enabled. Fault conditions are immediately analyzed.</div>

Analog Inputs: Wire Break Monitoring

Monitoring wire break		Analog input {x} [x = 1 or 2]: Wire break monitoring		Off / High / Low / high/low
Drahtbruchüberw.				
	{0}	{1o}	{1oc}	{2oc}
261	✓	✓	✓	✓
The analog input can be monitored for a wire break. The following configurations are used to monitor for a wire break:				
Off No wire break monitoring is performed.				
High If the actual value rises over the maximum value (overshoot), this is identified as a wire break.				
Low If the actual value falls below the minimum value (undershoot), this is identified as a wire break.				
high/low If the actual value rises over the maximum value (overshoot) or falls below the minimum value (undershoot), this is identified as a wire break.				



NOTE

If the control unit detects that the measuring range for an analog input has been exceeded and an alarm is issued, the limit value monitoring of this analog input is disabled.

The measuring range is recognized as being exceeded and an alarm is issued:

- 4 to 20 mA
 - Minimum value 2 mA Undershooting
 - Maximum value 20.5 mA Overshooting
- 0 to 500 Ohm
 - Minimum value 5 Ohm Undershooting (Offset = 0 Ohm)
 - Maximum value 515 Ohm Overshooting (Offset = 0 Ohm)

Note: Depending on what was configured for the offset value (Parameter 246) the displayed value may be shifted. This may result in a broken wire being recognized early or later than the actual value being measured. (An offset of +20ohms will recognize a wire break at 25ohms instead of 5ohms.)

Wire break alarm class					Analog in. {x} [x = 1 or 2]: Alarm cl. wire break monit.	Class A/B/C/D/E/F/Control
DE	Drahtbruch Alarmklasse					
	{0}	{1o}	{1oc}	{2oc}		
262	✓	✓	✓	✓		

① See chapter "Alarm" on page 125.

The alarm class assigned to each limit alarm.

DE	EN	Self acknowledge wire break				Analog input {x} [x = 1 or 2]: Self acknowledged		YES / NO
		Drahtbruch selbstquitt.						
		{0}	{1o}	{1oc}	{2oc}	YES.....	The control automatically clears the alarm if it is no longer valid.	
263		✓	✓	✓	✓	NO.....	An automatic reset of the alarm does not occur. The reset occurs manually by pressing the appropriate buttons, by activating the LogicsManager output "External acknowledgement" via an discrete input, or via an interface.	

Analog Inputs: Characteristics "Linear" (2 Point Scaling)




Figure 3-50: Analog input scaling - linear characteristics

		Value at 0%			
DE	EN	Wert bei 0%			
		{0}	{1o}	{1oc}	{2oc}

264 ✓ ✓ ✓ ✓

264

Scaling linear {x} [x = A/B]: Value at 0 % -9,999 to 9,999

The analog input is assigned to a straight line. This parameter defines the actual value at 0 % of the total range of the analog input. For example, the input is configured as a 0 to 20 mA input, 0 % equals 0 mA. If 4 to 20 mA is selected, 0 % equals 4 mA.

		Value at 100%			
DE EN		Wert bei 100%			
		{0}	{1o}	{1oc}	{2oc}
265		✓	✓	✓	✓

265

Scaling linear {x} [x = A/B]: Value at 100 % -9,999 to 9,999

The analog input is assigned to a straight line. This parameter defines the actual value at 100 % of the range of the analog input. For example, the input is configured as a 0 to 20 mA input, 100 % equals 20 mA.

Analog Inputs: Configure Flexible Thresholds

<div>EN</div> <div>DE</div> <div>266</div> <div>Monitoring Überwachung</div> <div>{0} ✓ {1o} ✓ {1oc} ✓ {2oc} ✓</div>	<div>Limit {x} [x = 1 to 4]: Monitoring ON / OFF</div> <hr/> <div>ON..... Monitoring of the limit {x} is carried out according to the following parameters.</div> <div>OFF..... Monitoring is disabled.</div>
<div>EN</div> <div>DE</div> <div>267</div> <div>Monitored analog input Überwachter Analogeingang</div> <div>{0} ✓ {1o} ✓ {1oc} ✓ {2oc} ✓</div>	<div>Limit {x} [x = 1 to 4]: Monitored analog input see selection below</div> <hr/> <div>Battery..... The battery voltage is monitored with the limit {x}.</div> <div>AnalogIn1.... The analog input 1 is monitored with the limit {x}.</div> <div>AnalogIn2.... The analog input 2 is monitored with the limit {x}.</div> <div>ECUSPN110 The coolant temperature from an ECU via the CAN bus is monitored with the limit {x} (J1939 SPN 110).</div> <div>ECUSPN100 The oil pressure from an ECU via the CAN bus is monitored with the limit {x} (J1939 SPN 100).</div> <div>ECUSPN190 The engine speed from an ECU via the CAN bus is monitored with the limit {x} (J1939 SPN 190).</div>
<div>EN</div> <div>DE</div> <div>268</div> <div>Limit Limit</div> <div>{0} ✓ {1o} ✓ {1oc} ✓ {2oc} ✓</div>	<div>Limit {x} [x = 1 to 4]: Threshold -32000 to +32000</div> <hr/> <div>The threshold limit of the value to be monitored is defined by this parameter. If this value is reached or exceeded / fallen below (dependent on Parameter 270) for at least the delay time configured in Parameter 269 the action is specified by the alarm class is initiated after the configured delay expires. The format for entering the threshold value depends on the monitored analog input:</div> <div>Battery..... Input in 0.1 V – example: 23.5 V > input: 00235</div> <div>ECUSPN110 Direct input in °C – example: 156°C > input: 00156</div> <div>ECUSPN100 Direct input in kPa – example: 600 kPa > input: 00600</div> <div>ECUSPN190 Direct input in rpm – example: 1500 rpm > input: 01500</div> <div>AnalogIn1/2 Input depends on the configured format of the respective analog input:</div> <div>VDO 5 bar... Input in 0.01 bar – example: 5.0 bar > input: 00500</div> <div>VDO 10 bar. Input in 0.01 bar – example: 6.6 bar > input: 00660</div> <div>VDO 150°C. Direct input in °C – example: 69°C > input: 00069</div> <div>VDO 120°C. Direct input in °C – example: 73°C > input: 00073</div> <div>Pt100..... Direct input in °C – example: 69°C > input: 00069</div> <div>Linear..... Input according to the configured format (Parameter 250)</div> <div>Tab. A/B..... Input according to the configured format (Parameter 250)</div>

Examples

Fuel level

- value at 0 %.....0
- value at 100 %.....1000
- desired displayup to 1,000mm
- this parameter.....0,000mm

Angle

- value at 0 %.....-1799
- value at 100 %.....1800
- desired display-179.9° to 180.0°
- this parameter.....0000.0°

Pressure

- value at 0 %.....0
- value at 100 %.....100
- desired displayup to 10.0bar
- this parameter.....00.0bar

	DE	EN	Limit {x} [x = 1 to 4]: Delay				00,02 to 99,99 s
			Verzögerung				
			{0}	{1o}	{1oc}	{2oc}	
269			✓	✓	✓	✓	If the monitored value exceeds or falls below the threshold value for the delay time configured here, an alarm will be issued. If the monitored value falls below the threshold (plus/minus the hysteresis, dependent on Parameter 270) before the delay expires the time will be reset.
	DE	EN	Limit {x} [x = 1 to 4]: Monitoring for				Overrun / Underrun
			Überwachung auf				
			{0}	{1o}	{1oc}	{2oc}	
270			✓	✓	✓	✓	OverrunThe monitored value must exceed the threshold limit for a fault to be recognized. UnderrunThe monitored value must fall below the threshold limit for a fault to be recognized.
	DE	EN	Limit {x} [x = 1 to 4]: Alarm class				Class A/B/C/D/E/F/Control
			Alarmklasse				
			{0}	{1o}	{1oc}	{2oc}	
271			✓	✓	✓	✓	① See chapter "Alarm" on page 125. The alarm class assigned to each limit alarm.
	DE	EN	Limit {x} [x = 1 to 4]: Self acknowledge				YES / NO
			Selbstquittierend				
			{0}	{1o}	{1oc}	{2oc}	
272			✓	✓	✓	✓	YESThe control automatically clears the alarm if it is no longer valid. NOAn automatic reset of the alarm does not occur. The reset occurs manually by pressing the appropriate buttons, by energizing the appropriate discrete input or via interface.
	DE	EN	Limit {x} [x = 1 to 4]: Engine speed delay				YES / NO
			Verzögert durch Motordrehz.				
			{0}	{1o}	{1oc}	{2oc}	
273			✓	✓	✓	✓	YESThe alarm is delayed until engine monitoring is enabled. Therefore the conditions of Parameter 55 "Engine delayed monitoring" must be fulfilled. NOThe alarm is not delayed until engine monitoring is enabled. Fault conditions are immediately analyzed.
	DE	EN	Limit {x} [x = 1 to 4]: Hysteresis				0 to 999
			Hysterese				
			{0}	{1o}	{1oc}	{2oc}	
274			✓	✓	✓	✓	During monitoring, the actual value must exceed or fall below one of the limits defined in parameter 268 to be recognized as out of permissible limits. For a value to register as having returned to the permissible limits, the monitored value must rise above or fall below this value for the hysteresis. The format for entering the hysteresis depends on the monitored analog input and corresponds with the one of the threshold listed in Parameter 268. Note: When using the flexible thresholds, the setting of Parameter 252 has no effect.
	DE	EN	Limit {x} [x = 1 to 4]: Message text				user-defined
			Beschreibung				
			{0}	{1o}	{1oc}	{2oc}	
L 275			✓	✓	✓	✓	If the configured threshold of the flexible analog input has been reached or exceeded this text is displayed in the control unit screen. The event log will store this text message and it is also used for the visualization screen.

Analog Inputs: Characteristics "Table A" And "Table B" (9 Point Scaling)

The characteristic curves of "Table A" and "Table B" (freely configurable over 9 defined percentage points) are independently configurable for all analog inputs. Each percentage point may be scaled to related values measured from the analog input (0 to 500 Ohm, 0 to 20 mA or 4 to 20 mA), so that the actual display reflects the measured values (i.e. -100 to 100 kW). The so developed characteristic curve can be used for visualization and monitoring via the configuration to "Table A" (for Table A) as well as "Table B" (for Table B)




Figure 3-51: Analog input scaling - table (example)



NOTE

The X and Y junction may be moved within the range of values (the junctions don't have to be equidistant).

When configuring the X coordinates, ensure the coordinates always increase in scale continuously. In the following example the first set of x/y coordinates are correct and the second set of x/y coordinates are wrong:

- correct**

X-coord.	0 %	10 %	20 %	40 %	50 %	60 %	80 %	90 %	100 %
Y-coordinate	-100	-95	-500	-10	+3	+17	+18	+100	+2000
- wrong**

X-coord.	0 %	10 %	20 %	60 %	20 %	30 %	80 %	40 %	100 %
Y-coordinate	-100	-50	-95	+18	+17	+3	-10	+2000	+100

If the first X coordinate is >0%, all values smaller than the first X value will be output with the first Y value. If the last Y value is <100%, all higher values will be output with the value of Y9.

DE	EN	X-value {a}			
		X-Wert {a}			
		{0}	{10}	{100}	{200}
276		✓	✓	✓	✓

Table {x} [x = A/B]: X-coordinate {a} [a = 1 to 9]

0 to 100 %

The analog input is assigned to a curve. This parameter defines the actual percentage assigned to each of the nine points along the X-axis of the total range of the selected hardware for analog input. For example: If a 0 to 20mA input is configured and the X1-coordinate=0%, then the Y1-coordinate=0mA. If a 4 to 20mA input is configured and the X1-coordinate=0%, then the Y1-coordinate=4mA

DE	EN	Y-value {b}			
		Y-Wert {b}			
		{0}	{10}	{100}	{200}
277		✓	✓	✓	✓

Table {x} [x = A/B]: Y-coordinate {b} [b = 1 to 9]

-9999 to 9999

This parameter defines the Y-coordinate (the displayed and monitored value) at the corresponding X-coordinate. For example: If a 0 to 20mA input is configured and the X2-coordinate=10%, then the Y2-coordinate=2mA. If a 4 to 20mA input is configured and the X2-coordinate=10%, then the Y2-coordinate=5.6mA.

Counters



Counters: Maintenance Call



NOTE

A maintenance call will be issued if the configured number of operating hours has expired or the configured number of days has expired since the last maintenance.

		Maintenance hours				Counter: Maintenance interval 'Hours'		0 to 9,999	
		Wartungsintervall Stunden							
		{0}	{1o}	{1oc}	{2oc}	ⓘ To disable the maintenance "hours" counter configure "0" for this entry.			
278		✓	✓	✓	✓				

This parameter defines the remaining hours until the next maintenance call occurs. Once the generator has been operated for the number of hours configured here, a maintenance message is displayed.

If the maintenance counter is reset either by the push-buttons at the front panel (see manual 37322), or by configuring the parameter "Reset maintenance call" to "YES" (see Parameter 280), the maintenance counter is reset to the configured value.

DE	Maintenance days				Counter: Maintenance interval 'Days'	0 to 999 day
	Wartungsintervall Tage					
EN	{0}	{1o}	{1oc}	{2oc}	ⓘ To disable the maintenance "days" counter configure "0" for this entry.	
	✓	✓	✓	✓		

This parameter defines the remaining days until the next maintenance call occurs. Once the configured number of days has expired since the last maintenance, a maintenance message is displayed.

If the maintenance counter is reset either by the push-buttons at the front panel (see manual 37322), or by configuring the parameter "Reset maintenance call" to "YES" (see Parameter 281), the maintenance counter is reset to the configured value.

DE	EN	Reset maintenance period h				Counter: Reset maintenance call counter 'Hours'	YES / NO
		Wartungsstunden rücksetzen					
280		{0}	{1o}	{1oc}	{2oc}	If this parameter is configured to "YES" the maintenance "hours" counter is reset to the configured value. Once the counter has been reset, the control unit changes this parameter to "NO".	
	✓	✓	✓	✓			

DE	Reset maintenance period days				Counter: Reset maintenance call counter 'Days'	YES / NO
	Wartungstage rücksetzen					
281					If this parameter is configured to "YES" the maintenance "days" counter is reset to the configured value. Once the counter has been reset, the control unit changes this parameter to "NO".	
	{0}	{1o}	{1oc}	{2oc}		

Code level for reset maintenance		Counter: Code level for resetting the maintenance call				0 to 3
Codeebene für Wrtg. rücksetzen						
	{0}	{1o}	{1oc}	{2oc}		
282	✓	✓	✓	✓	This parameter determines the required code level for resetting the visualization screen "Maintenance call in " User with a lower code level may not access this	

The following code levels exist:

3 = Commissioner

2 = Temporary commissioner

1 = Service level

0 = Operator

Counters: Running Hours, kWh And kvarh

<div>EN</div> <div>Counter value preset</div>	<div>Counter: Set point value for counters</div> <div>0 to 99,999,999</div>
<div>DE</div> <div>Zähler-Setzwert</div>	
<div>283</div> <div>{0} {1o} {1oc} {2oc}</div>	<div>This value is utilized to set the hours in the following parameters:</div>
	<ul style="list-style-type: none"> • running hours
	<ul style="list-style-type: none"> • kWh counter
	<ul style="list-style-type: none"> • kvarh counter
	<p>The number entered into this parameter is the number that will be set to the parameters listed above when they are enabled.</p>
<div>EN</div> <div>Set operation hours in 000h</div>	<div>Counter: Set running hours counter</div> <div>YES / NO</div>
<div>DE</div> <div>Betriebsstd. setzen in 000h</div>	
<div>284</div> <div>{0} {1o} {1oc} {2oc}</div>	<div>YES</div>
	<div>The current value of this counter is overwritten with the value configured in "set point value for counters". After the counter has been (re)set, this parameter changes back to "NO" automatically.</div>
	<div>NO</div>
	<div>The value of this counter is not changed.</div>
<div>EN</div> <div>Set active energy in 0.00MWh</div>	<div>Counter: Set kWh counter</div> <div>YES / NO</div>
<div>DE</div> <div>Wirkarbeitsz. setzen in 0,00MWh</div>	
<div>285</div> <div>{0} {1o} {1oc} {2oc}</div>	<div>YES</div>
	<div>The current value of this counter is overwritten with the value configured in "set point value for counters". After the counter has been (re)set, this parameter changes back to "NO" automatically.</div>
	<div>NO</div>
	<div>The value of this counter is not changed.</div>
<div>EN</div> <div>Set reactive energy 0.00Mvarh</div>	<div>Counter: Set kvarh counter</div> <div>YES / NO</div>
<div>DE</div> <div>Blindarbeitsz. set. 0,00Mvarh</div>	
<div>286</div> <div>{0} {1o} {1oc} {2oc}</div>	<div>YES</div>
	<div>The current value of this counter is overwritten with the value configured in "set point value for counters". After the counter has been (re)set, this parameter changes back to "NO" automatically.</div>
	<div>NO</div>
	<div>The value of this counter is not changed.</div>



NOTE

Example: The counter value preset (Parameter 283) is configured to "3456".

If Parameter 284 will be configured to YES, the operation hour counter will be set to 3456h.

If Parameter 285 will be configured to YES, the active energy counter will be set to 34.56MWh.

Counters: Start Counter

<div>EN</div> <div>Counter value preset</div>	<div>Counter: Set point value for start counter</div> <div>0 to 65535</div>
<div>DE</div> <div>Zähler-Setzwert</div>	
<div>287</div> <div>{0} {1o} {1oc} {2oc}</div>	<div>This parameter defines the number of times the control unit registers a start of the generator set. The number entered here will overwrite the current displayed value after confirming with Parameter 288.</div>
<div>EN</div> <div>Set number of starts</div>	<div>Counter: Set start counter</div> <div>YES / NO</div>
<div>DE</div> <div>Anzahl Starts setzen</div>	
<div>288</div> <div>{0} {1o} {1oc} {2oc}</div>	<div>YES.....</div>
	<div>The current value of the start counter is overwritten with the value configured in "Set point value for start counter". After the counter has been (re)set, this parameter changes back to "NO" automatically.</div>
	<div>NO</div>
	<div>The value of this counter is not changed..</div>

LogicsManager



LogicsManager: Limit Switch (Load)

LogicsManager: Limit switch 'generator power'

It is possible to configure multiple power limit set points that will energize a discrete output when a specific limit has been reached. By utilizing the *LogicsManager*, it is possible to use the monitored values of various parameters to evaluate the condition of the generator and power being monitored as command variable. This makes it possible to disconnect the load via an external circuit.



NOTE

This function **is not** designed to be a generator protection function. An external circuit may be combined with the functions performed here to create additional generator protective functions. The additional protective functions will not result in the issuing of a centralized alarm or a fault condition message being displayed in the LC Display of the control unit.

EN	Gen. load limit 1	Limit monitoring: Generator power: Limit (Limit 1)	0.0 to 200.0 %
DE	Generatorlast St.1	<p>① This value refers to the Rated active power (Parameter 10, see page 17).</p>	
289	{0} {1o} {1oc} {2oc}	<p>The percentage value, which is to be monitored, is configured with this parameter. If this value is reached or exceeded, the command variable is set to "TRUE".</p>	
	✓ ✓ ✓ ✓		
EN	Gen. load limit 2	Limit monitoring: Generator power: Limit (Limit 2)	0.0 to 200.0 %
DE	Generatorlast St.2	<p>① This value refers to the Rated active power (Parameter 10, see page 17).</p>	
290	{0} {1o} {1oc} {2oc}	<p>The percentage value, which is to be monitored, is configured with this parameter. If this value is reached or exceeded, the command variable is set to "TRUE".</p>	
	✓ ✓ ✓ ✓		
EN	Gen. load hysteresis	Limit monitoring: Generator power: hysteresis (Limit 1/Limit 2)	0.0 to 100.0 %
DE	Generatorlast Hysterese	<p>① This value refers to the Rated active power (Parameter 10, see page 17).</p>	
291	{0} {1o} {1oc} {2oc}	<p>If the monitored value has exceeded the configured set point, the monitored value must fall below the limit set point and the value configured here for the hysteresis (this value applies to both limit values). When the monitored value falls below the hysteresis, the internal flag is set to "FALSE".</p>	
	✓ ✓ ✓ ✓		

LogicsManager: Limit switch 'mains power' {2oc} (Load)

It is possible to configure multiple power limit set points that will energize a discrete output when that limit has been reached. By utilizing the *LogicsManager*, it is possible to use the monitored values of various parameters to evaluate the condition of the mains and power being monitored as command variable. This makes it possible to disconnect the load via an external circuit.

**NOTE**

This function **is not** designed to be a mains protection function. An external circuit may be combined with the functions performed here to create additional mains protective functions. The additional protective functions will not result in the issuing of a centralized alarm or a fault condition message being displayed in the LC Display of the control unit.

DE	EN	Mains load limit 1				Limit monitoring: Mains power: limit value (Limit 1)	-999.9 to 999.9 %
		Netzlast St.1					
		{0}	{1o}	{1oc}	{2oc}		
292		---	---	---	✓	① This value refers to the rated values of the mains current and voltage transformer (Parameters 14 or 15 and 19).	

The percentage value, which is to be monitored, is configured with this parameter. If this value is reached or exceeded, the command variable is set to "TRUE".

DE	EN	Mains load limit 2				Limit monitoring: Mains power: limit value (Limit 2)	-999.9 to 999.9 %
		Netzlast St.2					
		{0}	{1o}	{1oc}	{2oc}		
293		---	---	---	✓	① This value refers to the rated values of the mains current and voltage transformer (Parameters 14 or 15 and 19).	

The percentage value, which is to be monitored, is configured with this parameter. If this value is reached or exceeded, the command variable is set to "TRUE".

DE	EN	Mains load hysteresis				
		Netzlast Hysterese				
		{0}	{1o}	{1oc}	{2oc}	
294		---	---	---	✓	<div>Limit monitoring: Mains power: hysteresis (Limit 1/Limit 2)</div> <div>0.0 to 100.0 %</div> <div> ⓘ This value refers to the rated values of the mains current and voltage transformer (Parameters 14 or 15 and 19).</div>

If the monitored value has exceeded the configured set point, the monitored value must fall below the limit set point and the value configured here for the hysteresis (this value applies to both limit values). When the monitored value falls below the hysteresis, the internal flag is set to "FALSE".

LogicsManager: Internal Flags

Internal flags within the *LogicsManager* logical outputs may be programmed and used for multiple functions. For conditions and explanation of programming please refer to page 127 in chapter "*LogicsManager*".

		Flag {x}				Internal flags: Flag {x} [x = 1 to 8]	LogicsManager
DE	EN	Merker {x}					
		{0}	{1o}	{1oc}	{2oc}		
295		✓	✓	✓	✓	The flags may be used as auxiliary flags for complex combinations by using the logical output of these flags as command variable for other logical outputs.	

**NOTE**

Flag 1 is also used as placeholder in other logical combinations. Flag 8 is preset with a timer start.

LogicsManager: Timer

LogicsManager: Daily Time Set Point

Utilizing the *LogicsManager* it is possible to establish specific times of the day that functions (i.e. generator exerciser) can be enabled. The two daily time set points are activated each day at the configured time. Using the *LogicsManager* these set points may be configured individually or combined to create a time range.

DE	EN	Setpoint {x}: Hour				Timer: Daily time set point {x} [x = 1/2]: hour	0 to 23 h
		Setpoint {x}: Stunde					
296	✓	{0}	{1o}	{1oc}	{2oc}	Enter the hour of the daily time set point here. Example: 00 th hour of the day (midnight). 2323 rd hour of the day (11pm).	
DE	EN	Setpoint {x}: Minute				Timer: Daily time set point {x} [x = 1/2]: minute	0 to 59 min
		Setpoint {x}: Minute					
297	✓	{0}	{1o}	{1oc}	{2oc}	Enter the minute of the daily time set point here. Example: 00 th minute of the hour. 5959 th minute of the hour.	
DE	EN	Setpoint {x}: Second				Timer: Daily time set point {x} [x = 1/2]: second	0 to 59 s
		Setpoint {x}: Sekunde					
298	✓	{0}	{1o}	{1oc}	{2oc}	Enter the second of the daily time set point here. Example 00 th second of the minute. 5959 th second of the minute.	

LogicsManager: Active Time Set Point

Utilizing the *LogicsManager* it is possible to establish specific days (or hours, minutes, seconds) that functions (i.e. generator exerciser) can be enabled. The active switching point is activated only on a specified day (or hour, minute, second). The set points may be configured individually or combined via the *LogicsManager*. You may configure monthly, daily, hourly, minutely, or even secondly time set points depending on how you combine the set points in the *LogicsManager*.

EN	Active day				Timer: Active time set point: day	1 to 31
DE	Aktiver Tag					
	{0}	{1o}	{1oc}	{2oc}	Enter the day of the active switch point here. Example:	
299	✓	✓	✓	✓	011 st day of the month. 3131 st day of the month. The active time set point is enabled during the indicated day from 0:00:00 hours to 23:59:59 hours.	

EN	Active hour				Timer: Active time set point: hour	0 to 23 h
DE	Aktive Stunde					
	{0}	{1o}	{1oc}	{2oc}	Enter the hour of the active switch point here. Example:	
300	✓	✓	✓	✓	00 th hour of the day. 2323 rd hour if the day. The active time set point is enabled every day during the indicated hour from minute 0 to minute 59.	

EN	Active minute				Timer: Active time set point: minute	0 to 59 min
DE	Aktive Minute					
	{0}	{1o}	{1oc}	{2oc}	Enter the minute of the active switch point here. Example:	
301	✓	✓	✓	✓	00 th minute of the hour. 5959 th minute of the hour. The active time set point is enabled every hour during the indicated minute from second 0 to second 59.	

DE	EN	Active second				Timer: Active time set point: second	0 to 59 s
		Aktive Sekunde					
		{0}	{10}	{10c}	{20c}		
302		✓	✓	✓	✓	<p>Enter the second of the active switch point here. Example:</p> <p>0.....0th second of the minute.</p> <p>59.....59th second the minute.</p> <p>The active time set point is enabled every minute during the indicated second.</p>	

LogicsManager: Weekly Time Set Point

Utilizing the *LogicsManager* it is possible to establish specific days of the week that functions (i.e. generator exciser) can be enabled. The weekly time set point is enabled during the indicated day from 0:00:00 hours to 23:59:59 hours.

		{x} active				Timer: Weekly time set points {x} [x = Mo-Su]: days	YES / NO
DE	EN	{x} aktiv					
		{0}	{1o}	{1oc}	{2oc}		
303		✓	✓	✓	✓	Please enter the days of the weekly workdays. Example: Monday YES - The switch point is enabled every Monday NO - The switch point is disabled every Monday Tuesday YES - The switch point is enabled every Tuesday NO - The switch point is disabled every Tuesday Wednesday YES - The switch point is enabled every Wednesday NO - The switch point is disabled every Wednesday Thursday YES - The switch point is enabled every Thursday NO - The switch point is disabled every Thursday Friday YES - The switch point is enabled every Friday NO - The switch point is disabled every Friday Saturday YES - The switch point is enabled every Saturday NO - The switch point is disabled every Saturday Sunday YES - The switch point is enabled every Sunday NO - The switch point is disabled every Sunday	

Interfaces



DE	EN	Device number
		Gerätenummer
		{0} {1o} {1oc} {2oc}
304		✓ ✓ ✓ ✓

Interfaces: Device address

1 to 127

So that this control unit may be positively identified on the CAN bus, the unit address must be set in this parameter. The address may only be represented once on the CAN bus. All other addresses on the CAN bus are calculated on the basis of the address entered in this parameter.

Interfaces: CAN Bus (*FlexCAN*)



NOTE

For the description of CANopen parameters please refer to Manual 37262.

DE	EN	Protocol
		Protokoll
		{0} {1o} {1oc} {2oc}
305		✓ ✓ ✓ ✓

CAN bus: Protocol

OFF / CANopen / LeoPC

The CAN bus of this unit may be operated with different protocols and Baud rates. This parameter defines the protocol to be utilized. Please note, that all participants on the CAN bus must use the same protocol.

OFFThe CAN bus is disconnected. Values are not sent or received.

CANopenThe CANopen protocol is used. More information may be found in the interface manual 37262 under CANopen.

LeoPCThe CAN CAL protocol is used. More information may be found in the interface manual 37262 under CAN (CAL).

DE	EN	Baudrate
		Baudrate
		{0} {1o} {1oc} {2oc}
306		✓ ✓ ✓ ✓

CAN bus: Baud rate

20 / 50 / 100 / 125 / 250 / 500 / 800 / 1,000 kBaud

The CAN bus of this unit may be operated with different protocols and Baud rates. This parameter defines the used Baud rate. Please note, that all participants on the CAN bus must use the same Baud rate.

Interfaces: J1939

DE	EN	Device type
		Betriebsmodus
		{0} {1o} {1oc} {2oc}
307		✓ ✓ ✓ ✓

J1939 Interface: Device type

Off / Standard / S6 Scania / EMR

The J1939 interface of this device may be operated with different engine control units. This parameter determines the operating mode of the used ECU.

OffThe J1939 interface is disabled. No messages will be received.

StandardStandard J1939 messages will be received. Refer to manual 37262, chapter CAN SAE J1939, for more information.

S6 ScaniaStandard J1939 messages plus special S6 Scania messages will be received. Refer to manual 37262, chapter CAN SAE J1939, for more information.

EMRStandard J1939 messages plus special EMR messages will be received. Refer to manual 37262, chapter CAN SAE J1939, for more information.

	EN	Request send address				J1939 Interface: Request send address	0 to 255
	DE	Request Sendadresse					
308		{0}	{1o}	{1oc}	{2oc}		
		✓	✓	✓	✓		
The J1939 protocol device number is necessary to request special parameter groups, which are only sent on request. With this participant address also the acknowledge command for passive alarms is sent (Diagnostic Data Clear/Reset of Previously Active DTCs -DM3). Details may be found in the manual of the genset control.							
	EN	Receive device number				J1939 Interface: Request device number	0 to 255
	DE	Empf. Geräte Nummer					
309		{0}	{1o}	{1oc}	{2oc}		
		✓	✓	✓	✓		
Indicates the number of the J1939 device, whose data shall be displayed.							
	EN	Reset prev.active DTCs - DM3				J1939 Interface: Reset previously active DTCs - DM3	YES / NO
	DE	Quittieren passiver Fehler DM3					
310		{0}	{1o}	{1oc}	{2oc}		
		✓	✓	✓	✓		
If this parameter is set YES, a DM3 message "Acknowledge passive faults" is sent. After that this parameter is reset automatically to NO. As a result alarms (DM2) which no longer apply are cleared.							
	EN	SPN version				J1939 Interface: SPN version	Version 1 / Version 2 / Version 3
	DE	SPN Version					
311		{0}	{1o}	{1oc}	{2oc}		
		✓	✓	✓	✓		
The J1939 protocol provides 4 different versions for formatting Suspect Parameter Number. This is important for a correct display of the alarm messages. With this parameter it is defined if formatting occurs according to Version 1, Version 2, or Version 3. Formatting according to Version 4 is identified automatically. Details may be found in the engine control J1939 manual.							
	EN	ECU remote controlled				J1939 Interface: ECU remote control via J1939	ON / OFF
	DE	Fernsteuern der ECU über J1939					
312		{0}	{1o}	{1oc}	{2oc}		
		✓	✓	✓	✓		
ON The ECU remote control via the J1939 protocol will be activated. OFF The ECU remote control via the J1939 protocol will be deactivated. The blink codes can neither be read nor reset. The following two parameters will not be displayed.							
Note: This parameter is only available if Parameter 307 is configured to S6 Scania.							
	EN	ECU set droop mode				J1939 Interface: ECU set droop mode	ON / OFF
	DE	ECU Statik-Modus					
313		{0}	{1o}	{1oc}	{2oc}		
		✓	✓	✓	✓		
ON The droop mode of the ECU will be enabled via the J1939 interface. OFF The droop mode of the ECU will be disabled via the J1939 interface.							
	EN	Frequency Offset ECU				J1939 Interface: Frequency Offset ECU	OFF/ AnalagIn1 / AnalogIn2
	DE	Frequenz Offset ECU					
314		{0}	{1o}	{1oc}	{2oc}		
		✓	✓	✓	✓		
This parameter is used to configure a variable offset via an analog input of the easYgen. The analog input must be configured with a scaling from -125 to +125. If it is configured otherwise, it will be limited to the sizes -125 to 125. -125 corresponds to the maximum negative offset of the Scania S6 (EMS) by default 120 RPM. 125 corresponds with the maximum positive offset of the Scania S6 (EMS) by default 120 RPM.							

Interfaces: Serial Interface

DE	EN	Baudrate				Serial interface: Baud rate	2.4 / 4.8 / 9.6 / 14.4 / 19.2 / 38.4 / 65 / 115 kBaud
		Baudrate					
315		{0}	{1o}	{1oc}	{2oc}	<div>① A DPC (P/N 5417-557) must be used for connecting the control unit from the service interface to a PC or to another participant.</div>	
		✓	✓	✓	✓		
The serial interface of this unit connects to an RJ45-plug on the side of the housing. This parameter defines the baud rate that communications will be performed. Please note, that all participants on the service interface must use the same Baud rate.							
DE	EN	Parity				Serial interface: Parity	no / even / odd
		Parity					
316		{0}	{1o}	{1oc}	{2oc}	The used parity of the service interface is set here.	
		✓	✓	✓	✓		
DE	EN	Stop bits				Serial interface: Stop bits	one / two
		Stop Bits					
317		{0}	{1o}	{1oc}	{2oc}	The number of stop bits is set here.	
		✓	✓	✓	✓		
DE	EN	ModBus Slave ID				Serial interface: Modbus Slave ID	0 to 255
		ModBus Slave ID					
318		{0}	{1o}	{1oc}	{2oc}	Here, the Modbus device address is entered, which is used to identify the device via Modbus.	
		✓	✓	✓	✓		
DE	EN	Modbus Reply delay time				Serial interface: Reply delay time	0,00 to 1,00 s
		Modbus Zeitverzöger. der Antwort					
319		{0}	{1o}	{1oc}	{2oc}	This is the minimum delay time between a request from the Modbus master and the sent response of the slave. This time is also required if an external interface converter to RS-485 is used for example. Please note that you also need the DPC (see page 10) in this case.	
		✓	✓	✓	✓		



NOTE

The service interface may be used for the following connections:

- LeoPC1 via direct driver
- LeoPC1 via a modem
- Requests via Modbus protocol

System



System: Password System

EN	Code level CAN port	Password system: Code level via CAN-Bus	Info
DE	Codeebene CAN Schnittstelle		
	{0} {1o} {1oc} {2oc}		
320	✓ ✓ ✓ ✓	This value displays the code level which is currently selected for the access via the CAN bus.	
EN	Code level serial port/DPC	Password system: Code level via serial RS-232 (DPC) interface	Info
DE	Codeebene RS232/DPC		
	{0} {1o} {1oc} {2oc}		
321	✓ ✓ ✓ ✓	This value displays the code level that is currently selected for the access via the serial RS-232 (DPC) interface. The following code levels exist: 3 = Commissioner 2 = Temporary commissioner 1 = Service level 0 = Operator	



NOTE

The following passwords permit different levels of access to the parameters. Each individual password can be used to access the appropriate configuration level through the different methods of access (via the front panel, via serial RS-232 (DPC) interface, and via CAN bus).

EN	Commissioning level code	Password system: Password "Commissioner"	0000 to 9999
DE	Code Inbetriebnahme Ebene		
	{0} {1o} {1oc} {2oc}		
322	✓ ✓ ✓ ✓	Configuration of the password for the code level "Commissioner". See chapter Password on page 15 for default values.	
EN	Temp. commissioning level code	Password system: Password "Temporary Commissioner"	0000 to 9999
DE	Code temp. Inbetriebn. Ebene		
	{0} {1o} {1oc} {2oc}		
323	✓ ✓ ✓ ✓	Configuration of the password for the code level "Temporary Commissioner". See chapter Password on page 15 for default values.	
EN	Basic level code	Password system: Password "Service Level"	0000 to 9999
DE	Code Serviceebene		
	{0} {1o} {1oc} {2oc}		
324	✓ ✓ ✓ ✓	Configuration of the password for the code level "Service". See chapter Password on page 15 for default values.	

System: Factory Settings

EN	Ereignisspeicher löschen				Factory settings: Clear event log		YES / NO
DE	Clear event log						
325	{0}	{1o}	{1oc}	{2oc}	YES	The event log will be cleared.	
	✓	✓	✓	✓	NO	The event log will not be cleared.	
EN	Werkseinstellung DPC/RS232				Factory settings: Factory settings DPC/RS-232		YES / NO
DE	Factory Settings DPC/RS232						
326	{0}	{1o}	{1oc}	{2oc}	YES	The resetting of the factory settings via DPC/RS-232 will be enabled.	
	✓	✓	✓	✓	NO	The resetting of the factory settings via DPC/RS-232 will not be enabled.	
EN	Werkseinstellung CAN				Factory settings: Factory settings CAN		YES / NO
DE	Factory Settings CAN						
327	{0}	{1o}	{1oc}	{2oc}	YES	The resetting of the factory settings via CAN bus will be enabled.	
	✓	✓	✓	✓	NO	The resetting of the factory settings via CAN bus will not be enabled.	
EN	Standardwerte				Factory settings: Set default values		YES / NO
DE	Set default values						
328	{0}	{1o}	{1oc}	{2oc}	YES	The factory settings, which have been enabled with Parameter 327 or Parameter 328, will be transferred to the unit.	
	✓	✓	✓	✓	NO	The factory settings will not be transferred to the unit.	
EN	Bootloader starten				Factory settings: Start Bootloader		00000
DE	Start Bootloader						
329	{0}	{1o}	{1oc}	{2oc}	This function may be used to start the Bootloader. In order to do this, the correct code must be entered here while the unit is in the code level required for this.		
	✓	✓	✓	✓			

Attention: This function is used to flash the software and may only be used by authorized Woodward technicians!




NOTE

If the easYgen parameters are read out via CAN / DPC and stored as standard values, all parameters behind Parameter 328 (Set default values) will not be overwritten when writing back the standard value file via CAN / DPC.

This prevents an unintentional start of the Bootloader or an overwriting of the time or date in the unit with a wrong (old) value. The following version information is only for info anyway and cannot be overwritten.

System: Real-Time Clock



This screen shows the current date and time. The clock is implemented as real time clock. In case of a voltage supply failure an internal battery guarantees that the information is not lost. The data stand for:

XX:YY:ZZ hour:minute:second.

AAAA-BBB-CC Year-month-day.

System: Adjust Clock

DE	EN	Hour				Adjust clock: hour	0 to 23 h
		Stunden					
		{0}	{1o}	{1oc}	{2oc}		
330		✓	✓	✓	✓		

The current hour of the clock time is set here. Example:
0.....0th hour of the day.

The current hour of the clock time is set here. Example:

0..... 0th hour of the day.

23..... 23th hour of the day.

DE EN	Minute				Adjust clock: minute	0 to 59 min
	Minuten					
	{0}	{1o}	{1oc}	{2oc}		
331	✓	✓	✓	✓	The current minute of the clock time is set here. Example: 0.....0 th minute of the hour. 59.....59 th minute of the hour.	

The current minute of the clock time is set here. Example:

0..... 0th minute of the hour.

59..... 59th minute of the hour.

DE	Second				Adjust clock: second	0 to 59 s
	Sekunden					
	{0}	{1o}	{1oc}	{2oc}		
332	✓	✓	✓	✓	The current second of the clock time is set here. Example:	
	0.....0 th second of the minute.					
	59.....59 th second of the minute.					

The current second of the clock time is set here. Example:

0..... 0th second of the minute.

59..... 59th second of the minute.

System: Adjust Date

DE	EN	Day				Adjust clock: day	1 to 31
		Tag					
		{0}	{1o}	{1oc}	{2oc}		
333		✓	✓	✓	✓		

The current day of the date is set here. Example:

1..... 1st day of the month.

31..... 31st day of the month.

The current day of the date is set here. Example:

1..... 1st day of the month.

31..... 31st day of the month.

DE EN	Month				Adjust clock: month	1 to 12
	Monat					
	{0}	{1o}	{1oc}	{2oc}		
334	✓	✓	✓	✓	The current month of the date is set here. Example: 1..... 1 st month of the year. 12..... 12 th month of the year.	

The current month of the date is set here. Example:

1..... 1st month of the year.

12..... 12th month of the year.

DE EN					Year	Adjust clock: year	0 to 99
					Jahr		
	{0}	{1o}	{1oc}	{2oc}			
335	✓	✓	✓	✓			

The current year of the date is set here. Example:
0..... Year 2000.
99..... Year 2099.

The current year of the date is set here. Example:


0..... Year 2000.

99..... Year 2099.

System: Versions

The parameters in this section are informational only and cannot be modified.

The control unit may be identified from the numbers located on the unit and in the software. The most important technical information is located on the unit data plate. Technical data can be located in manual 37320.



1	S/N	serial number (numeric)
2	S/N	manufactured date (YYMM)
3	S/N	serial number (as Barcode)
4	P/N	part number
5	REV	part number revision
6	Details	technical data
7	Type	description (long)
8	Type	Description (short)
9	UL	UL sign

DE	EN	Serial number				Version: Serial number (S/N)	info
		Seriennummer					
336		{0}	{10}	{10c}	{20c}	The serial number (S/N) is utilized to identify individual control units. The number can also be found on the data plate (items #1 & #3).	
		✓	✓	✓	✓		
EN	DE	Boot item number				Version: Part number of the firmware (P/N)	info
		Boot Artikelnummer					
337		{0}	{10}	{10c}	{20c}	The part number (P/N) is the firmware in the control unit.	
		✓	✓	✓	✓		
EN	DE	Boot revision				Version: Revision of the item number of the firmware (REV)	info
		Boot Revision					
338		{0}	{10}	{10c}	{20c}	The revision number (REV) is the revision of the control unit firmware.	
		✓	✓	✓	✓		
EN	DE	Boot version				Version: Version of the firmware	info
		Boot Version					
339		{0}	{10}	{10c}	{20c}	This number (Vx.xxxx) represents the version of the control unit firmware.	
		✓	✓	✓	✓		
EN	DE	Program item number				Version: Item number of the application software (P/N)	info
		Programm Artikelnummer					
340		{0}	{10}	{10c}	{20c}	The part number (P/N) is the application software running the control unit.	
		✓	✓	✓	✓		
EN	DE	Program revision				Version: Revision of the item number of the software (REV)	info
		Programm Revision					
341		{0}	{10}	{10c}	{20c}	The revision number (REV) is the revision of the application software running the control unit.	
		✓	✓	✓	✓		
EN	DE	Program version				Version: Version of the application software	info
		Programm Version					
342		{0}	{10}	{10c}	{20c}	This number (Vx.xxxx) represents the version of the application software running the control unit.	
		✓	✓	✓	✓		

Appendix A. Common

Alarm Classes



The control functions are structured in the following alarm classes:

Alarm class	Visible in the display	LED "Alarm" & horn	Relay "Command: open GCB"	Shut-down engine	Engine blocked until ack. sequence has been performed
A	yes Warning Alarm This alarm does not interrupt the unit operation. A message output without a centralized alarm occurs: ⇒ Alarm text.	no	no	no	no
B	yes Warning Alarm This alarm does not interrupt the unit operation. An output of the centralized alarm occurs and the command variable 3.05 (horn) is issued. ⇒ Alarm text + flashing LED "Alarm" + Relay centralized alarm (horn).	yes	no	no	no
C	yes Responding Alarm With this alarm the GCB is opened and the engine is stopped. Coasting occurs. ⇒ Alarm text + flashing LED "Alarm" + Relay centralized alarm (horn) + GCB open + Coasting + Engine stop.	yes	immediately	cool down time	yes
D	yes Responding Alarm With this alarm the GCB is opened and the engine is stopped. Coasting occurs. ⇒ Alarm text + flashing LED "Alarm" + Relay centralized alarm (horn) + GCB open + Coasting + Engine stop.	yes	immediately	cool down time	yes
E	yes Responding Alarm With this alarm the GCB is opened immediately and the engine is stopped. ⇒ Alarm text + flashing LED "Alarm" + Relay centralized alarm (horn)+ GCB open + Engine stop.	yes	immediately	immediately	yes
F	yes Responding Alarm With this alarm the GCB is opened immediately and the engine is stopped. ⇒ Alarm text + flashing LED "Alarm" + Relay centralized alarm (horn)+ GCB open + Engine stop.	yes	immediately	immediately	yes
Control	no Control Signal This signal issues a control command only. It may be assigned to a digital input for example to get a control signal, which may be used in the <i>LogicsManager</i> . No alarm message and no entry in the alarm list or the event logger will be issued. This signal is always self-acknowledging, but considers a delay time and may also be configured with an engine delay.	no	no	no	no



NOTE

If an alarm has been configured with a shut-down alarm that has been enabled to self-acknowledge, and has been configured as engine delayed the following scenario may happen:

- The alarm shuts down the engine because of its alarm class.
- Due to the engine stopping, all engine delayed alarms are ignored.
- The alarm class is acknowledged automatically.
- The alarm will self-acknowledge and clear the fault message that shut the engine down. This prevents the fault from being analyzed. After a short delay, the engine will restart.
- After the engine monitoring delay expires, the fault that originally shut down the engine will do so again. This cycle will continue to repeat until corrected.

Conversion Factors



Temperature

$^{\circ}\text{C} \Leftrightarrow ^{\circ}\text{F}$	$^{\circ}\text{F} \Leftrightarrow ^{\circ}\text{C}$
$T\text{ [}^{\circ}\text{F]} = (T\text{ [}^{\circ}\text{C]} \times 1.8) + 32$	$T\text{ [}^{\circ}\text{C]} = (T\text{ [}^{\circ}\text{F]} - 32) / 1.8$

Pressure

$\text{bar} \Leftrightarrow \text{psi}$	$\text{psi} \Leftrightarrow \text{bar}$
$P\text{ [psi]} = P\text{ [bar]} \times 14.503$	$P\text{ [bar]} = P\text{ [psi]} / 14.503$

Appendix B.

LogicsManager


The *LogicsManager* is used to customize the sequence of events in the control unit such as the start command of the engine or the operation of control unit relay outputs. For example, the start routine may be programmed so that it requires the closing of a discrete input or a preset time of day. Depending on the application mode of the unit, the number of available relays that may be programmed with the *LogicsManager* will vary. Two independent time delays are provided for the configured action to take place and be reset. The following table shows the function of each relay in each of the application modes.

Starting the engine can be carried out externally via a discrete input. With it the *LogicsManager* is used whose conditions and programming is defined as follows:

Relay Number		Term.	Application mode			
			Basic {0}	GCB open {1o}	GCB open/close {1oc}	GCB/MCB open/close {2oc}
Internal relay outputs						
[R1]	30/35	LogicsManager				
[R2]	31/35	LogicsManager				
[R3]	32/35	Crank				
[R4]	33/35	Diesel: Fuel solenoid Gas: Gas valve				
[R5]	34/35	LogicsManager; pre-assigned with 'Diesel: Pre-glow, Gas: Ignition'				
[R6]	36/37	LogicsManager; pre-assigned with 'Auxiliary services'				
[R7]	38/39	LogicsManager	Command: open GCB			
[R8]	40/41	LogicsManager				Command: close MCB
[R9]	42/43	LogicsManager				Command: open MCB
[R10]	44/45	LogicsManager			Command: close GCB	
[R11]	46/47	Ready for operation / LogicsManager				
External relay output (via CANopen; not included in easYgen delivery; can be an expansion card like IKD1)						
[REx01]	---	LogicsManager				
[REx02]	---	LogicsManager				
[REx03]	---	LogicsManager				
[REx04]	---	LogicsManager				
[REx05]	---	LogicsManager				
[REx06]	---	LogicsManager				
[REx07]	---	LogicsManager				
[REx08]	---	LogicsManager				
[REx09]	---	LogicsManager				
[REx10]	---	LogicsManager				
[REx11]	---	LogicsManager				
[REx12]	---	LogicsManager				
[REx13]	---	LogicsManager				
[REx14]	---	LogicsManager				
[REx15]	---	LogicsManager				
[REx16]	---	LogicsManager				

Table 3-52: Relay outputs - Assignment

Structure and description of the *LogicsManager*

Figure 3-53: *LogicsManager* - function overview

- **Command (variable)** - A list of over 100 parameters and functions is provided for the command inputs. Examples of the parameters that may be configured into these commands are Generator undervoltage set points 1 and 2, Start fail, and Cool down. These command variables are used to control the output function or relay.
- **Sign** - The sign field can be used to invert the state of the command or to fix its output to a logical true or false if the command is not needed. Setting the sign to the NOT state changes the output of the command variable from true to false or vice versa.
- **Operator** - A logical device such as AND or OR.
- **(Logical) output** - The action or control sequence that occurs when all parameters set into the *LogicsManager* are met.



[Cx] - Command {x}	[Sx] - Sign {x}	[Ox] - Operator {x}	[Ax] - Output {x}
The description and the tables of all values, flags, and internal functions that are able to combine via the <i>LogicsManager</i> can be found on page 127.	Value {[Cx]} The value [Cx] is passed 1:1. —	AND Logical AND	The description and the tables of all logical outputs, flags, and functions that are able to combine via the <i>LogicsManager</i> can be found on page 127.
	NOT VALUE {[Cx]} The opposite of the value [Cx] is passed.  	NAND Logical negated AND	
	0 [always "0"] The value [Cx] is ignored and this logic path will always be FALSE. 0—	OR Logical OR	
	1 [always "1"] The value [Cx] is ignored and this logic path will always be TRUE. 1—	NOR Logical negated OR	
		XOR Exclusive OR	
		NXOR Exclusive negated OR (See Table 3-57 for symbols)	

Table 3-54: *LogicsManager* - command overview

NOTE

A logical output may either be delayed when switching on or switching off. The time starts when all logical functions of the operation have been met.

Configuration of the chain of commands

Using the values specified in the above table, the chain of commands of the *LogicsManager* (for example: operating the relays, setting the flags, specification of the automatic functions) is configured as follows:

$$[Ax] = (([C1] \& [S1]) \& [O1] \& ([C2] \& [S2])) \& [O2] \& ([C3] \& [S3])$$

Programming example for the *LogicsManager*:

Relay [R1] shall energize, whenever "Discrete input [D2]" is energized "AND" the control does "NOT" have a fault that is "Alarm class C" "AND" "Alarm class D" ⇒




Figure 3-55: *LogicsManager* - display in LeoPC




Figure 3-56: *LogicsManager* - display in LCD

Logical Symbols



The following symbols are used for the graphical programming of the *LogicsManager*.

	AND			OR			NAND			NOR			NXOR			XOR		
easYgen																		
DIN 40 700																		
LeoPC1 ASA US MIL																		
IEC617-12																		
Truth table	x1	x2	y	x1	x2	y	x1	x2	y	x1	x2	y	x1	x2	y	x1	x2	y
	0	0	0	0	0	0	0	0	1	0	0	1	0	0	1	0	0	0
	0	1	0	0	1	1	0	1	1	0	1	0	0	1	0	0	1	1
	1	0	0	1	0	1	1	0	1	1	0	0	1	0	0	1	0	1
	1	1	1	1	1	1	1	1	0	1	1	0	1	1	1	1	1	0

Table 3-57: *LogicsManager* - logical symbols

Logical Outputs



The logical outputs or combinations may be grouped into three categories:

- internal logical flags
- Internal functions
- relay outputs



NOTE

The numbers of the logical outputs in the third column may again be used as input variable for other outputs in the [LogicsManager](#).

Logical Outputs: Internal Flags

8 internal logical flags may be programmed to activate/deactivate functions. This permits more than 3 commands to be included in a logical function. The may be used like "auxiliary flags".

Name	Function	Number
Flag 1	Internal flag 1	00.01
Flag 2	Internal flag 2	00.02
Flag 3	Internal flag 3	00.03
Flag 4	Internal flag 4	00.04
Flag 5	Internal flag 5	00.05
Flag 6	Internal flag 6	00.06
Flag 7	Internal flag 7	00.07
Flag 8	Internal flag 8	00.08

Logical Outputs: Internal functions

The following logical functions may be used to activate/deactivate functions.

Name	Function	Number
Start request in AUTO	Start in AUTOMATIC operating mode (from page 23)	00.09
Stop request in AUTO	Stop in AUTOMATIC operating mode (from page 23)	00.10
Inhibit emergency run	Blocking or interruption of an emergency power operating in AUTOMATIC operating mode (from page 42)	00.11
Undelayed close GCB	Immediately closing of the GCB after engine start without waiting for the engine delayed monitoring and generator stable timers to expire (from page 39)	00.12
Critical mode	Activation of a Critical operation mode where most alarms are downgraded to warnings (functional description from page 25)	00.13
Constant idle run	Enables idle/rated speed modes (from page 36).	00.14
External acknowledge	The alarm acknowledgement is performed from an external source (from page 44)	00.15
Operation mode AUTO	Activation of the AUTOMATIC operating mode (from page 23)	00.16
Operation mode MAN	Activation of the MANUAL operating mode (from page 23)	00.17
Operation mode STOP	Activation of the STOP operating mode (from page 23)	00.18
Start without load request	Starting the engine without closing the GCB (from page 23)	00.19
Idle mode automatic	Automatic idle mode (blocks the undervoltage, underfrequency, and underspeed monitoring for a configured time automatically, from page 36)	00.20

Logical Outputs: Relay Outputs

All relays may be controlled directly by the *LogicsManager* depending on the respective application mode.

Name	Function	Number
Relay 1	If this logical output becomes true, the relay output 1 will be activated	13.01
Relay 2	If this logical output becomes true, the relay output 2 will be activated	13.02
Relay 3	If this logical output becomes true, the relay output 3 will be activated	13.03
Relay 4	If this logical output becomes true, the relay output 4 will be activated	13.04
Relay 5	If this logical output becomes true, the relay output 5 will be activated	13.05
Relay 6	If this logical output becomes true, the relay output 6 will be activated	13.06
Relay 7	If this logical output becomes true, the relay output 7 will be activated	13.07
Relay 8	If this logical output becomes true, the relay output 8 will be activated	13.08
Relay 9	If this logical output becomes true, the relay output 9 will be activated	13.09
Relay 10	If this logical output becomes true, the relay output 10 will be activated	13.10
Relay 11	If this logical output becomes true, the relay output 11 will be activated	13.11
External DO 1	If this logical output becomes true, the external relay output 1 will be activated	14.01
External DO 2	If this logical output becomes true, the external relay output 2 will be activated	14.02
External DO 3	If this logical output becomes true, the external relay output 3 will be activated	14.03
External DO 4	If this logical output becomes true, the external relay output 4 will be activated	14.04
External DO 5	If this logical output becomes true, the external relay output 5 will be activated	14.05
External DO 6	If this logical output becomes true, the external relay output 6 will be activated	14.06
External DO 7	If this logical output becomes true, the external relay output 7 will be activated	14.07
External DO 8	If this logical output becomes true, the external relay output 8 will be activated	14.08
External DO 9	If this logical output becomes true, the external relay output 9 will be activated	14.09
External DO 10	If this logical output becomes true, the external relay output 10 will be activated	14.10
External DO 11	If this logical output becomes true, the external relay output 11 will be activated	14.11
External DO 12	If this logical output becomes true, the external relay output 12 will be activated	14.12
External DO 13	If this logical output becomes true, the external relay output 13 will be activated	14.13
External DO 14	If this logical output becomes true, the external relay output 14 will be activated	14.14
External DO 15	If this logical output becomes true, the external relay output 15 will be activated	14.15
External DO 16	If this logical output becomes true, the external relay output 16 will be activated	14.16

Logical Command Variables



The logical command variables are grouped into 14 categories:

- [00.00] Internal flags
- [01.00] Alarm classes
- [02.00] System status
- [03.00] Engine control
- [04.00] Operating status
- [05.00] Alarms of the engine
- [06.00] Alarms of the generator
- [07.00] Alarms of the mains
- [08.00] Alarms of the system
- [09.00] Discrete inputs
- [10.00] Analog inputs
- [11.00] Time functions
- [12.00] External discrete inputs
- [13.00] Status of the internal relay outputs
- [14.00] Status of the external relay outputs

Logical Command Variables: [00.00] - Internal Flags

Internal flag, Logic command variables 00.01-00.20

Internal Flags are the result of the output of the logic ladders from Flag 1 to 8. Flags are internal logic that can be sent to other flags or Command variables.

No.	Name	Function	Note
00.01	Flag 1	Internal flag 1	Internal calculation; descr. page 130
00.02	Flag 2	Internal flag 2	Internal calculation; descr. page 130
00.03	Flag 3	Internal flag 3	Internal calculation; descr. page 130
00.04	Flag 4	Internal flag 4	Internal calculation; descr. page 130
00.05	Flag 5	Internal flag 5	Internal calculation; descr. page 130
00.06	Flag 6	Internal flag 6	Internal calculation; descr. page 130
00.07	Flag 7	Internal flag 7	Internal calculation; descr. page 130
00.08	Flag 8	Internal flag 8	Internal calculation; descr. page 130
00.09	Start request in AUTO	Start in AUTOMATIC operating mode	Internal calculation; descr. page 23
00.10	Stop request in AUTO	Stop in AUTOMATIC operating mode	Internal calculation; descr. page 23
00.11	Inhibit emergency run	Blocking or interruption of an emergency power operation in AUTOMATIC operating mode	Internal calculation; descr. page 42
00.12	Undelayed close GCB	Immediately closing of the GCB without waiting for the engine delayed monitoring timers to expire	Internal calculation; descr. page 39
00.13	Critical mode	Activation of the Critical operation	Internal calculation; descr. page 25
00.14	Constant idle run	Constant idle speed mode enabled (blocks alarm for undervoltage, underfrequency, and under-speed constantly)	Internal calculation; descr. page 36
00.15	External acknowledge	The alarm acknowledgement is performed from an external source	Internal calculation; descr. page 44
00.16	Operation mode AUTO	Activation of the AUTOMATIC operating mode	Internal calculation; descr. page 23
00.17	Operation mode MAN	Activation of the MANUAL operating mode	Internal calculation; descr. page 23
00.18	Operation mode STOP	Activation of the STOP operating mode	Internal calculation; descr. page 23
00.19	Start without load request	Starting the engine without closing the GCB	Internal calculation; descr. page 23
00.20	Idle mode automatic	Automatic idle speed mode (blocks alarm for undervoltage, underfrequency, and underspeed automatically for a set time)	Internal calculation; descr. page 36

Logical Command Variables: [01.00] - Alarm Classes

Alarm class commands, Logic command variables 01.01-01.10

Alarm classes may be configured as command variables for all logical outputs in the *LogicsManager*.

Number	Name / Function	Note
01.01	Alarm class A	Description see page 125 TRUE as long as this alarm class is active
01.02	Alarm class B	Description see page 125 TRUE as long as this alarm class is active
01.03	Alarm class C	Description see page 125 TRUE as long as this alarm class is active
01.04	Alarm class D	Description see page 125 TRUE as long as this alarm class is active
01.05	Alarm class E	Description see page 125 TRUE as long as this alarm class is active
01.06	Alarm class F	Description see page 125 TRUE as long as this alarm class is active
01.07	All alarm classes	Description see page 125 TRUE as long as at least one of the alarm classes A/B/C/D/E/F is active
01.08	Warning alarm	Description see page 125 TRUE as long as at least one of the alarm classes A/B is active
01.09	Stopping alarm	TRUE as long as one of alarm classes C / D / E / F is active
01.10	Centralized alarm	Description see page 125 TRUE as long as at least one of the alarm classes B/C/D/E/F is active

Logical Command Variables: [02.00] - System Status

System status commands, Logic command variables 02.01-02.15

The status of the system may be used as command variable in a logical output to set parameters for customized operations.

No.	Name	Function	Note
02.01	Firing speed	Ignition speed reached (via MPU/gen.frequency/DI)	TRUE as long as the ignition speed has been reached (either via the MPU, the generator frequency, or the <i>LogicsManager</i> output "ignition speed reached")
02.02	Speed	Speed recognized (via MPU/gen.frequency/DI)	TRUE as long as a speed is measured (this can be lower than the ignition speed)
02.03	Generator voltage ok	Generator voltage within default range	TRUE as long as the generator voltage is within the limits for dead bus start
02.04	Generator frequency ok	Generator frequency within default range	TRUE as long as the generator frequency is within the limits for dead bus start
02.05	Generator ok	Generator voltage/frequency within default range	TRUE as long as the generator voltage and frequency are within the limits for dead bus start
02.06		-Internal-	
02.07		-Internal-	
02.08		-Internal-	
02.09	Mains voltage ok	Mains voltage within default range	TRUE as long as the mains voltage is not within the limits for an emergency power operation
02.10	Mains frequency ok	Mains frequency within default range	TRUE as long as the mains frequency is not within the limits for an emergency power operation
02.11	Mains ok	Mains voltage/frequency within default range	TRUE as long as the mains voltage and frequency are not within the limits for an emergency power operation
02.12	Generator rotation CCW	Generator voltage: rotating direction CW	only possible for three-phase generator voltage measurement
02.13	Generator rotation CW	Generator voltage: rotating direction CCW	
02.14	Mains rotation CCW	Mains voltage: rotating direction CW	only possible for three-phase mains voltage measurement
02.15	Mains rotation CW	Mains voltage: rotating direction CCW	
02.16		-free-	
02.17		-free-	
02.18		-free-	
02.19		-free-	
02.20		-free-	

Logical Command Variables: [03.00] - Engine Control

Engine control commands, Logic command variables 03.01-03.14

These variables may be used as command variable in a logical output to set parameters for customized operations.

Number	Name / Function	Note
03.01	Auxiliary services	
03.02	Starter	
03.03	Start/stop (Diesel) Gas (valve) (Gas)	
03.04	Preglow (Diesel) Ignition (Gas)	
03.05	Horn (active)	TRUE if alarm class B to F is activated until the time until horn reset is expired or it is acknowledged for the first time.
03.06	Engine released	TRUE if the engine is requested and the start is released
03.07	Engine delay over (engine delayed monitoring expired)	TRUE after expiration of the "delayed engine monitoring" timer until the fuel relay is de-energized
03.08	Breaker delay over (engine delayed monitoring expired)	TRUE after expiration of the "breaker delay" timer until the fuel relay is de-energized (= CB may be closed)
03.09	Generator load limit 1 (reached)	TRUE = limit value exceeded
03.10	Generator load limit 2 (reached)	TRUE = limit value exceeded
03.11	Mains load limit 1(reached)	TRUE = limit value exceeded
03.12	Mains load limit 2 (reached)	TRUE = limit value exceeded
03.13	Blinking lamp ECU	TRUE as soon as the ECU activates the diagnosis light (only for EMS Scania ECU). This command variable is only active if remote control of the ECU via easYgen is activated.
03.14	ECU special ignition	TRUE as long as a reset or read-out of the Scania S6 ECU blink code is requested (only for EMS Scania ECU). This command variable is only active if remote control of the ECU via easYgen is activated.
03.15	-free-	
03.16	-free-	
03.17	-free-	
03.18	-free-	
03.19	-free-	
03.20	-free-	

Logical Command Variables: [04.00] - Operating Status

Operating status commands, 4.01-04.15

These operating statuses may be used as command variable in a logical output to set parameters for customized operations.

No.	Name	Function	Note
04.01	Auto mode	AUTOMATIC operating mode active	
04.02	Stop mode	STOP operating mode active	
04.03	Manual mode	MANUAL operating mode active	
04.04	Lamp test	A lamp test is being performed	TRUE if the lamp test is active
04.05	Acknowledge	"Acknowledge" push button has been pressed or an external acknowledgment via LogicsManager	Note: this condition is TRUE for approx. 40 ms and must be extended utilizing a delay time
04.06	GCB closed	GCB is closed ("Reply: GCB is closed" = 0)	{1oc} / {2oc}
04.07	MCB closed	MCB is closed ("Reply: MCB is closed" = 0)	{2oc}
04.08	MCB released	Enable MCB	only {2oc}
04.09	Emergency mode	Emergency power operation active	TRUE with the expiration of the emergency power delay; FALSE with the expiration of the mains setting time
04.10	Cool down	Engine cool-down cycle active	
04.11	Mains settling	Mains setting time active	
04.12	Start without load	Start without closing GCB is active	
04.13	Remote request	Request over remote control to activate a function	TRUE if the start bit is set via DPC (LeoPC1, Modbus) or CAN bus (LeoPC1, CANopen)
04.14	Remote acknowledge	Request over remote control to acknowledge	TRUE if the acknowledgement bit is set
04.15	Idle run active	Idle mode is active	TRUE if the idle mode is active. This may be used to issue an "Idle" command to a speed controller.
04.16		-free-	
04.17		-free-	
04.18		-free-	
04.19		-free-	
04.20		-free-	

Logical Command Variables: [05.00] - Alarms Of The Engine

Engine alarm status commands, 05.01-05.14

These engine alarms may be used as command variable in a logical output to set parameters for customized operations.

Number	Name / Function	Note
05.01	Overspeed (limit) 1	TRUE = limit value reached FALSE = alarm acknowledged
05.02	Overspeed (limit) 2	
05.03	Underspeed (limit) 1	
05.04	Underspeed (limit) 2	
05.05	Unintended stop	
05.06	Shutdown malfunction	
05.07	Speed detection alarm	
05.08	Start fail	
05.09	Maintenance days exceeded	
05.10	Maintenance hours exceeded	
05.11	-internal-	
05.12	Timeout dead bus operation (time for dead bus monitoring expired)	
05.13	Red stop lamp	
05.14	Amber warning lamp	
05.15	-free-	
05.16	-free-	
05.17	-free-	
05.18	-free-	
05.19	-free-	
05.20	-free-	

Logical Command Variables: [06.00] - Alarms Of The Generator

Generator alarm status commands, 06.01-06.22

These generator alarms may be used as command variable in a logical output to set parameters for customized operations.

Number	Name / Function	Note
06.01	Generator overfrequency (limit) 1	TRUE = limit value reached FALSE = alarm acknowledged
06.02	Generator overfrequency (limit) 2	
06.03	Generator underfrequency (limit) 1	
06.04	Generator underfrequency (limit) 2	
06.05	Generator overvoltage (limit) 1	
06.06	Generator overvoltage (limit) 2	
06.07	Generator undervoltage (limit) 1	
06.08	Generator undervoltage (limit) 2	
06.09	Generator (definite time) overcurrent (limit)1	
06.10	Generator (definite time) overcurrent (limit) 2	
06.11	Generator (definite time) overcurrent (limit) 3	
06.12	Generator reverse/reduced power (limit) 1	
06.13	Generator reverse/reduced power (limit) 2	
06.14	Generator overload (limit) 1	
06.15	Generator overload (limit) 2	
06.16	(Generator) unbalanced load (limit)1	
06.17	(Generator) unbalanced load (limit) 2	
06.18	Generator (voltage) asymmetry	
06.19	Ground fault (limit) 1	
06.20	Ground fault (limit) 2	
06.21	Generator mismatched phase rotation (rotation field alarm)	
06.22	(Generator) inverse time-overcurrent	
06.23	-free-	
06.24	-free-	
06.25	-free-	
06.26	-free-	
06.27	-free-	
06.28	-free-	
06.29	-free-	
06.30	-free-	
06.31	-free-	
06.32	-free-	
06.33	-free-	
06.34	-free-	
06.35	-free-	
06.36	-free-	
06.37	-free-	
06.38	-free-	
06.39	-free-	
06.40	-free-	

Logical Command Variables: [07.00] - Alarms Of The Mains

Alarms of the mains commands, 07.01-07.05

These mains alarms may be used as command variable in a logical output to set parameters for customized operations.

Number	Function	Note
07.01	Mains overfrequency emergency (power recognition)	TRUE = limit value reached FALSE = alarm acknowledged
07.02	Mains underfrequency emergency (power recognition)	
07.03	Mains overvoltage emergency (power recognition)	
07.04	Mains undervoltage emergency (power recognition)	
07.05	Mains mismatched phase rotation (rotation field alarm)	
07.06	-free-	
07.07	-free-	
07.08	-free-	
07.09	-free-	
07.10	-free-	
07.11	-free-	
07.12	-free-	
07.13	-free-	
07.14	-free-	
07.15	-free-	
07.16	-free-	
07.17	-free-	
07.18	-free-	
07.19	-free-	
07.20	-free-	
07.21	-free-	
07.22	-free-	
07.23	-free-	
07.24	-free-	
07.25	-free-	
07.26	-free-	
07.27	-free-	
07.28	-free-	
07.29	-free-	
07.30	-free-	

Logical Command Variables: [08.00] - Alarms Of The System

Alarms of the system commands, 08.01-08.10

These system alarms may be used as command variable in a logical output n to set parameters for customized operations.

Number	Function	Note
08.01	Battery overvoltage (limit) 1	TRUE = limit value reached FALSE = alarm acknowledged
08.02	Battery overvoltage (limit) 2	
08.03	Battery undervoltage (limit) 1	
08.04	Battery undervoltage (limit) 2	
08.05	GCB fail to close	
08.06	GCB fail to open	
08.07	MCB fail to close	
08.08	MCB fail to open	
08.09	CAN Open fault	
08.10	CAN-Fault J1939	
08.11	-free-	
08.12	-free-	
08.13	-free-	
08.14	-free-	
08.15	-free-	
08.16	-free-	
08.17	-free-	
08.18	-free-	
08.19	-free-	
08.20	-free-	

Logical Command Variables: [09.00] - Discrete Inputs

Control discrete input commands, 09.01-09.08

The discrete inputs may be used as command variable in a logical output to set parameters for customized operations.

Number	Function	Note
09.01	DI 1 (Discrete input [D1])	TRUE = logical "1" (delay times and NO/NC parameters are ignored) FALSE = logical "0" (alarm has been acknowledged or immediately after TRUE condition is not present anymore, if Control is configured as alarm class)
09.02	DI 2 (Discrete input [D2])	
09.03	DI 3 (Discrete input [D3])	
09.04	DI 4 (Discrete input [D4])	
09.05	DI 5 (Discrete input [D5])	
09.06	DI 6 (Discrete input [D6])	
09.07	DI 7 (Discrete input [D7])	
09.08	DI 8 (Discrete input [D8])	
09.09	-free-	
09.10	-free-	
09.11	-free-	
09.12	-free-	
09.13	-free-	
09.14	-free-	
09.15	-free-	
09.16	-free-	
09.17	-free-	
09.18	-free-	
09.19	-free-	
09.20	-free-	

Logical Command Variables: [10.00] - Analog Inputs

Control analog input commands, 10.01-10.10

The analog inputs may be used as command variable in a logical output.

Number	Name / Function	Note
10.01	Analog input 1 threshold 1	TRUE = limit value reached FALSE = logical "0" (alarm has been acknowledged or immediately after TRUE condition is not present anymore, if Control is configured as alarm class)
10.02	Analog input 1 threshold 2	
10.03	Analog input 1 wirebreak	
10.04	Analog input 2 threshold 1	
10.05	Analog input 2 threshold 2	
10.06	Analog input 2 wirebreak	
10.07	(Flexible) threshold 1 analog input	
10.08	(Flexible) threshold 2 analog input	
10.09	(Flexible) threshold 3 analog input	
10.10	(Flexible) threshold 4 analog input	
10.11	-free-	
10.12	-free-	
10.13	-free-	
10.14	-free-	
10.15	-free-	
10.16	-free-	
10.17	-free-	
10.18	-free-	
10.19	-free-	
10.20	-free-	

Logical Command Variables: [11.00] - Time Functions

Time function commands, 11.01-11.10

Time functions may be used as command variable in a logical output.

Number	Name / Function	Note
11.01	Set point 1 (exceeded)	see page 116
11.02	Set point 2 (exceeded)	see page 116
11.03	Active weekday (equal to setting)	see page 116
11.04	Active day (equal to setting)	see page 116
11.05	Active hour (equal to setting)	see page 116
11.06	Active minute (equal to setting)	see page 116
11.07	Active setting (equal to setting)	see page 116
11.08	Engine (running hours exceeded by) 1 hour	Status changes every operating hour
11.09	Engine (running hours exceeded by) 10 hour	Status changes every 10 operating hours
11.10	Engine (running hours exceeded by) 100 hour	Status changes every 100 operating hours
11.11	-free-	
11.12	-free-	
11.13	-free-	
11.14	-free-	
11.15	-free-	
11.16	-free-	
11.17	-free-	
11.18	-free-	
11.19	-free-	
11.20	-free-	

Logical Command Variables: [12.00] - External Discrete Inputs (Expansion Board)

External discrete input commands, 12.01-12.16

Additional discrete inputs from an expansion board (i.e. IKD 1 extension board) may be used as command variable in a logical output.

Number	Name / Function	Note
12.01	External discrete input 1 [D.E01]	TRUE = logical "1" (delay times and NO/NC parameters are ignored) FALSE = logical "0" (alarm has been acknowledged or immediately after TRUE condition is not present anymore, if Control is configured as alarm class)
12.02	External discrete input 2 [D.E02]	
12.03	External discrete input 3 [D.E03]	
12.04	External discrete input 4 [D.E04]	
12.05	External discrete input 5 [D.E05]	
12.06	External discrete input 6 [D.E06]	
12.07	External discrete input 7 [D.E07]	
12.08	External discrete input 8 [D.E08]	
12.09	External discrete input 9 [D.E09]	
12.10	External discrete input 10 [D.E10]	
12.11	External discrete input 11 [D.E11]	
12.12	External discrete input 12 [D.E12]	
12.13	External discrete input 13 [D.E13]	
12.14	External discrete input 14 [D.E14]	
12.15	External discrete input 15 [D.E15]	
12.16	External discrete input 16 [D.E16]	
12.17	-free-	
12.18	-free-	
12.19	-free-	
12.20	-free-	

Logical Command Variables: [13.00] - Status Of The Internal Relay Outputs

Discrete output commands, 13.01-13.08

The discrete outputs may be used as command variable in a logical output.

Number	Name / Function	Note
13.01	Digital output DO1 [R01]	TRUE = logical "1" (this condition indicates the logical status of the internal relays) FALSE = logical "0" (this condition indicates the logical status of the internal relays)
13.02	Digital output DO2 [R02]	
13.03	Digital output DO3 [R03]	
13.04	Digital output DO4 [R04]	
13.05	Digital output DO5 [R05]	
13.06	Digital output DO6 [R06]	
13.07	Digital output DO7 [R07]	
13.08	Digital output DO8 [R08]	
13.09	Digital output DO9 [R09]	
13.10	Digital output DO10 [R10]	
13.11	Digital output DO11 [R11]	
13.12	-free-	
13.13	-free-	
13.14	-free-	
13.15	-free-	
13.16	-free-	
13.17	-free-	
13.18	-free-	
13.19	-free-	
13.20	-free-	

Logical Command Variables: [14.00] - Status Of The External Relay Outputs

Discrete output commands, 14.01-14.16

The external discrete outputs may be used as command variable in a logical output.

Number	Name / Function	Note
14.01	External digital output DO1 [R01]	TRUE = logical "1" (this condition indicates the logical status of the relays, which are connected via external expansion boards) FALSE = logical "0" (this condition indicates the logical status of the relays, which are connected via external expansion boards)
14.02	External digital output DO2 [R02]	
14.03	External digital output DO3 [R03]	
14.04	External digital output DO4 [R04]	
14.05	External digital output DO5 [R05]	
14.06	External digital output DO6 [R06]	
14.07	External digital output DO7 [R07]	
14.08	External digital output DO8 [R08]	
14.09	External digital output DO9 [R09]	
14.10	External digital output DO10 [R10]	
14.11	External digital output DO11 [R11]	
14.12	External digital output DO12 [R12]	
14.13	External digital output DO13 [R13]	
14.14	External digital output DO14 [R14]	
14.15	External digital output DO15 [R15]	
14.16	External digital output DO16 [R16]	
14.17	-free-	
14.18	-free-	
14.19	-free-	
14.20	-free-	




Factory Setting



The inputs, outputs, and internal flags, which may be programmed via the *LogicsManager* have the following factory default settings when delivered:

simple (function)	extended (configuration)	result
-------------------	--------------------------	--------

Factory Setting: Functions

Start request in Auto				
{0}	✓	If TRUE the engine is started in AUTOMATIC operating mode. Prepared for start via clock (Flag 8) and remote start.		
{1o}	✓			
{1oc}	✓			
{2oc}	✓			
STOP	---			
AUTO	✓			
MAN	---			
				dependent on discrete input [D2]
Stop request in Auto				
{0}	✓	If TRUE the engine is either stopped in AUTOMATIC operating mode or a start of the engine is suppressed (also an emergency operation). Prepared for: Deactivated by default		
{1o}	✓			
{1oc}	✓			
{2oc}	✓			
STOP	---			
AUTO	✓			
MAN	---			
				FALSE
Start without load transfer				
{0}	✓	Engine start without load transfer to the generator (closing of the GCB is blocked). Prepared for: Deactivated by default Observe critical mode when activating		
{1o}	✓			
{1oc}	✓			
{2oc}	✓			
STOP	✓			
AUTO	✓			
MAN	✓			
				FALSE

dependent on discrete input [D2]


FALSE

FALSE


simple (function)		extended (configuration)	result
Operation mode AUTOMATIC			
{0}	✓	<div><div>Logics Manager</div><div>> Operation mode AUTO</div><div>> Delay ON 000.00 sec > Delay OFF 000.00 sec</div><div>00.01 Flag 1 0</div><div>00.01 Flag 1 1</div><div>00.01 Flag 1 1</div><div>OK Cancel Help</div></div>	FALSE
{1o}	✓		
{1oc}	✓		
{2oc}	✓		
STOP	✓		
AUTO	✓		
MAN	✓		
Operation mode MANUAL			
{0}	✓	<div><div>Logics Manager</div><div>> Operation mode MAN</div><div>> Delay ON 000.00 sec > Delay OFF 000.00 sec</div><div>00.01 Flag 1 0</div><div>00.01 Flag 1 1</div><div>00.01 Flag 1 1</div><div>OK Cancel Help</div></div>	FALSE
{1o}	✓		
{1oc}	✓		
{2oc}	✓		
STOP	✓		
AUTO	✓		
MAN	✓		
Operation mode STOP			
{0}	✓	<div><div>Logics Manager</div><div>> Operation mode STOP</div><div>> Delay ON 000.00 sec > Delay OFF 000.00 sec</div><div>00.01 Flag 1 0</div><div>00.01 Flag 1 1</div><div>00.01 Flag 1 1</div><div>OK Cancel Help</div></div>	FALSE
{1o}	✓		
{1oc}	✓		
{2oc}	✓		
STOP	✓		
AUTO	✓		
MAN	✓		

simple (function)	extended (configuration)	result
-------------------	--------------------------	--------


Critical mode

{0}	✓	If TRUE, critical mode operation is initiated (see page 23). Prepared for: Observe start fail + DI1 (emergency stop) when activating		FALSE
{1o}	✓			
{1oc}	✓			
{2oc}	✓			
STOP	---			
AUTO	✓			
MAN	---			


Firing speed reached

{0}	✓	If TRUE, the unit recognizes that the ignition speed has been reached. Prepared for: Deactivated by default		FALSE
{1o}	✓			
{1oc}	✓			
{2oc}	✓			
STOP	✓			
AUTO	✓			
MAN	✓			


Constant Idle run


{0}	✓	If TRUE, the control outputs an "Constant idle run" if a start request for the generator is present Prepared for: Deactivated by default		FALSE
{1o}	✓			
{1oc}	✓			
{2oc}	✓			
STOP	✓			
AUTO	✓			
MAN	✓			


Automatic Idle run

{0}	✓	If this condition is fulfilled, the control performs an idle run for a configured time at start-up . Prepared for: Deactivated by default		FALSE
{1o}	✓			
{1oc}	✓			
{2oc}	✓			
STOP	✓			
AUTO	✓	Note: This function is pre-configured and may be activated by passing through the command variable 00.09 Start req. in Auto ('—' instead of '0').		
MAN	✓			

	simple (function)	extended (configuration)	result
--	-------------------	--------------------------	--------


Undelayed close GCB			
{0}	---	If TRUE, the GCB will be closed in an emergency operation without waiting for expiration of the delayed engine monitoring.	
{1o}	---		
{1oc}	---		
{2oc}	✓		
STOP	---		
AUTO	✓		
MAN	✓		
			dependent on emergency operation


Inhibit emergency run			
{0}	---	If TRUE, an emergency operation is inhibited or interrupted. Prepared for: Deactivated by default	
{1o}	---		
{1oc}	---		
{2oc}	✓		
STOP	---		
AUTO	✓		
MAN	---		
			FALSE

External acknowledgment			
{0}	✓	If TRUE, alarms are acknowledged from an external source. Prepared for: External acknowledgement required? Remote acknowledgement prepared	
{1o}	✓		
{1oc}	✓		
{2oc}	✓		
STOP	✓		
AUTO	✓		
MAN	✓		
			FALSE

simple (function)	extended (configuration)	result
-------------------	--------------------------	--------

Factory Setting: Relay Outputs




Relay 1 [R01] - centralized alarm (horn) / freely configurable			
{0}	✓	Relay energizes if the internal condition "Horn" is TRUE	
{1o}	✓		
{1oc}	✓		
{2oc}	✓		
STOP	✓		
AUTO	✓		
MAN	✓		dependent on Logics Command Variable [03.05]





Relay 2 [R02] - shut-down alarm class active / freely configurable			
{0}	✓	Relay energizes if one of the alarm classes C, D, E or F is active	
{1o}	✓		
{1oc}	✓		
{2oc}	✓		
STOP	✓		
AUTO	✓		
MAN	✓		dependent on Logics Command Variable [01.09]


Relay 3 [R03] - Crank			
{0}	---	Fixed to "Crank"	N/A
{1o}	---		
{1oc}	---		
{2oc}	---		
STOP	✓		
AUTO	✓		
MAN	✓		---

Relay 4 [R04] – Fuel solenoid			
{0}	---	Fixed to "Fuel solenoid"	N/A
{1o}	---		
{1oc}	---		
{2oc}	---		
STOP	✓		
AUTO	✓		
MAN	✓		---


simple (function)	extended (configuration)	result
-------------------	--------------------------	--------

Relay 5 [R05] - preglow / ignition ON / freely configurable			
{0}	✓	Relay energizes to preglow the Diesel engine or enables the ignition of the gas engine	
{1o}	✓		
{1oc}	✓		
{2oc}	✓		
STOP	✓		
AUTO	✓		<p>dependent on Logics Command Variable [03.04]</p>
MAN	✓		
Relay 6 [R06] - auxiliary services			
{0}	✓	Relay energizes to activate the auxiliary services (it energizes prior to an engine start and de-energizes with the engine stop)	
{1o}	✓		
{1oc}	✓		
{2oc}	✓		
STOP	✓		
AUTO	✓		<p>dependent on Logics Command Variable [03.01]</p>
MAN	✓		
Relay 7 [R07] - free / Command: open GCB			
{0}	✓	In application mode {0} = freely configurable relay (unsigned)	
{1o}	---		
{1oc}	---		
{2oc}	---		
STOP	✓	In application mode {1o}, {1oc}, and {2oc} "Command: open GCB"	
AUTO	✓		
MAN	✓	Prepared for: Deactivated by default	FALSE

		simple (function)	extended (configuration)	result
Relay 8 [R08] - free / Command: close MCB				
{0}	✓	In application mode		FALSE
{1o}	✓	{0}, {1o} and {1oc} = freely configurable relay (unassigned)		
{1oc}	✓			
{2oc}	---			
STOP	✓	In application mode {2oc}		
AUTO	✓	"Command: close MCB"		
MAN	✓	Prepared for: Deactivated by default		
Relay 9 [R09] - free / Command: open MCB				
{0}	✓	In application mode		FALSE
{1o}	✓	{0}, {1o} and {1oc} = freely configurable relay (unassigned)		
{1oc}	✓			
{2oc}	---			
STOP	✓	In application mode {2oc}		
AUTO	✓	"Command: open MCB"		
MAN	✓	Prepared for: Deactivated by default		
Relay 10 [R10] - free / Command: close GCB				
{0}	✓	In application mode		FALSE
{1o}	✓	{0} and {1o} = freely configurable relay (unassigned)		
{1oc}	---			
{2oc}	---			
STOP	✓	In application mode {1oc} and {2oc} "Command: close GCB"		
AUTO	✓			
MAN	✓	Prepared for: Deactivated by default		
Relay 11 [R11] – Ready for operation OFF				
{0}	✓	Relay will be de-energized if		FALSE
{1o}	✓	unit is not ready for operation		
{1oc}	✓	or the logics manager output is TRUE.		
{2oc}	✓			
STOP	✓	Note:		
AUTO	✓	The unit is only ready for operation after a start-up delay following the power supply connection.		
MAN	✓			


simple (function)		extended (configuration)	result
External digital output {x} [REx{x}] - free (external expansion card, if connected; {x} = 1-16)			
{0}	✓	<div>Control of the external re- lay {x}, if this is connected</div> <div>Prepared for: Deactivated by default</div> <div></div>	FALSE
{1o}	✓		
{1oc}	✓		
{2oc}	✓		
STOP	✓		
AUTO	✓		
MAN	✓		

Factory Setting: Internal Flags




Internal flag 1 - free			
{0}	✓	freely configurable relay (unsigned)	
{1o}	✓		
{1oc}	✓		
{2oc}	✓		
STOP	✓		
AUTO	✓		
MAN	✓		

Note: This flag is used in all logical outputs as default setting.


FALSE

Internal flag 2 - free			
{0}	✓	freely configurable flag Prepared for: Deactivated by default	
{1o}	✓		
{1oc}	✓		
{2oc}	✓		
STOP	✓		
AUTO	✓		
MAN	✓		


FALSE

simple (function)		extended (configuration)	result
Internal flag 3 - free			
{0}	✓	freely configurable flag Prepared for: Deactivated by default	
{1o}	✓		
{1oc}	✓		
{2oc}	✓		
STOP	✓		
AUTO	✓		
MAN	✓		FALSE
Internal flag 4 - free			
{0}	✓	freely configurable flag Prepared for: Deactivated by default	
{1o}	✓		
{1oc}	✓		
{2oc}	✓		
STOP	✓		
AUTO	✓		
MAN	✓		FALSE
Internal flag 5 - free			
{0}	✓	freely configurable flag Prepared for: Deactivated by default	
{1o}	✓		
{1oc}	✓		
{2oc}	✓		
STOP	✓		
AUTO	✓		
MAN	✓		FALSE


simple (function)	extended (configuration)	result
-------------------	--------------------------	--------

Internal flag 6 - free		
{0}	✓	freely configurable flag Prepared for: Deactivated by default
{1o}	✓	
{1oc}	✓	
{2oc}	✓	
STOP	✓	
AUTO	✓	
MAN	✓	
		

FALSE

Internal flag 7 - extend emergency power operation		
{0}	✓	freely configurable flag Prepared for: Deactivated by default
{1o}	✓	
{1oc}	✓	
{2oc}	✓	
STOP	✓	
AUTO	✓	
MAN	✓	
		

dependent on
Logics
Command
Variables
[04.08] and
[04.07] and
[02.11]

Internal flag 8 - engine start via timer		
{0}	✓	Prepared for: TRUE once the configured time 1 has been reached [11.01], and the configured time 2 [11.02] has not been reached as well if the current day is the configured day [11.03] (see page 116 "LogicsManager: Timer")
{1o}	✓	
{1oc}	✓	
{2oc}	✓	
STOP	---	
AUTO	✓	
MAN	---	
		

dependent on
timer

Discrete Inputs

[D1]	{0}	freely configurable
	{1o}	EMERGENCY OFF
	{1oc}	alarm class F
	{2oc}	
[D2]	{0}	freely configurable
	{1o}	Remote start / start request
	{1oc}	alarm class Control
	{2oc}	
[D3]	{0}	
	{1o}	freely configurable discrete input (unassigned)
	{1oc}	alarm class B
	{2oc}	
[D4]	{0}	
	{1o}	freely configurable discrete input (unassigned)
	{1oc}	alarm class B
	{2oc}	
[D5]	{0}	
	{1o}	freely configurable discrete input (unassigned)
	{1oc}	alarm class B
	{2oc}	
[D6]	{0}	
	{1o}	freely configurable discrete input (unassigned)
	{1oc}	alarm class B
	{2oc}	Enable MCB (not available in the LogicsManager) If the parameter Enable MCB is configured to ALWAYS, this DI may be used as alarm input (LogicsManager)
[D7]	{0}	
	{1o}	freely configurable discrete input (unassigned)
	{1oc}	alarm class Control
	{2oc}	Reply: MCB is opened (not available in the LogicsManager)
[D8]	{0}	freely configurable discrete input (unassigned)
	{1o}	alarm class Control
	{1oc}	Reply: GCB is opened (not available in the LogicsManager)
	{2oc}	Reply: GCB is opened (not available in the LogicsManager)

Appendix C.

Characteristics Of The VDO Inputs

VDO Input "Pressure" (0 to 5 bar / 0 to 72 psi) - Index "III"



Since VDO sensors are available in various different types, the Index Numbers of the characteristic curve tables are listed. The customer must observe to order a sensor with the correct characteristic curve when selecting a VDO sensor. Manufacturers of VDO sensors usually list these tables in their catalogs.




Figure 3-58: Analog inputs - characteristics diagram VDO 0 to 5 bar, Index "III"

Ohm	bar	psi
10	0.00	0.00
15	0.13	1.81
20	0.25	3.63
25	0.38	5.44
30	0.50	7.25
35	0.64	9.27
40	0.78	11.28
45	0.92	13.30
50	1.06	15.36
55	1.21	17.49
60	1.35	19.62
65	1.50	21.76

Ohm	bar	psi
70	1.65	23.89
75	1.79	26.02
80	1.94	28.15
85	2.09	30.29
90	2.24	32.42
95	2.38	34.55
100	2.53	36.69
105	2.68	38.82
110	2.82	40.95
115	2.97	43.09
120	3.11	45.12
125	3.25	47.14

Ohm	bar	psi
130	3.39	49.15
135	3.53	51.19
140	3.68	53.32
145	3.82	55.46
150	3.97	57.59
155	4.12	59.72
160	4.26	61.86
165	4.41	63.99
170	4.56	66.17
175	4.72	68.44
180	4.88	70.71
185	5.03	72.97

VDO Input "Pressure" (0 to 10 bar / 0 to 145 psi) - Index "IV"




Figure 3-59: Analog inputs - characteristics diagram VDO 0 to 10 bar, Index "IV"

Ohm	bar	psi
10	0.00	0.00
15	0.24	3.45
20	0.48	6.91
25	0.71	10.36
30	0.95	13.81
35	1.19	17.27
40	1.43	20.72
45	1.67	24.17
50	1.90	27.63
55	2.16	31.30
60	2.42	35.11
65	2.68	38.93

Ohm	bar	psi
70	2.95	42.75
75	3.24	46.92
80	3.53	51.19
85	3.82	55.46
90	4.11	59.63
95	4.39	63.66
100	4.67	67.69
105	4.94	71.71
110	5.22	75.74
115	5.50	79.77
120	5.78	83.80
125	6.06	87.93
130	6.38	92.46

Ohm	bar	psi
135	6.69	97.00
140	7.00	101.53
145	7.33	106.36
150	7.67	111.20
155	8.00	116.03
160	8.33	120.87
165	8.67	125.70
170	9.00	130.54
175	9.36	135.72
180	9.71	140.90
185	10.07	146.08

VDO Input "Temperature" (40 to 120 °C / 104 to 248 °F)
- Index "92-027-004"




Figure 3-60: Analog inputs - characteristics diagram VDO 40 to 120 °C, Index "92-027-004"

Ohm	°C	°F
20	124	255
30	109	229
40	99	210
50	91	196
60	85	185
70	80	175
80	76	168
90	72	162
100	69	156

Ohm	°C	°F
110	66	151
120	64	146
130	61	142
140	59	138
150	57	135
160	56	132
170	54	129
180	52	126
190	51	123
200	50	121

Ohm	°C	°F
210	48	119
220	47	117
230	46	115
240	45	113
250	44	111
260	43	109
270	42	107

VDO Input "Temperature" (50 to 150 °C / 122 to 302 °F) - Index "92-027-006"




Figure 3-61: Analog inputs - characteristics diagram VDO 50 to 150 °C, Index "92-027-006"

Ohm	°C	°F
20	147	296
30	129	263
40	117	242
50	108	227
60	102	215
70	96	205
80	91	197
90	88	190
100	84	184
110	81	178

Ohm	°C	°F
120	79	174
130	78	172
140	76	169
150	75	166
160	73	164
170	72	161
180	70	159
190	69	156
200	68	154
210	66	151
220	65	148

Ohm	°C	°F
230	63	146
240	62	143
250	60	141
260	59	138
270	58	136
280	56	133
290	55	130
300	53	128
310	52	125
320	50	123

Appendix D. List Of Parameters

Unit number P/N _____ Rev _____

Version easYgen- _____

Project _____

Serial number S/N _____ Date _____

Par. No.	Parameter	Setting range	Default value	Customer setting	
----------	-----------	---------------	---------------	------------------	--

PASSWORD

1	Password CAN	0000 to 9999	0003		
2	Password DPC	0000 to 9999	0003		

1 MEASURING

3	Rated system frequency	50/60 Hz	50 Hz		
4	Rated voltage generator	50 to 650000 V	400 V		
5	Rated voltage mains	50 to 650000 V	400 V		
6	Generator voltage measuring	3Ph 4W 3Ph 3W 1Ph 2W 1Ph 3W	3Ph 4W	<input type="checkbox"/> 3Ph4W <input type="checkbox"/> 3Ph3W <input type="checkbox"/> 1Ph2W <input type="checkbox"/> 1Ph3W	<input type="checkbox"/> 3Ph4W <input type="checkbox"/> 3Ph3W <input type="checkbox"/> 1Ph2W <input type="checkbox"/> 1Ph3W
7	Generator current measuring	L1 L2 L3 Phase L1 Phase L2 Phase L3	L1 L2 L3	<input type="checkbox"/> L123 <input type="checkbox"/> Ph.L1 <input type="checkbox"/> Ph.L2 <input type="checkbox"/> Ph.L3	<input type="checkbox"/> L123 <input type="checkbox"/> Ph.L1 <input type="checkbox"/> Ph.L2 <input type="checkbox"/> Ph.L3
8	Mains voltage measuring	3Ph 4W 3Ph 3W 1Ph 2W 1Ph 3W	3Ph 4W	<input type="checkbox"/> 3Ph4W <input type="checkbox"/> 3Ph3W <input type="checkbox"/> 1Ph2W <input type="checkbox"/> 1Ph3W	<input type="checkbox"/> 3Ph4W <input type="checkbox"/> 3Ph3W <input type="checkbox"/> 1Ph2W <input type="checkbox"/> 1Ph3W
9	Mains current measuring	Phase L1 Phase L2 Phase L3	Phase L1	<input type="checkbox"/> Ph.L1 <input type="checkbox"/> Ph.L2 <input type="checkbox"/> Ph.L3	<input type="checkbox"/> Ph.L1 <input type="checkbox"/> Ph.L2 <input type="checkbox"/> Ph.L3
10	Rated active power [kW]	0.5 to 99999.9 kW	200.0 kW		
11	Rated current	5 to 32000 A	300 A		
1.1 Transformer					
12	Gen. voltage transf. primary	50 to 650000 V	400 V		
13	Gen. voltage transf. secondary	50 to 480 V	400 V		
14	Mains voltage transf. primary	50 to 650000 V	400 V		
15	Mains voltage transf. secondary	50 to 480 V	400 V		
16	Generator current transformer	1 to 32000/{x} A	500/{x} A		
17	Input mains current as	mains / ground current	mains current	<input type="checkbox"/> mains <input type="checkbox"/> ground	<input type="checkbox"/> mains <input type="checkbox"/> ground
18	Mains current transformer	1 to 32000/{x} A	500/{x} A		
19	Ground current transformer	1 to 32000/{x} A	500/{x} A		

Par. No.	Parameter	Setting range	Default value	Customer setting	
2 APPLICATION					
20	Application mode	None {0} GCB open {1o} GCB {1oc} GCB/MCB {2oc}	GCB/MCB {2oc}	<input type="checkbox"/> {0} <input type="checkbox"/> {1o} <input type="checkbox"/> {1oc} <input type="checkbox"/> {2oc}	<input type="checkbox"/> {0} <input type="checkbox"/> {1o} <input type="checkbox"/> {1oc} <input type="checkbox"/> {2oc}
21	Start req. in Auto	see descr. in LogicsManager chap. starting page 144; default: (09.02. + 0) + 0			
22	Stop req. in Auto	see descr. in LogicsManager chap. starting page 144; default: (0 & 1) & 1			
23	Start w/o load	see descr. in LogicsManager chap. starting page 144; default: (0 & 1) & !00.13			
24	Startup in mode	Stop Auto Manual last	Stop	<input type="checkbox"/> STOP <input type="checkbox"/> AUTO <input type="checkbox"/> MAN <input type="checkbox"/> last	<input type="checkbox"/> STOP <input type="checkbox"/> AUTO <input type="checkbox"/> MAN <input type="checkbox"/> last
25	Operation mode AUTO	see descr. in LogicsManager chap. starting page 144; default: (0 & 1) & 1			
26	Operation mode MAN	see descr. in LogicsManager chap. starting page 144; default: (0 & 1) & 1			
27	Operation mode STOP	see descr. in LogicsManager chap. starting page 144; default: (0 & 1) & 1			
28	Alternative screen	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
29	Show mains data	YES/NO	YES	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
2.1 Critical Mode					
30	Critical mode	see descr. in LogicsManager chap. start. page 144; default: (0 & !05.08) & !09.01			
31	Critical mode postrun	0 to 6000 s	600 s		
32	close GCB in override	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
33	Override alarmcl. also in MAN	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
34	Break emergency in override	0 to 999 s	5 s		
3 CONFIGURE ENGINE					
35	Start/stop mode	Diesel Gas External	Diesel	<input type="checkbox"/> Diesel <input type="checkbox"/> Gas <input type="checkbox"/> External	<input type="checkbox"/> Diesel <input type="checkbox"/> Gas <input type="checkbox"/> External
3.1 Engine type: Diesel					
36	Fuel relay: close to stop	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
37	Preglow time	0 to 300 s	3 s		
38	Preglow mode	NO Always Analog input [T1] Analog input [T2]	NO	<input type="checkbox"/> No <input type="checkbox"/> Always <input type="checkbox"/> [T1] <input type="checkbox"/> [T2]	<input type="checkbox"/> No <input type="checkbox"/> Always <input type="checkbox"/> [T1] <input type="checkbox"/> [T2]
39	Preglow temp. threshold	-10 to 140 °C	0 °C		
3.2 Engine type: Gas					
40	Ignition delay	0 to 999 s	3 s		
41	Gas valve delay	0 to 999 s	3 s		
42	Min. speed for ignition	10 to 1800 RPM	100 RPM		
3.3 Pickup					
43	Speed Pickup	ON/OFF	ON	<input type="checkbox"/> 1 <input type="checkbox"/> 0	<input type="checkbox"/> 1 <input type="checkbox"/> 0
44	Nominal speed	500 to 4000 RPM	1500 RPM		
45	Number of gear teeth	2 to 260	118		
3.4 Start/stop automatic					
46	Auxiliary services prerun	0 to 999 s	0 s		
47	Starter time	1 to 99 s	5 s		
48	Start pause time	1 to 99 s	7 s		
49	Cool down time	1 to 999 s	20 s		
50	Auxiliary services postrun	0 to 999 s	0 s		
51	Time of engine stop	0 to 99 s	10 s		
52	Firing speed	5 to 60 Hz	15 Hz		
53	Logism. for firing speed	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
54	Ignition speed	see descr. in LogicsManager chap. starting page 144; default: (0 & 1) & 1			
55	Engine monit. delay time	0 to 99 s	8 s		
3.5 Idle Mode					
56	Constant idle run	see descr. in LogicsManager chap. starting page 144; default: (0 & 1) & 1			
57	Idle mode automatic	see descr. in LogicsManager chap. starting page 144; default: (0 & 1) & 1			
58	Time for automatic idle run	1 to 9999 s	10 s		
59	During emerg/critical	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N

Par. No.	Parameter	Setting range	Default value	Customer setting	
----------	-----------	---------------	---------------	------------------	--

4 BREAKER

60	GCB open relay	N.O. N.C.	N.O.	<input type="checkbox"/> N.O. <input type="checkbox"/> N.C.	<input type="checkbox"/> N.O. <input type="checkbox"/> N.C.
61	GCB time pulse	0.04 to 1.00 s	0.24 s		
62	GCB close pulse	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
63	GCB auto unblock	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
64	Undelayed close GCB	see descr. in <i>LogicsManager</i> chap. starting page 144; default: (04.09 & 1) & 1			
65	GCB frequency window	0.2 to 10.0 %	2.0 %		
66	GCB voltage window	1 to 100 %	10 %		
67	CB settling time	0 to 99 s	2 s		
68	MCB auto unlock	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
69	Close MCB in STOP mode	YES/NO	YES	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
70	MCB time pulse	0.04 to 1.00 s	0.24 s		
71	Enable MCB	ALWAYS / via DI6	ALWAYS	<input type="checkbox"/> A <input type="checkbox"/> DI6	<input type="checkbox"/> A <input type="checkbox"/> DI6
72	Transfer time GCB/MCB	0.10 to 99.99 s	1.00 s		

5 EMERGENCY POWER (AMF)

73	On/Off	ON/OFF	ON	<input type="checkbox"/> 1 <input type="checkbox"/> 0	<input type="checkbox"/> 1 <input type="checkbox"/> 0
74	Mains fail delay time	0.20 to 99.99 s	3.00 s		
75	Mains settling time	1 to 9.999 s	20 s		
76	Emerg. start with MCB failure	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
77	Inhibit emergency run	see descr. in <i>LogicsManager</i> chap. starting page 144; default: (0 & 1) & 1			

6 MONITORING

78	Time until horn reset	0 to 1,000 s	180 s		
79	External acknowledge	see descr. in <i>LogicsManager</i> chap. starting page 144; default: (0 & !04.03) + 0			
6.1 Monitoring Generator					
80	Voltage monitoring generator	3 phase/4 phase	3 phase	<input type="checkbox"/> 3 <input type="checkbox"/> 4	<input type="checkbox"/> 3 <input type="checkbox"/> 4
6.1.1 Generator: overfrequency level 1					
81	Monitoring level 1	ON/OFF	ON	<input type="checkbox"/> 1 <input type="checkbox"/> 0	<input type="checkbox"/> 1 <input type="checkbox"/> 0
82	Limit level 1	50.0 to 130.0 %	110.0 %		
83	Delay level 1	0.02 to 99.99 s	1.50 s		
84	Alarm class level 1	A/B/C/D/E/F	B		
85	Self acknowledge level 1	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
6.1.2 Generator: overfrequency level 2					
81	Monitoring level 2	ON/OFF	ON	<input type="checkbox"/> 1 <input type="checkbox"/> 0	<input type="checkbox"/> 1 <input type="checkbox"/> 0
82	Limit level 2	50.0 to 130.0 %	115.0 %		
83	Delay level 2	0.02 to 99.99 s	0.30 s		
84	Alarm class level 2	A/B/C/D/E/F	F		
85	Self acknowledge level 2	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
6.1.3 Generator: underfrequency level 1					
86	Monitoring level 1	ON/OFF	ON	<input type="checkbox"/> 1 <input type="checkbox"/> 0	<input type="checkbox"/> 1 <input type="checkbox"/> 0
87	Limit level 1	50.0 to 130.0 %	90.0 %		
88	Delay level 1	0.02 to 99.99 s	5.00 s		
89	Alarm class level 1	A/B/C/D/E/F	B		
90	Self acknowledge level 1	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
91	Delayed by engine speed level 1	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
6.1.4 Generator: underfrequency level 2					
86	Monitoring level 2	ON/OFF	ON	<input type="checkbox"/> 1 <input type="checkbox"/> 0	<input type="checkbox"/> 1 <input type="checkbox"/> 0
87	Limit level 2	50.0 to 130.0 %	84.0 %		
88	Delay level 2	0.02 to 99.99 s	0.30 s		
89	Alarm class level 2	A/B/C/D/E/F	F		
90	Self acknowledge level 2	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
91	Delayed by engine speed level 2	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N

Par. No.	Parameter	Setting range	Default value	Customer setting	
6 MONITORING					
6.1.5 Generator: overvoltage level 1					
92	Monitoring level 1	ON/OFF	ON	<input type="checkbox"/> 1 <input type="checkbox"/> 0	<input type="checkbox"/> 1 <input type="checkbox"/> 0
93	Limit level 1	50.0 to 125.0 %	108.0 %		
94	Delay level 1	0.02 to 99.99 s	5.00 s		
95	Alarm class level 1	A/B/C/D/E/F	B		
96	Self acknowledge level 1	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
97	Delayed by engine speed level 1	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
6.1.6 Generator: overvoltage level 2					
92	Monitoring level 2	ON/OFF	ON	<input type="checkbox"/> 1 <input type="checkbox"/> 0	<input type="checkbox"/> 1 <input type="checkbox"/> 0
93	Limit level 2	50.0 to 125.0 %	112.0 %		
94	Delay level 2	0.02 to 99.99 s	0.30 s		
95	Alarm class level 2	A/B/C/D/E/F	F		
96	Self acknowledge level 2	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
97	Delayed by engine speed level 2	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
6.1.7 Generator: undervoltage level 1					
98	Monitoring level 1	ON/OFF	ON	<input type="checkbox"/> 1 <input type="checkbox"/> 0	<input type="checkbox"/> 1 <input type="checkbox"/> 0
99	Limit level 1	50.0 to 125.0 %	92.0 %		
100	Delay level 1	0.02 to 99.99 s	5.00 s		
101	Alarm class level 1	A/B/C/D/E/F	B		
102	Self acknowledge level 1	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
103	Delayed by engine speed level 1	YES/NO	YES	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
6.1.8 Generator: undervoltage level 2					
98	Monitoring level 2	ON/OFF	ON	<input type="checkbox"/> 1 <input type="checkbox"/> 0	<input type="checkbox"/> 1 <input type="checkbox"/> 0
99	Limit level 2	50.0 to 125.0 %	88.0 %		
100	Delay level 2	0.02 to 99.99 s	0.30 s		
101	Alarm class level 2	A/B/C/D/E/F	F		
102	Self acknowledge level 2	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
103	Delayed by engine speed level 2	YES/NO	YES	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
6.1.9 Generator: overcurrent level 1					
104	Monitoring level 1	ON/OFF	ON	<input type="checkbox"/> 1 <input type="checkbox"/> 0	<input type="checkbox"/> 1 <input type="checkbox"/> 0
105	Limit level 1	50.0 to 300.0 %	110.0 %		
106	Delay level 1	0.02 to 99.99 s	30.00 s		
107	Alarm class level 1	A/B/C/D/E/F	E		
108	Self acknowledge level 1	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
6.1.10 Generator: overcurrent level 2					
104	Monitoring level 2	ON/OFF	ON	<input type="checkbox"/> 1 <input type="checkbox"/> 0	<input type="checkbox"/> 1 <input type="checkbox"/> 0
105	Limit level 2	50.0 to 300.0 %	150.0 %		
106	Delay level 2	0.02 to 99.99 s	1.00 s		
107	Alarm class level 2	A/B/C/D/E/F	F		
108	Self acknowledge level 2	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
6.1.11 Generator: overcurrent level 3					
104	Monitoring level 3	ON/OFF	ON	<input type="checkbox"/> 1 <input type="checkbox"/> 0	<input type="checkbox"/> 1 <input type="checkbox"/> 0
105	Limit level 3	50.0 to 300.0 %	250.0 %		
106	Delay level 3	0.02 to 99.99 s	0.40 s		
107	Alarm class level 3	A/B/C/D/E/F	F		
108	Self acknowledge level 3	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
6.1.12 Gen.: reverse/reduced pow. lev. 1					
109	Monitoring level 1	ON/OFF	ON	<input type="checkbox"/> 1 <input type="checkbox"/> 0	<input type="checkbox"/> 1 <input type="checkbox"/> 0
110	Limit level 1	-99.9 to 99.9 %	-3.0 %		
111	Delay level 1	0.02 to 99.99 s	5.00 s		
112	Alarm class level 1	A/B/C/D/E/F	B		
113	Self acknowledge level 1	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
114	Delayed by engine speed level 1	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
6.1.13 Gen.: reverse/reduced pow. lev. 2					
109	Monitoring level 2	ON/OFF	ON	<input type="checkbox"/> 1 <input type="checkbox"/> 0	<input type="checkbox"/> 1 <input type="checkbox"/> 0
110	Limit level 2	-99.9 to 99.9 %	-5.0 %		
111	Delay level 2	0.02 to 99.99 s	3.00 s		
112	Alarm class level 2	A/B/C/D/E/F	E		
113	Self acknowledge level 2	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
114	Delayed by engine speed level 2	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N

Par. No.	Parameter	Setting range	Default value	Customer setting
6 MONITORING				
6.1.14 Generator: overload level 1				
115	Monitoring level 1	ON/OFF	ON	<input type="checkbox"/> 1 <input type="checkbox"/> 0 <input type="checkbox"/> 0
116	Limit level 1	50.0 to 300.0 %	110.0 %	
117	Delay level 1	0.02 to 99.99 s	11.00 s	
118	Alarm class level 1	A/B/C/D/E/F	B	
119	Self acknowledge level 1	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N <input type="checkbox"/> Y <input type="checkbox"/> N
6.1.15 Generator: overload level 2				
115	Monitoring level 2	ON/OFF	ON	<input type="checkbox"/> 1 <input type="checkbox"/> 0 <input type="checkbox"/> 0
116	Limit level 2	50.0 to 300.0 %	120.0 %	
117	Delay level 2	0.02 to 99.99 s	0.10 s	
118	Alarm class level 2	A/B/C/D/E/F	E	
119	Self acknowledge level 2	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N <input type="checkbox"/> Y <input type="checkbox"/> N
6.1.16 Generator: unbalanced load lev. 1				
120	Monitoring level 1	ON/OFF	ON	<input type="checkbox"/> 1 <input type="checkbox"/> 0 <input type="checkbox"/> 0
121	Limit level 1	0.0 to 100.0 %	10.0 %	
122	Delay level 1	0.02 to 99.99 s	10.00 s	
123	Alarm class level 1	A/B/C/D/E/F	B	
124	Self acknowledge level 1	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N <input type="checkbox"/> Y <input type="checkbox"/> N
125	Delayed by engine speed level 1	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N <input type="checkbox"/> Y <input type="checkbox"/> N
6.1.17 Generator: unbalanced load lev. 2				
120	Monitoring level 2	ON/OFF	ON	<input type="checkbox"/> 1 <input type="checkbox"/> 0 <input type="checkbox"/> 0
121	Limit level 2	0.0 to 100.0 %	15.0 %	
122	Delay level 2	0.02 to 99.99 s	1.00 s	
123	Alarm class level 2	A/B/C/D/E/F	E	
124	Self acknowledge level 2	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N <input type="checkbox"/> Y <input type="checkbox"/> N
125	Delayed by engine speed level 2	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N <input type="checkbox"/> Y <input type="checkbox"/> N
6.1.18 Generator: voltage asymmetry				
126	Monitoring	ON/OFF	ON	<input type="checkbox"/> 1 <input type="checkbox"/> 0 <input type="checkbox"/> 0
127	Limit	0.5 to 99.9 %	10.0 %	
128	Delay	0.02 to 99.99 s	5.00 s	
129	Alarm class	A/B/C/D/E/F	F	
130	Self acknowledge	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N <input type="checkbox"/> Y <input type="checkbox"/> N
131	Delayed by engine speed	YES/NO	YES	<input type="checkbox"/> Y <input type="checkbox"/> N <input type="checkbox"/> Y <input type="checkbox"/> N
6.1.19 Generator: ground fault level 1				
132	Monitoring level 1	ON/OFF	OFF	<input type="checkbox"/> 1 <input type="checkbox"/> 0 <input type="checkbox"/> 0
133	Limit level 1	0 to 300 %	10 %	
134	Delay level 1	0.02 to 99.99 s	0.20 s	
135	Alarm class level 1	A/B/C/D/E/F	B	
136	Self acknowledge level 1	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N <input type="checkbox"/> Y <input type="checkbox"/> N
137	Delayed by engine speed level 1	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N <input type="checkbox"/> Y <input type="checkbox"/> N
6.1.20 Generator: ground fault level 2				
132	Monitoring level 2	ON/OFF	OFF	<input type="checkbox"/> 1 <input type="checkbox"/> 0 <input type="checkbox"/> 0
133	Limit level 2	0 to 300 %	30 %	
134	Delay level 2	0.02 to 99.99 s	0.10 s	
135	Alarm class level 2	A/B/C/D/E/F	F	
136	Self acknowledge level 2	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N <input type="checkbox"/> Y <input type="checkbox"/> N
137	Delayed by engine speed level 2	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N <input type="checkbox"/> Y <input type="checkbox"/> N
6.1.21 Generator: phase rotation				
138	Generator phase rotation	CW (+)/CCW (-)	CW	<input type="checkbox"/> + <input type="checkbox"/> - <input type="checkbox"/> -
139	Monitoring	ON/OFF	ON	<input type="checkbox"/> 1 <input type="checkbox"/> 0 <input type="checkbox"/> 0
140	Alarm class	A/B/C/D/E/F	F	
141	Self acknowledge	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N <input type="checkbox"/> Y <input type="checkbox"/> N
142	Delayed by engine speed	YES/NO	YES	<input type="checkbox"/> Y <input type="checkbox"/> N <input type="checkbox"/> Y <input type="checkbox"/> N
6.1.22 Gen.: inverse-time overcurrent				
143	Monitoring	ON/OFF	ON	<input type="checkbox"/> 1 <input type="checkbox"/> 0 <input type="checkbox"/> 0
144	Inverse time characteristic	Normal/High/Extreme	Normal	<input type="checkbox"/> n <input type="checkbox"/> h <input type="checkbox"/> e <input type="checkbox"/> e
145	Inv. time overcurrent Tp=	0.01 to 1.99 s	0.06 s	
146	Inv. time overcurrent Ip=	10.0 to 300.0 %	100.0 %	
147	Inv. time overcurrent I-start=	100.0 to 300.0 %	115.0 %	
148	Alarm class	A/B/C/D/E/F	F	
149	Self acknowledge	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N <input type="checkbox"/> Y <input type="checkbox"/> N
150	Delayed by engine speed	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N <input type="checkbox"/> Y <input type="checkbox"/> N

Par. No.	Parameter	Setting range	Default value	Customer setting	
6 MONITORING					
6.2 Monitoring Mains					
151	Voltage monitoring mains	3 phase/4 phase	3 phase	<input type="checkbox"/> 3 <input type="checkbox"/> 4	<input type="checkbox"/> 3 <input type="checkbox"/> 4
6.2.1 Mains phase rotation					
152	Mains phase rotation	CW (+)/CCW (-)	CW	<input type="checkbox"/> + <input type="checkbox"/> -	<input type="checkbox"/> + <input type="checkbox"/> -
153	Monitoring	ON/OFF	ON	<input type="checkbox"/> 1 <input type="checkbox"/> 0	<input type="checkbox"/> 1 <input type="checkbox"/> 0
154	Alarm class	A/B/C/D/E/F	B		
155	Self acknowledge	YES/NO	YES	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
156	Delayed by engine speed	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
6.2.2 Mains failure					
157	High voltage threshold	50.0 to 130.0 %	110.0 %		
158	Low voltage threshold	50.0 to 130.0 %	90.0 %		
159	Voltage hysteresis	0.0 to 50.0 %	2.0 %		
160	High frequency threshold	70.0 to 160.0 %	110.0 %		
161	Low frequency threshold	70.0 to 160.0 %	90.0 %		
162	Frequency hysteresis	0.0 to 50.0 %	2.0 %		
6.3 Monitoring Breakers					
163	GCB monitoring	ON/OFF	ON	<input type="checkbox"/> 1 <input type="checkbox"/> 0	<input type="checkbox"/> 1 <input type="checkbox"/> 0
164	GCB alarm class	A/B/C/D/E/F	B		
165	GCB max. closing attempts	1 to 10	5		
166	GCB open monitoring	0.10 to 5.00 s	2.00 s		
167	MCB monitoring	ON/OFF	ON	<input type="checkbox"/> 1 <input type="checkbox"/> 0	<input type="checkbox"/> 1 <input type="checkbox"/> 0
168	MCB alarm class	A/B	B		
169	MCB max. closing attempts	1 to 10	5		
170	MCB open monitoring	0.10 to 5.00 s	2.00 s		
6.4 Monitoring Engine					
6.4.1 Engine: overspeed level 1					
171	Monitoring level 1	ON/OFF	ON	<input type="checkbox"/> 1 <input type="checkbox"/> 0	<input type="checkbox"/> 1 <input type="checkbox"/> 0
172	Limit level 1	0 to 9999 RPM	1850 RPM		
173	Delay level 1	0.02 to 99.99 s	1.00 s		
174	Alarm class level 1	A/B/C/D/E/F	B		
175	Self acknowledge level 1	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
176	Delayed by engine speed level 1	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
6.4.2 Engine: overspeed level 2					
171	Monitoring level 2	ON/OFF	ON	<input type="checkbox"/> 1 <input type="checkbox"/> 0	<input type="checkbox"/> 1 <input type="checkbox"/> 0
172	Limit level 2	0 to 9999 RPM	1900 RPM		
173	Delay level 2	0.02 to 99.99 s	0.10 s		
174	Alarm class level 2	A/B/C/D/E/F	F		
175	Self acknowledge level 2	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
176	Delayed by engine speed level 2	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
6.4.3 Engine: underspeed level 1					
177	Monitoring level 1	ON/OFF	ON	<input type="checkbox"/> 1 <input type="checkbox"/> 0	<input type="checkbox"/> 1 <input type="checkbox"/> 0
178	Limit level 1	0 to 9999 RPM	1300 RPM		
179	Delay level 1	0.02 to 99.99 s	1.00 s		
180	Alarm class level 1	A/B/C/D/E/F	B		
181	Self acknowledge level 1	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
182	Delayed by engine speed level 1	YES/NO	YES	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
6.4.4 Engine: underspeed level 2					
177	Monitoring level 2	ON/OFF	ON	<input type="checkbox"/> 1 <input type="checkbox"/> 0	<input type="checkbox"/> 1 <input type="checkbox"/> 0
178	Limit level 2	0 to 9999 RPM	1250 RPM		
179	Delay level 2	0.02 to 99.99 s	0.10 s		
180	Alarm class level 2	A/B/C/D/E/F	F		
181	Self acknowledge level 2	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
182	Delayed by engine speed level 2	YES/NO	YES	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
6.4.5 Speed detection					
183	Monitoring	ON/OFF	ON	<input type="checkbox"/> 1 <input type="checkbox"/> 0	<input type="checkbox"/> 1 <input type="checkbox"/> 0
184	Mismatch limit	1.5 to 8.5 Hz	5.0 Hz		
185	Delay	0.02 to 99.99 s	2.00 s		
186	Activation frequency	15 to 85 Hz	20 Hz		
187	Alarm class	A/B/C/D/E/F	E		
188	Self acknowledge	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N

Par. No.	Parameter	Setting range	Default value	Customer setting	
6 MONITORING					
6.4.6 Start failure					
189	Monitoring	ON/OFF	ON	<input type="checkbox"/> 1 <input type="checkbox"/> 0	<input type="checkbox"/> 1 <input type="checkbox"/> 0
190	Start attempts	1 to 20	3		
191	Start attempts override	1 to 20	10		
192	Alarm class	A/B/C/D/E/F	F		
193	Self acknowledge	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
6.4.7 Shutdown malfunction					
194	Monitoring	ON/OFF	ON	<input type="checkbox"/> 1 <input type="checkbox"/> 0	<input type="checkbox"/> 1 <input type="checkbox"/> 0
195	Max. stop delay	3 to 999 s	30 s		
196	Alarm class	A/B/C/D/E/F	F		
197	Self acknowledge	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
6.4.8 Unintended stop					
198	Monitoring	ON/OFF	ON	<input type="checkbox"/> 1 <input type="checkbox"/> 0	<input type="checkbox"/> 1 <input type="checkbox"/> 0
199	Alarm class	A/B/C/D/E/F	F		
6.4.9 Dead bus operation					
200	Monitoring	ON/OFF	ON	<input type="checkbox"/> 1 <input type="checkbox"/> 0	<input type="checkbox"/> 1 <input type="checkbox"/> 0
201	Delay	1 to 999 s	30 s		
202	Alarm class	A/B/C/D/E/F	B		
203	Self acknowledge	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
6.5 Monitoring Battery					
6.5.1 Battery: overvoltage level 1					
204	Monitoring level 1	ON/OFF	ON	<input type="checkbox"/> 1 <input type="checkbox"/> 0	<input type="checkbox"/> 1 <input type="checkbox"/> 0
205	Limit level 1	8.0 to 42.0 V	32.0 V		
206	Delay level 1	0.02 to 99.99 s	5.00 s		
207	Alarm class level 1	A/B/C/D/E/F/Control	B		
208	Self acknowledge level 1	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
209	Delayed by engine speed level 1	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
6.5.2 Battery: overvoltage level 2					
204	Monitoring level 2	ON/OFF	OFF	<input type="checkbox"/> 1 <input type="checkbox"/> 0	<input type="checkbox"/> 1 <input type="checkbox"/> 0
205	Limit level 2	8.0 to 42.0 V	35.0 V		
206	Delay level 2	0.02 to 99.99 s	1.00 s		
207	Alarm class level 2	A/B/C/D/E/F/Control	B		
208	Self acknowledge level 2	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
209	Delayed by engine speed level 2	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
6.5.3 Battery: undervoltage level 1					
210	Monitoring level 1	ON/OFF	ON	<input type="checkbox"/> 1 <input type="checkbox"/> 0	<input type="checkbox"/> 1 <input type="checkbox"/> 0
211	Limit level 1	8.0 to 42.0 V	24.0 V		
212	Delay level 1	0.02 to 99.99 s	60.00 s		
213	Alarm class level 1	A/B/C/D/E/F/Control	B		
214	Self acknowledge level 1	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
215	Delayed by engine speed level 1	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
6.5.4 Battery: undervoltage level 2					
210	Monitoring level 2	ON/OFF	ON	<input type="checkbox"/> 1 <input type="checkbox"/> 0	<input type="checkbox"/> 1 <input type="checkbox"/> 0
211	Limit level 2	8.0 to 42.0 V	20.0 V		
212	Delay level 2	0.02 to 99.99 s	10.00 s		
213	Alarm class level 2	A/B/C/D/E/F/Control	B		
214	Self acknowledge level 2	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
215	Delayed by engine speed level 2	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N

Par. No.	Parameter	Setting range	Default value	Customer setting	
6 MONITORING					
6.6 Monitoring Interface					
6.6.1 Monitoring CAN Open interface					
216	Monitoring	ON/OFF	OFF	<input type="checkbox"/> 1 <input type="checkbox"/> 0	<input type="checkbox"/> 1 <input type="checkbox"/> 0
217	Timeout	0.1 to 650.0 s	2.0 s		
218	Alarm class	A/B/C/D/E/F	B		
219	Self acknowledge	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
220	Delayed by engine speed	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
6.6.2 J1939 Interface					
6.6.2.1 Monitoring J1939 Interface					
221	Monitoring	ON/OFF	OFF	<input type="checkbox"/> 1 <input type="checkbox"/> 0	<input type="checkbox"/> 1 <input type="checkbox"/> 0
222	Timeout	0.0 to 650.0 s	20.0 s		
223	Alarm class	A/B/C/D/E/F	B		
224	Self acknowledge	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
225	Delayed by engine speed	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
6.6.2.2 Amber warning lamp DM1					
226	Monitoring	ON/OFF	OFF	<input type="checkbox"/> 1 <input type="checkbox"/> 0	<input type="checkbox"/> 1 <input type="checkbox"/> 0
227	Timeout	0.0 to 650.0 s	2.0 s		
228	Alarm class	A/B/C/D/E/F/Control	A		
229	Self acknowledge	YES/NO	YES	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
230	Delayed by engine speed	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
6.6.2.3 Red stop lamp DM1					
231	Monitoring	ON/OFF	OFF	<input type="checkbox"/> 1 <input type="checkbox"/> 0	<input type="checkbox"/> 1 <input type="checkbox"/> 0
232	Timeout	0.0 to 650.0 s	2.0 s		
233	Alarm class	A/B/C/D/E/F/Control	A		
234	Self acknowledge	YES/NO	YES	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
235	Delayed by engine speed	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N

Par. No.	Parameter	Setting range	Default value	Customer setting	
7 DISCRETE INPUTS					
7.1 Discrete input [D1]					
236	DI 1 operation	N.O. N.C.	N.C.	<input type="checkbox"/> N.O. <input type="checkbox"/> N.C.	<input type="checkbox"/> N.O. <input type="checkbox"/> N.C.
237	DI 1 delay	0.08 to 650.00 s	0.20 s		
238	DI 1 alarm class	A/B/C/D/E/F/Control	F		
239	DI 1 delayed by eng. speed	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
240	DI 1 self acknowledge	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
241	DI 1 text	user-defined	Emergency Stop		
7.2Discrete input [D2]					
236	DI 2 operation	N.O. N.C.	N.O.	<input type="checkbox"/> N.O. <input type="checkbox"/> N.C.	<input type="checkbox"/> N.O. <input type="checkbox"/> N.C.
237	DI 2 delay	0.08 to 650.00 s	0.50 s		
238	DI 2 alarm class	A/B/C/D/E/F/Control	Control		
239	DI 2 delayed by eng. speed	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
240	DI 2 self acknowledge	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
241	DI 2 text	user-defined	Startreq. in AUTO		
7.3 Discrete input [D3]					
236	DI 3 operation	N.O. N.C.	N.O.	<input type="checkbox"/> NO <input type="checkbox"/> NC	<input type="checkbox"/> N.O. <input type="checkbox"/> N.C.
237	DI 3 delay	0.08 to 650.00 s	0.50 s		
238	DI 3 alarm class	A/B/C/D/E/F/Control	B		
239	DI 3 delayed by eng. speed	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
240	DI 3 self acknowledge	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
241	DI 3 text	user-defined	Digital Inp. 3		
7.4 Discrete input [D4]					
236	DI 4 operation	N.O. N.C.	N.O.	<input type="checkbox"/> N.O. <input type="checkbox"/> N.C.	<input type="checkbox"/> N.O. <input type="checkbox"/> N.C.
237	DI 4 delay	0.08 to 650.00 s	0.50 s		
238	DI 4 alarm class	A/B/C/D/E/F/Control	B		
239	DI 4 delayed by eng. speed	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
240	DI 4 self acknowledge	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
241	DI 4 text	user-defined	Digital Inp. 4		
7.5 Discrete input [D5]					
236	DI 5 operation	N.O. N.C.	N.O.	<input type="checkbox"/> N.O. <input type="checkbox"/> N.C.	<input type="checkbox"/> N.O. <input type="checkbox"/> N.C.
237	DI 5 delay	0.08 to 650.00 s	0.50 s		
238	DI 5 alarm class	A/B/C/D/E/F/Control	B		
239	DI 5 delayed by eng. speed	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
240	DI 5 self acknowledge	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
241	DI 5 text	user-defined	Digital Inp. 5		
7.6 Discrete input [D6]					
236	DI 6 operation	N.O. N.C.	N.O.	<input type="checkbox"/> N.O. <input type="checkbox"/> N.C.	<input type="checkbox"/> N.O. <input type="checkbox"/> N.C.
237	DI 6 delay	0.08 to 650.00 s	0.50 s		
238	DI 6 alarm class	A/B/C/D/E/F/Control	B		
239	DI 6 delayed by eng. speed	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
240	DI 6 self acknowledge	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
241	DI 6 text	user-defined	Digital Inp. 6		
7.7 Discrete input [D7]					
236	DI 7 operation	N.O. N.C.	N.C.	<input type="checkbox"/> N.O. <input type="checkbox"/> N.C.	<input type="checkbox"/> N.O. <input type="checkbox"/> N.C.
237	DI 7 delay	0.08 to 650.00 s	0.00 s		
238	DI 7 alarm class	A/B/C/D/E/F/Control	Control		
239	DI 7 delayed by eng. speed	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
240	DI 7 self acknowledge	YES/NO	YES	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
241	DI 7 text	user-defined	Digital Inp. 7		
7.8 Discrete input [D8]					
236	DI 8 operation	N.O. N.C.	N.C.	<input type="checkbox"/> N.O. <input type="checkbox"/> N.C.	<input type="checkbox"/> N.O. <input type="checkbox"/> N.C.
237	DI 8 delay	0.08 to 650.00 s	0.00 s		
238	DI 8 alarm class	A/B/C/D/E/F/Control	Control		
239	DI 8 delayed by eng. speed	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
240	DI 8 self acknowledge	YES/NO	YES	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
241	DI 8 text	user-defined	Digital Inp. 8		

Par. No.	Parameter	Setting range	Default value	Customer setting	
7 DISCRETE INPUTS					
7.9 Discrete input [DEx01]					
236	Operation	N.O. N.C.	N.O.	<input type="checkbox"/> N.O. <input type="checkbox"/> N.C.	<input type="checkbox"/> N.O. <input type="checkbox"/> N.C.
237	Delay	0.05 to 650.00 s	0.20 s		
238	Alarm class	A/B/C/D/E/F/Control	Control		
239	Delayed by eng. speed	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
240	Self acknowledge	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
241	Ext. DI 1 Text	user-defined	Ext. DI 1		
7.10 Discrete input [DEx02]					
236	Operation	N.O. N.C.	N.O.	<input type="checkbox"/> N.O. <input type="checkbox"/> N.C.	<input type="checkbox"/> N.O. <input type="checkbox"/> N.C.
237	Delay	0.05 to 650.00 s	0.20 s		
238	Alarm class	A/B/C/D/E/F/Control	Control		
239	Delayed by eng. speed	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
240	Self acknowledge	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
241	Ext. DI 2 Text	user-defined	Ext. DI 2		
7.11 Discrete input [DEx03]					
236	Operation	N.O. N.C.	N.O.	<input type="checkbox"/> N.O. <input type="checkbox"/> N.C.	<input type="checkbox"/> N.O. <input type="checkbox"/> N.C.
237	Delay	0.05 to 650.00 s	0.20 s		
238	Alarm class	A/B/C/D/E/F/Control	Control		
239	Delayed by eng. speed	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
240	Self acknowledge	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
241	Ext. DI 3 Text	user-defined	Ext. DI 3		
7.12 Discrete input [DEx04]					
236	Operation	N.O. N.C.	N.O.	<input type="checkbox"/> N.O. <input type="checkbox"/> N.C.	<input type="checkbox"/> N.O. <input type="checkbox"/> N.C.
237	Delay	0.05 to 650.00 s	0.20 s		
238	Alarm class	A/B/C/D/E/F/Control	Control		
239	Delayed by eng. speed	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
240	Self acknowledge	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
241	Ext. DI 4 Text	user-defined	Ext. DI 4		
7.13 Discrete input [DEx05]					
236	Operation	N.O. N.C.	N.O.	<input type="checkbox"/> N.O. <input type="checkbox"/> N.C.	<input type="checkbox"/> N.O. <input type="checkbox"/> N.C.
237	Delay	0.05 to 650.00 s	0.20 s		
238	Alarm class	A/B/C/D/E/F/Control	Control		
239	Delayed by eng. speed	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
240	Self acknowledge	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
241	Ext. DI 5 Text	user-defined	Ext. DI 5		
7.14 Discrete input [DEx06]					
236	Operation	N.O. N.C.	N.O.	<input type="checkbox"/> NO <input type="checkbox"/> NC	<input type="checkbox"/> N.O. <input type="checkbox"/> N.C.
237	Delay	0.05 to 650.00 s	0.20 s		
238	Alarm class	A/B/C/D/E/F/Control	Control		
239	Delayed by eng. speed	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
240	Self acknowledge	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
241	Ext. DI 6 Text	user-defined	Ext. DI 6		
7.15 Discrete input [DEx07]					
236	Operation	N.O. N.C.	N.O.	<input type="checkbox"/> N.O. <input type="checkbox"/> N.C.	<input type="checkbox"/> N.O. <input type="checkbox"/> N.C.
237	Delay	0.05 to 650.00 s	0.20 s		
238	Alarm class	A/B/C/D/E/F/Control	Control		
239	Delayed by eng. speed	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
240	Self acknowledge	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
241	Ext. DI 7 Text	user-defined	Ext. DI 7		
7.16 Discrete input [DEx08]					
236	Operation	N.O. N.C.	N.O.	<input type="checkbox"/> N.O. <input type="checkbox"/> N.C.	<input type="checkbox"/> N.O. <input type="checkbox"/> N.C.
237	Delay	0.05 to 650.00 s	0.20 s		
238	Alarm class	A/B/C/D/E/F/Control	Control		
239	Delayed by eng. speed	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
240	Self acknowledge	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
241	Ext. DI 8 Text	user-defined	Ext. DI 8		

Par. No.	Parameter	Setting range	Default value	Customer setting	
7 DISCRETE INPUTS					
7.17 Discrete input [DEx09]					
236	Operation	N.O. N.C.	N.O.	<input type="checkbox"/> N.O. <input type="checkbox"/> N.C.	<input type="checkbox"/> N.O. <input type="checkbox"/> N.C.
237	Delay	0.05 to 650.00 s	0.20 s		
238	Alarm class	A/B/C/D/E/F/Control	Control		
239	Delayed by eng. speed	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
240	Self acknowledge	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
241	Ext. DI 9 Text	user-defined	Ext. DI 9		
7.18 Discrete input [DEx10]					
236	Operation	N.O. N.C.	N.O.	<input type="checkbox"/> N.O. <input type="checkbox"/> N.C.	<input type="checkbox"/> N.O. <input type="checkbox"/> N.C.
237	Delay	0.05 to 650.00 s	0.20 s		
238	Alarm class	A/B/C/D/E/F/Control	Control		
239	Delayed by eng. speed	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
240	Self acknowledge	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
241	Ext. DI 10 Text	user-defined	Ext. DI 10		
7.19 Discrete input [DEx11]					
236	Operation	N.O. N.C.	N.O.	<input type="checkbox"/> N.O. <input type="checkbox"/> N.C.	<input type="checkbox"/> N.O. <input type="checkbox"/> N.C.
237	Delay	0.05 to 650.00 s	0.20 s		
238	Alarm class	A/B/C/D/E/F/Control	Control		
239	Delayed by eng. speed	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
240	Self acknowledge	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
241	Ext. DI 11 Text	user-defined	Ext. DI 11		
7.20 Discrete input [DEx12]					
236	Operation	N.O. N.C.	N.O.	<input type="checkbox"/> N.O. <input type="checkbox"/> N.C.	<input type="checkbox"/> N.O. <input type="checkbox"/> N.C.
237	Delay	0.05 to 650.00 s	0.20 s		
238	Alarm class	A/B/C/D/E/F/Control	Control		
239	Delayed by eng. speed	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
240	Self acknowledge	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
241	Ext. DI 16 Text	user-defined	Ext. DI 12		
7.21 Discrete input [DEx13]					
236	Operation	N.O. N.C.	N.O.	<input type="checkbox"/> N.O. <input type="checkbox"/> N.C.	<input type="checkbox"/> N.O. <input type="checkbox"/> N.C.
237	Delay	0.05 to 650.00 s	0.20 s		
238	Alarm class	A/B/C/D/E/F/Control	Control		
239	Delayed by eng. speed	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
240	Self acknowledge	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
241	Ext. DI 13 Text	user-defined	Ext. DI 13		
7.22 Discrete input [DEx14]					
236	Operation	N.O. N.C.	N.O.	<input type="checkbox"/> N.O. <input type="checkbox"/> N.C.	<input type="checkbox"/> N.O. <input type="checkbox"/> N.C.
237	Delay	0.05 to 650.00 s	0.20 s		
238	Alarm class	A/B/C/D/E/F/Control	Control		
239	Delayed by eng. speed	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
240	Self acknowledge	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
241	Ext. DI 14 Text	user-defined	Ext. DI 14		
7.23 Discrete input [DEx15]					
236	Operation	N.O. N.C.	N.O.	<input type="checkbox"/> N.O. <input type="checkbox"/> N.C.	<input type="checkbox"/> N.O. <input type="checkbox"/> N.C.
237	Delay	0.05 to 650.00 s	0.20 s		
238	Alarm class	A/B/C/D/E/F/Control	Control		
239	Delayed by eng. speed	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
240	Self acknowledge	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
241	Ext. DI 15 Text	user-defined	Ext. DI 15		
7.24 Discrete input [DEx16]					
236	Operation	N.O. N.C.	N.O.	<input type="checkbox"/> N.O. <input type="checkbox"/> N.C.	<input type="checkbox"/> N.O. <input type="checkbox"/> N.C.
237	Delay	0.05 to 650.00 s	0.20 s		
238	Alarm class	A/B/C/D/E/F/Control	Control		
239	Delayed by eng. speed	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
240	Self acknowledge	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
241	Ext. DI 16 Text	user-defined	Ext. DI 16		

Par. No.	Parameter	Setting range	Default value	Customer setting
8 RELAY OUTPUTS (<i>LogicsManager</i>)				
	Relay 1	see descr. in <i>LogicsManager</i> chap. starting page 148; default: (03.05 & 1) & 1		
	Relay 2	see descr. in <i>LogicsManager</i> chap. starting page 148; default: (01.09 & 1) & 1		
	Relay 5	see descr. in <i>LogicsManager</i> chap. starting page 148; default: (03.04 & 1) & 1		
	Relay 6	see descr. in <i>LogicsManager</i> chap. starting page 148; default: (03.01 & 1) & 1		
	Relay 7	see descr. in <i>LogicsManager</i> chap. starting page 148; default: (0 & 1) & 1		
	Relay 8	see descr. in <i>LogicsManager</i> chap. starting page 148; default: (0 & 1) & 1		
	Relay 9	see descr. in <i>LogicsManager</i> chap. starting page 148; default: (0 & 1) & 1		
	Relay10	see descr. in <i>LogicsManager</i> chap. starting page 148; default: (0 & 1) & 1		
	Ready for operat.OFF	see descr. in <i>LogicsManager</i> chap. starting page 148; default: (0 & 1) & 1		
	External DO 1	see descr. in <i>LogicsManager</i> chap. starting page 148; default: (0 & 1) & 1		
	External DO 2	see descr. in <i>LogicsManager</i> chap. starting page 148; default: (0 & 1) & 1		
	External DO 3	see descr. in <i>LogicsManager</i> chap. starting page 148; default: (0 & 1) & 1		
	External DO 4	see descr. in <i>LogicsManager</i> chap. starting page 148; default: (0 & 1) & 1		
	External DO 5	see descr. in <i>LogicsManager</i> chap. starting page 148; default: (0 & 1) & 1		
	External DO 6	see descr. in <i>LogicsManager</i> chap. starting page 148; default: (0 & 1) & 1		
	External DO 7	see descr. in <i>LogicsManager</i> chap. starting page 148; default: (0 & 1) & 1		
	External DO 8	see descr. in <i>LogicsManager</i> chap. starting page 148; default: (0 & 1) & 1		
	External DO 9	see descr. in <i>LogicsManager</i> chap. starting page 148; default: (0 & 1) & 1		
	External DO 10	see descr. in <i>LogicsManager</i> chap. starting page 148; default: (0 & 1) & 1		
	External DO 11	see descr. in <i>LogicsManager</i> chap. starting page 148; default: (0 & 1) & 1		
	External DO 12	see descr. in <i>LogicsManager</i> chap. starting page 148; default: (0 & 1) & 1		
	External DO 13	see descr. in <i>LogicsManager</i> chap. starting page 148; default: (0 & 1) & 1		
	External DO 14	see descr. in <i>LogicsManager</i> chap. starting page 148; default: (0 & 1) & 1		
	External DO 15	see descr. in <i>LogicsManager</i> chap. starting page 148; default: (0 & 1) & 1		
	External DO 16	see descr. in <i>LogicsManager</i> chap. starting page 148; default: (0 & 1) & 1		

Par. No.	Parameter	Setting range	Default value	Customer setting	
9 ANALOG INPUTS (<i>FlexIn</i>)					
242	Display temperature in	°C / °F	°C	<input type="checkbox"/> °C <input type="checkbox"/> °F	<input type="checkbox"/> °C <input type="checkbox"/> °F
243	Display pressure in	bar / psi	bar	<input type="checkbox"/> bar <input type="checkbox"/> psi	<input type="checkbox"/> bar <input type="checkbox"/> psi
9.1 Analog input [T1]					
244	Type	OFF VDO 5bar VDO 10bar VDO 120°C VDO 150°C Pt100 Linear Table A Table B	OFF	<input type="checkbox"/> OFF <input type="checkbox"/> 5bar <input type="checkbox"/> 10bar <input type="checkbox"/> 120°C <input type="checkbox"/> 150°C <input type="checkbox"/> Pt100 <input type="checkbox"/> linear <input type="checkbox"/> Tab.A <input type="checkbox"/> Tab.B	<input type="checkbox"/> OFF <input type="checkbox"/> 5bar <input type="checkbox"/> 10bar <input type="checkbox"/> 120°C <input type="checkbox"/> 150°C <input type="checkbox"/> Pt100 <input type="checkbox"/> linear <input type="checkbox"/> Tab.A <input type="checkbox"/> Tab.B
245	Select hardware	0 to 500 Ohm 0 to 20 mA 4 to 20 mA	0 to 500 Ohm	<input type="checkbox"/> 500Ohm <input type="checkbox"/> 0-20mA <input type="checkbox"/> 4-20mA	<input type="checkbox"/> 500Ohm <input type="checkbox"/> 0-20mA <input type="checkbox"/> 4-20mA
246	Offset	-20.0 to 20.0 Ohm	0.0 Ohm		
247	Bargraph minimum	-9999 to 9999	00000		
248	Bargraph maximum	-9999 to 9999	01000		
249	Description	user-defined	Analog inp. 1		
250	Value format	user-defined	0000		
251	Filter time constant	OFF/1/2/3/4/5	3		
252	Hysteresis	0 to 999	1		
9.1.1 Limit 1 AI 1					
253	Monitoring level 1	ON/OFF	ON	<input type="checkbox"/> 1 <input type="checkbox"/> 0	<input type="checkbox"/> 1 <input type="checkbox"/> 0
254	Limit level 1	-9999 to 9999	200		
255	Limit level 1 idle run	-9999 to 9999	200		
256	Delay level 1	0.02 to 99.99 s	1.00 s		
257	Monitoring level 1 at	Overrun Underrun	Overrun	<input type="checkbox"/> over <input type="checkbox"/> under	<input type="checkbox"/> over <input type="checkbox"/> under
258	Alarm class level 1	A/B/C/D/E/F/Control	B		
259	Self acknowledge level 1	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
260	Delayed by engine level 1	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
9.1.2 Limit 2 AI 1					
253	Monitoring level 2	ON/OFF	ON	<input type="checkbox"/> 1 <input type="checkbox"/> 0	<input type="checkbox"/> 1 <input type="checkbox"/> 0
254	Limit level 2	-9999 to 9999	100		
255	Limit level 2 idle run	-9999 to 9999	100		
256	Delay level 2	0.02 to 99.99 s	1.00 s		
257	Monitoring level 2 at	Overrun Underrun	Overrun	<input type="checkbox"/> over <input type="checkbox"/> under	<input type="checkbox"/> over <input type="checkbox"/> under
258	Alarm class level 2	A/B/C/D/E/F/Control	F		
259	Self acknowledge level 2	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
260	Delayed by engine level 2	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
9.1.3 Wire Break AI 1					
261	Monit. wire break	OFF High Low high/low	OFF	<input type="checkbox"/> OFF <input type="checkbox"/> high <input type="checkbox"/> low <input type="checkbox"/> h/l	<input type="checkbox"/> OFF <input type="checkbox"/> high <input type="checkbox"/> low <input type="checkbox"/> h/l
262	Wire break alarm class	A/B/C/D/E/F/Control	B		
263	Self acknowledge wire break	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
9.1.4 Linear Scale AI 1					
264	Value at 0 %	-9999 to 9999	0		
265	Value at 100 %	-9999 to 9999	1000		

Par. No.	Parameter	Setting range	Default value	Customer setting	
9 ANALOG INPUTS (<i>FlexIn</i>)					
9.2 Analog input [T2]					
244	Type	OFF VDO 5bar VDO 10bar VDO 120°C VDO 150°C Pt100 Linear Table A Table B	OFF	<input type="checkbox"/> OFF <input type="checkbox"/> 5bar <input type="checkbox"/> 10bar <input type="checkbox"/> 120°C <input type="checkbox"/> 150°C <input type="checkbox"/> Pt100 <input type="checkbox"/> linear <input type="checkbox"/> Tab.A <input type="checkbox"/> Tab.B	<input type="checkbox"/> OFF <input type="checkbox"/> 5bar <input type="checkbox"/> 10bar <input type="checkbox"/> 120°C <input type="checkbox"/> 150°C <input type="checkbox"/> Pt100 <input type="checkbox"/> linear <input type="checkbox"/> Tab.A <input type="checkbox"/> Tab.B
245	Select hardware	0 to 500 Ohm 0 to 20 mA 4 to 20 mA	0-500 Ohm	<input type="checkbox"/> 500Ohm <input type="checkbox"/> 0-20mA <input type="checkbox"/> 4-20mA	<input type="checkbox"/> 500Ohm <input type="checkbox"/> 0-20mA <input type="checkbox"/> 4-20mA
246	Offset	-20.0 to 20.0 Ohm	0.0 Ohm		
247	Bargraph minimum	-9999 to 9999	00000		
248	Bargraph maximum	-9999 to 9999	01000		
249	Description	user-defined	Analog inp. 2		
250	Value format	user-defined	0000		
251	Filter time constant	OFF/1/2/3/4/5	3		
252	Hysteresis	0 to 999	1		
9.2.1 Limit 1 AI 2					
253	Monitoring level 1	ON/OFF	ON	<input type="checkbox"/> 1 <input type="checkbox"/> 0	<input type="checkbox"/> 1 <input type="checkbox"/> 0
254	Limit level 1	-9999 to 9999	95		
255	Limit level 1 idle run	-9999 to 9999	95		
256	Delay level 1	0.02 to 99.99 s	1.00 s		
257	Monitoring level 1 at	Overrun Underrun	Overrun	<input type="checkbox"/> over <input type="checkbox"/> under	<input type="checkbox"/> over <input type="checkbox"/> under
258	Alarm class level 1	A/B/C/D/E/F/Control	B		
259	Self acknowledge level 1	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
260	Delayed by engine level 1	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
9.2.2 Limit 2 AI 2					
253	Monitoring level 2	ON/OFF	ON	<input type="checkbox"/> 1 <input type="checkbox"/> 0	<input type="checkbox"/> 1 <input type="checkbox"/> 0
254	Limit level 2	-9999 to 9999	100		
255	Limit level 2 idle run	-9999 to 9999	100		
256	Delay level 2	0.02 to 99.99 s	1.00 s		
257	Monitoring level 2 at	Overrun Underrun	Overrun	<input type="checkbox"/> over <input type="checkbox"/> under	<input type="checkbox"/> over <input type="checkbox"/> under
258	Alarm class level 2	A/B/C/D/E/F/Control	F		
259	Self acknowledge level 2	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
260	Delayed by engine level 2	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
9.2.3 Wire Break AI 2					
261	Monit. wire break	OFF High Low high/low	OFF	<input type="checkbox"/> OFF <input type="checkbox"/> high <input type="checkbox"/> low <input type="checkbox"/> h/l	<input type="checkbox"/> OFF <input type="checkbox"/> high <input type="checkbox"/> low <input type="checkbox"/> h/l
262	Wire break alarm class	A/B/C/D/E/F/Control	B		
263	Self acknowledge wire break	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
9.2.4 Linear Scale AI 2					
264	Value at 0 %	-9999 to 9999	0		
265	Value at 100 %	-9999 to 9999	1000		

Par. No.	Parameter	Setting range	Default value	Customer setting	
9 ANALOG INPUTS (<i>FlexIn</i>)					
9.3 Flexible Thresholds					
9.3.1 Configure limit 1					
266	Monitoring	ON/OFF	ON	<input type="checkbox"/> 1 <input type="checkbox"/> 0	<input type="checkbox"/> 1 <input type="checkbox"/> 0
267	Monitored analog input	Battery voltage AnalogIn1 AnalogIn2 ECUSPN110 ECUSPN100 ECUSPN190	AnalogIn1	<input type="checkbox"/> Battery <input type="checkbox"/> AnIn1 <input type="checkbox"/> AnIn2 <input type="checkbox"/> SPN110 <input type="checkbox"/> SPN100 <input type="checkbox"/> SPN190	<input type="checkbox"/> Battery <input type="checkbox"/> AnIn1 <input type="checkbox"/> AnIn2 <input type="checkbox"/> SPN110 <input type="checkbox"/> SPN100 <input type="checkbox"/> SPN190
268	Limit	-32000 to +32000	+00100		
269	Delay	00.02 to 99.99 s	01.00 s		
270	Monitoring at	Overrun / Underrun	Underrun	<input type="checkbox"/> O / <input type="checkbox"/> U	<input type="checkbox"/> O / <input type="checkbox"/> U
271	Alarm class	A/B/C/D/E/F/Control	B		
272	Self acknowledge	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
273	Delayed by engine speed	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
274	Hysteresis	000	001		
275	Description	user-defined	Flexible Limit 1		
9.3.2 Configure limit 2					
266	Monitoring	ON/OFF	ON	<input type="checkbox"/> 1 <input type="checkbox"/> 0	<input type="checkbox"/> 1 <input type="checkbox"/> 0
267	Monitored analog input	Battery voltage AnalogIn1 AnalogIn2 ECUSPN110 ECUSPN100 ECUSPN190	AnalogIn1	<input type="checkbox"/> Battery <input type="checkbox"/> AnIn1 <input type="checkbox"/> AnIn2 <input type="checkbox"/> SPN110 <input type="checkbox"/> SPN100 <input type="checkbox"/> SPN190	<input type="checkbox"/> Battery <input type="checkbox"/> AnIn1 <input type="checkbox"/> AnIn2 <input type="checkbox"/> SPN110 <input type="checkbox"/> SPN100 <input type="checkbox"/> SPN190
268	Limit	-32000 to +32000	+00100		
269	Delay	00.02 to 99.99 s	01.00 s		
270	Monitoring at	Overrun / Underrun	Underrun	<input type="checkbox"/> O / <input type="checkbox"/> U	<input type="checkbox"/> O / <input type="checkbox"/> U
271	Alarm class	A/B/C/D/E/F/Control	B		
272	Self acknowledge	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
273	Delayed by engine speed	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
274	Hysteresis	000	001		
275	Description	user-defined	Flexible Limit 2		
9.3.3 Configure limit 3					
266	Monitoring	ON/OFF	ON	<input type="checkbox"/> 1 <input type="checkbox"/> 0	<input type="checkbox"/> 1 <input type="checkbox"/> 0
267	Monitored analog input	Battery voltage AnalogIn1 AnalogIn2 ECUSPN110 ECUSPN100 ECUSPN190	AnalogIn2	<input type="checkbox"/> Battery <input type="checkbox"/> AnIn1 <input type="checkbox"/> AnIn2 <input type="checkbox"/> SPN110 <input type="checkbox"/> SPN100 <input type="checkbox"/> SPN190	<input type="checkbox"/> Battery <input type="checkbox"/> AnIn1 <input type="checkbox"/> AnIn2 <input type="checkbox"/> SPN110 <input type="checkbox"/> SPN100 <input type="checkbox"/> SPN190
268	Limit	-32000 to +32000	+00100		
269	Delay	00.02 to 99.99 s	01.00 s		
270	Monitoring at	Overrun / Underrun	Underrun	<input type="checkbox"/> O / <input type="checkbox"/> U	<input type="checkbox"/> O / <input type="checkbox"/> U
271	Alarm class	A/B/C/D/E/F/Control	B		
272	Self acknowledge	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
273	Delayed by engine speed	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
274	Hysteresis	000	001		
275	Description	user-defined	Flexible Limit 3		
9.3.4 Configure limit 4					
266	Monitoring	ON/OFF	ON	<input type="checkbox"/> 1 <input type="checkbox"/> 0	<input type="checkbox"/> 1 <input type="checkbox"/> 0
267	Monitored analog input	Battery voltage AnalogIn1 AnalogIn2 ECUSPN110 ECUSPN100 ECUSPN190	AnalogIn2	<input type="checkbox"/> Battery <input type="checkbox"/> AnIn1 <input type="checkbox"/> AnIn2 <input type="checkbox"/> SPN110 <input type="checkbox"/> SPN100 <input type="checkbox"/> SPN190	<input type="checkbox"/> Battery <input type="checkbox"/> AnIn1 <input type="checkbox"/> AnIn2 <input type="checkbox"/> SPN110 <input type="checkbox"/> SPN100 <input type="checkbox"/> SPN190
268	Limit	-32000 to +32000	+00100		
269	Delay	00.02 to 99.99 s	01.00 s		
270	Monitoring at	Overrun / Underrun	Underrun	<input type="checkbox"/> O / <input type="checkbox"/> U	<input type="checkbox"/> O / <input type="checkbox"/> U
271	Alarm class	A/B/C/D/E/F/Control	B		
272	Self acknowledge	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
273	Delayed by engine speed	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
274	Hysteresis	000	001		
275	Description	user-defined	Flexible Limit 4		

Par. No.	Parameter	Setting range	Default value	Customer setting	
----------	-----------	---------------	---------------	------------------	--

9 ANALOG INPUTS (*FlexIn*)**9.4 Define Table A**

276	X-value 1	0 to 100 %	2 %		
277	Y-value 1	-9999 to 9999	0		
276	X-value 2	0 to 100 %	8 %		
277	Y-value 2	-9999 to 9999	207		
276	X-value 3	0 to 100 %	16 %		
277	Y-value 3	-9999 to 9999	512		
276	X-value 4	0 to 100 %	24 %		
277	Y-value 4	-9999 to 9999	838		
276	X-value 5	0 to 100 %	27 %		
277	Y-value 5	-9999 to 9999	970		
276	X-value 6	0 to 100 %	31 %		
277	Y-value 6	-9999 to 9999	1160		
276	X-value 7	0 to 100 %	36 %		
277	Y-value 7	-9999 to 9999	1409		
276	X-value 8	0 to 100 %	37 %		
277	Y-value 8	-9999 to 9999	1461		
276	X-value 9	0 to 100 %	41 %		
277	Y-value 9	-9999 to 9999	1600		

9.5 Define Table B

276	X-value 1	0 to 100 %	4 %		
277	Y-value 1	-9999 to 9999	2553		
276	X-value 2	0 to 100 %	6 %		
277	Y-value 2	-9999 to 9999	2288		
276	X-value 3	0 to 100 %	8 %		
277	Y-value 3	-9999 to 9999	2100		
276	X-value 4	0 to 100 %	13 %		
277	Y-value 4	-9999 to 9999	1802		
276	X-value 5	0 to 100 %	16 %		
277	Y-value 5	-9999 to 9999	1685		
276	X-value 6	0 to 100 %	23 %		
277	Y-value 6	-9999 to 9999	1488		
276	X-value 7	0 to 100 %	28 %		
277	Y-value 7	-9999 to 9999	1382		
276	X-value 8	0 to 100 %	42 %		
277	Y-value 8	-9999 to 9999	1188		
276	X-value 9	0 to 100 %	58 %		
277	Y-value 9	-9999 to 9999	1035		

10 CONFIGURE COUNTERS

278	Maintenance hours	0 to 9999 h	300 h		
279	Maintenance days	0 to 999 days	365 days		
280	Reset maintenance period h	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
281	Reset maintenance period days	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
282	Code level for reset maintenance	0 to 3	3		
283	Counter value preset	0 to 99999999	00000000		
284	Set operation hours in 000h	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
285	Set active energy in 0.00MWh	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
286	Set reactive energy in 0.00Mvarh	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
287	Counter value preset	0 to 65535	00000		
288	Set number of starts	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N

Par. No.	Parameter	Setting range	Default value	Customer setting
----------	-----------	---------------	---------------	------------------

11 LogicsManager**11.1 Limit switch**

289	Gen. load limit 1	0.0 to 200.0 %	80.0 %	
290	Gen. load limit 2	0.0 to 200.0 %	90.0 %	
291	Gen. load hysteresis	0.0 to 100.0 %	5.0 %	
292	Mains load limit 1	-999.9 to 999.9 %	80.0 %	
293	Mains load limit 2	-999.9 to 999.9 %	90.0 %	
294	Mains load hysteresis	0.0 to 100.0 %	5.0 %	

11.2 Internal Flags

295	Flag 1	see descr. in <i>LogicsManager</i> chap. starting page 151; default: (0 & 1) & 1		
295	Flag 2	see descr. in <i>LogicsManager</i> chap. starting page 151; default: (0 & 1) & 1		
295	Flag 3	see descr. in <i>LogicsManager</i> chap. starting page 151; default: (0 & 1) & 1		
295	Flag 4	see descr. in <i>LogicsManager</i> chap. starting page 151; default: (0 & 1) & 1		
295	Flag 5	see descr. in <i>LogicsManager</i> chap. starting page 151; default: (0 & 1) & 1		
295	Flag 6	see descr. in <i>LogicsManager</i> chap. starting page 151; default: (0 & 1) & 1		
295	Flag 7	see descr. in <i>LogicsManager</i> chap. starting page 151; default: (0 & 1) & 1		
295	Flag 8	see descr. in <i>LogicsManager</i> chap. start. page 151; def.: (11.01 & !11.02) & 11.03		

11.3 Set Timers

296	Setpoint 1: Hour	0 to 23 h	8 h	
297	Setpoint 1: Minute	0 to 59 min	0 min	
298	Setpoint 1: Second	0 to 59 s	0 s	
296	Setpoint 2: Hour	0 to 23 h	17 h	
297	Setpoint 2: Minute	0 to 59 min	0 min	
298	Setpoint 2: Second	0 to 59 s	0 s	
299	Active day	1 to 31	1	
300	Active hour	0 to 23 h	12 h	
301	Active minute	0 to 59 min	0 min	
302	Active second	0 to 59 s	0 s	
303	Monday active	YES/NO	YES	<input type="checkbox"/> Y <input type="checkbox"/> N <input type="checkbox"/> Y <input type="checkbox"/> N
303	Tuesday active	YES/NO	YES	<input type="checkbox"/> Y <input type="checkbox"/> N <input type="checkbox"/> Y <input type="checkbox"/> N
303	Wednesday active	YES/NO	YES	<input type="checkbox"/> Y <input type="checkbox"/> N <input type="checkbox"/> Y <input type="checkbox"/> N
303	Thursday active	YES/NO	YES	<input type="checkbox"/> Y <input type="checkbox"/> N <input type="checkbox"/> Y <input type="checkbox"/> N
303	Friday active	YES/NO	YES	<input type="checkbox"/> Y <input type="checkbox"/> N <input type="checkbox"/> Y <input type="checkbox"/> N
303	Saturday active	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N <input type="checkbox"/> Y <input type="checkbox"/> N
303	Sunday active	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N <input type="checkbox"/> Y <input type="checkbox"/> N

12 COMMUNICATION INTERFACES

304	Device number	1 to 127	1	
12.1 CAN Interfaces				
305	Protocol	OFF CANopen LeoPC	CANopen	<input type="checkbox"/> OFF <input type="checkbox"/> CANop. <input type="checkbox"/> LeoPC <input type="checkbox"/> OFF <input type="checkbox"/> CANop. <input type="checkbox"/> LeoPC
306	Baudrate	20/50/100/125/250/500/ 800/1000 kBd	125 kBd	

Par. No.	Parameter	Setting range	Default value	Customer setting
----------	-----------	---------------	---------------	------------------

12 COMMUNICATION INTERFACES

12.1.1 CANopen	Parameter settings 'CAN bus': see manual 37262			
CAN-Open Master	YES/NO	YES	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
Producer Heartbeat Time	20 to 65530 ms	2000 ms		
COB-ID SYNC Message	1 to 4294967295	128		
Max. answer time ext. devices	0,1 to 9,9 s	3,0 s		
Time re-init. ext. devices	0 to 9999 s	10 s		
12.1.1.1 Additional S-DO				
2nd Client->Server COB-ID (rx)	1 to 4294967295	2147485185		
2nd Server->Client COB-ID (tx)	1 to 4294967295	2147485057		
3rd Client->Server COB-ID (rx)	1 to 4294967295	2147485186		
3rd Server->Client COB-ID (tx)	1 to 4294967295	2147485058		
4th Client->Server COB-ID (rx)	1 to 4294967295	2147485187		
4th Server->Client COB-ID (tx)	1 to 4294967295	2147485059		
5th Client->Server COB-ID (rx)	1 to 4294967295	2147485188		
5th Server->Client COB-ID (tx)	1 to 4294967295	2147485060		
12.1.1.2 CAN OPEN RPDO 1				
COB-ID	1 to 4294967295	513		
Function	no func. / 1st IKD / 2nd IKD / BK 16DIDO/Co 16DIDO	no func.		
Node-ID of the device	1 to 127	2		
RPDO-COB-ID ext. device 1	1 to 4294967295	385		
12.1.1.3 CAN OPEN RPDO 2				
COB-ID	1 to 4294967295	514		
Function	no func. / 1st IKD / 2nd IKD	no func.		
Node-ID of the device	1 to 127	3		
RPDO-COB-ID ext. device 2	1 to 4294967295	386		
12.1.1.5 CAN OPEN TPDO 1				
COB-ID	1 to 4294967295	385		
Transmission type	0 to 255	255		
Event-timer	20 to 65000 ms	20 ms		
Number of mapped objects	0 to 4	4		
1.Mapped Object	0 to 65535	8001		
2.Mapped Object	0 to 65535	8000		
3.Mapped Object	0 to 65535	8000		
4.Mapped Object	0 to 65535	8000		
12.1.1.6 CAN OPEN TPDO 2				
COB-ID	1 to 4294967295	386		
Transmission type	0 to 255	255		
Event-timer	20 to 65000 ms	20 ms		
Number of mapped objects	0 to 4	4		
1.Mapped Object	0 to 65535	8002		
2.Mapped Object	0 to 65535	8000		
3.Mapped Object	0 to 65535	8000		
4.Mapped Object	0 to 65535	8000		
12.1.1.7 CAN OPEN TPDO 3				
COB-ID	1 to 4294967295	897		
Transmission type	0 to 255	255		
Event-timer	20 to 65000 ms	20 ms		
Number of mapped objects	0 to 4	1		
1.Mapped Object	0 to 65535	3196		
2.Mapped Object	0 to 65535	8000		
3.Mapped Object	0 to 65535	8000		
4.Mapped Object	0 to 65535	8000		
12.1.1.8 CAN OPEN TPDO 4				
COB-ID	1 to 4294967295	1153		
Transmission type	0 to 255	255		
Event-timer	20 to 65000 ms	20 ms		
Number of mapped objects	0 to 4	1		
1.Mapped Object	0 to 65535	3190		
2.Mapped Object	0 to 65535	8000		
3.Mapped Object	0 to 65535	8000		
4.Mapped Object	0 to 65535	8000		

Par. No.	Parameter	Setting range	Default value	Customer setting
----------	-----------	---------------	---------------	------------------

12 COMMUNICATION INTERFACES


12.1.2 J1939				
307	Device type	Off / Standard / S6 Scania / EMR	Off	<input type="checkbox"/> Off <input type="checkbox"/> Standard <input type="checkbox"/> S6Scania <input type="checkbox"/> EMR
308	Request send address	0 to 255	3	<input type="checkbox"/> Off <input type="checkbox"/> Standard <input type="checkbox"/> S6Scania <input type="checkbox"/> EMR
309	Receive device number	0 to 255	0	<input type="checkbox"/> Off <input type="checkbox"/> Standard <input type="checkbox"/> S6Scania <input type="checkbox"/> EMR
310	Reset prev. active DTCs DM3	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N
311	SPN version	Version 1/2/3	Version 1	<input type="checkbox"/> V1 <input type="checkbox"/> V2 <input type="checkbox"/> V3
312	ECU remote controlled	ON/OFF	OFF	<input type="checkbox"/> ON <input type="checkbox"/> OFF
313	ECU set droop mode	ON/OFF	OFF	<input type="checkbox"/> ON <input type="checkbox"/> OFF
314	Frequency offset ECU	OFF / AnalogIn1 / AanalogIn2	OFF	<input type="checkbox"/> OFF <input type="checkbox"/> AI1 <input type="checkbox"/> AI2
12.2 Serial Interfaces				
315	Baudrate	2400/4800/9600 Bd / 14.4/19.2/38.4/56/115 kBd	9,600 Bd	
316	Parity	None/even/odd	None	
317	Stop Bits	one/two	one	
318	ModBus Slave ID	0 to 255	0	
319	Modbus Reply delay time	0.00 to 1.00 s	0.00 s	

13 SYSTEM

13.1 Codes				
320	Code level CAN port	Info	---	
321	Code level serial port / DPC	Info	---	
322	Commissioning level code	0000 to 9999	---	
323	Temp. commissioning level code	0000 to 9999	---	
324	Basic level code	0000 to 9999	---	
325	Clear event log	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N
326	Factory settings DPC/RS232	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N
327	Factory settings CAN	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N
328	Set default values	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N
329	Start Bootloader	00000 to 99999		
13.2 Clock Set				
330	Hours	0 to 23 h	---	
331	Minutes	0 to 59 min	---	
332	Seconds	0 to 59 s	---	
333	Day	1 to 31	---	
334	Month	1 to 12	---	
335	Year	0 to 99	---	
13.3 Versions				
336	Serial number	Info	---	
337	Boot item number	Info	---	
338	Boot revision	Info	---	
339	Boot version	Info	---	
340	Program item number	Info	---	
341	Program revision	Info	---	
342	Program version	Info	---	

Appendix E. Technical Data

Nameplate -----



1	S/N	Serial number (numerical)
2	S/N	Date of production (YYMM)
3	S/N	Serial number (Barcode)
4	P/N	Part number
5	REV	Part revision number
6	Details	Technical data
7	Type	Description (short)
8	Type	Description (long)
9	UL	UL sign

Measuring values, voltages -----

- Measuring voltages

[1] 120 Vac (terminals 22/24/26/28 & 14/16/18/20)

Rated value (Vn)..... 69/120 Vac
 Maximum value (Vmax)..... max. 86/150 Vac
 Rated voltage phase – ground..... 150 Vac
 Rated surge voltage 2.5 kV

[5] 480 Vac (terminals 23/25/27/29 & 15/17/19/21)

Rated value (Vn)..... 277/480 Vac
 Maximum value (Vmax)..... max. 346/600 Vac
 Rated voltage phase – ground..... 300 Vac
 Rated surge voltage 45 kV

- Linear measuring range..... $1.3 \times V_n$
 - Measuring frequency 50/60 Hz (40.0 to 70.0 Hz)
 - Accuracy Class 1
 - Input resistance per path [1] 0.498 M Ω , [5] 2.0 M Ω
 - Maximum power consumption per path < 0.15 W

Measuring values, currents -----

- Measuring current

[../1] Rated value (In)/1 A
[../5] Rated value (In)/5 A

- Accuracy Class 1
 - Linear measuring range Generator (terminals 5-8) $3.0 \times I_n$
 Mains/ground current (terminals 1/2) ... approx. $1.5 \times I_n$
 - Maximum power consumption per path < 0.15 VA
 - Rated short-time current (1 s) [../1 A] $50.0 \times I_n$
 [../5 A] $10.0 \times I_n$

Ambient variables -----

- Power supply 12/24 Vdc (6.5 to 40.0 Vdc)
 Battery ground (terminal 48) must be grounded to the chassis
 - Intrinsic consumption max. 15 W
 - Degree of pollution 2

Discrete inputs ----- isolated	
- Input range (VCont, digital input).....	Rated voltage 12/24 Vdc (6.5 to 40.0 Vdc)
- Input resistance.....	approx. 6.7 kΩ
Relay outputs ----- potential free	
- Contact material	AgCdO
- General purpose (GP) (VCont, relay output)	
AC	2.00 Aac@250 Vac
DC	2.00 Adc@24 Vdc
	0.36 Adc@125 Vdc
	0.18 Adc@250 Vdc
- Pilot duty (PD) (VCont, relay output)	
AC	B300
DC	1.00 Adc@24 Vdc
	0.22 Adc@125 Vdc
	0.10 Adc@250 Vdc
Analog inputs ----- freely scaleable	
- Resolution.....	10 Bit
- 0/4 to 20 mA input	internal load 50 Ω
- 0 to 180/380 Ω input	load current ≤ 2.3 mA
- Accuracy	solely two-pole sensors ≤ 1%
	single-pole sensors ≤ 2.5%
Magnetic Pickup Input ----- capacitive decoupled	
- Input impedance	min. approx. 17 kΩ
- Input voltage.....	refer to manual 37320, section Pickup

Interface -----**Service interface**

- Version..... RS-232
 - Signal level5V
- Level conversion and insulation by using DPC (P/N 5417-557)

CAN bus interface**isolated**

- Insulation voltage..... 1,500 Vdc
- Version..... CAN bus
- Internal line termination..... Not available

Battery -----

- Type NiCd
- Durability (at operation without power supply)..... approx. 5 years
- Battery field replacement..... not possible

Housing -----

- Type APRANORM DIN 43 700
- Dimensions (W × H × D)..... 192 × 144 × 64 mm
- Front cutout (W × H) 186 [+1.1] × 138 [+1.0] mm
- Wiringscrew-plug-terminals 2.5 mm²
- Recommended locked torque..... 4 inch pounds / 0.5 Nm
- use 60/75 °C copper wire only
- use class 1 wire only or equivalent
- Weight..... approx. 800 g

Protection -----

- Protection system..... IP42 from front with proper installation
- IP54 from front with gasket (gasket: P/N 8923-1043)
- IP20 from back
- Front folio insulating surface
- EMC test (CE)tested according to applicable EN guidelines
- Listings CE marking; UL listing for ordinary locations
- Type approval UL/cUL listed, Ordinary Locations, File No.: 231544

Appendix F. Environmental Data

Dynamics	
- Frequency Range – Sine Sweep	5Hz to 150Hz
- Acceleration	4G
- Frequency Range - Random	10Hz to 500Hz
- Power Density	0,015G ² /Hz
- RMS Value	1,04 Grms
- Standards	EN 60255-21-1 (EN 60068-2-6, Fc) EN 60255-21-3 Lloyd's Register, Vibration Test2 SAEJ1455 Chasis Data MIL-STD 810F, M514.5A, Cat.4, Truck/Trailer tracked-restrained cargo, Fig. 514.5-C1
Shock	
- 40G, Sawtooth Puls, 11ms	
- Standards	EN 60255-21-2 MIL-STD 810F, M516.5, Procedure 1
Temperature	
- Cold, Dry Heat (storage)	-30°C (-22°F) / 80°C (176°F)
- Cold, Dry Heat (operating)	-20°C (-4°F) / 70 °C (158°F)
- Standards	IEC 60068-2-2, Test Bb and Bd IEC 60068-2-1, Test Ab and Ad
Humidity	
- 60°C, 95% RH, 5 days	
- Standards	IEC 60068-2-30, Test Db
Marine Environmental Categories	
- Bureau Vertias (BV)	33
- Det Norske Veritas (DNV)	Temperature Class:..... B Vibration Class:..... B Humidity Class:..... B
- Germanischer Lloyd (GL)	Environmental Class D
- Lloyd's Register of Shipping (LRS)	ENV1, ENV2, ENV3 und ENV4

Appendix G. Service Options

Product Service Options



The following factory options are available for servicing Woodward equipment, based on the standard Woodward Product and Service Warranty (5-01-1205) that is in effect at the time the product is purchased from Woodward or the service is performed. If you are experiencing problems with installation or unsatisfactory performance of an installed system, the following options are available:

- Consult the troubleshooting guide in the manual.
- Contact Woodward technical assistance (see "How to Contact Woodward" later in this chapter) and discuss your problem. In most cases, your problem can be resolved over the phone. If not, you can select which course of action you wish to pursue based on the available services listed in this section.

Returning Equipment For Repair



If a control (or any part of an electronic control) is to be returned to Woodward for repair, please contact Woodward in advance to obtain a Return Authorization Number. When shipping the unit(s), attach a tag with the following information:

- name and location where the control is installed;
- name and phone number of contact person;
- complete Woodward part numbers (P/N) and serial number (S/N);
- description of the problem;
- instructions describing the desired type of repair.



CAUTION

To prevent damage to electronic components caused by improper handling, read and observe the precautions in Woodward manual 82715, *Guide for Handling and Protection of Electronic Controls, Printed Circuit Boards, and Modules*.

Packing A Control

Use the following materials when returning a complete control:

- protective caps on any connectors;
- antistatic protective bags on all electronic modules;
- packing materials that will not damage the surface of the unit;
- at least 100 mm (4 inches) of tightly packed, industry-approved packing material;
- a packing carton with double walls;
- a strong tape around the outside of the carton for increased strength.

Return Authorization Number RAN

When returning equipment to Woodward, please telephone and ask for the Customer Service Department in Stuttgart [+49 (0) 711 789 54-0]. They will help expedite the processing of your order through our distributors or local service facility. To expedite the repair process, contact Woodward in advance to obtain a Return Authorization Number, and arrange for issue of a purchase order for the unit(s) to be repaired. No work can be started until a purchase order is received.



NOTE

We highly recommend that you make arrangement in advance for return shipments. Contact a Woodward customer service representative at +49 (0) 711 789 54-0 for instructions and for a Return Authorization Number.

Replacement Parts



When ordering replacement parts for controls, include the following information:

- the part numbers P/N (XXXX-XXX) that is on the enclosure nameplate;
- the unit serial number S/N, which is also on the nameplate.

How To Contact Woodward



Please contact following address if you have questions or if you want to send a product for repair:

Woodward GmbH
Handwerkstrasse 29
70565 Stuttgart - Germany

Phone: +49 (0) 711 789 54-0 (8.00 - 16.30 German time)
Fax: +49 (0) 711 789 54-100
eMail: sales-stuttgart@woodward.com

For assistance outside Germany, call one of the following international Woodward facilities to obtain the address and phone number of the facility nearest your location where you will be able to get information and service.

Facility	Phone number
USA	+1 (970) 482 5811
India	+91 (129) 230 7111
Brazil	+55 (19) 3708 4800
Japan	+81 (476) 93 4661
The Netherlands	+31 (23) 566 1111

You can also contact the Woodward Customer Service Department or consult our worldwide directory on Woodward's website (**www.woodward.com**) for the name of your nearest Woodward distributor or service facility. [For worldwide directory information, go to **www.woodward.com/ic/locations**.]

Engineering Services



Woodward Industrial Controls Engineering Services offers the following after-sales support for Woodward products. For these services, you can contact us by telephone, by e-mail, or through the Woodward website.

- Technical support
- Product training
- Field service during commissioning

Technical Support is available through our many worldwide locations, through our authorized distributors, or through GE Global Controls Services, depending on the product. This service can assist you with technical questions or problem solving during normal business hours. Emergency assistance is also available during non-business hours by phoning our toll-free number and stating the urgency of your problem. For technical engineering support, please contact us via our toll-free or local phone numbers, e-mail us, or use our website and reference technical support.

Product Training is available on-site from several of our worldwide facilities, at your location, or from GE Global Controls Services, depending on the product. This training, conducted by experienced personnel, will assure that you will be able to maintain system reliability and availability. For information concerning training, please contact us via our toll-free or local phone numbers, e-mail us, or use our website and reference *customer training*.

Field Service engineering on-site support is available, depending on the product and location, from our facility in Colorado, or from one of many worldwide Woodward offices or authorized distributors. Field engineers are experienced on both Woodward products as well as on much of the non-Woodward equipment with which our products interface. For field service engineering assistance, please contact us via our toll-free or local phone numbers, e-mail us, or use our website and reference *field service*.

Technical Assistance



If you need to telephone for technical assistance, you will need to provide the following information. Please write it down here before phoning:

Contact

Your company _____

Your name _____

Phone number _____

Fax number _____

Control (see name plate)

Unit no. and revision: P/N: _____ REV: _____

Unit type easYgen- _____

Serial number S/N _____

Description of your problem

Please be sure you have a list of all parameters available. You can print this using LeoPC. Additionally you can save the complete set of parameters (standard values) and send them to our Service department via e-mail.

We appreciate your comments about the content of our publications.
Please send comments to: stgt-documentation@woodward.com
Please include the manual number from the front cover of this publication.



Woodward GmbH
Handwerkstrasse 29 - 70565 Stuttgart - Germany
Phone +49 (0) 711 789 54-0 • Fax +49 (0) 711 789 54-100
sales-stuttgart@woodward.com

Homepage

<http://www.woodward.com/power>

Woodward has company-owned plants, subsidiaries, and branches, as well as authorized distributors and other authorized service and sales facilities throughout the world.

Complete address/phone/fax/e-mail information
for all locations is available on our website (www.woodward.com).