


Product Manual 35203V1 (Revision -, 6/2023) Original Instructions



## **Large Engine System Platform**

**Packages** 

**Developer Manual** 



General **Precautions**  Read this entire manual and all other publications pertaining to the work to be performed before installing, operating, or servicing this equipment.

Practice all plant and safety instructions and precautions.

Failure to follow instructions can cause personal injury and/or property damage.



Revisions

This publication may have been revised or updated since this copy was produced. The latest version of most publications is available on the Woodward website.

http://www.woodward.com

If your publication is not there, please contact your customer service representative to get the latest copy.



**Proper Use** 

Any unauthorized modifications to or use of this equipment outside its specified mechanical, electrical, or other operating limits may cause personal injury and/or property damage, including damage to the equipment. Any such unauthorized modifications: (i) constitute "misuse" and/or "negligence" within the meaning of the product warranty thereby excluding warranty coverage for any resulting damage, and (ii) invalidate product certifications or listings.



If the cover of this publication states "Translation of the Original Instructions" please note:

## **Translated**

The original source of this publication may have been updated since this translation was made. The latest version of most publications is available on the Publications Woodward website.

www.woodward.com/publications

Always compare with the original for technical specifications and for proper and safe installation and operation procedures.

If your publication is not on the Woodward website, please contact your customer service representative to get the latest copy.

Revisions— A bold, black line alongside the text identifies changes in this publication since the last revision.

Woodward reserves the right to update any portion of this publication at any time. Information provided by Woodward is believed to be correct and reliable. However, no responsibility is assumed by Woodward unless otherwise expressly undertaken.

> Manual 35203V1 Copyright © Woodward, Inc. 2023 All Rights Reserved

## Contents

Warnings and Notices	6
REGULATORY COMPLIANCE	8
CHAPTER 1. OVERVIEW	ç
Introduction	
Application Development Environment	
Understanding Project Directory Structure	
Upgrading Project Framework Dependencies	
Closer Look: Model_setup.m	
Enumerations	
LESP Custom DataTypes	
LESP User Blocks	
CHAPTER 2. MODEL ARCHITECTURE	
Introduction	
Model Root	
OS Event Management	
InputsInputs	
Control	
Outputs Subsystem	
Diagnostics & Monitoring Subsystem	
Application Subsystem	
CHAPTER 3. EID INTERFACING	
Introduction	
General EID Interfaces	
MixedMode & Ignition Control Interfaces	50
Injection Control Interfaces	
EID Interface Diagnostics	52
CHAPTER 4. AUX INTERFACING	54
Introduction	
General Aux Interfaces	
Acoustic Knock Interfaces	
RTCDC Interfaces	
Aux Interface Diagnostics	
CHAPTER 5. DIAGNOSTICS MANAGEMENT	
Introduction	
Standard Platform Diagnostic Structure	
Standard Platform Diagnostic Structure	00
CHAPTER 6. LECM MAIN ENCODER	78
Introduction	78
Blockset	81
CHAPTER 7. TOOLKIT	90
Introduction	
ToolKit Integration/Features	
ToolKit Structure	
CHAPTER 8. EXAMPLES	
Introduction	
Input Examples	
Diagnostic Examples	
Output Examples	118
CHAPTER 9. PRODUCT SUPPORT AND SERVICE OPTIONS	125
Product Support Options	
1.1 1	

Product Service Options	125		
	126		
	126		
	127		
	127		
	128		
REVISION HISTORY	129		
Illustrations and Tables			

Figure 1-1. LECM IO Starter Package Overview	9
Figure 1-2. LECM CRS DF µP Package Overview	
Figure 1-3. LESP Package Initial Directory Structure	
Figure 1-4. Upgrading Framework Dependencies	
Figure 1-5. Model_setup.m Script	
Figure 1-6. Framework Enumerations Example	
Figure 1-7. Enumeration Example	
Figure 1-8. LESP Enumerations Dialog	
Figure 1-9. My Enumeration Definition	18
Figure 1-10. Bus Constants	
Figure 1-11. LESP Custom DataType Examples	
Figure 1-12. Simulink Bus Editor	
Figure 1-13. Open Simulink Library Browser	
Figure 1-14. [Before] Refreshing Simulink Library Browser	26
Figure 1-15. [After] Refreshing Simulink Library Browser	
Figure 2-1. Model Root Layout	
Figure 2-2. Target Definition Selection	
Figure 2-3. Target Definition Name	
Figure 2-4. LECM_IO Build Configuration Subsystem	
Figure 2-5. LECM_IO Model Configuration Subsystem	
Figure 2-6. LECM_IO System Model Subsystem	
Figure 2-7. OS Event Management Layout	
Figure 2-8. Medium Priority Medium Rate Events Example	
Figure 2-9. Input Subsystem Default Layout	
Figure 2-10. Control Subsystem	
Figure 2-11. Outputs Subsystem	37
Figure 2-12. LECM Discrete Output Mapping Example	38
Figure 2-13. LECM Analog Output Mapping Example	39
Figure 2-14. Diagnostics & Monitoring Subsystem	40
Figure 2-15. Application Subsystem	
Figure 3-1. LECM EID Interface Blocks	
Figure 3-2. EID Interface Definition	44
Figure 3-3. EID → Main Feedback/Reporting Interface Example	
Figure 3-4. EID Diagnostics & Status Interface	
Figure 3-5. EID Output Diagnostics Interface	
Figure 3-6. EID Control & Configuration Interface	
Figure 3-7. EID Cylinder PLi Interface	48
Figure 3-8. EID Cylinder Misfire Interface	48
Figure 3-9. EID Cylinder Diagnostics Interface	
Figure 3-10. EID General Signal Interface	
Figure 3-11. EID Cylinder Control Interfaces #1 - #3	
Figure 3-12. EID MP Pulse Control Interfaces #1 - #4	
Figure 3-13. EID MP Cylinder Control Interfaces #1 - #4	
Figure 3-14. EID Common Rail Signal Interface	
Figure 3-15. EID Interface Transmit/Receive Diagnostics	
Figure 3-16. EID Faults Diagnostic	53

Figure 4-1. LECM Aux Interface Blocks	
Figure 4-2. Aux Interface Definition	
Figure 4-3. Aux → Main Feedback/Reporting Interface Example	. 57
Figure 4-4. Aux Diagnostics & Status Interface	
Figure 4-5. Aux Control & Configuration Interface	
Figure 4-6. Aux Thermocouple Interfaces	
Figure 4-7. Aux Engine Sensors Interface	. 60
Figure 4-8. Aux Cylinder Knock Ratio Interfaces #1 - #3	. 60
Figure 4-9. Aux Cylinder Knock Window Control Interfaces #1 - #3	. 61
Figure 4-10. Aux Cylinder Reference Window Control Interfaces #1 - #3	. 62
Figure 4-11. Aux RTCDC Status Interface	. 62
Figure 4-12. Aux RTCDC Cycle Data Interfaces	
Figure 4-13. Aux RTCDC Average Data Interfaces	
Figure 4-14. Aux Interface Transmit/Receive Diagnostics	. 65
Figure 4-15. Aux Faults Diagnostic	
Figure 5-1. Fault States	. 67
Figure 5-2. Example Fault Condition/Action Mapping	
Figure 5-3. Fault Action Enumeration Definition	
Figure 5-4. Fault Property Defaults	. 70
Figure 5-5. Fault Property Defaults Example	. 70
Figure 5-6. J1939 SPN/FMI Definitions Block	
Figure 5-7. J1939 SPN/FMI Database	. 71
Figure 5-8. Fault Identification Code Database	. 72
Figure 5-9. LE Standard Diagnostic Management Definition Block	. 72
Figure 5-10. Fault Property Manager Launcher	. 73
Figure 5-11. Fault Property Manager	. 74
Figure 5-12. Fault Property Manager Auto-Generated Files	. 74
Figure 5-13. Fault Action Get Block	. 75
Figure 5-14. Fault Requests Get Block	. 75
Figure 5-15. Diagnostic Management Fault Manager	. 75
Figure 5-16. ToolKit Event Manager	
Figure 5-17. ToolKit Event Manager Definition File	. 76
Figure 5-18. Fault Definition Blocks	. 77
Figure 5-19. Fault Definition Example	
Figure 6-1. 3-Sensor Encoder Example	
Figure 6-2. 2-Sensor Encoder Example (N-M Crank)	. 80
Figure 6-3. 2-Sensor Encoder Example with Cam Failover Option	. 80
Figure 6-4. 2-Sensor Redundant Encoder System	. 81
Figure 6-5. LECM Main Encoder Definition	
Figure 6-6. LECM Main Encoder Inputs	
Figure 6-7. LESP-based Encoder State	. 84
Figure 6-8. LECM Main Encoder Control	
Figure 6-9. LECM Main Encoder Diagnostic Management	. 88
Figure 6-10. Encoder Error State Logic	. 89
Figure 6-11. LECM Encoder Emulation	
Figure 7-1. ToolKit Interface with MotoHawk Application	. 90
Figure 7-2. LESP ToolKit Standard Interface Definition	. 91
Figure 7-3. ToolKit WAPP Programming	
Figure 7-4. ToolKit Save Values Function	. 92
Figure 7-5. ToolKit Save Values DAB Function (Manage ToolKit Request)	. 93
Figure 7-6. ToolKit Permissives (Manage ToolKit Request Permissives)	. 93
Figure 7-7. Application Read ToolKit Service Requests (Read ToolKit Requests)	
Figure 7-8. Application Shutdown Management (Execute Requests)	
Figure 7-9. ToolKit Designer / Tool Hierarchy	
Figure 7-10. Tool Devices	
Figure 7-11. SID File Association	. 96
Figure 7-12. Example HOME Page	. 97
Figure 7-13. Standard Page Design	. 98
Figure 8-1. Sensor Processing Example	. 99

Figure 8-2. lecm_analog_in_mapping_enum	. 100
Figure 8-3. Ambient Air Pressure IO Mapping Configuration	. 100
Figure 8-4. Dynamic IO Mapping Selector	
Figure 8-5. Inputs Pressure Sensor Subsystem	. 101
Figure 8-6. Ambient Air Pressure Input Processing Strategy	. 102
Figure 8-7. Ambient Air Pressure Input Processing Implementation	
Figure 8-8. Ambient Air Pressure Input Processing Conversion	
Figure 8-9. Ambient Air Pressure Input Processing Signal Diagnostics	
Figure 8-10. Ambient Air Pressure Input Processing Filter	
Figure 8-11. Ambient Air Pressure Input Processing Defaulting	
Figure 8-12. Aux RTCDC Cylinder Cycle Data Interface	
Figure 8-13. Datalink In Slow Subsystem	
Figure 8-14. RTCDC Cycle Data Subsystem	
Figure 8-15. RTCDC Cycle Data Interfaces	
Figure 8-16. Aux Board Definition RTCDC Cycle Data Interface Enables	
Figure 8-17. LECM EID Interfaces Simulink Browser	
Figure 8-18. LECM EID Interface Bus Creators	
Figure 8-19. Fuel Control Subsystem	
Figure 8-20. EID Multi-Pulse Interfaces	
Figure 8-21. EID Board Definition Injection Data Interface Enables	
Figure 8-22. Diagnostics Medium Pressure Input Subsystem	
Figure 8-23. Ambient Air Pressure Diagnostics & Monitoring	
Figure 8-24. Ambient Air Pressure Diagnostics & Monitoring Implementation	. 112
Figure 8-25. Ambient Air Pressure Sensor Diagnostics	
Figure 8-26. Ambient Air Pressure Monitors	
Figure 8-27. LESP Context Menu (Fault Property Manager)	
Figure 8-28. Fault Property Manager	112
Figure 8-29. Fault Property Manager (Ambient Air Pressure Defaults)	
Figure 8-30. Fault Property Manager Notes	115
Figure 8-31. Fault Property Manager (Ambient Air Pressure Fault Properties)	116
Figure 8-32. Fault Property Manager (Regenerate Files)	
Figure 8-33. fault_action_enum Script	
Figure 8-34. fault_action_enum Script (MyFaultAction)	
Figure 8-35. Refresh Block Workspaces	
Figure 8-36. LECM-based Discrete Output Mapping Block	
Figure 8-37. HSO Controls Subsystem	
Figure 8-38. HSO1/HSO2 Controls Subsystem Logic	
Figure 8-39. LECM Discrete Output Mapping Interface Update	
Figure 8-40. Discrete Output Mapping Conflict Fault Detection Logic	
Figure 8-41. LECM-based Analog Output Mapping Block	
Figure 8-42. AOUT1 Control Subsystem	
Figure 8-43. AOUT1 Control Subsystem Logic	
Figure 8-44. LECM Analog Output Mapping Interface Update	
Figure 8-45. Analog Output Mapping Conflict Fault Detection Logic	
Tigure o To. 7 trialog output Mapping Commet Fault Betoetien Logic	
Table 3-1. EID Diagnostics & Status Interface Definition	46
Table 3-2. EID Output Diagnostics Interface Definition	
Table 3-3. EID Control & Configuration Interface Definition	
Table 3-4. EID Cylinder PLi Interface Definition	
Table 3-5. EID Cylinder Misfire Interface Definition	
Table 3-6. EID Cylinder Diagnostics Interface Definition	
Table 3-7. EID General Signal Interface Definition	50
Table 3-8. EID Cylinder Control Interfaces #1 - #3 Definition	50 50
Table 3-9. EID MP Pulse Control Interfaces #1 - #4 Definition	
Table 3-10. EID MP Cylinder Control Interfaces #1 - #4 Definition	
Table 3-10. EID for Cylinder Control Interfaces #1 - #4 Definition	
Table 4-1. Aux Diagnostics & Status Interface Definition	
Table 4-2. Aux Control & Configuration Interface Definition	
Table 4-3. Aux Thermocouple Interfaces Definition	
. Sale . C MA THORNOCOUPIO INCHAGOO DOMINOTHAMADA AND AND AND AND AND AND AND AND AND	

Table 4-4. Aux Engine Sensors Interface Definition	60
Table 4-5. Aux Cylinder Knock Ratio Interfaces #1 - #3 Definition	61
Table 4-6. Aux Cylinder Knock Window Control Interfaces #1 - #3 Definition	61
Table 4-7. Aux Cylinder Reference Window Control Interfaces #1 - #3 Definition	62
Table 4-8. Aux RTCDC Status Interface Definition	62
Table 4-9. Aux RTCDC Cycle Data Interface Definition	63
Table 4-10. Aux RTCDC Average Data Interface Definition	
Table 6-1. LECM Main Encoder Sources Definition	78
Table 6-2. LECM Main Encoder Pattern Support	78
Table 6-3. Global Encoder Info Bus Definition	
Table 6-4. Absolute Encoder Source Info Bus Definition	85
Table 6-5. Companion Encoder Source Info Bus Definition	
Table 6-6. Encoder Source Diagnostics Bus Definition	86
Table 6-7. EncoderSourceInfoEventsBus Definition	86
Table 6-8. EncoderSourceErrorEventsBus Definition	86
Table 6-9. EncoderSourceErrorStatesBus Definition	86
Table 6-10. LECM Main Encoder Control Inputs	87

## **Warnings and Notices**

#### **Important Definitions**



This is the safety alert symbol used to alert you to potential personal injury hazards. Obey all safety messages that follow this symbol to avoid possible injury or death.

- DANGER Indicates a hazardous situation, which if not avoided, will result in death or serious injury.
- WARNING Indicates a hazardous situation, which if not avoided, could result in death or serious injury.
- **CAUTION** Indicates a hazardous situation, which if not avoided, could result in minor or moderate injury.
- NOTICE Indicates a hazard that could result in property damage only (including damage to the control).
- **IMPORTANT** Designates an operating tip or maintenance suggestion.



Lockout/Tagout LOTO

Ensure that personnel are fully trained on LOTO procedures prior to attempting to replace or service equipment on a "live" running engine. All safety protective systems (overspeed, over temperature, overpressure, etc.) must be in proper operational condition prior to the start or operation of a running engine. Personnel should be equipped with appropriate personal protective equipment to minimize the potential for injury due to release of hot hydraulic fluids, exposure to hot surfaces and/or moving parts, or any moving parts that may be activated and are located in the area of control of the unit.



Overspeed /
Overtemperature /
Overpressure

The engine, turbine, or other type of prime mover should be equipped with an overspeed shutdown device to protect against runaway or damage to the prime mover with possible personal injury, loss of life, or property damage.

The overspeed shutdown device must be totally independent of the prime mover control system. An overtemperature or overpressure shutdown device may also be needed for safety, as appropriate.



Personal Protective Equipment The products described in this publication may present risks that could lead to personal injury, loss of life, or property damage.

Always wear the appropriate personal protective equipment (PPE) for the job at hand. Equipment that should be considered includes but is not limited to:

- Eve Protection
- Hearing Protection
- Hard Hat
- Gloves
- Safety Boots
- Respirator

Always read the proper Material Safety Data Sheet (MSDS) for any working fluid(s) and comply with recommended safety equipment.



Start-up

Be prepared to make an emergency shutdown when starting the engine, turbine, or other type of prime mover, to protect against runaway or overspeed with possible personal injury, loss of life, or property damage.

## **MARNING**

Automotive Applications On- and off-highway Mobile Applications: Unless Woodward's control functions as the supervisory control, customer should install a system totally independent of the prime mover control system that monitors for supervisory control of engine (and takes appropriate action if supervisory control is lost) to protect against loss of engine control with possible personal injury, loss of life, or property damage.



IOLOCK

IOLOCK: driving I/O into a known state condition. When a control fails to have all the conditions for normal operation, watchdog logic drives it into an IOLOCK condition where all output circuits and signals will default to their de-energized state as described below. The system MUST be applied such that IOLOCK and power OFF states will result in a SAFE condition of the controlled device.

- Microprocessor failures will send the module into an IOLOCK state.
- Discrete outputs / relay drivers will be non-active and de-energized.
- Analog and actuator outputs will be non-active and deenergized with zero voltage or zero current.

Network connections like CAN stay active during IOLOCK. This is up to the application to drive actuators controlled over network into a safe state.

The IOLOCK state is asserted under various conditions, including:

- Watchdog detected failures
- Microprocessor failure
- PowerUp and PowerDown conditions
- System reset and hardware/software initialization
- PC tool initiated

NOTE—Additional watchdog details and any exceptions to these failure states are specified in the related section of the product manual.

## NOTICE

Battery Charging Device To prevent damage to a control system that uses an alternator or battery-charging device, make sure the charging device is turned off before disconnecting the battery from the system.

## **Regulatory Compliance**

The LESP is partially completed Motohawk blocks meant to assist end users in designing their applications. As such, the LESP is a partially complete subsystem of individual parts. The device/system it is used in is only complete when the Motohawk application is integrated with reciprocating engines on or in completed "Engine Packages", "Engine Skids", "Construction, Earth Moving, Agricultural, Forestry, & Offroad Vehicles & Equipment", "Semi-Mobile Industrial" (small installations that are fixed during operation), and stationary industrial "Fixed Installations".

The LESP is a system of individually qualified devices; most do not have a function unless integrated into the fully operating package or vehicle.

Regulatory Compliance for each country that the finished device will ship into or be retrofit is the responsibility of the OEM or Aftermarket Retrofit Contractor. This includes the three essential items of marking the finished product, creating regulatory documentation, and any evaluation of the finished device/product.

The LESP has no regulatory marking requirements since it is a part of the system and performs no function on its own. The OEM or Aftermarket Retrofit Contractor are responsible for any marking required by the governing body for the location or locations of operation.

For the various parts mentioned in the following manual, please refer to the appropriate hardware manuals for regulatory compliance.

Manual #	Description
03425	LECM Product Spec
26757	Large Engine Control Module
35014	LECM Platform EID MixedMode Driver
35079	LECM Aux RTCDC
35079	RT-CDC
35100	LECM Platform EID Ignition Driver
35112	LECM Aux Thermocouple
35138	LECM Aux Platform Knock
35175	LECM Platform EID Injection Driver
35188	LECM Aux Protection IO
35200	MotoHawk Developer Guide
35203V1	LESP Packages Developer Manual
35203V2	LESP Software Features Developer Manual

# Chapter 1. Overview

#### Introduction

The following application developer's manual provides detailed instructions and an in-depth understanding of developing a MotoHawk-based application from an initial Large Engine System Platform (LESP) starter package. Woodward MotoHawk training is a pre-requisite to comprehending the material within this manual. Please refer to MotoHawk Development Guide 35200 or contact your provider for MotoHawk training. The content in this section contains a high-level description of different LESP-based starter packages and a general overview of each offering.

#### **LECM IO Starter Package**

The LECM IO package contains a basic Woodward LECM IO model, LESP-standard model architecture, and LESP framework dependencies for getting started with development on the Woodward Large Engine Control Module (LECM). As illustrated below, the basic model architecture/layout, hardware input reads, and hardware output writes are complete. The input processing (hardware  $\rightarrow$  engineering conversion), control logic, and output processing (engineering commands  $\rightarrow$  hardware conversion) containers are left blank for customer development.




Figure 1-1. LECM IO Starter Package Overview

#### The package includes:

- LESP standard OS Tasking/Events
- LESP standard diagnostics management
- LESP standard HMI communications
- LECM Analog + Discrete + Temperature inputs
- LECM Analog + Discrete + Trigger outputs
- Woodward LECM Aux/EID standard interfacing
- LECM Standard Encoder System
  - o 1-, 2-, or 3-sensor encoder system support
  - Standard pattern support (NX, SingleTooth, N-M, N+1)
  - Failover to Cam capabilities
  - Encoder emulation

#### LECM DF CRS µP Starter Package

The LECM DF CRS µP package contains the basic LECM IO package as described above; however, in addition, it includes pre-built software features (see 35203V2 for individual feature details). This package

provides a more comprehensive engine package that allows customer development to focus on customizations and other rapid prototyping development rather than basic engine controls and features.

- LECM IO Package Contents
- · Standard DF Sensors with Input Processing
- Engine State Management
- Speed Controller
- Common Rail Pressure Control + WLO FMV Controller
- LECM Aux Platform Acoustic Mitigation




Figure 1-2. LECM CRS DF µP Package Overview

#### **Application Development Environment**

Before getting started, it's important to ensure the application development environment and all dependencies are properly installed and licensed.

- MathWorks MATLAB/Simulink
  - o See individual package release notes for version requirements
- MathWorks StateFlow Toolbox
- MathWorks Simulink Coder Toolbox
- MathWorks Embedded Coder Toolbox
- Woodward MotoHawk
  - See individual package release notes for version requirements
- Woodward Application Support Blocks (ASB) License
  - Contact provider for licensing. Licensing authorization can be accessed at <a href="https://www.woodward.com">https://www.woodward.com</a>
- Woodward ToolKit with Developer License
  - Contact provider for licensing. Licensing authorization can be accessed at https://www.woodward.com



MATLAB/Simulink and Woodward MotoHawk training is a prerequisite to understanding the subsequent material of this manual. Please ensure a fundamental understanding of the MATLAB/Simulink ADE and application development with Woodward MotoHawk has been taken into consideration before proceeding. Contact your provider for more information on MotoHawk training.

#### **Licensing Checklist**

Refer to the package release notes for Matlab/Simulink version requirements and ensure all
required toolboxes are licensed and installed as indicated above.
Refer to package release notes for MotoHawk version requirements. Use Windows Start Menu $ ightarrow$
MotoTools → License Viewer to verify MotoHawk licensing. See Manual 35200 for more details
on MotoHawk licensing.
Open Matlab and the package model. Execute ">> asb_license_manager" in the Matlab
command line or navigate to the Model/Build Configuration/ASB License block and enter the ASB
License key for each respective licensed PC node.
Open ToolKit and navigate to the Tools Ribbon → License Authorization button and enter the

#### **Understanding Project Directory Structure**

First, it is important to understand the initial project directory layout. An LESP package is distributed in two archive files:

- <packagename>\_framework\_<version>.zip
  - Example: LECM\_IO\_framework\_1\_1\_1\_1.zip

ToolKit License key for each respective licensed PC node.

- <packagename>\_package\_<version>.zip
  - Example: LECM\_IO\_package\_1\_1\_1.zip

The version number is of the form Major\_Minor\_Build. The **framework** archive is used for <u>upgrading</u> the LESP framework libraries and dependencies within a local project and is only required if performing an upgrade. The **package** archive contains ALL of the files necessary to get started, including the framework files, the initial model, and local model supporting files. If getting started with a new project, extract the **package** archive; otherwise, if upgrading an existing project, use the **framework** archive. Once the package is extracted to a desired directory, the output should contain the following structure:

Name	Date modified	Туре	Size
Framework	3/21/2022 3:05 PM	File folder	
Libraries	2/24/2022 2:58 PM	File folder	
	3/21/2022 3:05 PM	File folder	
☐ Tools	3/21/2022 3:05 PM	File folder	
LECM_IO.slx	3/14/2022 1:07 PM	Simulink Model	284 KB
LECM_IO_setup.m	3/1/2022 6:51 PM	MATLAB Code	1 KB

Figure 1-3. LESP Package Initial Directory Structure

#### • [Folder – ReadOnly] Framework

 The Framework folder contains all of the LESP framework libraries and supporting scripts. This folder contents should be considered readonly and NEVER modified unless upgraded with newer versions of the <packagename>\_framework\_<version> archive.
 Modifications to contents within this folder will be overridden when upgrading; therefore, if

there is a need to make a change, careful tracking of changes is required OR customizations should be moved to local supporting files instead.

#### • [Folder – ReadWrite] Libraries

 The **Libraries** folder is used to host any local project-specific Simulink libraries outside the scope of the LESP framework. This directory will only be updated at the user's discretion and not during upgrades.

#### • [Folder - ReadWrite] Scripts

 The **Scripts** folder is used to host any local project-specific MATLAB scripts or supporting files outside the scope of the LESP framework. This directory will only be updated at the user's discretion and not during upgrades.

#### • [Folder – ReadWrite] Tools

 The **Tools** folder is used to host any local project-specific HMI or tool files outside the scope of the LESP framework. This directory will only be updated at the user's discretion and not during upgrades.

#### • [File - ReadWrite] < ModelName > .slx

 The <ModelName>.slx file contains the initial starting point for the MotoHawk application model. This file should be renamed to a desired application name.

#### • [File – ReadWrite] < ModelName > \_setup.m

The <ModelName>\_setup.m file is executed from the <ModelName>.slx preload model callback function and is used to configure the environment by adding MATLAB search paths and initializing the workspace when the model is first loaded. The filename should match the <ModelName>\_setup.m format. This file can be modified to further expand on initialization steps required during model development.



Before making any project-specific changes, it is highly recommended to confirm the initial package opens, updates, and builds successfully:

- 1. Open model
- 2. Confirm model updates successfully (Ctrl+D)
- 3. Confirm model builds successfully (Ctrl+B) or provided use local\_build script

It's noteworthy to mention that the format of a project directory is often based on developer preferences and styles. There is no limitation to using a different directory format if desired; however, it's recommended to use the structure suggested in this document in order to follow further outlined instructions. The key instruction to follow is to not modify the LESP **Framework** folder in order to support upgrades in the future.

### **Upgrading Project Framework Dependencies**

As previously mentioned, within a project directory, a folder named **Framework** contains all LESP-related package dependencies, including Simulink libraries, Matlab scripts, enumerations, etc. As part of a package distribution, the framework dependencies are archived independently in a 

cpackagename>\_framework\_

cversion> archive file. To update a local project's framework dependencies, delete the existing **Framework** folder within the project's directory, and extract the newer 
cpackagename>\_framework\_ archive file contents to a new local **Framework** project folder.



Note: Be sure the default framework folder is named Framework so it will be added to the Matlab search path using the default Model setup.m script.




Figure 1-4. Upgrading Framework Dependencies

- What if one of the framework files contains a software issue?
  - If there is an issue related to a framework dependency file, a patched or modified file with the same name that is higher on the Matlab path (e.g., local project directory ./Scripts or ./Libraries path) can be used to override (shadow) the framework file until the framework can be upgraded.

#### Closer Look: Model\_setup.m

Upon opening the model, the model postload callback function will execute any script with matching <ModelName>\_setup.m that is on the Matlab path.




Figure 1-5. Model setup.m Script

By default, this script should be located alongside the model and is used to configure the application development environment and load any project-specific content. The script performs three important actions. First, it adds search paths of the local Framework, Libraries, and Scripts folders. Second, it populates the workspace with four project-specific parameters: OSConfig, HardwareConfig, SpeedConfig, and EncoderConfig structures. These structs are used to control global parameter settings as well as Simulink variant selections.

- OSConfig
  - o Defines the OS fast, medium, and slow task rates.
- HardwareConfig
  - Defines the hardware target that is used to drive specific LESP blockset variants. This is currently extracted directly from the selection set in the MotoHawk Target Definition block using the lesp\_get\_hardware\_target script.
- SpeedConfig
  - This struct is used to define the current LECM system variant for which frequency/duty cycle speed definitions should be defined. For example, even though the target may be an LECM 3-Stack, the encoder may consume the Main and EID speed resources; therefore, only the Aux speed resource variant is selected.
- EncoderConfig
  - This struct is used to define the encoder system stroke (2 or 4) and the selected LECM encoder variant (if applicable).
- BuildConfig

 This struct is used to drive the build versioning with a Major/Minor/Build number versioning scheme. This struct must be manually created by the user.

Lastly, all framework workspace variables are loaded to the Matlab workspace with the lesp\_load\_all\_lib\_data function. Any additional search paths to be added, data to be loaded to the base workspace, or any other environment initialization actions should be added to this script.

```
localdir = fileparts(mfilename('fullpath'));
%% Add Paths
addpath(genpath(fullfile(localdir, 'Libraries')));
addpath(genpath(fullfile(localdir, 'Scripts')));
addpath(genpath(fullfile(localdir, 'Framework')));
%% Create Configurations
OSConfig = struct('FastRateSec', 0.005, ...
    'MediumRateSec', 0.010, ...
    'SlowRateSec', 0.050);
if ~exist('HardwareConfig', 'var')
    HardwareConfig = struct('Target', lesp_get_hardware_target);
if ~exist('SpeedConfig', 'var')
    SpeedConfig = struct('System', LecmSpeedInDefn.AUX);
end
if ~exist('EncoderConfig', 'var')
    EncoderConfig = struct('Stroke', uint8(4), ...
        'System', LecmFlexEncoderSystemsDefn.LECM_MAINEID_2STACK);
end
if ~exist('BuildConfig', 'var')
    BuildConfig = struct('Major', 0, ...
        'Minor', 0, ...
        'Build', 0);
end
%% Load Library Data
lesp_load_all_lib_data;
clear localdir;
```

#### **Enumerations**

The LE system platform implements enumeration definitions in scripts (functions). Each script can be called with the string value of the enumeration and returns the corresponding numeric value or vice versa. This enables enumerations to be referenced directly in the model without hardcoded numeric values.



Figure 1-6. Framework Enumerations Example

The below example illustrates the lesp\_engine\_state\_enum script. When no arguments are supplied, the enumeration as originally defined is returned. If a string or cell array of strings is input, the numeric value(s) are returned respectively. If the numeric value is input, the string(s) are returned respectively.

```
Command Window
  >> lesp_engine_state_enum
  ans =
    1×8 <u>cell</u> array
      {'Stopped'}
                     {'Prestart'}
                                    {'Starting'}
                                                      {'Warmup'}
                                                                    {'Running'}
                                                                                   {'Cooldown'}
                                                                                                    {'Stopping'}
                                                                                                                     {'Postrun'}
  >> lesp_engine_state_enum('Running')
  >> lesp_engine_state_enum(2)
      'Starting'
  >> lesp_engine_state_enum({'Warmup', 'Running', 'Cooldown'})
  >> lesp engine state enum([0 1 2])
    1×3 <u>cell</u> array
      {'Stopped'}
                     {'Prestart'}
                                    {'Starting'}
fx >>
```

Figure 1-7. Enumeration Example

To review all available enumerations, LESP supports an "Enumeration" context menu, which will open a dialog that searches for all scripts currently on the Matlab path that end with \_enum.m[p] and return an expected enumeration. This tool can be used to review and search available enumerations.




Figure 1-8. LESP Enumerations Dialog

#### **Defining An Enumeration**

To define your own custom enumeration that utilizes the same structure, define a function using a name for the enumeration. Define your enumeration using either a cell string array for zero-based numeric values, a struct with name and value fields for explicit name-value pairs, or by utilizing a motohawk\_enum object.




Figure 1-9. My Enumeration Definition

Subsequently, in the model, you can use ASB Enum Constant, Enum Comparison blocks, and other standard Simulink blocks to access the enumeration values by name, allowing for the enumeration to be modified in a single location if needed in addition to easier model source code to interpret.

#### **LESP Custom DataTypes**

As part of the LE system platform, a number of custom datatypes are defined and used within the model. These compound types are used as interface definitions for standard LESP blocks and are defined as busses that are loaded in the Matlab workspace during the model setup ( $lesp\_load\_all\_lib\_data$ ). Note: Struct datatypes that end in Bus (e.g., AlwaysActiveDiscreteInBus, AlwaysInactiveDiscreteInBus, DefaultDiscreteInBus, DefaultAnalogSensorBus, etc...) are bus constants that match the corresponding bus type's structure and can be used with a Simulink Constant block to output a nonvirtual constant valued bus.

#### Examples:

```
DefaultDiscreteInBus = struct('DiscreteState', false, ...
    'Frequency_Hz', single(0), ...
    'DutyCycle_Pct', single(0));
AlwaysActiveDiscreteInBus = struct('DiscreteState', true, ...
    'Frequency_Hz', single(0), ...
    'DutyCycle_Pct', single(0));
AlwaysInactiveDiscreteInBus = struct('DiscreteState', false, ...
    'Frequency_Hz', single(0), ...
    'DutyCycle_Pct', single(0));
DefaultAnalogSensorBus = struct('FilteredValue', single(0), ...
     'MeasurementStatus enum', uint8(lesp measurement status enum('Disabled')));
                                        <DiscreteState>
       AlwaysActiveDiscreteInBus
                                        <Frequency_Hz>
                                                                0
                                         DutyCycle Pct
                                        <FilteredValue>
        DefaultAnalogSensorBus
                                        <MeasurementStatus_enum>
```

Figure 1-10. Bus Constants




Figure 1-11. LESP Custom DataType Examples

Below are a few commonly used bus structures:

#### **AnalogInBus**

The AnalogInBus is used for all AIN input signals with the following bus structure:

AnalogInBus

- Mode enum (uint8)
  - The input mode of the AIN input (e.g., 4-20 mA input, 0-5V input, +- 2.5V input, etc.
  - See lesp\_analog\_in\_mode\_enum script for supported modes and enumeration definition
- Value (single)
  - The hardware units value of the input (V, mA, ...)
- ADC (uint16)
  - The hardware ADC counts of the input
- ADCToHwUnitsGain (single)
  - The gain used to convert from ADC to hardware units (V, mA, ...)
- ADCToHWUnitsOffset (single)
  - The offset used to convert from ADC to hardware units (V, mA)
- PullupResistorValue\_ohms (single)
  - The value of the pullup resistor of the input if applicable

#### **AnalogOutBus**

The AnalogOutBus is used to command supported AOUTs on the module with the following bus structure:

- AnalogOutBus
  - IOSelect enum (uint8)
    - Dynamic IO mapping support. Enumeration is hardware-dependent.
    - See lecm analog out io select enum enumeration for LECM hardware.
  - State\_enum (uint8)
    - Value of Not Used, Inactive, or Active. See lesp\_analog\_out\_state\_enum.
  - CurrentDemand uA (uint16)
    - The current demand for the analog output in uA.

#### **AnalogSensorBus**

The AnalogSensorBus is used for analog sensors in the input processing logic to report the following compound signal value for each applicable sensor:

- AnalogSensorBus
  - FilteredValue (single)
    - The final engineering value of the analog sensor (e.g., Ambient Air Pressure sensor filtered value in units of kPa).
  - MeasurementStatus enum (uint8)
    - An enumerated value indicating the status of the FilteredValue signal. See lesp\_measurement\_status\_enum.

#### **DateTimeBus**

The DateTime is used as a compound signal to report the current DateTime (e.g., from real-time clock logic, fault timestamps, etc.):

- DateTimeBus
  - Year (uint16)
  - Month (uint8)
  - o Day (uint8)
  - O Hour (uint8)
  - Minute (uint8)

- Second (uint8)
- Microsecond (uint32)

#### **DiscreteAnalogInBus**

The DiscreteAnalogInBus is used to combine AnalogInBus and DiscreteInBus input signals to allow for analog and discrete input bus types to be used for discrete logic with following bus structure:

- DiscreteAnalogInBus
  - Type\_enum (uint8)
    - None, Discrete, or Analog. Used to indicate the type of hardware input this signal represents.
  - AnalogADC (uint16)
    - The analog input ADC count if the type is an Analog.
  - DiscreteState (boolean)
    - 0 = Inactive, 1 = Active if the type is Discrete

#### **DiscreteInBus**

The DiscreteInBus is used for all DIN input signals with the following bus structure:

- DiscreteInBus
  - DiscreteState (boolean)
    - 0 = Inactive, 1 = Active. This is used for state-based discrete inputs.
  - Frequency\_Hz (single)
    - The frequency in Hz of the discrete input. This is used for frequency/duty-cycle based discrete inputs.
  - DutyCycle\_Pct (single)
    - The duty cycle of the discrete input in units of percent. This is used for frequency/duty-cycle based discrete inputs.

#### **DiscreteOutputBus**

The DiscreteOutputBus is used for all digital output-based command signals with the following bus structure:

- DiscreteOutputBus
  - IOSelect enum (uint8)
    - Dynamic IO mapping support. Enumeration is hardware-dependent.
    - See lecm discrete out io select enum enumeration for LECM hardware
  - BehaviorSelect enum (uint8)
    - Defines the behavior of the output as either Discrete or Pulse-Width-Modulated (PWM). See lesp\_discrete\_out\_behavior\_select\_enum enumeration.
  - State enum (uint8)
    - Value of Not Used, Inactive, or Active. See lesp discrete out state enum.
  - DutyCycle Pct (single)
    - Duty cycle command of the output if configured with PWM behavior.
  - Frequency Hz (single)
    - Frequency command of the output if configured with PWM behavior.

#### **FaultBus**

The FaultBus is used for LESP standard diagnostic management fault interfacing with the following bus structure:

- FaultBus
  - AssertionStatus (boolean)
    - True signal to indicate if the respective fault should be assert if not already asserted.
  - ConditionalStatus (boolean)
    - True signal to indicate the conditions for the fault to assert are true, independent of the actual fault state.
  - InhibitStatus (boolean)
    - True signal to indicate if conditions for the fault to be inhibited are valid.

#### **LEDControlBus**

The LEDControlBus is used controlling an LED with a standard LESP LED controller block with the following bus structure:

- LEDControlBus
  - Color\_enum (uint8)
    - Indicates the desired color of the LED. See lesp\_led\_color\_enum enumeration.
  - State enum (uint8)
    - Defines the desired control state of the LED. See lesp\_led\_state\_enum enumeration.
  - BlinkCode (uint8)
    - Indicates the desired blink code of the LED if the state is equal to "Code."

#### **LEDOutputBus**

The LEDOutputBus is used controlling the state of an LED:

- LEDOutputBus
  - RedLEDState (boolean)
    - True if the Red color of the LED should be active.
  - GreenLEDState (boolean)
    - True if the Green color of the LED should be active.

#### **TcRtdInBus**

The TcRtdInBus is used for all Thermocouple/RTD input signals with the following bus structure:

- TcRtdInBus
  - Mode\_enum (uint8)
    - The input mode of the TcRtd input (e.g., 0-5V input, Thermocouple input, RTD input, Datalink degC, etc.
    - See lesp\_tcrtd\_in\_mode\_enum script for supported modes and enumeration definition.
  - Status (uint8)
    - The status of the input as either Not Available, Error, Open, or Valid. See lesp\_tcrtd\_in\_status\_enum.
  - PullupResistorValue\_ohms (single)
    - The value of the pullup resistor of the input if applicable.

- o Value (single)
  - The hardware units value of the input (degC).

#### **TimeSpanBus**

The TimeSpanBus is used as a compound signal to report the Timestamps (e.g., engine hour meter):

- TimeSpanBus
  - o Days (int32)
  - o Hours (int8)
  - Minutes (int8)
  - Seconds (int8)
  - o Microseconds (int32)

#### Transducer5VoltBus

The Transducer5VoltBus is used for the transducer 5V power supply of the module:

- Transducer5VoltBus
  - FilteredValue\_V (single)
    - The filtered transducer power supply voltage.
  - MeasurementStatus\_enum (uint8)
    - An enumerated value indicating the status of the FilteredValue signal. See lesp measurement status enum.
  - RatiometricCorrectionFactor (single)
    - A gain multiplier indicating the transducer voltage relative to the nominal expected voltage. This value can be used as a multiplier for ratiometric sensor types.
    - This multiplier is calculated based on the formula:

$$RatiometricFactor = \left\{ \frac{Nominal\ Voltage}{Actual\ Voltage} \right\}_{0.95}^{1.05}$$

#### TransducerHighVoltBus

The TransducerHighVoltBus is used for the transducer HV power supply of the module:

- TransducerHighVoltBus
  - FilteredValue V (single)
    - The filtered transducer power supply voltage
  - MeasurementStatus\_enum (uint8)
    - An enumerated value indicating the status of the FilteredValue signal. See lesp measurement status enum.
  - RatiometricCorrectionFactor (single)
    - A gain multiplier indicating the transducer voltage relative to the nominal expected voltage. This value can be used as a multiplier for ratiometric sensor types.
    - This multiplier is calculated based on the formula:

$$RatiometricFactor = \left\{ \frac{Nominal\ Voltage}{Actual\ Voltage} \right\}_{0.95}^{1.05}$$

- VoltageSelect enum (uint8)
  - Indicates the current voltage selection of the transducer power supply, see
     lesp\_hv\_transducer\_select\_enum.

There are numerous other LECM platform EID/Aux bus definitions that describe the interfaces to EID/Aux platform application communications as described in more detail in subsequent chapters. To view the details of each bus definition, execute ">> buseditor" in the Matlab command line. New custom compound datatypes can be defined; however, do not modify the LESP-defined types as these will be restored when reloading the framework data. If defining custom bus types, be sure to save them to a file and reload by adding to the Model\_setup.m script.




Figure 1-12. Simulink Bus Editor

#### **LESP User Blocks**

Before continuing, it's important to ensure the Simulink Library Browser has been refreshed and is actively showing all Woodward ASB and LESP libraries. This is accomplished by opening the Simulink Browser. If the LESP and ASB libraries are not all visible, hit the "F5" key to refresh the browser view, then select "Fix" and "Generate repositories in memory" option. This should expose all LESP and ASB libraries in the browser.



Figure 1-13. Open Simulink Library Browser




Figure 1-14. [Before] Refreshing Simulink Library Browser




Figure 1-15. [After] Refreshing Simulink Library Browser

## Chapter 2. Model Architecture

#### Introduction

The following chapter provides a deeper understanding of an LESP-based standard application model layout for engine control software development. The sections will work *downward* through the model hierarchy, starting at the model root.

#### **Model Root**

The following illustration below shows a simple package example which includes the standard directory structure with the Libraries (1) subfolder used to hold any non-framework dependency libraries or project-specific libraries. The Scripts (2) subfolder contains local project-specific scripts. The Matlab workspace (3) contains the global definitions of Simulink Busses, Structs, System Variants, and other model accessible definitions. Most of these definitions are loaded by default during the model initialization phase as previously discussed. The root level of the model contains four subsystems:

#### Target Definition

o The target definition subsystem is a container for the MotoHawk target definition.

#### Build Configuration

 The build configuration subsystem contains blocks related to generic configuration of the model. Including the MotoHawk Toolchain Definition (compiler selection), Version Requirements block, ASB License, etc. These blocks do not need to be located within an execution context.

#### Model Configuration

The model configuration subsystem contains definition-level blocks of features and blocksets used within the model. These blocks do not need to be located within an execution context as they simply define high level features, software stacks, and hardware configurations. These include blocks such as CAN Definitions, Protocol Definitions, Diagnostic & Management Definitions, etc.

#### System Model

The system model subsystem contains the core execution logic of the model. The contents of this subsystem have a standard Simulink dataflow layout (Inputs → Control → Outputs).




Figure 2-1. Model Root Layout

#### **Target Definition**

The target definition subsystem contains the MotoHawk Target Definition block. This is used to control the MotoHawk control module target selection (e.g., LECM Main 3-Stack Variant = LECM-5556-210-065-141x) as well as define the output file names.




Figure 2-2. Target Definition Selection




Figure 2-3. Target Definition Name

In the default get\_model\_name script, the output file naming convention takes on the form <ModelName>\_<LECMStackVariant>\_<EncoderStroke>\_<Version>. The <ModelName> token is set to the filename of the model. The <LECMStackVariant> token uses a friendly LECM variant name of 3Stack, 2Stack, or Standalone based on the current hardware configuration. The <EncoderStroke> token is represented as 2S or 4S respectively. Finally, the version string uses an x\_x\_x format for Major\_Minor\_Build based on the values set by the BuildConfig workspace variable. This script is local to the project and can be modified to use any naming or versioning scheme desired by the developer.

#### **Build Configuration**

The Build Configuration subsystem contains blocks related to the model/build and other non-execution related blocks including the following:

- ToolChain Definition
  - o This block defines the compiler used to compile the generated C-code for the target.
- Bootloader Security Control
  - This block is used to disable bootloader security if desired, allowing bootstrapping without security privileges.
- Matlab/MotoHawk Version Requirements
  - o This block is used to verify the specified Matlab/MotoHawk version constraints are met.
- Model Color Palette
  - This block can be used to auto-theme blocks in the model (disabled by default).
- ASB License
  - This block must be defined in the model to validate the ASB license. Open the mask of this block to update your ASB license.




Figure 2-4. LECM IO Build Configuration Subsystem

#### **Model Configuration**

The Model Configuration subsystem defines the core model definition blocks of the OS, hardware, and features. These blocks do not execute within a triggered context. For example, in the LECM\_IO package, the following are standard model definitions:

- Standard OS Definition (Tasks, Stacks, Heap, Slip detection definitions)
- Standard NonVolatile Memory + Fixed NonVolatile Memory Definitions
- Standard LECM variant-based CAN Definitions
- Standard LECM Ethernet Definition
- Standard XCP/ERI/ToolKit HMI Communication Definitions + Features
- Standard LECM Main Encoder System + Main Speed Digital Filter + Trigger Emulation Definitions
- Standard LESP Diagnostics Management
- Standard LESP Thermocouple/RTD (TcRtd) Conversion Table Definitions
- Standard SAEJ1939 Protocol Definition
- Standard LESP-based Woodward Platform EID and Aux Application Interface Definitions
  - LECM EID Injection, MixedMode, Ignition
  - LECM Aux Thermocouple, Acoustic Knock, RTCDC, Protection IO

See subsequent chapters for more information on each of the above definitions in their respective chapters.



Each of the standard LESP-based features/definitions expose a set of default configurations at the mask level that can be adjusted on a per-application basis; however, all blocks are considered "starting points" for the respective feature. If structural changes are required, a local version of the block should be created with the desired custom modifications made using the original block as the "starting point."




Figure 2-5. LECM\_IO Model Configuration Subsystem

#### **System Model**

The System Model subsystem contains the core executable logic of the model following a Simulink classic dataflow layout of Inputs  $\rightarrow$  Control  $\rightarrow$  Outputs. In addition, there are the OS Event Management, Diagnostics & Monitoring, and Application containers used to manage other aspects of the model. Inputs can be viewed as "reading" data to be used in downstream Control/Output subsystems. Thus, an optional Feedback subsystem exists for any control-related parameters that also need to be referenced within an "input-related" function. In general, the amount of information to feedback is often non-existent or limited (e.g., fuel demand may be fed back in order to calculate load used in other input calculations). If using Feedback signals, be sure to use 1/z unit delay blocks.

#### OS Event Management

 $\circ\quad$  Manager OS event triggers and their order of execution

#### Inputs

Includes containers for hardware reads, IO mappings, input characterizations, functions, calculations, and other application global data.

#### Control

 Includes containers for control features (e.g., speed control, pump control, module control, etc.)

#### Outputs

Includes containers output characterization, hardware writes, and datalink

#### Diagnostics & Monitoring

Includes containers for managing diagnostic and monitor-related functions

#### Application

 Includes containers for managing global application data and other necessary feature management (e.g., statistics, app performance monitoring, app shutdown management, etc.)




Figure 2-6. LECM\_IO System Model Subsystem

#### **OS Event Management**

The OS Event Management subsystem contains the OS "events" used to drive application executable logic in a user-prescribed order. This logic can be viewed as two sequential sections. The left section (outlined in red) contains the LESP standard OS Event events for a single core three-tiered tasking structure of "High Priority Fast Rate," "Medium Priority Medium Rate," and "Low Priority Slow Rate" in addition to the standard application Startup, Shutdown, and Idle events. These provide the basic application OS events as follows:

- High Priority Fast Rate
  - Executes downstream triggered logic in the High application task at the fastest rate defined by the OSConfig.FastRateSec.
- Medium Priority Medium Rate
  - Executes downstream triggered logic in the Medium application task at the medium rate defined by the OSConfig.MediumRateSec.
- Low Priority Slow Rate
  - Executes downstream triggered logic in the Low application task at the slow rate defined by the OSConfig.SlowRateSec.
- Idle Event
  - o Executes when the application idle event is entered
- Startup Event
  - Executes once upon application startup
- Shutdown Event
  - o Executes just prior to the application shutting down

The subsequent logical section (outlined in blue) takes the standard OS event triggers and splits them into multiple application-referenced triggers in a user-defined order of execution using Simulink function-call split blocks. This structure provides a single location of OS event triggers and order of execution control. It is possible to extended OS events or modify the structure by using MotoHawk Trigger blocks directly instead of the standard events depending on the application needs; however, the structure is designed to be flexible.




Figure 2-7. OS Event Management Layout




Figure 2-8. Medium Priority Medium Rate Events Example

In the above example, the Medium task/Medium rate OS event is split into multiple events that execute in a left to right order (*HardwareInputsMedium* triggered subsystem executes, then *FunctionsMedium* subsystem executes, etc.).

#### Inputs

The Inputs subsystem is structured by default with the following layout:

#### 1. Read Hardware

a. This subsystem contains triggered subsystems used to hardwired inputs of the module (e.g., Analog Inputs, Discrete Inputs, etc.)

#### 2. Application

a. This subsystem is used to read global application-level data (e.g., fault event requests, ToolKit HMI requests, Engine global parameters, etc.)

#### 3. IO Mapping

a. This subsystem is used to support dynamic mapping of hardware inputs to sensors (e.g., AIN1 maps to Ambient Air Pressure sensor). If static mapping is used, this subsystem can be removed and reduce processing overhead.

#### 4. Input Processing

a. This subsystem is used to convert hardware units to sensor engineering units (e.g., Ambient Air Pressure = AIN1 [V] \* Gain [kPa/V] + Offset [kPa] + Filtering + Defaulting, Sensor Diagnostic Range Checks, etc.). This system is also used for Datalink input conversion.

#### 5. Functions

a. This subsystem is used for functions, calculations, and other "virtual" sensing types of inputs (e.g., Engine State, Fault Actions, Fuel Density calculation, etc.)




Figure 2-9. Input Subsystem Default Layout

All the inputs are placed onto grouped virtual bus structures and then bussed together for global access in an "Inputs" bus that is referenced in downstream subsystems.

### Control

The control subsystem contains the three different contexts for control-related logic: Fast, Medium, and Slow. Each subsystem is triggered from the OS Events as previously described. High priority and fast executing controllers/control logic should be located in the Control (Fast) function-call subsystem, whereas lower priority controllers/control logic should be located in the Medium or Slow triggered subsystems respectively. For example, engine speed and fueling controls may be located in the high priority fast execution context; whereas engine start logic may be located in a lower priority/slower subsystem in order to reduce processing utilization.




Figure 2-10. Control Subsystem

# **Outputs Subsystem**

The outputs subsystem is used to convert control requests to hardwired commands (e.g., activating an LSO output) and to send/update datalink messages. Each of these core functions is implemented in the standard Fast, Medium, and Slow execution contexts. By default, the applications come structured with a dynamic output mapping structure. If dynamic mapping is not required, this logic can be removed, and static mapping can be used to reduce processing overhead.




Figure 2-11. Outputs Subsystem

# **Dynamic Discrete Output Mapping**

The dynamic discrete output mappings platform blocks accept an array of "DiscreteOutputBus" types and properly map the commands to the respective hardware output. Example: LECM-based discrete output mapping:




Figure 2-12. LECM Discrete Output Mapping Example

# **Dynamic Analog Output Mapping**

The dynamic analog output mappings platform blocks accept an array of "AnalogOutputBus" types and properly map the commands to the respective hardware output. Example: LECM-based analog output mapping:




Figure 2-13. LECM Analog Output Mapping Example

# **Diagnostics & Monitoring Subsystem**

The diagnostics and monitoring (D&M) subsystem is used to manage diagnostics and monitors as well as the general D&M activities. LESP standard D&M structure is outlined in a subsequent chapter. Each D&M function should be located is an appropriate execution context.




Figure 2-14. Diagnostics & Monitoring Subsystem

# **Application Subsystem**

The application subsystem is used to manage application and background tasks. This may include logic to execute on application startup and shutdown events, in addition to background tasks such as shutdown management, real-time clock management, statistics, etc.




Figure 2-15. Application Subsystem

# Chapter 3. EID Interfacing

#### Introduction

The following chapter describes interfacing with Woodward standard platform EID applications using the prebuilt LESP framework interface blocks. Before getting started, it's important to understand the Woodward standard EID applications variants.

#### **EID MixedMode**

The MixedMode software is designed as an LECM Eid Ignition + Injection driver application with up to 20-cylinder support. The application contains three control options: local, shared memory region control interfaces, and external communication interfaces (J1939). The local control enables the application to act as a standalone board where configuration and controls are local to the board (usually for test purposes). The shared memory region controls options expose multiple control interfaces using ASB shared memory regions that allow for a plug and play (PnP) control blocks in supporting libraries that can be quickly added to LECM main board applications. The external communication interfaces support standard external communications (e.g., J1939, ...) for EID standalone and 3rd party controls. The software architecture is a componentization design with "Plug-N-Play" subsystems to support multiple variations of the application with the control logic being developed in core re-usable components. The scope of this application and the overall high-level architecture is designed to operate the following LE engine contexts:

- Ignition Only (up to 20 cylinders)
- Injection Only (up to 20 cylinders)
- Ignition + Injection (up to 20 cylinders distributed between output types, e.g., 10+10, 8+12, 9+9, ...)
- Injection TypeA + Injection TypeB (up to 20 cylinders of two different injection types distributed between the output types, e.g., 10 SOGAV + 10 Micropilot injectors)
- Injection TypeA + Injection TypeB + Ignition (up to 6 cylinders of two different injection types and ignition in a single EID board)

## **EID** Ignition

The Ignition software is designed as an LECM Eid Ignition only driver application with up to 20-cylinder support. The application contains three control options: local, shared memory region control interfaces, and external communication interfaces (J1939 Standard + IC920 Proprietary). The local control enables the application to act as a standalone board where configuration and controls are local to the board (usually for test purposes). The shared memory region control options expose several control interfaces using ASB shared memory regions that allow for a plug and play (PnP) control blocks in supporting libraries that can be quickly added to LECM main board applications. The external communication interfaces support standard external communications (J1939, IC92x, ...) for EID standalone and 3rd party controls. The software architecture is a componentization design with "Plug-N-Play" subsystems to support multiple variations of the application with the control logic being developed in core re-usable components. The scope of this application and the overall high-level architecture is designed to operate the following LE engine contexts:

- Ignition Only (up to 20 cylinders)
- IC92x Replacement (up to 20 cylinders)

## **EID Injection**

The EidInjection software is designed as an LECM Eid Common Rail + Dual Fuel Injection driver application with up to 20 cylinder / 5 event support. The application contains two control options: local and

shared memory region control interfaces. The local control enables the application to act as a standalone board where configuration and controls are local to the board (usually for test purposes). The shared memory region controls options expose multiple control interfaces using ASB shared memory regions that allow for a plug and play (PnP) control blocks in supporting libraries that can be quickly added to LECM main board applications. The software architecture is a componentization design with "Plug-N-Play" subsystems to support multiple variations of the application with the control logic being developed in core re-usable components. The scope of this application and the overall high-level architecture is designed to operate the following LE engine contexts:

- Common Rail Injection, 1-5 events/cylinder/cycle (up to 20 cylinders)
- Dual Fuel Injection, 1-5 events/cylinder/cycle (up to 20 cylinders)

#### **LESP EID Interface Blocks**

The EID Interface blocks can be located in the Simulink Library Browser under the LESP folder.




Figure 3-1. LECM EID Interface Blocks



For more details on EID interfaces and descriptions, please refer to the respective application manuals:

MixedMode: B35014 Ignition: B35100 Injection: B35175

#### Definition

As previously described in Chapter 2, under the Model Configuration subsystem, EID interface definitions should be defined. If interfacing with more than one EID, enter a new definition with a unique EID number instance. Note, the definition is a variant subsystem to support compilation on a Main Standalone vs a Main Stacked unit.




Figure 3-2. EID Interface Definition

The block variant is controlled by the IsLECMStandaloneVariant workspace parameter, which is defined as follows:

IsLECMStandaloneVariant = strcmp(HardwareConfig.Target, 'LECM-5566-210-065-142x')

## **General EID Interfaces**

The following section describes common EID interface blocks supported for all EID application variants. All EID  $\rightarrow$  Main feedback/reporting interfaces have a two-layer bus interface as follows:

- Interface (bus)
  - o EIDRxInterfaceStatusBus
    - IsEnabled (bool)
    - Timeout\_ms (uint32)
    - RegionAge\_ms (uint32)
    - ConfigurationFault (bool)

- TimeoutFault (bool)
- DatalinkSelect\_enum (uin8)
- \*DataBus
  - Data is interface dependent

All Main → EID command interfaces report the following status bus that can be used to drive diagnostics if the interface fails to transmit:

- Interface (bus)
  - EIDTxInterfaceStatusBus
    - IsConnected (bool)
    - TxError (bool)
    - LoopTime ms (uint32)
    - SourceAddress (uint8)




Figure 3-3. EID Main Feedback/Reporting Interface Example

## **Diagnostics & Status Interface**

The diagnostics and status interface reports general EID diagnostic and status information to the main board. It's the responsibility of the application developer to integrate this information into the application as deemed appropriate (see diagnostics example in subsequent section below).




Figure 3-4. EID Diagnostics & Status Interface

The data definition for this interface includes the following:

Table 3-1. EID Diagnostics & Status Interface Definition

Parameter	DataType	Description
ShutdownPendingStatus	Boolean	True if EID will soon shutdown
ShutdownStatus	Boolean	True if EID is in a shutdown state
FPGAFlashRetentionStatus	Boolean	True if EID should be reprogrammed
DriverEnableStatus	Boolean	True if the EID HW driver enable is
		active
IOLockStatus	Boolean	True if IOLock status is active on the
		EID
IOLockRequest	Boolean	True if EID is actively requesting
		IOLock
BackupSettingsInUse	Boolean	True if backup settings are active
UnconfiguredSettingsInUse	Boolean	True if unit has been freshly
		programmed and settings have not
		been saved
UnexpectedSystemResetFault_enum	UInt8	
BoostSupplyFault_enum	UInt8	
MemoryFault_enum	UInt8	
OutputFault_enum	UInt8	
OverspeedFault_enum	UInt8	
InternalVoltageFault_enum	UInt8	
HVTransducerFault_enum	UInt8	
TempSensorFault_enum	UInt8	See lecm_eid_fault_status_enum
InvalidConfigFault_enum	UInt8	
SupplyVoltageLowFault_enum	UInt8	
SupplyVoltageHighFault_enum	UInt8	
OperationalTempHighFault_enum	UInt8	
CriticalTempHighFault_enum	UInt8	
InternalError_enum	UInt8	
RemoteInterfaceFault_enum	UInt8	
CANPortFault_enum	UInt8	
ActiveEncoderSource_enum	UInt8	See lecm_eid_active_enc_src_enum
PrimaryCrankStatus	EIDEncoderStatusBus	SourceState_enum (uint8)
PrimaryCamStatus	EIDEncoderStatusBus	RelativeLossError (bool)
PrimarySyncStatus	EIDEncoderStatusBus	ToothCountMismatch (bool)
AlternateCrankStatus	EIDEncoderStatusBus	SignalError (bool)
AlternateCamStatus	EIDEncoderStatusBus	LossError (bool)
AlternateSyncStatus	EIDEncoderStatusBus	SyncError (bool)
		ConfigurationError (bool)
		See
		lecm_eid_encoder_src_state_enum
SystemState onum	UInt8	
SystemState_enum AverageSpeed_RPM	UInt16	See lecm_eid_system_state_enum Average speed as observed by the
AverageSpeeu_RPIVI		
		EID

SoftwareVersionNumber	UInt16	Major software version of the EID
		firmware

## **Output Diagnostics Interface**

The output diagnostics interface reports summarized EID output driver error conditions for each output #1 - #20.




Figure 3-5. EID Output Diagnostics Interface

The data definition for this interface includes the following:

Table 3-2. EID Output Diagnostics Interface Definition

Parameter	DataType	Description
Output01Output20	EIDOutputDiagnosticsBus	ConfigurationError (bool)
		BoostVoltageError (bool)
		OpenError (bool)
		ShortError (bool)
		DetrimentalError (bool)

# **Control & Configuration Interface**

The control and configuration interface is used as the global control interface for the EID firmware and supported features. The block accepts an EIDControlAndConfigurationInterfaceBus input type with the following parameters:




Figure 3-6. EID Control & Configuration Interface

Table 3-3. EID Control & Configuration Interface Definition

Parameter	DataType	Description
OutputDriverEnable	Boolean	Set to true to enable all output drivers if configured
		for remote control
FaultReset	Boolean	Toggle from false to true to request Active faults on
		the EID to clear
EncoderSwitch	Boolean	Toggle from false to true to request the redundant
		encoder system on the EID to switch (if applicable)
DOutCommand	Boolean	EID DOUT pin state control if configured for remote
		control
AssertFlashRetention	Boolean	Request EID Flash retention flag to assert
MisfireCylinderSelect_enum	UInt8	Sets the cylinder selection enumeration for misfire
		test mode. See
		lecm_eid_misfire_cylinder_select_enum

MisfireLevel_Pct	UInt8	Sets the requested misfire percentage when misfire test mode is active
PrimaryTDCOffset_x16deg	Int16	Sets the primary encoder TDC offset in units of 1/16 degCA if configured for remote configuration. Positive values will advance the offset, negative values will retard the offset.
AlternateTDCOffset_x16deg	Int16	Sets the alternate encoder TDC offset in units of 1/16 degCA if configured for remote configuration.  Positive values will advance the offset, negative values will retard the offset.
ContinuityTestModeEnable	Boolean	Set to true to enable continuity test mode
ContinuityTestModeSelect_enum	UInt8	Sets the output # for which to command in continuity test mode. See lecm_eid_continuity_test_mode_output_select_enum
SimulationTestModeEnable	Boolean	Set to true to enable simulation test mode
SimulationTestModeSpeed_RPM	UInt16	Set the simulation test mode speed setpoint
SkipFireEnable	Boolean	Set to true to enable skipfire mode
SkipFireN	UInt16	Sets the number of skips (N) for skipfire mode
SpeedInterpolationSetting_enum	UInt8	Sets the speed interpolation mode on the EID. See lecm_eid_speed_interpolation_enum
InhibitEncoderErrors	Boolean	Request EID to inhibit all encoder errors from reporting

# **Cylinder PLi Interface**

The cylinder Plug Life Indicator (PLi) interface reports PLi values for each output #1 - #20. This interface is only applicable to MixedMode and Ignition variants.




Figure 3-7. EID Cylinder PLi Interface

The data definition for this interface includes the following:

Table 3-4. EID Cylinder PLi Interface Definition

Parameter	DataType	Description
Cylinder01PLiCylinder20PLi	Float32	The plug life indicator value for the
		respective cylinder in units of %

# **Cylinder Misfire Interface**

The cylinder misfire interface reports cylinder misfire speed values for each cylinder #1 - #20.



Figure 3-8. EID Cylinder Misfire Interface

The data definition for this interface includes the following:

Table 3-5. EID Cylinder Misfire Interface Definition

Parameter	DataType	Description
Cylinder01RPMCylinder20RPM	Float32	The selective misfire speed value for the respective cylinder in units of
		RPM

# **Cylinder Diagnostics Interface**

The cylinder diagnostics interface reports detailed output diagnostics on a per-cylinder basis speed values for each cylinder #1 - #20. This interface is only applicable to the Ignition variant.




Figure 3-9. EID Cylinder Diagnostics Interface

The data definition for this interface includes the following:

Table 3-6. EID Cylinder Diagnostics Interface Definition

Parameter	DataType	Description
Cylinder01Cylinder20	EIDCylinderDiagnosticsBus	ControlInterface_enum (uint8)
		EarlyTerminationError (bool)
		ShortPSToCoilMinusError (bool)
		ShortPSToCoilPlusError (bool)
		ShortGndToCoilPlusError (bool)
		ShortGndToCoilMinusError (bool)
		ShortCoilError (bool)
		OpenCoilError (bool)
		SevereUnderBoostVoltageError (bool)
		MaxBoostVoltageError (bool)
		MinBoostVoltageError (bool)
		MinOnTimeError (bool)
		OverrunError (bool)

# **General Signal Interface**

The general signal interface reports general high-speed EID data.




Figure 3-10. EID General Signal Interface

The data definition for this interface includes the following:

Table 3-7. EID General Signal Interface Definition

Parameter	DataType	Description
InstantaneousSpeed_RPM	Float32	Instantaneous speed reports
CycleAverageSpeed_RPM	Float32	Cycle average speed reports

# MixedMode & Ignition Control Interfaces

# Cylinder Control Interfaces #1 - #3

The cylinder control interfaces #1 - #3 are used to control output drivers that are mapped to the respective interface, including state, duration, and timing. The block accepts an EIDCylinderControlInterfaceBus input type with the following parameters:




Figure 3-11. EID Cylinder Control Interfaces #1 - #3

Table 3-8. EID Cylinder Control Interfaces #1 - #3 Definition

Parameter	DataType	Description
CylinderEnables	Boolean [1x20]	True to enable each respective cylinder #1#20
CylinderDurations	UInt32 [1x20]	The duration command for each respective cylinder #1#20
TimingOffsets_x16deg	Int16 [1x20]	The individual timing offset in units of for each respective cylinder #1#20
GlobalTiming_x16deg	Int16	A global timing command applied to all cylinders on the interface
SlotSelect_enum	UInt8	The profile selection for this controlling interface. See lecm_eid_profile_slot_select_enum
TimingUnitSelect_enum	Boolean	The units of the TimingOffsets_x16deg and GlobalTiming_x16deg signals. False = degATDC, True = degBTDC

# **Injection Control Interfaces**

#### MP Pulse Control Interface #1 - #4

The multi-pulse pulse control interfaces #1 - #4 are used to control the main pulse train of the output drivers that are mapped to the respective interface, including pulse state, base duration, and relative timings. This interface provides the "base" pulse-train commands and is augmented on an individual cylinder basis by the MP Cylinder Control Interfaces. The block accepts an EIDMultiPulseControlInterfaceBus input type with the following parameters:




Figure 3-12. EID MP Pulse Control Interfaces #1 - #4

Table 3-9. EID MP Pulse Control Interfaces #1 - #4 Definition

Parameter	DataType	Description
Mode_enum	UInt8	Sets the controlling mode of the pulse train.
		See lesp_crs_fuel_control_mode_enum
TimingRangeResolutionSelect_enum	UInt8	Sets the desired timing range/resolution of
		the interface. See
		lesp_crs_fuel_timing_range_resolution_enum
SlotSelect_enum	UInt8	Sets the desired profile used by the interface.
		See lecm_eid_profile_slot_select_enum
PulseEnables	Boolean [1x5]	True to enable the state of each Pulse
		#1Pulse #5
TimingOffsets degATDC	Int16 [1x5]	Relative timing offsets of each Pulse
		#1Pulse #5 relative to each cylinder's TDC
Magnitudes	Float32 [1x5]	Magnitude command of the output drivers
		based on the selected Mode_enum

# MP Cylinder Control Interface #1 - #4

The multi-pulse cylinder control interfaces Cylinder #1-#10 (#11-#20) #1 - #4 are used to adjust the primary pulse train as controlled by the MP Pulse Control interface and make individual adjustments on a per-cylinder basis, including individual cylinder state control, timing, and magnitude trims. The block accepts an EIDMultiPulseCylinderInterfaceBus input type with the following parameters:



Figure 3-13. EID MP Cylinder Control Interfaces #1 - #4

Table 3-10. EID MP Cylinder Control Interfaces #1 - #4 Definition

Input	DataType	Description
Mode_enum	UInt8	Must match the Mode_enum of the corresponding Pulse Control interface. See lesp_crs_fuel_control_mode_enum
CylinderEnables	Boolean [1x10]	Individual on/off enable control for the respective cylinder
PulseSOITrimApplyFlags	Boolean [1x5]	Set to true to indicate if the Cylinder SOI Trim should apply to the respective Pulse #1Pulse #5
CylinderSOITrims_x8deg	Int8 [1x5]	Relative timing offsets applied to each Pulse Trim apply indicated pulse relative to each cylinder's TDC. Note: These values have units of 1/8 degree resolution (i.e., 1 = 1/8 degCA).
CylinderMagnitudeTrims	Float32 [1x5]	Relative magnitude trim added to the Main Pulse (Pulse #3) of the corresponding cylinder

# **Common Rail Signal Interface**

The common rail signal interface is used to set the rail pressure command on the EID and accepts the RailPressure as an AnalogSensor input type.



Figure 3-14. EID Common Rail Signal Interface

Table 3-11. EID Common Rail Signal Interface Definition

Input	DataType	Description
Rail Pressure	AnalogSensor	Rail Pressure signal as an
		AnalogSensor bus input type with
		units in bar

# **EID Interface Diagnostics**

The EID interface library comes with standard receive and transmit interface diagnostics that can be associated with a fault to indicate an error condition has occurred with the interface. The blocks output a FaultBus type and accept the EIDTxInterfaceStatusBus and EIDRxInterfaceStatusBus types in the Status ports respectively.




Figure 3-15. EID Interface Transmit/Receive Diagnostics

In addition, the EID Faults diagnostic block can be used to create 7 summarized faults for the respective EID instance as follows:




Figure 3-16. EID Faults Diagnostic

# Chapter 4. Aux Interfacing

## Introduction

The following chapter describes interfacing with Woodward standard platform Aux applications using the prebuilt LESP framework interface blocks. Before getting started, it's important to understand the Woodward standard Aux applications variants.

## **Aux 24 Thermocouple**

The Aux 24 thermocouple software is designed to provide 24 extra thermocouples from the aux board. Datalink communications include ASB shared memory region interfaces as well as configurable J1939 for external communications. Both J- and K-type thermocouples are supported with open-wire detection.

## **Aux Acoustic Knock + Thermocouple**

The Aux acoustic knock + thermocouple software is designed for up to 20 cylinders of acoustic knock and up to 24 thermocouples. Any desired mix of acoustic knock and thermocouples is possible based on hardware configuration. Thermocouple features match those as defined in the Aux 24 thermocouple variant. Acoustic knock samples knock sensors within a user-defined angular window and calculates a knock ratio or knock intensity metric for each cylinder [0 – 100%] based on observed frequency content within the sampling window. Knock ratios are reported with ASB shared memory region interfaces as well as J1939 standard messages for external communications.

## Aux Real Time Combustion Diagnostics & Control (RTCDC) + Thermocouple

The Aux RTCDC + thermocouple software is designed for up to 12 cylinders of in-cylinder pressure sensing and combustion monitoring. Pressure and thermocouple mix depends on hardware variant. Standard combustion analytics (e.g., SOC, heat release, peak pressure, mean effective pressures, etc...) are reported using ASB shared memory region interfaces as well as J1939 messages for external communications. Thermocouple features match those as defined in the Aux 24 thermocouple variant.

#### Aux Acoustic Knock + RTCDC

The Aux acoustic knock + RTCDC software is design as primarily an acoustic knock application with a small sample set of RTCDC-enabled pressure inputs (e.g., 1, 2, or 4 pressure inputs depending on hardware configuration). The same features for acoustic knock and RTCDC exist; however, these application variants provide a means for acoustic knock protection with limited in-cylinder combustion metric analysis to support acoustic knock setup and/or limited RTCDC-based cylinder monitoring.

#### **Aux Protection + Remote IO**

The Aux protection + remote IO application is designed as a general-purpose Aux IO expansion application along with optional configurable protection-related functions. This application is designed with only J1939 Proprietary messaging available on both internal and external CAN datalinks.

#### **LESP Aux Interface Blocks**

The Aux Interface blocks can be located in the Simulink Library Browser under the LESP folder.





Figure 4-1. LECM Aux Interface Blocks



#### **Definition**

As previously described in Chapter 2, under the Model Configuration subsystem, Aux interface definitions should be defined. If interfacing with more than one Aux, enter a new definition with a unique Aux number instance. Note: The definition is a variant subsystem to support compilation on a Main Standalone vs a Main Stacked unit.




Figure 4-2. Aux Interface Definition

The block variant is controlled by the IsLECMStandaloneVariant workspace parameter, which is defined as follows:

IsLECMStandaloneVariant = strcmp(HardwareConfig.Target, 'LECM-5566-210-065-142x')

### **General Aux Interfaces**

The following section describes common Aux interface blocks supported for all (except protection IO) Aux application variants. All Aux → Main feedback/reporting interfaces have a two-layer bus interface as follows:

- Interface (bus)
  - o AuxRxInterfaceStatusBus
    - IsEnabled (bool)
    - Timeout\_ms (uint32)
    - RegionAge\_ms (uint32)
    - ConfigurationFault (bool)
    - TimeoutFault (bool)
    - DatalinkSelect\_enum (uin8)
  - > \*DataBus
    - Data is interface dependent

All Main → Aux command interfaces report the following status bus that can be used to drive diagnostics if the interface fails to transmit:

- Interface (bus)
  - AuxTxInterfaceStatusBus
    - IsConnected (bool)
    - TxError (bool)




Figure 4-3. Aux → Main Feedback/Reporting Interface Example

## **Diagnostics & Status Interface**

The diagnostics and status interface reports general Aux diagnostic and status information to the main board. It's the responsibility of the application developer to integrate this information into the application as deemed appropriate (see diagnostics example in subsequent section below).



Figure 4-4. Aux Diagnostics & Status Interface

The data definition for this interface includes the following:

Table 4-1. Aux Diagnostics & Status Interface Definition

Parameter	DataType	Description
ApplicationShutdownInhibited	Boolean	True if the Aux application is currently inhibited from shutting down.
IOLockStatus	Boolean	True if the Aux application IOLock is active.
IOLockRequest	Boolean	True if Aux application is currently requesting IOLock.
BackupSettingsInUse	Boolean	True if backup settings are active.

UnconfiguredSettingsInUse	Boolean	True if unit has been freshly programmed and settings have not been saved.
UnexpectedSystemResetFault	UInt8	
MemoryFault	UInt8	
InternalVoltageFault	UInt8	
TemperatureSensorFault	UInt8	
TemperatureHighFault	UInt8	
SupplyVoltageLowFault	UInt8	
SupplyVoltageHighFault	UInt8	Soo loom ouy foult status onum
RemoteInterfaceFault	UInt8	See lecm_aux_fault_status_enum
CANPortFault	UInt8	
InternalError	UInt8	
DOut1Fault	UInt8	
DOut2Fault	UInt8	
AOut1Fault	UInt8	
AOut2Fault	UInt8	
AOut1Current_mA	Float32	Current readback of AOut1 in mA
AOut2Current_mA	Float32	Current readback of AOut2 in mA
ActiveEncoderSourceEnum	UInt8	See
		lecm_aux_active_enc_src_enum
AverageSpeed_RPM	UInt16	Average speed as observed by
		Aux encoder system
PrimaryCrankStatus	AuxEncoderStatusInterfaceBus	State_enum (uint8)
PrimaryCamStatus	AuxEncoderStatusInterfaceBus	RelativeLoss (bool)
PrimarySyncStatus	AuxEncoderStatusInterfaceBus	ToothCountMismatch (bool)
AlternateCrankStatus	AuxEncoderStatusInterfaceBus	SignalError (bool)
AlternateCamStatus	AuxEncoderStatusInterfaceBus	LossError (bool)
AlternateSyncStatus	AuxEncoderStatusInterfaceBus	SyncError (bool)
		ConfigurationError (bool)
SoftwareVersionNumber	UInt16	Major software version of the Aux
		firmware.

# **Control & Configuration Interface**

The control and configuration interface is used as the global control interface for the Aux firmware and supported features. The block accepts an AuxControlAndConfigurationInterfaceBus input type with the following parameters:




Figure 4-5. Aux Control & Configuration Interface

Table 4-2. Aux Control & Configuration Interface Definition

Parameter	DataType	Description
FaultReset	Boolean	Toggle from false to true to request Active faults on the Aux to clear.
InhibitApplicationShutdown	Boolean	Set to true to inhibit the Aux
		application from executing its shutdown sequence when requested.

EncoderSwitch	Boolean	Toggle from false to true to request the redundant encoder system on the Aux to switch (if applicable).
SimulationTestModeEnable	Boolean	Set to true to enable simulation test mode.
SimulationTestModeSpeed_RPM	UInt16	Set the simulation test mode speed setpoint (standalone units only).
SpeedInterpolationSetting_enum	UInt8	Sets the speed interpolation mode on the Aux. See lecm_aux_speed_interpolation_enum
KnockDetectionEnable	Boolean	Set to true to enable acoustic knock detection.
DOut1Command	Boolean	Aux DOUT1 pin state control if configured for remote control
DOut2Command	Boolean	Aux DOUT2 pin state control if configured for remote control
PrimaryTDCOffset_x16deg	Int16	Sets the primary encoder TDC offset in units of 1/16 degCA if configured for remote configuration. Positive values will advance the offset, negative values will retard the offset.
AlternateTDCOffset_x16deg	Int16	Sets the alternate encoder TDC offset in units of 1/16 degCA if configured for remote configuration. Positive values will advance the offset, negative values will retard the offset.
AOut1Command_uA	Ulnt16	AOUT1 current command in uA if configured for remote control.
AOut2Command_uA	UInt16	AOUT2 current command in uA if configured for remote control.

# Thermocouple Interfaces #1 - #3

The thermocouple interfaces report Aux thermocouple values and statuses to the main board. LESP implements all three interfaces to in a single block to report thermocouple statuses for AIN1...AIN24. Each interface maps to the AIN inputs as follows:

- Thermocouple Interface #1 = AIN1...AIN8
- Thermocouple Interface #2 = AIN9...AIN16
- Thermocouple Interface #3 = AIN17...AIN24



Figure 4-6. Aux Thermocouple Interfaces

The data definition for this interface includes the following:

Table 4-3. Aux Thermocouple Interfaces Definition

Parameter	DataType	Description
Statuses_enum	UInt8 [1x8]	Individual thermocouple statuses. See lecm aux thermocouple status enum
Temperatures_degC	Float32 [1x8]	Individual thermocouple temperatures in units of °C

## **Engine Sensors Interface**

The engine sensors interface is used to set the engine state, Manifold Air Pressure, and Engine Coolant Temp signals on the Aux and accepts an AuxEngineSensorsInterfaceBus input type.




Figure 4-7. Aux Engine Sensors Interface

Table 4-4. Aux Engine Sensors Interface Definition

Parameter	DataType	Description
EngineState_enum	UInt8	A simplified Aux engine state. See
		lecm_aux_engine_state_enum
ManifoldAirPress	AnalogSensorBus	The current manifold air pressure in
		units of kPa
EngineCoolantTemp	AnalogSensorBus	The current engine coolant
		temperature in units of degC

## **Acoustic Knock Interfaces**

## Cylinder Knock Ratio Interfaces #1 - #3

The cylinder knock ratio interfaces #1 - #3 are used to report the cylinder knock ratios (knock intensities). The interfaces mapped to the cylinders as follows:

- Interface #1 = Cylinders #1...#8
- Interface #2 = Cylinders #9...#16
- Interface #3 = Cylinders #17...#24



Figure 4-8. Aux Cylinder Knock Ratio Interfaces #1 - #3

Table 4-5. Aux Cylinder Knock Ratio Interfaces #1 - #3 Definition

Parameter	DataType	Description
Statuses_enum	UInt8 [1x8]	Reports the respective cylinder knock window status. See
		lecm_aux_knock_window_status_enum
NewSamples	Boolean [1x8]	Reports true if the reported knock ratio
		is a new sample
KnockRatios_pct	Float32 [1x8]	Reports the current cylinder knock ratio
		in units of %
KnockSaturations_pct	Float32 [1x8]	Reports the current cylinder knock
		window saturation in units of %
ReferenceSaturations_pct	Float32 [1x8]	Reports the current cylinder reference
		window saturation in units of %

# Cylinder Knock Window Control Interfaces #1 - #3

The cylinder knock window control interfaces #1 - #3 are used to control the knock window start angles and durations from the Main board. The interfaces map to the cylinder knock windows as follows:

- Interface #1 = Cylinder Knock Windows #1 #8
- Interface #2 = Cylinder Knock Windows #9 #16
- Interface #3 = Cylinder Knock Windows #17 #24

The block accepts an AuxKnockWindowControlInterfaceBus input type with the following parameters:



Figure 4-9. Aux Cylinder Knock Window Control Interfaces #1 - #3

Table 4-6. Aux Cylinder Knock Window Control Interfaces #1 - #3 Definition

Parameter	DataType	Description
StartAngles_x16degATDC	Int16 [1x8]	The cylinder knock window start angles in units of degATDC for the respective cylinders
Widths_x16deg	UInt16 [1x8]	The cylinder knock window widths in units of degCA for the respective cylinders

# Cylinder Reference Window Control Interfaces #1 - #3

The cylinder reference window control interfaces #1 - #3 are used to control the reference window start angles and durations from the Main board. The interfaces map to the cylinder reference windows as follows:

- Interface #1 = Cylinder Reference Windows #1 #8
- Interface #2 = Cylinder Reference Windows #9 #16
- Interface #3 = Cylinder Reference Windows #17 #24

The block accepts an AuxKnockWindowControlInterfaceBus input type with the following parameters:



Figure 4-10. Aux Cylinder Reference Window Control Interfaces #1 - #3

Table 4-7. Aux Cylinder Reference Window Control Interfaces #1 - #3 Definition

Parameter	DataType	Description
StartAngles_x16degATDC	Int16 [1x8]	The cylinder reference window start angles in units of degATDC for the respective cylinders
Widths_x16deg	UInt16 [1x8]	The cylinder reference window widths in units of degCA for the respective cylinders

# **RTCDC Interfaces**

#### **RTCDC Status Interface**

The RTCDC status interface is used to report the RTCDC sampling status information. The interface reports the following information:




Figure 4-11. Aux RTCDC Status Interface

Table 4-8. Aux RTCDC Status Interface Definition

Parameter	DataType	Description
TotalMissedSamples	UInt32	Reports the total number of RTCDC samples
		that have been missed.
ADCVectorSamplingStatus_enum	UInt8	Reports the status of the RTCDC sampling
		engine. See
		lecm_aux_rtcdc_sampling_status_enum.
MeanCycles	UInt8	Reports the total number of average cycles
		used for average metric reporting.
PeggingSource_enum	UInt8	Reports the active pegging source. See
		lecm_aux_rtcdc_pegging_source_enum.
PeggingSourceStatus_enum	UInt8	Reports the status of the pegging source signal.
_		See
		lecm_aux_rtcdc_pegging_source_status_enum.

## RTCDC Cycle Data Interfaces #1 - #20

The RTCDC cycle data interfaces report the combustion metrics for the respective cylinder on a per engine-cycle basis. Because these interfaces are cycle-based, the timeout mechanism is based on a function of the engine speed; thus, the block requires the current speed as an input in order to properly determine if the interface is timed out. The interface reports the following information:




Figure 4-12. Aux RTCDC Cycle Data Interfaces

Table 4-9. Aux RTCDC Cycle Data Interface Definition

Parameter	DataType	Description
PressureSensorStatus	AuxRTCDCPressureSensorStatusBus	IsFaulted (bool)
		SensorOpenCircuitStatus (bool)
		SensorShortCircuitStatus (bool)
		SignalNoiseStatus (bool)
		SignalDriftedLowStatus (bool)
		SignalDriftedHighStatus (bool)
		PeggingErrorStatus (bool)
		DataValiditySuspectStatus (bool)
		SensorNonResponsiveStatus
		(bool)
SOC_degATDC	Float32	Reports the start of combustion in
3		units of degATDC
CA10 degATDC	Float32	Reports the 10% mass fraction
g		burn in units of degATDC
CAx1_degATDC	Float32	Reports the x1% mass fraction
o, a.ta.ag. t.t = 0		burn in units of degATDC
CA50_degATDC	Float32	Reports the 50% mass fraction
o, 100_40g, 11 2 0	1104102	burn in units of degATDC
CAx2_degATDC	Float32	Reports the x2% mass fraction
o, uaog, b o	1104102	burn in units of degATDC
CA90_degATDC	Float32	Reports the 90% mass fraction
0,100_d0g,1120	1104102	burn in units of degATDC
PMEP_bar	Float32	Reports the pumping mean
		effective pressure in units of bar.
IMEPGross_bar	Float32	Reports the gross indicated mean
_		effective pressure in units of bar.
IMEPNet_bar	Float32	Reports the net indicated mean
_		effective pressure in units of bar.
COV_IMEP_pct	Float32	Reports the coefficient of
		variance of IMEP in units of %
PeakPressure_bar	Float32	Reports the peak pressure in
_		units of bar.
PeakLocation degATDC	Float32	Reports the peak location in units
_ 3		of degATDC.
ROPRMax barperdeg	Float32	Reports the maximum rate of
= . 0		pressure rise in units of
		bar/degCA.
MisfireStatus	Boolean	Reports true if the cycle is
		considered a misfire condition.
MisfireCount	UInt32	Increments by 1 each time a
		misfire event is observed.
MisfirePercentOfAverag	Float32	A relative average misfire
e_pct		percent.
LatefireStatus	Boolean	Reports true if the cycle is
		considered a latefire condition.

LatefireCount	UInt32	Increments by 1 each time a latefire event is observed.
LatefirePercentOfAverag e_pct	Float32	A relative average of latefire percent.
KnockIntensity_pct	Float32	Reports the pressure-based knock intensity.
KnockRippleSum_bar	Float32	Reports an accumulation of the amount of knock ripple in units of bar.
MaxKnockPressure_bar	Float32	Reports the maximum knock pressure in units of bar.
CombustionIntensity	Float32	Reports the combustion intensity metric.

# RTCDC Average Data Interfaces #1 - #20

The RTCDC average data interfaces report the averaged combustion metrics for the respective cylinder. The interface reports the following information:




Figure 4-13. Aux RTCDC Average Data Interfaces

Table 4-10. Aux RTCDC Average Data Interface Definition

Parameter	DataType	Description
MeanCycles	UInt8	Reports the current number of cycles used to average
CompressionGammaAverage	Float32	Reports the average compression gamma
ExpansionGammaAverage	Float32	Reports the average expansion gamma
SOCAverage_degATDC	Float32	Reports the average start of combustion
CA10Average_degATDC	Float32	Reports the average 10% mass fraction burn
CA50Average_degATDC	Float32	Reports the average 50% mass fraction burn
CA90Average_degATDC	Float32	Reports the average 90% mass fraction burn
PMEPAverage_bar	Float32	Reports the average pumping mean effective pressure
IMEPGrossAverage_bar	Float32	Reports the average gross indicated mean effective pressure
IMEPNetAverage_bar	Float32	Reports the average net indicated mean effective pressure
PeakPressure_bar	Float32	Reports the average peak pressure
PeakLocation_degATDC	Float32	Reports the average peak location
CumulativeHRAverage_Joule	Float32	Reports the cumulative heat release average
HRRMaxAverage_Joule	Float32	Reports the heat release rate maximum average
HRRMaxLocationAverage_degATDC	Float32	Reports the heat release rate maximum location average
ROPRMaxAverage_barperdeg	Float32	Reports the maximum rate of pressure rise average
KnockIntensityAverage_pct	Float32	Reports the knock intensity average

# **Aux Interface Diagnostics**

The Aux interface library comes with standard receive and transmit interface diagnostics that can be associated with a fault to indicate an error condition has occurred with the interface. The blocks output a FaultBus type and accept the AuxTxInterfaceStatusBus and AuxRxInterfaceStatusBus types in the Status ports respectively.




Figure 4-14. Aux Interface Transmit/Receive Diagnostics

In addition, the Aux Faults diagnostic block can be used to create two summarized faults for the respective Aux instance as follows:



Figure 4-15. Aux Faults Diagnostic

# **Chapter 5. Diagnostics Management**

#### Introduction

The following chapter describes the LE system platform approach to diagnostics management using the MotoHawk OBD fault management blockset. The MotoHawk OBD fault management blockset is used in order to support built-in SAEJ1939 DM messaging and ISO15765 services that are integrated with the OBD fault management blockset, even though OBD-style diagnostics are not used; therefore, only a limited set of OBD fault blocks are used with customizations to support a general non-OBD based fault management structure.

# **Standard Platform Diagnostic Structure**

#### **Fault States**

The large engine system platform diagnostic structure implements faults with that support the following states:

#### **Primary Fault State**

This is the general state of the fault used to indicate if the fault is inactive, active, and/or previously active.

- Inactive State
  - The fault is current inactive.
- Active State
  - The fault is active. This state maps to the OBD fault state of "Confirmed" and is a latching condition.
- Stored
  - The fault was previously active. This state maps to the OBD fault state of "Previously Active" and is a latching condition.

#### ACK/NACK Fault State

This is a parallel state to the primary fault state used to indicate if a fault has been acknowledged once it initially enters an active state. This can be used to drive a horn or other form of alarm indication for systems that support fault acknowledgement features without a change to the primary fault state.

- Not Acknowledged
  - A parallel state to the primary fault Inactive/Active/Stored state that indicates the fault has not been acknowledged after the first occurrence.
- Acknowledged
  - Indicates the fault is not in an Active state OR is in an Active state and has been subsequently acknowledged.




Figure 5-1. Fault States

## **Fault Properties**

In addition to the fault states, the platform supports the following properties that are automatically created for each fault instance:

- [ReadOnly] IdentificationCode (uint8) [enum]
  - Allows user to create a unique identification code for the fault in the form of "FLTxxxx" where xxxx are digits from 0000-9999.
- [ReadOnly] ConditionalStatus (boolean)
  - Indicates true if the condition to assert the fault is true, independent of the actual fault
    assertion status. This logic is used to avoid clearing a fault if the condition for the fault is
    still valid.
- [ReadOnly] InhibitStatus (boolean)
  - Indicates true if the fault's inhibit status is active, indicating the fault will not assert, regardless of the conditional status.
- [ReadOnly] OccurrenceCount (uint8)
  - Increments by 1 each time the fault enters the Active state. The value is limited from 0 –
     127 to support SAEJ1939 DM FMI reporting.
- [ReadOnly] FirstTimeOfOccurrence (datetime)
  - Records the real time clock timestamp of the very first occurrence of the fault (i.e., OccurrenceCount == 1).
- [ReadOnly] RecentTimeOfOccurrence (datetime)
  - Records the real time clock timestamp of the most recent occurrence of the fault (i.e., OccurrenceCount > 0).
- [ReadWrite] FaultCondition1 (uint8) [enum]
  - Enumerated fault condition that asserts the corresponding FaultAction1 fault action when the fault's state matches the condition. Available values include Active, Stored, or Not Acknowledged.

- [ReadWrite] FaultAction1 (uint8) [enum]
  - Used to assert the mapped fault action when the corresponding fault's FaultCondition1 state matches. Fault actions are defined by the application developer.
- [ReadWrite] FaultCondition2 (uint8) [enum]
  - Second instance equivalent to FaultCondition1 that allows for a fault to be mapped to a second fault action.
- [ReadWrite] FaultAction2 (uint8) [enum]
  - Second instance equivalent to FaultAction1.
- [ReadWrite] AutoRecoveryTime (uint8) [s]
  - When non-zero, the fault will automatically clear in this many seconds if the condition for the fault no longer exists. A value of 0 disables this feature and the fault will require an explicit clear request.
- [ReadOnly] AutoRecoveryTimeRemaining (uint8) [s]
  - o The total amount of time remaining before the fault will automatically clear.
- [ReadWrite] ActiveClearEngineStoppedRequired (boolean)
  - Check to require the engine to be in a stopped state before the fault will be allowed to clear.
- [ReadOnly] EngineHours (timespan)
  - A snapshot of the engine runtime hours of the most recent occurrence of the fault entering an active state.




Figure 5-2. Example Fault Condition/Action Mapping

These fields are referred to as "Custom Fields" and effectively allow the developer to extend the "definition" of a fault with additional properties. Each defined custom field is applied to each fault defined in the application.

#### **Fault Actions**

Fault actions are logical signals that are defined by the application developer, in which the application is designed to support up to 30 unique actions. Fault actions are defined in the local project ./Scripts directory with the fault\_action\_enum.m script.




Figure 5-3. Fault Action Enumeration Definition

The above figure shows an example of five fault actions:

- None
  - o This fault action should always be defined to indicate a "no mapping" condition.
- Alarm
  - Used to indicate an alarm indicator status.
- Shutdown
  - Used to indicate a fault is requesting the engine to stop under normal conditions.
- ImmediateShutdown
  - Used to indicate a fault is requesting an emergency stop.
- StartInterlock
  - o Used to indicate a fault is requesting the engine starter to be inhibited from engagement

The above fault actions are a sample starting point. Any naming convention of fault actions can be used (up to 30). These will generate the equivalent logical fault action signals that can then be retrieved with the Fault Actions Get block and used in downstream logic to drive the appropriate requested behaviors.

## **Fault Property Defaulting**

ReadWrite fault properties can be configured to a default value using the custom\_field\_defaults.m script located under the local ./Scripts folder.




Figure 5-4. Fault Property Defaults

The figure below illustrates an example of using this file to set fault action mapping defaults for faults named "InvalidCylinderConfigurationFault" and "OutputMappingConflictFault" to Active → ImmediateShutdown and Active → StartInterlock.

```
%% Default ImmediateShutdown and StartInterlock
faultnames = { 'InvalidCylinderConfigurationFault', 'OutputMappingConflictFault' };
for i=1:length(faultnames)
    fname = faultnames{i};
    cfield_ctr = cfield_ctr + 1;
    deflts.customfields{cfield_ctr}.name = 'FaultCondition1';
    deflts.customfields{cfield ctr}.fault name = fname;
    deflts.customfields{cfield_ctr}.default_value = uint8(lesp_std_diag_mgr_fault_selectable_state_enum('Active'));
    cfield_ctr = cfield_ctr + 1;
    deflts.customfields{cfield ctr}.name = 'FaultAction1';
    deflts.customfields{cfield_ctr}.fault_name = fname;
    deflts.customfields{cfield_ctr}.default_value = uint8(fault_action_enum('ImmediateShutdown'));
    cfield_ctr = cfield_ctr + 1;
    deflts.customfields{cfield_ctr}.name = 'FaultCondition2';
    deflts.customfields{cfield ctr}.fault name = fname;
    deflts.customfields{cfield_ctr}.default_value = uint8(lesp_std_diag_mgr_fault_selectable_state_enum('Active'));
    cfield ctr = cfield ctr + 1;
    deflts.customfields{cfield ctr}.name = 'FaultAction2';
    deflts.customfields{cfield_ctr}.fault_name = fname;
    deflts.customfields{cfield_ctr}.default_value = uint8(fault_action_enum('StartInterlock'));
```

Figure 5-5. Fault Property Defaults Example

# **SAEJ1939 SPN/FMI Fault Property Extensions**

In addition to the standard fault properties, if J1939 Diagnostic Message (DM) is desired, the faults can be extended with SPN and FMI fault properties with the J1939 SPN/FMI Definitions block. This block will add SPN/FMI fault properties to all defined faults using custom field extensions, which are required for proper J1939 DM Diagnostic Trouble Code (DTC) fault reporting.




Figure 5-6. J1939 SPN/FMI Definitions Block

The default J1939 SPN/FMI values are controlled with a database file. The database file must then be converted to a j1939\_spn\_fmi\_custom\_field\_defaults.m script, which is then referenced by the J1939 SPN/FMI Definition block.




Figure 5-7. J1939 SPN/FMI Database

The conversion from the database file to the custom field defaults file can be managed with the LESP Fault Property manager tool. This tool is described in more details in subsequent sections.

# **Identification Code Fault Property**

As previously mentioned, the standard diagnostic management structure supports a fault identification code for each fault, that can be used as a unique numeric identifier for each fault. This property is a uint16 numeric value but presented as an enumeration of the form "FLTxxxx." The fault identification codes are defined in the fault\_identification\_code\_database.m script under the local ./Scripts directory. The database file must be converted to an equivalent enumeration definition (fault\_identification\_code\_enum.m) and custom field defaults form (fault\_identification\_code\_custom\_field\_defaults.m). This conversion is handled automatically using the Fault Property Manager (see below).




Figure 5-8. Fault Identification Code Database

# **Diagnostic Management Definition**

The LE system platform standard fault definition block should be located in the Model Configuration subsystem.




Figure 5-9. LE Standard Diagnostic Management Definition Block

The mask of the block supports three tabs with configuration parameters:

#### General

- Custom Field Defaults
  - Enter the local custom field defaults script.
- o Instrumentation Group
  - Enter a default instrumentation group path for global D&M properties.

#### Identification Codes

Identification Code Defaults

- Enter the script for the fault identification code custom field defaults
- o Identification Code Enum
  - Enter the script for the fault identification code enum
- Fault Actions
  - Fault Actions Enumeration
    - Enter the script for the local fault\_action\_enum



When changing the fault action enumeration definition, this block will require an explicit refresh to update the underlying structure. See Chapter 8 for an example/process of adding a fault action.

# **Fault Property Manager**

The fault property manager tool is used to manage fault identification codes as well as J1939 SPN/FMI fault associations. The fault property manager can be launched from the fault definition block:




Figure 5-10. Fault Property Manager Launcher

When the fault manager is first launched, it will load all faults defined in the model. Using the default databases as outlined in the red box (verify the correct files are referenced), it will retrieve the current ID codes, J1939 SPN, and J1939 FMI values for each corresponding fault. If the fault is not defined in the database, it will default to 0. Use this tool, the headers to sort, and the blue box to show the next available values. Replace all 0 valued ID/SPN/FMI defaults with proper values and then click the "Regenerate \*.m Files" to automatically regenerate the following files:

- fault\_identification\_code\_database.m
- fault identification code custom field defaults.m
- · fault identification code enum.m
- j1939 spn fmi database
- j1939 spn fmi custom field defaults.m

This tool provides for a simple method to manage these dependencies files without any direct file manipulation required. In addition, the tool supports the ability to import/export the \*.m database files to Microsoft® Excel equivalents.




Figure 5-11. Fault Property Manager

The figure below illustrates all auto-generated files managed by the property manager, thus not requiring any direct modification by the user (highlighted). All other files are explicitly managed/modified by the user.




Figure 5-12. Fault Property Manager Auto-Generated Files

#### **Fault Actions Get**

The Fault Actions Get block is used to retrieve the current logical states of all fault actions defined in the Fault Definition (fault\_action\_enum.m). This block is typically located in the Inputs/Functions and returns the Fault Action states to be consumed in downstream logic to drive appropriate fault action behaviors. It also supports a Fault Protection Override input and built-in tunables to force the fault actions that are mapped to be included with the fault protection override feature to de-assert if the fault protection override input is active.




Figure 5-13. Fault Action Get Block



When changing the fault action enumeration definition, this block may require an explicit refresh to update the underlying structure. See Chapter 8 for an example/process of adding a fault action.

# **Fault Requests Get**

The Fault Request Get block is used to report event counters for fault manager requests. This block is generally located in the Inputs/Application Read subsystem. A change to the event counter can be used in downstream logic to take actions when one of the following requests occurs:


- Clear All Active Fault Request
- Clear All Stored Fault Request
- Acknowledge All Fault Request
- Fault-Related Memory Save Request



Figure 5-14. Fault Requests Get Block

# **Diagnostic Management Fault Manager**

The diagnostic management fault manager block is the core engine for fault management and must be located in an execution context within the model. This block is generally located in Diagnostics Idle or Slow execution context. This block manages fault assertion/de-assertion events, auto-recovery behaviors, and fault timestamping.




LE Standard Diagnostic Management Fault Manager

Figure 5-15. Diagnostic Management Fault Manager

# **ToolKit Event Manager**

If using Woodward ToolKit as an HMI, service, or developer tool, display of faults and their corresponding property values is supported with a ToolKit Event Manager. The LE standard diagnostic management implements a standard ToolKit event manager using the LE Standard ToolKit Event Manager block in addition to a toolkit event manager definition that describes the conditions for showing faults, the filter conditions, and the fault properties to show.



LE Standard ToolKit Event Manager

Figure 5-16. ToolKit Event Manager




Figure 5-17. ToolKit Event Manager Definition File



Note: The state names used to show faults must match the OBD fault state names. In the case of LESP D&M implementation, Confirmed OBD fault state maps to the Active fault state and PreviouslyActive OBD fault state maps to the Stored fault state.

# **Fault Definition**

The fault definition blocks are used to define a fault in the model. These blocks are designed to accept a FaultBus type and properly map the Active/Stored states to the OBD fault state equivalents. The library supports two fault definition instances. The basic definition and a secondary definition that also allows for a custom field defaults file specific to the fault to be defined. The fault definition blocks do not support

filtering. It's the responsibility of the application developer to implement fault filtering external to this block if desired.



Figure 5-18. Fault Definition Blocks

# **Example Fault Definition:**

In this example, an ASB Range Comparison block is used to detect if a sensor value is out of range. This value is fed into a Boolean Persistence Filter, which is used to filter that the condition persists for at least 1 second before driving the fault assertion status. The conditional status is tied directly to the fault condition (pre-filter). The inhibit logic is based on if the sensor is used ("Disabled"). These signals are assigned to a FaultBus create block, which is an input to the fault definition.




Figure 5-19. Fault Definition Example

# Chapter 6. LECM Main Encoder

# Introduction

The following chapter describes LECM Main encoder system definition. This encoder blockset supports standard and configurable NX, N-M, N+1, and SingleTooth encoder patterns with up to a single 3-sensor encoder system with failover to Cam as an optional backup. The encoder logic blocks exist in the lecm\_flex\_encoder\_simple\_lib.slx Simulink library and are not made visible in the Simulink browser as these blocks should already be integrated into the package application.



This manual assumes the developer has completed MotoHawk flexible encoder training and has familiarity with the flexible encoder blockset.

In addition, the LECM\_IO package will be used as an example when describing the encoder implementation; however, the relative locations of blocks and implementation should match other LECM-based packages.

The encoder system defines encoder sources and mappings to speed inputs as follows:

Table 6-1. LECM Main Encoder Sources Definition

Source	Type/Speed Input	Description
Crank	Absolute Source MainSpeed1	The primary speed Crank encoder source used to track encoder position and drive crank synchronous behaviors.
Cam	Absolute Source MainSpeed2	A secondary absolute encoder source intended for Cam usage that can independently track encoder position and support a failover option (run only on Cam) OR simply be used to provide halfcycle information to the Crank source.
Sync	Companion Source	A supporting encoder source not capable of position tracking but is intended to provide sync information to the Crank source. This source is only used in 3-sensor encoder systems with an NX Crank pattern to provide the "TDC" or "Reset" event.

# **Supported Encoder Patterns**

Any source can be mapped to one of the following encoder patterns:

Table 6-2. LECM Main Encoder Pattern Support

Pattern	Configurations	Description
EncNXConfig1	Runtime	Two independent instances of NX encoder pattern
EncNXConfig2	configurable from	definitions (N equally spaced teeth).
	2 – 750 teeth	Zarrana sasa
		Survey

EncNMinusMConfig1	Runtime	Two independent instances of N-M encoder pattern	
EncNMinusMConfig2	configurable with	definitions (N equally spaced teeth, with M missing tooth	
	N from 2 – 750, M	region).	
	>= 1	www.	
		200 SS	
		3	
		5 3	
		3 5	
		8	
		The industrial and the state of N. I. and the	
5 ND 40 5 4	- ··	· vwv	
EncNPlus1Config1	Runtime	I wo independent instances of N+1 encoder pattern	
EncNPlus1Config2	configurable with	definitions (N equally spaced teeth, with 1 extra tooth).	
	from 1 to 36	run - Tra	
		\frac{1}{2}	
		5	
		}	
		\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\	
		\(\frac{\lambda}{\chi}\)	
		Swanner of the same of the sam	
EncSingleTooth	Fixed	A fixed single one tooth (1X) pattern definition.	
Emulated60X	Fixed	A pre-defined unique 60X pattern used for encoder	
		emulation with standard EID/Aux platform applications.	

# **Supported Encoder System Examples**

In this first 3-sensor example, the Crank is configured as the primary encoder with an 190X pattern. Since the NX pattern has no unique marker to indicate a "zero" position, the Sync companion source is a single tooth encoder pattern that revolves at the same rate as the crank and provides the "zero" position marker. This is also commonly referred to as the "TDC, Reset, or Sync" event. The Cam also uses the single tooth pattern but revolves once per engine cycle and provides the halfcycle information  $(0-360^{\circ} \text{ vs } 360-720^{\circ} \text{ phase of the engine cycle})$  to the Crank source.




Figure 6-1. 3-Sensor Encoder Example

In this second example, only the Crank and Cam are used in a 2-sensor encoder system. The Crank utilizes a 60-1 pattern. Since this pattern type supports a unique "zero" position marker, a Sync source is not required. The Cam utilizes a single-tooth encoder pattern and provides the halfcycle information to the Crank in the same manner as described in the example above.




Figure 6-2. 2-Sensor Encoder Example (N-M Crank)

This next example is similar to the example above; however, the Cam also utilizes an N-M pattern like the crank. The Cam still provides half-cycle information to the Crank source since it revolves twice per engine cycle but can also be used as a failover (run on Cam only) if the Crank signal were to be lost. This provides a partially redundant encoder system.




Figure 6-3. 2-Sensor Encoder Example with Cam Failover Option

This next example is similar to the example above; however, the "Crank" source is treated as a Cam in that it revolves only once per engine cycle as well. This type of encoder system in-effect consists of two independent Cam sources (two encoder sources that revolve once per engine cycle) and provides a truly redundant encoder system.




Figure 6-4. 2-Sensor Redundant Encoder System

There are multiple other encoder patterns/configuration options available with this encoder system design; however, if more complex redundant systems are required, the blockset will need to be extended with other speed sources (e.g., Eid/Aux speeds on a stacked LECM) to support redundant 2/3-sensor encoder systems.

# **Blockset**

# **Encoder Configuration Workspace Variable**

As previously mentioned, the blockset also relies on a workspace struct variable denoted as EncoderConfig with the following fields:

- EncoderConfig
  - Stroke (uint8) = 2 or 4
  - System (LecmFlexEncoderSystemsDefn) This value is only used for variant encoder systems and not applicable to the LECM Main Simple Encoder system.

This variable is set in the <Model> setup.m script.

# **LECM Main Encoder Definition**

The LECM Main Encoder Definition must first be defined in the model under Model Configuration. This block is used to define the Crank, Cam, Sync encoder sources and encoder patterns.




Figure 6-5. LECM Main Encoder Definition

# **LECM Main Encoder Inputs**

The encoder speeds, error events, source information, and other global encoder information is reported via the LECM Main Encoder Inputs block, which should be integrated in the package under the Inputs as illustrated in the example below. This information is made available on an Encoder bus structure to be used in downstream logic.




Figure 6-6. LECM Main Encoder Inputs

# Global Encoder Information

The first information bus structure on the Encoder inputs bus is of the GlobalEncoderInfoBus, which includes the following data:

Table 6-3. Global Encoder Info Bus Definition

Parameter	DataType	Description
EncoderState_enum	UInt8	This value reports the LESP-based encoder state. See lesp_encoder_state_enum and a detailed description of the LESP encoder state logic described in a
IsSpeedDetected	Boolean	subsequent section.  This flag asserts when speed from any encoder source or pseudo encoder speed is non-zero and active.
IsCrankshaftRotating	Boolean	This flag asserts when speed is observed an any external encoder source (does not include pseudo encoder).
InstSpeed_RPM	Float32	This value reports the instantaneous speed of the current <i>active</i> encoder source.
AverageSpeed_RPM	Float32	This value reports the average speed of the current <i>active</i> encoder source.
CycleAverageSpeed_RPM	Float32	This value reports the cycle average speed of the current <i>active</i> encoder source.
AverageDerivative	EncoderAverageDerivativeBus	This value reports the averaged speed-based derivative of the <i>active</i> encoder source.
EncoderAngle_1_16degCA	Float32	Reports the current encoder crank angle in units of degCA (0-360 or 0 – 720).

IsAlternateActive	Boolean	Reports true if the alternate Cam source is the current active encoder source.
ActiveAbsoluteSource_enum	UInt8	Reports the current active encoder source.
DegreesPerEngineCycle_deg	Float32	Reports the current number of degrees per engine cycle (360 for 2-stroke or 720 for 4-stroke).

#### LESP-based Encoder State

It's important to note the encoder state reporting based on LESP-logic adds an additional state to the standard MotoHawk encoder state:

- lesp\_encoder\_state\_enum
  - o [0] Not Created Reports if encoder system has all sources disabled.
  - o [1] ZeroSpeed Reports a zerospeed condition.
  - [2] Rotating Reports a non-zerospeed condition; however, the active source has not achieved synchronization.
  - [3] Partial Synchronization Reports a non-zerospeed condition; however, the active source has not achieved full synchronization.
  - [4] Full Synchronization Pending This is a LESP-specific state added to indicate MotoHawk encoder system is reporting full synchronization; however, the LESP-based encoder state requires the observation of N user-defined error-free revolutions before accepting the Full Synchronization state.
  - [5] Full Synchronization System has achieved full synchronization and at least N userdefined error-free revolutions.

This logic provides a mechanism to fully trust the encoder state prior to enabling key features (e.g., injection).




Figure 6-7. LESP-based Encoder State

# **Encoder Source Information**

The encoder source information bus reports the Crank, Cam, and Sync source-specific content using the AbsoluteEncoderSourceInfoBus for Crank and Cam sources and the CompanionEncoderSourceInfoBus for the Sync source. This information can be used in downstream logic to drive application behaviors or encoder failover logic.

Table 6-4. Absolute Encoder Source Info Bus Definition

Parameter	DataType	Description
State_enum	UInt8	Reports a source-dependent state. See motohawk_flexible_encoder_state_en um.
InstantaneousSpeed_RPM	Float32	Reports the instantaneous speed of this source.
AverageSpeed_RPM	Float32	Reports the average speed of this source.
CycleAverageSpeed_RPM	Float32	Reports the cycle average speed of this source.
AverageDerivative	EncoderAverageDerivativeBus	Reports the average derivative of this source.
IsCreated	Boolean	Reports true if this source is created.
NumberOfTeethInPattern	UInt16	Reports the number of teeth defined in the associated pattern of this source.
NumberOfRevsPerCycle	UInt8	Reports the number of revolutions per engine cycle defined for this source.
SourceID	UInt8	Reports a unique identifier for this source.
LossCompanionID	UInt8	Reports the unique identifier of another source that is the loss companion of this source.
HalfCycleCompanionID	UInt8	Reports the unique identifier of another source that is assigned as the halfcycle companion of this source.
SyncCompanionID	UInt8	Reports the unique identifier of another source that is assigned as the sync companion of this source.
SyncCompanion	CompanionEncoderSourceInfo Bus	Reports the source-specific information of the sync companion for this source.

Table 6-5. Companion Encoder Source Info Bus Definition

Parameter	DataType	Description
State_enum	UInt8	Reports a source-dependent state.
		See
		motohawk_flexible_encoder_compsta
		te_enum.
InstantaneousSpeed_RPM	Float32	Reports the instantaneous speed of
		this source.
IsCreated	Boolean	Reports true if this source is created.
NumberOfTeethInPattern	UInt16	Reports the number of teeth defined
		in the associated pattern of this
		source.
NumberOfRevsPerCycle	UInt8	Reports the number of revolutions per
		engine cycle defined for this source.
SourceID	UInt8	Reports a unique identifier for this
		source.
LossCompanionID	UInt8	Reports the unique identifier of
		another source that is the loss
		companion of this source.

# **Encoder Diagnostics Information**

The last set of bus structures include the encoder source diagnostic event and state reports. MotoHawk flexible encoder reports encoder errors as events to the application layer. These events are converted to local counters and error states that can be used to drive application behaviors. Each encoder source (Crank, Cam, Sync) reports the following encoder error-related information in an EncoderSourceDiagnosticsBus type. Error fault counts are auto cleared by the encoder state logic. To drive failover behaviors, it's recommended to use the encoder error states.

Table 6-6. Encoder Source Diagnostics Bus Definition

Parameter	DataType	Description
Info	EncoderSourceInfoEventsBus	Reports event-related information
ErrorEvents	EncoderSourceErrorEventsBus	Reports error event counters
ErrorStates	EncoderSourceErrorStatesBus	Reports error states

Table 6-7. EncoderSourceInfoEventsBus Definition

Parameter	DataType	Description
NumberOfResyncEvents	UInt32	Increments by 1 each time the encoder observes a synchronization event (i.e., "tooth #0" is observed on the source).
NumberOfTeethBetween SyncEvents	UInt16	Reports the most recent number of teeth observed between consecutive NumberOfResyncEvents.

Table 6-8. EncoderSourceErrorEventsBus Definition

Parameter	DataType	Description
AbsentKeyFaultCount		
BadHalfCycleWindowFaultCount		
InvertedKeyFaultCount		
LossFaultCount		Ingraments by 1 when the respective fault
PhaseFaultCount	UInt32	Increments by 1 when the respective fault event is observed.
ReverseRotationFaultCount		event is observed.
SyncFaultCount		
NoiseSuspectedFaultCount		
SlipFaultCount		
TotalFaultCount	UInt32	An accumulated total of all the above faults.

Table 6-9. EncoderSourceErrorStatesBus Definition

Parameter	DataType	Description
AbsentKeyErrorState		·
BadHalfCycleWindowErrorState		
InvertedKeyErrorState		
LossErrorState		Reports an error state of OK, Intermittent, or Continuous for the
PhaseErrorState	UInt8	
ReverseRotationErrorState		respective fault condition.
SyncErrorState		respective fault condition.
NoiseSuspectedErrorState		
SlipErrorState		
TotalErrorState		

# **LECM Main Encoder Control**

Next, is the LECM Main Encoder Control block which should be integrated in the Control subsystem. This block accepts four inputs from user-defined external logic to drive Cam failover conditions and when to enable/activate the pseudo encoder system. Internally, the block supports encoder source TDC offset, and synchronizer slip controls.




Figure 6-8. LECM Main Encoder Control

Table 6-10. LECM Main Encoder Control Inputs

Parameter	DataType	Description
Cam Encoder Select	Boolean	Set to true to request the Cam absolute source be the active encoder source.
Pseudo Select	Boolean	Set to true to enable the pseudo encoder system. This will override the active encoder source.
Pseudo Speed [RPM]	UInt16	Sets the desired pseudo encoder speed setpoint.
Encoder	Inputs encoder bus	The bus structure from the LECM Main Encoder Inputs block.

# **LECM Main Encoder Diagnostic Management**

Lastly, the LECM Main Encoder Diagnostic Management block should be integrated in the Diagnostics & Monitoring subsystem of the model. This block is responsible for managing fault counters and error states for each encoder source. In addition, it outputs encoder pattern status FaultBus types that can be integrated into an application fault definition as defined by the developer. An input also exists to inhibit reporting of encoder errors. This input is intended for special use-cases (e.g., engine is stopping) in which reporting of encoder error should be disabled. The block requires the LECM Main Encoder Inputs bus.




Figure 6-9. LECM Main Encoder Diagnostic Management

#### Error Events

The LECM Main Encoder Diagnostic Management block implements two sets of encoder error event counters. The primary set increments each error counter by 1 on the report of the respective error event but is automatically cleared by the encoder state logic. These counters are used to drive the encoder state. The second set of error event counters are used for HMI purposes and are denoted as "history" event counters. These counters also increment by 1 on the report of the respective error event but are only cleared when the encoder state transitions <u>out of</u> a ZeroSpeed condition. This enables a history of event counts between engine run cycles. It's recommended to use error state to drive application encoder-related behaviors (e.g., failover logic).

#### $Error\ Events \rightarrow State\ Conversion$

The LECM Main Encoder Diagnostic Management block contains the logic for converting observations of encoder error events to a state that is function of the engine cycle. The states consist of the following:

- [0] No Error No error events
- [1] Intermittent Error events are being observed intermittently
- [2] Continuous Error events are being observed continuously

The state conversion is performed using an up-down counter and an emulated TDC1 event. On the observation of an encoder error report, an internal state count increments by the up count. If the count is at or above the intermittent level, the state is equal to *Intermittent*. If the count is at or above the continuous level, the state is equal to *Continuous*. On the next emulated TDC1 event, if the state count has not changed, it will decrement the state count by 1. Once the state count reaches zero, the state will report *No Error*. This provides a mechanism to observe asynchronous reports of encoder error events in the context of an engine cycle and to determine if it is happening intermittently or continuously. The up counts, intermittent, and continuous levels are configurable values. Note the TDC1 events are emulated in the time domain based on the engine speed in order to have an independent TDC1 report from the encoder system.




Figure 6-10. Encoder Error State Logic

# **LECM Encoder Emulation**

Lastly, the LECM Encoder Emulation block configures the ability to emulate an encoder pattern (nominally the Emulated60X pattern) on MainSpeed4, IgnTrig1, and IgnTrig2. For multiple LECM systems or a stacked unit, this enables the encoders for the external LECMs or stacked EID/Aux units to use the emulated encoder signal. This signal remains in sync with the LECM Main encoder system, enabling a single encoder source definition for the entire system. This block by default is located under the Control subsystem. If encoder emulation is not required, MainSpeed4 is needed for other uses, or the IgnTrig1/IgnTrig2 are used for other purposes, this block can be removed or used as a reference for a custom implementation.




Figure 6-11. LECM Encoder Emulation

# Chapter 7. ToolKit

# Introduction

The following chapter describes the default ToolKit HMI Service Tool included with the packages. The Service Tool provides a default starting point for interfacing with the default packaged software. It's up to the developer to extend the Service Tool and add new tools and pages for new features.

# **IMPORTANT**

Before getting started, ensure a ToolKit Developer License has been authorized on the developer's PC. The developer license can be verified under the Tools ribbon of ToolKit by clicking on the "License Authorization" button.

This document is not intended to describe the details of using the Woodward ToolKit Service Tool. Please refer to ToolKit training and built-in ToolKit documentation for a full set of ToolKit features and development.

This document will use the LECM IO package as an example; however, different packages may contain different initial page content.

# **ToolKit Integration/Features**

Interfacing with ToolKit requires MotoHawk applications to define XCP communications in addition to a ToolKit integration definition that defines the ToolKit features in the application. The parameter namespace is defined by a Service Interface Definition file (\*.sid). This is the ToolKit equivalent of an ASAP2 database (\*.a2l) used for other 3<sup>rd</sup> party XCP-based tools. The SID file is automatically generated by the build process when the ToolKit interface definition is defined. These features include the following:

- ToolKit Event Manager Definitions
- ToolKit Data-Access Based Functions
- ToolKit Programming Support (\*.wapp)
- Service Interface Definition File Options (\*.sid)




Figure 7-1. ToolKit Interface with MotoHawk Application

# **LESP ToolKit Standard Interface Definition**

LESP implements a standard ToolKit interface definition using the ToolKit Standard Interface Definition block.




Figure 7-2. LESP ToolKit Standard Interface Definition

This block adds the following ToolKit features:

- SID File Generation with Default Settings
- Woodward Application programming file (\*.wapp) support
- DAB Functions
  - o IO Lock Request
  - Save Runtime Values Request
  - Save & Reboot Values Request
- XCP Module Reset Request
- [Optional] XCP-based security
- See Diagnostics Management chapter for ToolKit Event Manager integration

#### SID File Generation

The SID file is automatically generated at the end of the build process and will be located by output Build/TDB directory. It's recommended to use a local build script to perform a post-build action of copying the SID File to a local common SID file repository that is referenced by ToolKit.

# Woodward Application Programming File

A toolkit-based Woodward Application programming file (\*.wapp) is also generated to support ToolKit flashing of the firmware. The \*.wapp file is combination of the softboot programmer and the firmware application and therefore, the hardware-specific softboot file must be provided to generate the \*.wapp file. By default, this softboot file is provided in the framework files and retrieved via the <code>lesp\_get\_softboot\_xcp</code> function as illustrated in the figure above.




Figure 7-3. ToolKit WAPP Programming

#### Data-Access Based (DAB) Functions

The standard LESP ToolKit integration supports DAB functions for enabling ToolKit requests to save values and IO Lock the unit while loading settings. Any number of custom DAB functions can be supported; however, the functions marked with [Standard] are default ToolKit built-in functions. DAB functions allow the developer to implement a button event on the Service Tool. The tool sends a request to the control to execute the function and the control will return a success or error code. If the error code is returned, the function is not performed; otherwise, the function should be executed. Error codes returned can result in user-defined error messages to be reported by ToolKit to indicate why the function failed to execute.

#### [Standard] Save Values Function

The standard Save Values function is implemented in LESP as a "Save Values & Reboot the Control" function. The access to this function on the tool can be added manually with a DAB Function button component but is also integrated into the ribbon menu by default with the Save Values function.



Figure 7-4. ToolKit Save Values Function

When the button is clicked in ToolKit the control sends a Save Values DAB function request to the control and triggers the SaveValuesDABFunction trigger located under the ToolKit Standard Interface definition block. When executed, this trigger sets a response code of 0 if the ToolKitSaveValuesPermissive datastore is true; otherwise, it returns a -1 error code with a message indicating the service is currently not available; however, if the service is available, it increments a ToolKitSaveRequestEvents counter. The ToolKitSaveValuesPermissive is set by user-defined application logic using the Application/Application Write (Idle) subsystem. This enables the application developer to specify conditions for which a save/reboot operation would be allowed to proceed (e.g., only allow during a zero speed condition). Lastly, a counter is incremented to indicate a request has been observed. This counter is subsequently read in the Inputs/Application/Application Read (Idle) subsystem and referenced in the Application/Application Slow/Shutdown Management subsystem to execute the request.




Figure 7-5. ToolKit Save Values DAB Function (Manage ToolKit Request)




Figure 7-6. ToolKit Permissives (Manage ToolKit Request Permissives)




Figure 7-7. Application Read ToolKit Service Requests (Read ToolKit Requests)




Figure 7-8. Application Shutdown Management (Execute Requests)

#### [Standard] IO Lock Request

Similar to the example above, an IOLock request is also supported. This feature is built into ToolKit when it executes a settings load operation. If the IOLock feature is supported, the tool will automatically execute this request during a settings load. See similar implementation as described above.

# [Custom] Save Runtime Values Request

Lastly, a third non-standard DAB function is supported that will execute a EEPROM save request independent of a permissive. This can be useful for saving EEPROM-based nonvolatile memory during any operational condition; however, this will not save flash-based calibrations, which requires a save/reboot operation to be executed.

# XCP Reset Request

The ToolKit Standard Interface definition block implements the XCP Reset Request event. ToolKit will request this event after a firmware load is complete.

#### XCP Security

By default, packages do not come standard with XCP security defined. It's up to the developer to implement security if desired; however, if implemented, different levels can translate to different parameter access, and this can be integrated into ToolKit by specifying the levels and the name of the XCP security file. See MotoHawk XCP security documentation for more information on implementing a security algorithm.

# ToolKit Structure

The ToolKit Service Tool design is divided into three core parts: Views, Pages, and Components. Each tool can support multiple views, each view hosting multiple pages, and each page hosting multiple different components or subpages. This is visualized in the Designer Window, where the red box outlines a View, the blue box indicates pages (some organized in folders), and the green box illustrates example components, which include views like gauges, charts, text, edit boxes, checkboxes, buttons, etc. Components are associated with runtime accessible parameters defined in the control (Calibrations, probes, Lookup Tables, Arrays, etc.).




Figure 7-9. ToolKit Designer / Tool Hierarchy

In addition to views, each device for which the tool will connect, must be defined under the Tool Devices.





Figure 7-10. Tool Devices



Each view defined in the tool is associated with one or more SID files that defines the available parameter namespace. The SID can be updated by entering design mode, selecting the view, and changing the SID association for each device defined in the tool.




Figure 7-11. SID File Association

Each view will always contain a default HOME page. This page can only contain labels and image-based components as it is the default page made visible when the tool is first opened to the user. It's recommended to use this page as an introductory page for the tool with relevant information (e.g., connection information). This page can optionally be hidden if desired.



Figure 7-12. Example HOME Page

Each tool will contain a default set of pages for each respective view. For example, the LECM IO package is organized into folders of pages for Module Configuration, Inputs, Control, Outputs, System, Diagnostics, and Datalink. This organization is ultimately up to the application developer in order to provide a standard set of pages that interface with different software features defined in the firmware. The default pages utilize a "dashboard" (left docked pane – blue box) and a "navigation pane" (top docked pane – red box) page design. Each of these two components are shared across all ToolKit pages to provide a standard set of parameters and navigation buttons common to all pages. The remaining portion of the page is used for page-specific content.




Figure 7-13. Standard Page Design

# Chapter 8. Examples

# Introduction

The following chapter provides a set of "how to" examples for developers to use as a reference. It's important to note however, that there are many different approaches to code design and structure, and this chapter is only intended to provide references and general examples and not to prescribe a particular design strategy.

# Input Examples

# **Adding Dynamically Mapped Sensors**

This example demonstrates how to add a sensor that has a runtime configurable (dynamic) mapping to hardware IO. For the purposes of this exercise, we will add a 0-5V Ambient Air Pressure sensor that reports the current barometric pressure in units of kPa to the application.




Figure 8-1. Sensor Processing Example

Analog Input	Sensor	Valid Sensor Range
AIN18 [0-5V] (runtime configurable)	Ambient Air Pressure	0.5 – 4.5 V

First navigate to the Inputs/IO Mapping/IO Mapping Configurations/Pressure subsystem. Inside, you should see an example bus structure with MotoHawk calibrations that contain the runtime mappings of pressure inputs. These calibrations use the standard lecm\_analog\_in\_mapping\_enum enumeration, which is defined as 0 = Not Used and 1...37 = AIN01...AIN37 respectively, thus allowing the respective sensor to be mapped to any analog input or none if not used. Change the AmbientAirPress default value to lecm\_analog\_in\_mapping\_enum('AIN18') to default the calibration to using AIN18.

```
>> lecm_analog_in_mapping_enum
ans =
  1×38 <u>cell</u> array
  Columns 1 through 9
                                                                                                       {'AIN07'}
                                                                                                                     {'AIN08'}
    {'Not Used'}
                    {'AIN01'}
                                  {'AIN02'}
                                                {'AIN03'}
                                                              {'AIN04'}
                                                                            {'AIN05'}
                                                                                          {'AIN06'}
  Columns 10 through 18
    {'AIN09'}
                 {'AIN10'}
                               {'AIN11'}
                                             {'AIN12'}
                                                           {'AIN13'}
                                                                         {'AIN14'}
                                                                                       {'AIN15'}
                                                                                                    {'AIN16'}
                                                                                                                  {'AIN17'}
  Columns 19 through 27
    {'AIN18'}
                  {'AIN19'}
                               {'AIN20'}
                                             {'AIN21'}
                                                           {'AIN22'}
                                                                         {'AIN23'}
                                                                                       {'AIN24'}
                                                                                                    {'AIN25'}
                                                                                                                  {'AIN26'}
  Columns 28 through 36
    {'AIN27'}
                  {'AIN28'}
                               {'AIN29'}
                                             {'AIN30'}
                                                           {'AIN31'}
                                                                         {'AIN32'}
                                                                                       {'AIN33'}
                                                                                                    {'AIN34'}
                                                                                                                  {'AIN35'}
  Columns 37 through 38
    {'AIN36'}
                  {'AIN37'}
```

Figure 8-2. lecm\_analog\_in\_mapping\_enum




Figure 8-3. Ambient Air Pressure IO Mapping Configuration

Next, navigate to the Inputs/IO Mapping/IO Mapping (Medium)/Pressure subsystem. Inside, you should notice example platform blocks that implement the data selector of the respective analog input. This block accepts an AnalogInBus input array that matches the lecm\_analog\_in\_mapping\_enum and the desired mapping input. The mask of the block requires a handle to the analog input enumeration (@lecm\_analog\_in\_mapping\_enum) and will output the respective AnalogInBus object based on the input mapping.




Figure 8-4. Dynamic IO Mapping Selector

Next navigate to the Inputs/Input Processing/Input Processing (Medium)/Pressure subsystem. This will execute the sensor logic in the medium rate execution context (10 ms in this example). Add a subsystem for Ambient Air Pressure Input Processing.




Figure 8-5. Inputs Pressure Sensor Subsystem

In this subsystem, we'll perform the input validation, convert from V to kPa, filter, and provide some simple defaulting logic. The logic will accept the AnalogInBus type and convert to an AnalogSensorBus type which contains two signals: FilteredValue and Status.




Figure 8-6. Ambient Air Pressure Input Processing Strategy




Figure 8-7. Ambient Air Pressure Input Processing Implementation

The Convert V to kPa utilizes subsystem gains and offsets the V to convert to kPa if the analog input mode is equal to 0 – 5V mode; otherwise, the sensor is considered disabled and outputs a zero value.




Figure 8-8. Ambient Air Pressure Input Processing Conversion

The Signal Diagnostics subsystem verifies the sensor input is valid and outputs a sensor measurement status using the lesp\_measurement\_status\_enum. A value of Disabled (1) is used for the sensor status if the analog input mode is not equal to 0-5V. This occurs if the input is not mapped to a 0-5V input; otherwise, the nominal sensor analog input range of 0.5 to 4.5 V is checked and the corresponding SignalLow (2) and SignalHigh (3) statuses are reported if the value is outside this range respectively. Lastly, if all these conditions are not met, the sensor status will report Valid (0).




Figure 8-9. Ambient Air Pressure Input Processing Signal Diagnostics

Next, the input is filtered using an ASB Low Pass tau filter. The filter is configured to Initialize if the input is not valid to ensure invalid inputs reset the filter.




Figure 8-10. Ambient Air Pressure Input Processing Filter

Lastly, the Defaulting is used to report a default Ambient Air Pressure value if the status is not equal to Valid. This enables downstream logic to use a configured default and ignore the status if applicable. Finally, these signals are combined into an AnalogSensorBus type to be used in downstream logic.




Figure 8-11. Ambient Air Pressure Input Processing Defaulting



Note: This logic is a relatively simple example to demonstrate the concept/process of adding a sensor input to the application. A more comprehensive input conversion strategy may be employed (e.g., ratiometric sensing options, advanced filters, hysteretic signal diagnostics, more complex defaulting logic, etc.). In addition, if dynamic IO mapping is not required, the AnalogInBus can be used directly from the Read Hardware bus structure and the IO Mapping logic can be skipped.

It's also recommended, for common sensor types, to create a local library of blocks that are parameterized to allow for re-use.

# Adding Aux RTCDC Cycle Data Interfacing

This example demonstrates how to read LECM Aux RTCDC cylinder cycle data into the application. As previously discussed in Chapter 4, Aux RTCDC cylinder cycle data interfaces report cycle-based incylinder combustion metrics asynchronously. The asynchronous reporting therefore requires the current operational speed to be used to determine an appropriate message timeout.




Figure 8-12. Aux RTCDC Cylinder Cycle Data Interface

In this example, let's assume our maximum engine speed is 1500 RPM (4-stroke). This equates to a maximum engine cycle time of 80 milliseconds.

$$Max\ Cycle\ Time\ \left[\frac{ms}{cycle}\right] = \frac{720\ \left[\frac{deg}{cycle}\right]}{\left(\frac{360\ deg}{1\ rev}x\ \frac{1500\ rev}{1\ min}\ x\ \frac{1\ min}{60000\ ms}\right)\left[\frac{deg}{ms}\right]} =\ 80\ \left[\frac{ms}{cycle}\right]$$

A maximum cycle time of 80 ms requires the interface to be located in a rate group faster than 80 ms. In this example, we'll add to the Datalink Slow processing rate group (50 ms); however, note the current engine speed is required as an input for proper message timeout detection. Navigate to the Input

Processing subsystem and add the Sensors Medium bus as an input to the Datalink In Slow subsystem in order to read the current speed from the encoder inputs.




Figure 8-13. Datalink In Slow Subsystem

Next, inside of the Datalink In Slow subsystem, add a subsystem for RTCDC Cycle Data and use a bus selector to select the AverageSpeed signal from the encoder inputs.




Figure 8-14. RTCDC Cycle Data Subsystem

Inside of the RTCDC Cycle Data subsystem, add the RTCDC Cycle Data interfaces for the cylinders of interest and locate these interfaces on a bus creator. The RTCDC data can then be used downstream to implement control logic and interface diagnostics.




Figure 8-15. RTCDC Cycle Data Interfaces

After adding the interfaces, be sure to enable them by default under the Aux Definition block.




Figure 8-16. Aux Board Definition RTCDC Cycle Data Interface Enables

#### **Adding EID Injection Command Interfacing**

This example demonstrates how to add EID Injection command interfacing to the application. In referencing the EID Injection Manual (B35175), recall the EID Multi-pulse injection interfaces are divided into two interfaces: Pulse control interface and Cylinder Trim interfaces. The pulse control interface provides the commands for a base pulse train of up to 5 pulses (base pulse timings, durations, and pulse control mode). This base pulse train is relative to each cylinder's TDC that is mapped to this interface. The trim interface enables individual cylinder adjustments of states, timing offsets, and magnitude trims. These interfaces are accessible under the LECM EID/Interfaces Simulink library browser.




Figure 8-17. LECM EID Interfaces Simulink Browser

Before adding the interfaces, use the bus create blocks for these respective interfaces and create the control logic in a Control/Control Fast/Fuel Control subsystem. The example below illustrates the interfaces with stubs for inputs.

#### Pulse Control Interface

- Mode utilizes the lecm\_eid\_mp\_pulse\_control\_mode\_enum. This mode defines the mode of operation for the interface and the units of the Magnitudes inport.
  - Disabled, Volume Control, or Duration Control.

- Timing Range Resolution Select input uses the lecm\_eid\_mp\_timing\_range\_resolution\_enum which specifies the allowable range and resolution of the Timing Offsets inport.
  - LowRange-HighResolution, MediumRange-MediumResolution, HighRange-LowResolution
- Slot Select is used to select the desired profile slot to be used.
- Pulse Enables is a 1x5 boolean array for state control of each pulse #1...#5.
- Timing Offsets is a fixed-point value representing each pulse #1...#5 relative timing to each cylinder's TDC. Note: The multiplication factor (16, 8, 4) depends on the timing range resolution selection respectively.
- Magnitudes is used to control the volume or duration command based on the mode of operation.

#### • Cylinder Trim Interface

- Mode must match the corresponding pulse control interface in order to properly interpret the Magnitude Trims inport.
- Cylinder Enables allow individual cylinder state control.
- Pulse SOI Apply Flags are used to indicate the pulses for which the SOI Trims will apply.
- The Cylinder SOI Trims input is used to adjust the timing of each applied pulse. This
  resolution is always fixed to 1/8.
- Cylinder Magnitude Trims is used to adjust the magnitude of the Main pulse (pulse #3) only for the respective cylinder.




Figure 8-18. LECM EID Interface Bus Creators




Figure 8-19. Fuel Control Subsystem

Next, navigate to Outputs/Outputs Fast and add the EID Multi-Pulse Pulse/Cylinder control interfaces. Subsequently, interface fault monitors can be added in the Diagnostics & Monitoring to report if the interface communications fail. See Adding Faults section below for more details on how to add a new fault.




Figure 8-20. EID Multi-Pulse Interfaces

After adding the interfaces, be sure to enable them by default under the EID Definition block.




Figure 8-21. EID Board Definition Injection Data Interface Enables

# **Diagnostic Examples**

#### **Adding Faults**

This example demonstrates how to add new diagnostic faults into the application by adding sensor and range diagnostics to the AmbientAirPress sensor example demonstrated above. First, navigate to the Diagnostics (Medium) execution subsystem and add a subsystem for Pressure inputs. Inside of the Pressure subsystem, add a new AmbientAirPress subsystem.




Figure 8-22. Diagnostics Medium Pressure Input Subsystem

In the AmbientAirPress subsystem, we'll create typical sensor diagnostics and range validation monitors. This will consist of a total of four faults:

- [Diagnostic] AmbientAirPressureSensorLowFault
  - o Asserts when the sensor's voltage is below nominal range.
- [Diagnostic] AmbientAirPressureSensorHighFault
  - Asserts when the sensor's voltage is above the nominal range.
- [Monitor] AmbientAirPressureLowFault
  - Assert's when the engineering value of the ambient air pressure is considered too low, but sensor diagnostics are valid.
- [Monitor] AmbientAirPressureHighFault
  - Assert's when the engineering value of the ambient air pressure is considered too high, but sensor diagnostics are valid.

In this example, the sensor *diagnostics* validates the sensor hardware (V) is within range and valid. If the sensor is considered valid, then range low and high fault *monitors* (kPa) are used to monitor if the engineering value is below or above an acceptable nominal range.




Figure 8-23. Ambient Air Pressure Diagnostics & Monitoring

Add subsystems for the sensor diagnostics and sensor monitors along with fault definitions using the example structure above as a guide.




Figure 8-24. Ambient Air Pressure Diagnostics & Monitoring Implementation

Inside the Sensor Diagnostics, use a bus selector to select the Ambient Air Pressure Measurement Status. Recall from the example, the signal diagnostic checks are performed in the input processing of the sensor and reported as a status, thus the sensor diagnostic fault conditional logic can reference the signal status and assert a fault based on the status report. In this example, the SensorLowFault and SensorHighFault conditional logic is based on the measurement status reporting SignalLow and SignalHigh values respectively. These signals are tied to the FaultBus Create Conditional Status port (i.e., the condition for the fault exists). An ASB Boolean Persistence Filter is then used with the conditional status signal to provide a fault filter by ensuring the condition remains active for 250 ms continuously before asserting the fault by driving the Assertion Status port. The fault is considered inhibited if the Measurement Status reports Disabled (i.e., the sensor is not used).




Figure 8-25. Ambient Air Pressure Sensor Diagnostics

Lastly, the Sensor Monitors subsystem implements range check logic on the filtered Ambient Air Pressure value with hysteresis using the ASB Range Comparison block. The inhibit logic is used to prevent the fault from asserting if the sensor diagnostic conditional statuses are active (i.e., sensor is not valid) or if the sensor diagnostics are inhibited (i.e., the sensor is disabled). The ASB Boolean Persistence filter is also used to drive the assertion status of the fault; however, not the input to the filter is gated with the "Not Inhibited" signal. This condition forces the filter to reset if the inhibit condition is true.




Figure 8-26. Ambient Air Pressure Monitors

Now that the four faults have been added, we need to update their Fault ID code and J1939 SPN/FMI mappings. Navigate to the LESP Standard Diagnostics Management Definition block under Model Configuration and launch the fault property manager. The fault manager can also be launched by right-clicking on the Simulink model window and using the LESP context menu.




Figure 8-27. LESP Context Menu (Fault Property Manager)




Figure 8-28. Fault Property Manager

If the new faults are not visible at the top, click the ID header to sort by ID in ascending order. This will bring 0 valued codes to the top of the list.




Figure 8-29. Fault Property Manager (Ambient Air Pressure Defaults)

Use the fields to enter unique IDs and for each fault. The tool will display the next available ID codes in 0-999, 1000-1999, 2000-2999, 3000-3999, and 4000-4999 ranges for convenience; however, any ID code strategy can be employed. Click on the Notes tab to view suggestions and J1939 FMI codes. Use the J1939 standard to lookup an appropriate SPN for ambient air pressure signal (SPN108).




Figure 8-30. Fault Property Manager Notes




Figure 8-31. Fault Property Manager (Ambient Air Pressure Fault Properties)

Lastly, verify the correct scripts are referenced and hit the Regenerate \*.m Files button to recreate the new fault property files.




Figure 8-32. Fault Property Manager (Regenerate Files)

#### **Adding Fault Actions**

This example demonstrates how to add new diagnostic fault actions into the application. Fault actions are defined in the local fault\_actions\_enum.m script located under ./Scripts folder.




Figure 8-33. fault action enum Script

Open the script for editing and append a new fault action. After adding the fault action, any dependent fault action enumeration blocks (e.g., LESP Standard Diagnostics Management Definition, Get Fault Actions blocks) need to be refreshed.

```
function value = fault action enum(arg)
1 -
 2
 3
       enum = { 'None', 'Alarm', 'Shutdown', 'ImmediateShutdown', 'StartInterlock', 'MyFaultAction' };
 4
       if nargin == 1
 5
           value = asb enum get(enum, arg);
 6
       else
 7
           value = enum;
8
       end
9
10
       end
```

Figure 8-34. fault action enum Script (MyFaultAction)

This can be accomplished by executing the asb\_model\_eval\_block\_mask\_workspaces script and passing in the name of the model (or bdroot if the model is in the foreground). After the refresh is complete, verify the model updates without errors. At this point, the new fault action will be available to bind to faults defined in the model and the new fault action boolean signal should be available in the FaultActions bus that can be used in application logic to drive the appropriate control behaviors.



Do not skip the step of asb\_model\_eval\_block\_mask\_workspaces; otherwise, the blocks may report errors during a model update.




Figure 8-35. Refresh Block Workspaces

# **Output Examples**

#### Adding LSO Discrete/PWM Control

The LESP platform supports hardware-dependent discrete output manager blocks that accept DiscreteOutputBus types and dynamically map the input busses to the assigned discrete output resource (LSOx, HSOx, etc.). In addition, the mappings array is output and used with the Discrete Output Mapping Conflict diagnostic block to assert a fault if a mapping conflict arises. This block enables control logic to support dynamic IO mapping of outputs if desired. If dynamic mapping is not required, this block can be removed, and direct mapping implemented.




Figure 8-36. LECM-based Discrete Output Mapping Block

In this example, we'll add two different discrete output controllers: Discrete (on/off) and PWM. The first will drive HSO1 to an active (on) state when the ImmediateShutdown fault action is active. The second, will pulse-width-modulate HSO2 at a frequency of 100 Hz and a duty cycle that is a function of the current engine speed (0...1800 RPM  $\rightarrow$  0...100% duty cycle). First, navigate to the Control Medium subsystem and add a subsystem for HSO1 and HSO2 controls with an Inputs bus inport.




Figure 8-37. HSO Controls Subsystem

Inside of the subsystem, open the Simulink browser and add a copy of the DiscreteOutBus (Discrete Mode) and DiscreteOutBus (PWM Mode) blocks. Use the lecm\_discrete\_out\_io\_select\_enum to select the respective HSO1 and HSO2 resources and associated with the IO Select inports. For HSO1, select the ImmediateShutdown fault action signal and connect to the Activate port. For HSO2, use a MotoHawk 1D lookup table to convert from speed to duty cycle and connect with the Duty Cycle inport along with a fix valued Enable and Frequency ports. Note: MotoHawk calibrations or other logic can be used instead of constants or for the IO Select ports if runtime IO mapping is desired. Locate the DiscreteOutputBus types on a bus creator to be used in the output logic.




Figure 8-38. HSO1/HSO2 Controls Subsystem Logic

Lastly, navigate to the Outputs/Hardware Fast/Discrete Output Mapping subsystem. Use a bus selector to select the HSO1 and HSO2 control busses from the Control bus. Use a Signal Conversion block to convert the bus to a NonVirtual type and expand the vector concatenate block to three ports. Also change the mask parameter of the LECM Discrete Mapping block to three. Note, the first "Default" input must be maintained as this is the signal selected when the IO is not used. Finally, navigate to Diagnostics & Monitoring Idle subsystem and change the Output Mapping Fault mask width parameter to a value of three as well. Verify the model updates without errors. This process can be used to expand to any number of different discrete/PWM-based controls and commands.




Figure 8-39. LECM Discrete Output Mapping Interface Update

Figure 8-40. Discrete Output Mapping Conflict Fault Detection Logic

#### **Adding Analog Output Control**

The LESP platform supports hardware-dependent analog output manager blocks that accept AnalogOutputBus types and dynamically maps the input busses to the assigned analog output resource (e.g., AOUT1). In addition, the mappings array is output and used with the Output Mapping Conflict diagnostic block to assert a fault if a mapping conflict arises. This block enables control logic to support dynamic IO mapping of outputs if desired. If dynamic mapping is not required, this block can be removed, and direct mapping implemented.




Figure 8-41. LECM-based Analog Output Mapping Block

In this example, we'll add an Analog output that uses AOUT1 and maps the current engine speed to an AOUT1 command (0...1800 RPM  $\rightarrow$  4...20 mA). First, navigate to the Control Medium subsystem and add a subsystem for AOUT1 control with an Inputs bus inport.




Figure 8-42. AOUT1 Control Subsystem

Inside of the subsystem, open the Simulink browser and add a copy of the AnalogOutBus block. Use the lecm\_analog\_out\_io\_select\_enum to select the respective AOUT1 resource and associate with the IO Select inport. Use a MotoHawk 1D lookup table to convert from speed to mA command and associate with the Current Demand inport along with a fix valued Enable port. Note: MotoHawk calibrations can be used instead of constants or for the IO Select ports if runtime IO mapping is desired.




Figure 8-43. AOUT1 Control Subsystem Logic

Lastly, navigate to the Outputs/Hardware Fast/Analog Output Mapping subsystem. Use a bus selector to select the AOUT1 bus from the Control bus. Use a Signal Conversion block to convert the bus to a NonVirtual type and expand the vector concatenate block more ports if required. Verify the mask parameter of the LECM Analog Mapping block matches the input width. Note, the first "Default" input must be maintained as this is the bus selected when the IO is not used. Finally, navigate to Diagnostics & Monitoring Idle subsystem and change the Analog Output Mapping Fault mask width parameter to match as well. Verify the model updates without errors.




Figure 8-44. LECM Analog Output Mapping Interface Update



Figure 8-45. Analog Output Mapping Conflict Fault Detection Logic

# Chapter 9. Product Support and Service Options

## **Product Support Options**

If you are experiencing problems with the installation, or unsatisfactory performance of a Woodward product, the following options are available:

- 1. Consult the troubleshooting guide in the manual.
- 2. Contact the **OE Manufacturer or Packager** of your system.
- 3. Contact the **Woodward Business Partner** serving your area.
- 4. Contact Woodward technical assistance via email (<a href="EngineHelpDesk@Woodward.com">EngineHelpDesk@Woodward.com</a>) with detailed information on the product, application, and symptoms. Your email will be forwarded to an appropriate expert on the product and application to respond by telephone or return email.
- 5. If the issue cannot be resolved, you can select a further course of action to pursue based on the available services listed in this chapter.

**OEM or Packager Support:** Many Woodward controls and control devices are installed into the equipment system and programmed by an Original Equipment Manufacturer (OEM) or Equipment Packager at their factory. In some cases, the programming is password-protected by the OEM or packager, and they are the best source for product service and support. Warranty service for Woodward products shipped with an equipment system should also be handled through the OEM or Packager. Please review your equipment system documentation for details.

**Woodward Business Partner Support:** Woodward works with and supports a global network of independent business partners whose mission is to serve the users of Woodward controls, as described here:

- A **Full-Service Distributor** has the primary responsibility for sales, service, system integration solutions, technical desk support, and aftermarket marketing of standard Woodward products within a specific geographic area and market segment.
- An Authorized Independent Service Facility (AISF) provides authorized service that includes repairs, repair parts, and warranty service on Woodward's behalf. Service (not new unit sales) is an AISF's primary mission.
- A Recognized Engine Retrofitter (RER) is an independent company that does retrofits and
  upgrades on reciprocating gas engines and dual-fuel conversions, and can provide the full line of
  Woodward systems and components for the retrofits and overhauls, emission compliance upgrades,
  long term service contracts, emergency repairs, etc.

A current list of Woodward Business Partners is available at www.woodward.com/local-partner.

# **Product Service Options**

Depending on the type of product, the following options for servicing Woodward products may be available through your local Full-Service Distributor or the OEM or Packager of the equipment system.

- Replacement/Exchange (24-hour service)
- Flat Rate Repair
- Flat Rate Remanufacture

**Replacement/Exchange:** Replacement/Exchange is a premium program designed for the user who is in need of immediate service. It allows you to request and receive a like-new replacement unit in minimum time (usually within 24 hours of the request), providing a suitable unit is available at the time of the request, thereby minimizing costly downtime.

This option allows you to call your Full-Service Distributor in the event of an unexpected outage, or in advance of a scheduled outage, to request a replacement control unit. If the unit is available at the time of the call, it can usually be shipped out within 24 hours. You replace your field control unit with the like-new replacement and return the field unit to the Full-Service Distributor.

**Flat Rate Repair**: Flat Rate Repair is available for many of the standard mechanical products and some of the electronic products in the field. This program offers you repair service for your products with the advantage of knowing in advance what the cost will be.

**Flat Rate Remanufacture:** Flat Rate Remanufacture is very similar to the Flat Rate Repair option, with the exception that the unit will be returned to you in "like-new" condition. This option is applicable to mechanical products only.

# **Returning Equipment for Repair**

If a control (or any part of an electronic control) is to be returned for repair, please contact your Full-Service Distributor in advance to obtain Return Authorization and shipping instructions.

When shipping the item(s), attach a tag with the following information:

- Return number
- Name and location where the control is installed.
- Name and phone number of contact person
- Complete Woodward part number(s) and serial number(s)
- Description of the problem
- Instructions describing the desired type of repair

#### **Packing a Control**

Use the following materials when returning a complete control:

- Protective caps on any connectors
- Antistatic protective bags on all electronic modules
- Packing materials that will not damage the surface of the unit
- At least 100 mm (4 inches) of tightly packed, industry-approved packing material
- A packing carton with double walls
- A strong tape around the outside of the carton for increased strength



To prevent damage to electronic components caused by improper handling, read and observe the precautions in Woodward manual 82715, Guide for Handling and Protection of Electronic Controls, Printed Circuit Boards, and Modules.

# **Replacement Parts**

When ordering replacement parts for controls, include the following information:

- The part number(s) (XXXX-XXXX) that is on the enclosure nameplate
- The unit serial number, which is also on the nameplate.

# **Engineering Services**

Woodward's Full-Service Distributors offer various Engineering Services for our products. For these services, you can contact the Distributor by telephone or by email.

- Technical Support
- Product Training
- Field Service

**Technical Support** is available from your equipment system supplier, your local Full-Service Distributor, or from many of Woodward's worldwide locations, depending upon the product and application. This service can assist you with technical questions or problem solving during the normal business hours of the Woodward location you contact.

**Product Training** is available as standard classes at many Distributor locations. Customized classes are also available, which can be tailored to your needs and held at one of our Distributor locations or at your site. This training, conducted by experienced personnel, will assure that you will be able to maintain system reliability and availability.

**Field Service** engineering on-site support is available, depending on the product and location, from one of our Full-Service Distributors. The field engineers are experienced both on Woodward products as well as on much of the non-Woodward equipment with which our products interface.

For information on these services, please contact one of the Full-Service Distributors listed at www.woodward.com/local-partner.

# **Contacting Woodward's Support Organization**

For the name of your nearest Woodward Full-Service Distributor or service facility, please consult our worldwide directory at <a href="www.woodward.com/support">www.woodward.com/support</a>, where you may also find the most current product support and contact information.

You can also contact the Woodward Customer Service Department at one of the following Woodward facilities to obtain the address and phone number of the nearest facility at which you can obtain information and service.

<b>Products Used in</b>		
Electrical Power Systems		
FacilityPhone Number		
Brazil+55 (19) 3708 4800		
China+86 (512) 8818 5515		
Germany:+49 (711) 78954-510		
India+91 (124) 4399500		
Japan+81 (43) 213-2191		
Korea+82 (32) 422-5551		
Poland+48 (12) 295 13 00		
United States+1 (970) 482-5811		

Engine Systems		
FacilityPhone Number		
Brazil+55 (19) 3708 4800		
China+86 (512) 8818 5515		
Germany +49 (711) 78954-510		
India+91 (124) 4399500		
Japan+81 (43) 213-2191		
Korea+ 82 (32) 422-5551		
The Netherlands+31 (23) 5661111		
United States+1 (970) 482-5811		

Products Used in

Products Used in Industria
<b>Turbomachinery Systems</b>
Facility Phone Numbe
Brazil+55 (19) 3708 4800
China+86 (512) 8818 5513
India+91 (124) 439950
Japan+81 (43) 213-219
Korea+ 82 (32) 422-555
The Netherlands+31 (23) 566111
Poland+48 (12) 295 13 0
United States+1 (970) 482-581

## **Technical Assistance**

If you need to contact technical assistance, you will need to provide the following information. Please write it down here before contacting the Engine OEM, the Packager, a Woodward Business Partner, or the Woodward factory:

General	
Your Name	
Site Location	
Phone Number	
Fax Number	
Prime Mover Information	
Manufacturer	
Engine Model Number	
Number of Cylinders	
Type of Fuel (gas, gaseous, diesel, dual-fuel, etc.)	
Power Output Rating	
Application (power generation, marine, etc.)	
Control/Governor Information	
Control/Governor #1	
Woodward Part Number & Rev. Letter	
Control Description or Governor Type	
Serial Number	
Control/Governor #2	
Woodward Part Number & Rev. Letter	
Control Description or Governor Type	
Serial Number	
Control/Governor #3	
Woodward Part Number & Rev. Letter	
Control Description or Governor Type	
Serial Number	
Symptoms	
Description	

If you have an electronic or programmable control, please have the adjustment setting positions or the menu settings written down and with you at the time of the call.

# **Revision History**

#### Changes in Revision —

New manual

We appreciate your comments about the content of our publications.

Send comments to: industrial.support@woodward.com

Please reference publication XXXXX.





PO Box 1519, Fort Collins CO 80522-1519, USA 1041 Woodward Way, Fort Collins CO 80524, USA Phone +1 (970) 482-5811

Email and Website—www.woodward.com

Woodward has company-owned plants, subsidiaries, and branches, as well as authorized distributors and other authorized service and sales facilities throughout the world.

Complete address / phone / fax / email information for all locations is available on our website.