

easYgen-1800

Operation Manual | Genset Control



easYgen-1800

Version 3.0.1.3

Document ID: B37690A, Revision E - Build 53527

Manual (original)

This is no translation but the original Technical Manual in English.

Designed in Germany and Poland; manufactured in China.

Woodward GmbH

Handwerkstr. 29

70565 Stuttgart

Germany

Telephone: +49 (0) 711 789 54-510

Fax: +49 (0) 711 789 54-101

E-mail: marketing_pg@woodward.com

Internet: <http://www.woodward.com>

© 2023 Woodward GmbH. All rights reserved.

Table of Contents

| | | |
|----------|--|-----------|
| 1 | General Information | 5 |
| 1.1 | About this Manual | 5 |
| 1.1.1 | Revision History | 5 |
| 1.1.2 | Symbols Used in this manual | 6 |
| 1.2 | Copyright And Disclaimer | 7 |
| 1.3 | Service And Warranty | 8 |
| 1.4 | Safety | 8 |
| 1.4.1 | Intended Use | 8 |
| 1.4.2 | Personnel | 9 |
| 1.4.3 | General hazard warnings | 10 |
| 2 | System Overview | 11 |
| 2.1 | HMI Status Screens | 11 |
| 2.2 | ToolKit-SC Status Screens | 11 |
| 3 | Operation | 15 |
| 3.1 | Front Panel: Operating and Display Elements | 15 |
| 3.2 | Warning/Alarm Signaling | 17 |
| 3.2.1 | Alarm Acknowledgment | 17 |
| 3.3 | Operation Modes | 18 |
| 3.3.1 | Operation Mode AUTO | 18 |
| 3.3.2 | Operation Mode MANual | 19 |
| 3.3.3 | Operation Mode STOP | 19 |
| 3.4 | START/STOP Operation | 19 |
| 3.4.1 | Start engine to supply load | 20 |
| 3.4.2 | Stop engine after mains supplying load (again) | 22 |
| 3.4.3 | MANual START/STOP | 24 |
| 3.5 | Transition Procedures | 24 |
| 3.5.1 | Disconnect during cranking | 24 |
| 3.5.2 | Manual Breaker Transition | 25 |
| 3.6 | Trouble Shooting | 26 |

Table of Contents

| | | |
|----------|---|-----------|
| 4 | Appendix | 28 |
| 4.1 | Alarms and Warnings | 28 |
| 4.1.1 | Alarm Classes | 28 |
| 4.1.2 | Warnings | 28 |
| 4.1.3 | Shutdown Alarms | 30 |
| 4.1.4 | Trip and Stop Alarms | 31 |
| 4.1.5 | Trip Alarms | 32 |
| 5 | Glossary and List of Abbreviations | 33 |
| 6 | Index | 34 |

1 General Information

1.1 About this Manual

1.1.1 Revision History

| Rev. | Date | Editor | Changes |
|------|---------|--------|--|
| E | 2023-08 | MK | Operation Manual updated title page |
| D | 2021-03 | MK | Operation Manual corrected first page |
| C | | | Software Revision 3.0.1.3 and ToolKit-SC version 1.5.1.3 |
| B | 2019-05 | PW | <p>Software Revision 3.0.1.2 and ToolKit-SC version 1.5.0.4</p> <p>NEW features & functions</p> <ul style="list-style-type: none"> • Display optimization for Main page and Engine page of temperature sensor and oil pressure sensor; • Als 01-03 reworked. All sensors can be set as temperature, pressure and level ones. • Delay On/Off added to the logic flag output; • Polish added in the PC software language package; • Expansion module lamp panel easYlite-200 added; • Breaker plausibility check at start in the manual mode enhanced; • Acknowledge button in the web interface added; • Response button command "SMS ACK" for GSM text added; • Support of Woodward IKD1 and IKD2 added, each module with 8 inputs and 8 outputs. • The arrow down button added as the lamp test button. • Added Limits for Als 1-3 same as AI 4-5. • Fixed AI 2 output configuration delay to Max. working time and value 0=unlimited. There shall be a remark on the ToolKit SC. • Fixed KingBAND ECU data display. • Changed 26 MTU-ADEC & 27 MTU-ADEC-SAM to issue speed command at stop status. • Changed 3: VDO to 3: VDO 120 for temperature sensor curve. • Fixed bugs: <ul style="list-style-type: none"> ◦ easYgen breaker feedback not being used; ◦ easYgen-800/1800 sensor data fluctuation after repower on; ◦ communication issue. |
| A | 2018-03 | GG | Describes device implemented software version 2.2 and ToolKit-SC version 1.4.0.2 |

1 General Information

1.1.2 Symbols Used in this manual

1.1.2 Symbols Used in this manual***Safety instructions***

Safety instructions are marked with symbols. The safety instructions are always introduced by signal words that express the severity of the danger.

DANGER!

This combination of symbol and signal word indicates an immediately dangerous situation that can cause death or severe injuries if not avoided.

WARNING!

This combination of symbol and signal word indicates a possibly dangerous situation that can cause death or severe injuries if it is not avoided.

CAUTION!

This combination of symbol and signal word indicates a possibly dangerous situation that can cause slight injuries if it is not avoided.

NOTICE!

This combination of symbol and signal word indicates a possibly dangerous situation that can cause property and environmental damage if it is not avoided.


Tips and recommendations

This symbol indicates useful tips and recommendations as well as information on efficient and trouble-free operation.

Additional markings

To highlight instructions, results, lists, references, and other elements, the following markings are used in these instructions:

| Marking | Explanation |
|---------|--|
| | Step-by-step instructions |
| | Results of action steps |
| | References to sections of these instructions and to other relevant documents |
| • | Listing without fixed sequence |

| Marking | Explanation |
|---|---|
| »Buttons« | Operating elements (e.g. buttons, switches), display elements (e.g. signal lamps) |
| »Display« | Screen elements (e.g. buttons, programming of function keys) |
| [Screen xx / Screen xy / Screen xz] ... | Menu path. The following information and setting refer to a page on the HMI screen or ToolKit located as described here. |
|  | Some parameters/settings/screens are available only either in ToolKit or on the HMI/display. |



Dimensions in Figures

All dimensions with no units specified are in **mm**.

1.2 Copyright And Disclaimer

Disclaimer

All information and instructions in this manual have been provided under due consideration of applicable guidelines and regulations, the current and known state of the art, as well as our many years of in-house experience. Woodward assumes no liability for any damages due to:

- Failure to comply with the instructions in this manual
- Improper use / misuse
- Willful operation by non-authorized persons
- Unauthorized conversions or non-approved technical modifications
- Use of non-approved spare parts

The originator is solely liable for the full extent for damages caused by such conduct. The obligations agreed-upon in the delivery contract, the general terms and conditions, the manufacturer's delivery conditions, and the statutory regulations valid at the time the contract was concluded, apply.

Copyright

This manual is protected by copyright. No part of this manual may be reproduced in any form or incorporated into any information retrieval system without written permission of Woodward GmbH.

Delivery of this manual to third parties, duplication in any form - including excerpts - as well as exploitation and/or communication of the content, are not permitted without a written declaration of release by Woodward GmbH.

Actions to the contrary will entitle us to claim compensation for damages. We expressly reserve the right to raise any further accessory claims.

1.3 Service And Warranty

Opening the device will nullify any warranty!

CAUTION!



Any unauthorized modifications or use of this equipment outside its specified mechanical, electrical, or other operating limits may cause personal injury and/or property damage, including damage to the equipment.

Any such unauthorized modifications

- constitute "misuse" and/or "negligence" as per the product warranty
- thereby exclude warranty coverage for any resulting damage, and
- invalidate product certifications or listings.

Our Customer Service is available for technical information. Please see page 2 for contact details.

In addition, our employees are interested in any new information and experiences that arise from usage and could be valuable for improving our products.

Warranty terms



Please enquire about the terms of warranty from your nearest Woodward representative.

To find your closest Customer Service representative, go to: \Rightarrow <http://www.woodward.com/Directory.aspx>

1.4 Safety

1.4.1 Intended Use

The easYgen unit has been designed and constructed solely for the intended use described in this Operation Manual and - with even more details - in the Technical Manual.

- Intended use requires operation of the control unit within the range outlined in the written specifications.
- Steps to be taken for commissioning are outlined in the Technical Manual.
- Intended use includes compliance with all instructions and safety notes presented in this manual.
- Any use which exceeds or differs from the intended use shall be considered improper use.

- No claims for any kind of damage will be considered if such claims result from improper use.

NOTICE!***Damage due to improper use!***

Improper use of the remote panel unit may cause damage to the control unit as well as to the connected components.

Improper use includes, but is not limited to:

- Operation outside the specified operating conditions.

1.4.2 Personnel**WARNING!*****Hazards due to insufficiently qualified personnel!***

If unqualified personnel perform work on or with the control unit hazards may arise which can cause serious injury and substantial damage to property.

- Therefore, all work must only be carried out by appropriately qualified personnel.

This manual specifies the personnel qualifications required for the different areas of work, listed below:

- Well trained for electrical installations.
- Aware of the local safety regulations.
- Experienced in working with electronic measuring and control devices.
- Allowed to manage the controlled (engine/generator) system.

The workforce must only consist of persons who can be expected to carry out their work reliably. Persons with impaired reactions due to, for example, the consumption of drugs, alcohol, or medication are prohibited.

When selecting personnel, the age-related and occupation-related regulations governing the operating location must be observed.

1 General Information

1.4.3 General hazard warnings

1.4.3 General hazard warnings***Hazards by system controlled*****DANGER!*****Moving parts and dangerous electricity!***

Be aware that the remote control of a system that is managing life-threatening engine-generator-electricity parts must be adapted to the local situation!

The following safety notes cover both the device itself and basics of the overall genset system. The dedicated genset-system safety instruction must be considered, too!

Prime mover safety**WARNING!*****Hazards due to insufficient prime mover protection***

The engine, turbine, or any other type of prime mover must be equipped with an overspeed (over-temperature, or over-pressure, where applicable) shutdown device(s) that operates independently of the prime mover control device(s) to protect from runaway or damage to the engine, turbine, or any other type of prime mover. Failure to comply with this also poses the risk of personal injury or loss of life if the mechanical-hydraulic governor(s) or electric control(s), the actuator(s), fuel control(s), the driving mechanism(s), the linkage(s), or the controlled device(s) fail.

2 System Overview

General notes

The easYgen is a stand-alone genset controller with measuring, monitoring, and breaker control functionality. It comes with an easily mountable plastic housing covering a thoroughly tested electronic-electrical system.

Display and buttons of the HMI offer access to states and values, as well as access to the application. Password protection enables the assignment of multiple operation access levels. Remote access, monitoring, visualization, and configuration are possible via integrated interfaces. Communication between easYgens using PLC control or as a network member offers an enhanced system management range; additionally supported by easy to implement accessories.



For even higher challenges in genset control, the easYgen series offers further solutions encompassing complex and ambitious applications.

For dedicated protection tasks, ask Woodward for its protection (relay) solutions.

Operation Modes

- See [↪](#) “3.3 Operation Modes”

2.1 HMI Status Screens

HMI comes with status screens:

- Status
- Engine
- Gen(erator)
- Load
- Mains
- Alarm
- Log
- Others
- About
- ... and the home screen

in a loop


2.2 ToolKit-SC Status Screens

General notes

ToolKit-SC enables dedicated access to status information summarized into the following screens:

2 System Overview

2.2 ToolKit-SC Status Screens



The Ext. analog inputs status screen is currently not in use.

Generator Status

[PARAMETER / STATUS MENU / Generator status]

| Items | Parameters | Description |
|-----------------------|--|--|
| Engine/Sensor info | Engine speed, Engine temp, Oil pressure, Fuel level, Battery volt, Charger volt | |
| More info | Fuel temp, Inlet temp, Exhaust temp, Coolant pressure, Fuel pressure, Turbo pressure, Total fuel consume, Coolant level, Oil temp | Selection of ECU data via J1939. |
| Status and delay | Gen status, Breaker status, Remote start, Mains status | |
| Alarms | | Display of current alarms and warnings |
| Digital inputs | 1 start request in AUTO, 2 High temperature, 3 Low oil pressure, 4 User defined, 5 User-defined, 6 User-defined, 7 Lamp test, 8 User defined, Emergency stop | |
| Accumulation | Active power (kW), Reactive power (kvar), Apparent power (kVA) | |
| Digital output | 1 Engine flag 1, 2 Idle control, 3 Close GCB, 4 Close MCB, 5 Stop solenoid, 6 Centralized alarm Fuel relay, Start relay | |
| Status | Stop mode, Manual mode, Test mode, Auto mode, Mains available, Mains Closed, Gen available, Gen closed, Alarm indicator, Running indicator | |
| Current date and time | Date (yyyy-mm-dd), Time (hh:mm:ss) | |

Measured Values

[PARAMETER / STATUS MENU / Measured values]

| Items | Parameters | Description |
|-----------------------------|--|-------------|
| Electricity quantity | | |
| Mains | L1, L2, L3, L1-2, L2-3, L3-1, L1Phase, L2Phase, L3Phase, Frequency | |
| Generator | L1, L2, L3, L1-2, L2-3, L3-1, L1Phase, L2Phase, L3Phase, Frequency | |
| Current (A) | L1, L2, L3 | |
| Active power (kW) | L1, L2, L3, Total | |
| Reactive power (kvar) | L1, L2, L3, Total | |
| Apparent power (kVA) | L1, L2, L3, Total | |
| Power factor | L1, L2, L3, Avg | |

Ext. Discrete Inputs/Outputs

[PARAMETER / STATUS MENU / Ext. discrete inputs/outputs]

| Items | Parameters | Description |
|-----------------------------------|-----------------------|--------------|
| Ext. discrete inputs 1-16 | | |
| Input {X} | (contact open/closed) | {X}: 1 or 16 |
| Ext. discrete outputs 1-16 | | |
| Output {Y} | (Hi/Low) | {Y}: 1 or 16 |

Miscellaneous

[PARAMETER / STATUS MENU / Miscellaneous]

| Items | Parameters | Description |
|-----------------------|---|-------------|
| Total A | Run time, Starts, Total energy | |
| Total B | Run time, Starts, Total energy | |
| SD card | Status, Total capacity, Remain capacity | |
| Earth fault current | Percent | |
| Next maintenance time | Maintenance 1 to 3 | |

Event Log and Version

[PARAMETER / STATUS MENU / Event log and version]

| Items | Parameters | Description |
|-------------|--|--|
| Module Info | Model, Hardware Version, Software Version, Issue Date | |
| Event log | <p>Fixed view of:</p> <p>No., Event type</p> <p>Columns "move behind" visible part of the screen:</p> <p>Event Item, Date, Time,</p> <p>Mains Uab (V) / Ubc (V) / Uca (V), Mains Ua (V), Mains Ub (V), Mains Uc (V), Mains f (Hz),</p> | Event log report table. Showing the 99 latest events or – with SD card – the content of the .DAT file(s) |

2 System Overview

2.2 ToolKit-SC Status Screens

| Items | Parameters | Description |
|-------|---|--|
| | Gens Uab (V) ..., Gens Ua (V) ..., Gens f(Hz), Current Ia (A) ..., Power (kW), Speed (r/min), Temp. (°C), Press. (kPa), Volt. (V) | |
| | Read log Clear Export to Txt | Push buttons to manage logged data (internal or SD card) |

SD-Card

[PARAMETER / STATUS MENU / SD-Card]



The SD-Card stores the same information as »Event log and version« but on the inserted SD card in a .DAT file format.

| Items | Description |
|--|--|
| Read all log | Event table is filled with all stored data |
| ((number selection boxes)) Read log | Read and displayed events can be pre-selected by min and max number e.g. for better overview |
| Export to Txt | List of current (selected) events can be saved as .TXT file |

3 Operation

3.1 Front Panel: Operating and Display Elements










Fig. 2: HMI (front panel) easYgen-1800

| Icons | Keys | Description |
|---|-------------------------------|--|
|  | STOP | <p>Auto/Manual mode: Stop running generator</p> <p>Stop mode: Reset alarm</p> <p>Lamp test (press at least 3 seconds)</p> <p>Notes</p> <p>During stopping process, press this button again to stop generator immediately.</p> |
|  | I (START) | MANual mode: Start genset |
|  | MAN (Manual Mode) | Press this key and controller enters into MANual mode |
|  | AUTO (Automatic Mode) | Press this key and controller enters into AUTO mode |
|  | Mute "Horn"/Alarm acknowledge | <p>Press once: Alarming sound OFF</p> <p>Press second time:</p> <ul style="list-style-type: none"> Alarm is acknowledged Alarm LED changes from twinkling to permanently illuminated |

3 Operation

3.1 Front Panel: Operating and Display Elements

| Icons | Keys | Description |
|---|------------------|---|
|  | Gen Open/Close | MANual mode: Switch Generator breaker ON or OFF |
| | Mains Open/Close | MANual mode: Switch Mains breaker ON or OFF |
|  | Up/Increase | 1) Screen scroll 2) Settings menu: Up cursor and increase value in |
|  | Down/Decrease | 1) Screen scroll 2) Settings menu: Down cursor and decrease value |
|  | Left | 1) Screen scroll 2) Settings menu: Left move cursor |
|  | Right | 1) Screen scroll 2) Settings menu: Right move cursor |
|  | Set/Confirm | Select viewing area |
|  | Exit | 1) Returns to the main menu 2) In settings menu returns to the previous menu |
|  | Warning | |
|  | Alarm | |
|  | Running | |
|  | Genset | |
|  | Busbar | |
|  | Mains | |



In MANual mode:

Pressing **MAN** and **I** (START) simultaneously will force the generator to crank. Successful start will not be judged according to crank disconnect conditions, the operator needs to crank the starter motor manually; Once the engine has fired, the operator must release the button. Only then the start output will be deactivated, safety on delay will start.

WARNING!

Users can change passwords. Please make note of the new password after changing it. If you forget the password, please contact Woodward services and send all device information on the "ABOUT" page of the controller for legitimation.

3.2 Warning/Alarm Signaling

The Alarm type and Warning are visualized through flashing of the LED lights »Alarm« and »Warning« located beside the display.

| Alarm Indicator LED | Warning Indicator LED | Alarm Type |
|------------------------------|------------------------------|--|
| Slow flashing | Slow flashing | Warning |
| Fast flashing | Off | Shutdown or Trip Alarm |
| Fast flashing | Slow flashing | Shutdown or Trip Alarm with Warning |
| ON (permanently illuminated) | Off | Common Alarm, acknowledged |
| ON (permanently illuminated) | ON (permanently illuminated) | Shutdown or Trip Warning, Alarm acknowledged |

3.2.1 Alarm Acknowledgment

General notes

The alarm acknowledge handling is valid for following alarm classes

- Warning
- Shutdown
- Trip/Stop
- Trip

Mute Horn

Any new active alarm activates the horn and is made visible by the flashing Alarm LED.

After pressing the mute/acknowledge button the horn is deactivated and the Alarm LED changes from flashing to constant active and stays active as long as any alarm is present. An additional active alarm reactivates the horn and the Alarm LED starts flashing again.

Stop by alarm

The operation mode automatically changes to STOP if a stopping alarm is active (»Shutdown« or »Trip/Stop«).

Acknowledge alarm

The alarm reset is done with additional (2nd time) pressing the mute/acknowledge button (Alarm LED is no longer flashing).

3.3 Operation Modes**General notes**

The easYgen offers three operation modes:

- AUTO
- MANUAL (MAN)
- STOP
- ... and an internal (non) operating phase during the start of the device itself

The operation mode can be initiated – provided the current settings allow for this function:

- directly by pressing the respective button on the front panel
- directly by click on the respective button on the ToolKit-SC remote screen
- via discrete inputs
- via interface

3.3.1 Operation Mode AUTO**General notes**

In operation mode AUTO, both genset and breakers are under easYgen control. The start and stopping of the engine are managed automatically, along with open, close, and breaker transition.

- supply load by mains
- supply load by generator
- transition load supply from mains to generator or from generator to mains
- start the engine
- stop the engine

Load supply transition from mains to genset**Situation**

- Mains becomes abnormal when one or more parameter are outside their working range and one of the following occurs:
 - »Overvoltage«
 - »Undervoltage«

- »Overfrequency«
- »Underfrequency«
- »Mains voltage asymmetry«
- »Mains phase rotation fail«

The start procedure includes breaker handling, engine start, and signaling/warning.

Load supply transition from genset (back) to mains

All of the above listed parameters are (back) in normal range.

The stop procedure includes breaker handling, engine stand-by, and signaling/warning.

3.3.2 Operation Mode MANual

General notes

In operation mode MANual, both genset and breakers are independent of each other under easYgen control.

The starting and stopping of the engine are managed using the same procedure as in AUTO mode but without breaker control. Breakers can be opened and closed without taking care of load, genset, or mains state!

CAUTION!



MANual breaker open/close request can destroy the genset and/or substantial damage mains.

Take care for genset and supply.

3.3.3 Operation Mode STOP

General notes

In operation mode STOP, the breakers are open and the engine is not running.



This is a configurable operation mode, only. This is NO emergency STOP!

3.4 START/STOP Operation

3 Operation

3.4.1 Start engine to supply load

3.4.1 Start engine to supply load**General notes**

| * | Pre-Condition | | | |
|---|--|-------------------|---------------|---------------------|
| | Mode | Energy | Breakers | Genset |
| | AUTO | Mains is "normal" | GCB is open | Not running |
| | | | MCB is closed | Ready for operation |
| | Situation | | | |
| | <ul style="list-style-type: none"> • Mains becomes abnormal when one or more parameter are outside their working range and one of the following occurs: <ul style="list-style-type: none"> ◦ »Overvoltage« ◦ »Undervoltage« ◦ »Overfrequency« ◦ »Underfrequency« ◦ »Mains voltage asymmetry« ◦ »Mains phase rotation fail« | | | |

The AUTO Start procedure runs sub procedures with own timers.



If the mains is back during the process, re-connecting the mains has priority.

The remaining time of each of the timers initiated displays.

When started via "Remote Start (off Load)" input, the starting procedure is the same as shown below but the generator close relay is deactivated.

Because there is no mains control, only the "Start engine" section (green background) is relevant.




Fig. 3: Transition Mains to Genset including engine start procedure

3 Operation

3.4.2 Stop engine after mains supplying load (again)

3.4.2 Stop engine after mains supplying load (again)**General notes**

| * | Pre-Condition | | | |
|---|--|---------------------|---------------|------------------|
| | Mode | Energy | Breakers | Genset |
| | AUTO | Mains is "abnormal" | GCB is closed | Running |
| | | | MCB is open | Delivering power |
| | Situation | | | |
| | <ul style="list-style-type: none"> • Mains becomes normal when all of the parameters below are inside their working ranges: <ul style="list-style-type: none"> ◦ »Overvoltage« ◦ »Undervoltage« ◦ »Overfrequency« ◦ »Underfrequency« ◦ »Mains voltage asymmetry« ◦ »Mains phase rotation fail« | | | |

The AUTO Stop procedure is going through sub procedures with own timers.



If the mains becomes abnormal during the process, remaining with generator load has priority.

The remaining time of each of the timers initiated displays.

When started via "Remote Stop (off Load)" input, the starting procedure is the same as shown below but the generator close relay is deactivated.




Fig. 4: Transition genset to mains including engine stop/stand-by procedure

3.4.3 MANual START/STOP



Engine control is separated from breaker management. Breaker(s) must be manually opened/closed (supply should be in normal range).



MANual Start


1. ▷

Press the MAN button



The LED next to the button will illuminate to confirm the operation


2. ▷

Press the START button  to start the genset as described above. In case of abnormal conditions, such as overheating, low oil pressure, over speed and abnormal voltage during generator running occur, the controller can protect genset by stopping quickly.



MANual Stop

1. ▷

Pressing  can stop the running generator as described above.

3.5 Transition Procedures

3.5.1 Disconnect during cranking

There are three conditions under control to abort the starting of the engine:

- speed sensor
- generator frequency
- engine oil pressure

They can be used separately or in combinations.

We recommend selecting all three at the same time: engine oil pressure together with speed sensor, and generator frequency. This allows for an immediate separation of the starter motor from the engine. Additionally, crank disconnect can be checked exactly.

When set to speed sensor, ensure that the number of flywheel teeth is the same as setting.



Sensor not used? Make sure not to select a sensor that is not in use. Otherwise, an error message might occur.



If the speed sensor (»Firing speed RPM«) is not selected, the rotating speed displayed on the controller is calculated from generator frequency and the number of poles.

If the generator frequency (»Firing speed Hz«) is not selected, the relative power quantity will neither be registered nor displayed (e.g. water pump application).

HMI only! In ToolKit-SC frequency, speed, and oil pressure can be enabled/disabled separately; HMI is using a table »Firing speed« instead:

| No. | Setting description |
|-----|---|
| 0 | Gen frequency |
| 1 | Speed sensor |
| 2 | Speed sensor + Gen frequency |
| 3 | Oil pressure |
| 4 | Oil pressure + Gen frequency |
| 5 | Oil pressure + Speed sensor |
| 6 | Oil pressure + Speed sensor + Gen frequency |

3.5.2 Manual Breaker Transition

When the controller is in MANual mode, the procedures to switch supply between mains and genset will be started by a manual process when the breaker switch is pressed.

CAUTION!



Neither mains nor generator state is taken into account. Breaker open/close works independent from the load.

If the generator or the mains are "out of range", the load can be damaged!



> Both breakers GCB and MCB open:

1. ▷ Taking load

Press the breaker switch



▶ The respective breaker is closed.
The closing signal will last for the »Closing time«



During this time, all other breaker signals are suppressed.

3 Operation

3.6 Trouble Shooting

**Unload**

> One of the breakers is closed - open this breaker.

1. ▷

Press the breaker switch  of the closed breaker

- ▶ The respective breaker will be opened.
The opening signal will last for the »Opening time«



During this time, all other breaker signals are suppressed.

**Transfer load**

> One of the breakers is closed - close the other breaker.

1. ▷

Press the breaker switch  of the open breaker

- ▶ The other (closed) breaker is opened.
The opening signal will last for the »Opening time«



During this time, all other breaker signals are suppressed.

2. ▷ After this, the other breaker (selected by pressed button) will be closed

- ▶ Closing signal will last for the »Closing time«



During this time, all other breaker signals are suppressed.

3.6 Trouble Shooting

| Symptoms | Possible Solutions |
|---|--|
| Controller has no power. | Check starting batteries; Check controller connection wiring; Check DC fuse. |
| Genset shutdown | Check if the water/cylinder temperature exceeds the limits; Check the genset AC voltage; Check DC fuse. |
| Controller emergency stop | Check if emergency stop button works properly; Check whether the starting battery's positive pole is connected to the emergency stop input; Check whether the circuit is open. |
| Low oil pressure alarm after crank disconnect | Check the oil pressure sensor and its connections. |

| Symptoms | Possible Solutions |
|---|--|
| High water temp. alarm after crank disconnect | Check the temperature sensor and its connections. |
| Shutdown Alarm in running | Check the switch and its connections according to the information on LCD; Check auxiliary input ports. |
| Fail to start | Check the fuel oil circuit and its connections; Check the starting batteries; Check the speed sensor and its connections; Refer to the engine manual. |
| Starter no response | Check the starter connections; Check the starting batteries. |
| Genset running while ATS not transfer | Check the ATS; Check the connections between ATS and controllers. |
| RS485 communication is abnormal | Check the connections; Check if the COM port setting is correct; Check RS-485 connections of A and B are reverse connected; Check if the RS485 transfer model is damaged; Check if the communication port of the computer is damaged. |
| ECU communication failed | Check the CAN connections for high and low polarity; Check if the 120 Ω resistor is connected properly; Check if the type of engine is correct; Check if the connections from the controller to the engine and the output ports settings are correct. |
| ECU warning or shutdown | Get information from the LCD of the alarm page; If there is a detailed alarm, check the respective engine. If there is no detailed alarm, please refer to the relevant section of the engine manual as specified in the SPN alarm code. |

4 Appendix

4.1 Alarms and Warnings

4 Appendix

4.1 Alarms and Warnings

4.1.1 Alarm Classes

| Alarm class | Visible in the display | LED and horn | Open GCB | Shut-down engine | Engine blocked until acknowledge |
|-------------|---|--------------|-------------|------------------|----------------------------------|
| Warn | X | X | | | |
| | This alarm does not interrupt the operation of the unit. An output of the centralized alarm occurs and the "Horn" command is issued. Alarm text + flashing LED + Relay centralized alarm (horn) | | | | |
| Shutdown | X | X | Immediately | Immediately | X |
| | The GCB is opened and the engine is stopped. Alarm text + flashing LED + Relay centralized alarm (horn) + GCB open + Engine stop. | | | | |
| Trip/shut | x | x | Immediately | Cool down time | X |
| | The GCB is opened immediately and the engine is stopped after cool down. Alarm text + flashing LED + Relay centralized alarm (horn) + GCB open + Cool down + Engine stop. | | | | |
| Trip | X | X | X | | |
| | The GCB is opened but does not interrupt the operation of the unit. Alarm text + flashing LED + Relay centralized alarm (horn) + GCB open. | | | | |
| Indication | X | | | | |
| | This alarm does not interrupt the operation of the unit. A message output without a centralized alarm occurs. Alarm text | | | | |

4.1.2 Warnings

| No | Type | Description |
|----|----------------------|---|
| 1 | Overspeed | When the controller detects that the engine speed has exceeded the pre-set value, it will initiate a warning alarm. |
| 2 | Underspeed | When the controller detects that the engine speed has fallen below the pre-set value, it will initiate a warning alarm. |
| 3 | Loss of speed signal | When the controller detects that the engine speed is 0 and the selected action is "Warn", it will initiate a warning alarm. |
| 4 | Gen. overfrequency | When the controller detects that the genset frequency has exceeded the pre-set value, it will initiate a warning alarm. |
| 5 | Gen. underfrequency | When the controller detects that the genset frequency has fallen below the pre-set value, it will initiate a warning alarm. |
| 6 | Gen. overvoltage | When the controller detects that the generator voltage has exceeded the pre-set value, the controller will initiate a warning alarm. |
| 7 | Gen. undervoltage | When the controller detects that the genset voltage has fallen below the pre-set value, it will initiate a warning alarm. |
| 8 | Gen. overcurrent | When the controller detects that the genset current has exceeded the pre-set value and the selected action is "Warn", it will initiate a warning alarm. |
| 9 | Fail to stop | After "Stop solenoid hold" delay, if genset does not stop completely, it will initiate a warning alarm. |

| No | Type | Description |
|----|--------------------------------|---|
| 10 | Charge alternator low voltage | When the controller detects that charger voltage has fallen below the pre-set value, it will initiate a warning alarm. |
| 11 | Battery undervoltage | When the controller detects that start battery voltage has fallen below the pre-set value, it will initiate a warning alarm. |
| 12 | Battery overvoltage | When the controller detects that start battery voltage has exceeded the pre-set value, it will initiate a warning alarm. |
| 13 | Maintenance due | When count down time is 0 and the selected action is "Warn", it will initiate a warning alarm. |
| 14 | Gen. reverse power | If reverse power detection is enabled, when the controller detects that the reverse power value (power is negative) has fallen below the pre-set value and the selected action is "Warn", it will initiate a warning alarm. |
| 15 | Overload | If over power detection is enabled, when the controller detects that the over power value (power is positive) has exceeded the pre-set value and the selected action is "Warn", it will initiate a warning alarm. |
| 16 | ECU warning alarm | If an error message is received from ECU via J1939, it will initiate a warning alarm. |
| 17 | Gen. loss of phase | If loss of phase detection is enabled, When controller detects the generator loss phase, it will initiate a warning alarm. |
| 18 | Gen. phase rotation mismatch | When the controller detects a phase rotation error, it will initiate a warning alarm. |
| 19 | Breaker open/close fail | When the controller detects that the breaker close or open failure occurs, and the selected action is "Warn", it will initiate a warning alarm. |
| 20 | Temperature sensor wire break | When the controller detects that the temperature sensor is open circuit and the selected action is "Warn", it will initiate a warning alarm. |
| 21 | High temperature | When the controller detects that engine temperature has exceeded the pre-set value, it will initiate a warning alarm. |
| 22 | Low temperature | When the controller detects that engine temperature has fallen below the pre-set value, it will initiate a warning alarm. |
| 23 | Oil pressure sensor wire break | When the controller detects that the oil pressure sensor is open circuit and the selected action is "Warn", it will initiate a warning alarm. |
| 24 | Low oil pressure | When the controller detects that the oil pressure has fallen below the pre-set value, it will initiate a warning alarm. |
| 25 | Fuel level sensor wire break | When the controller detects that the level sensor is open circuit and the selected action is "Warn", it will initiate a warning alarm. |
| 26 | Low fuel level | When the controller detects that the fuel level has fallen below the pre-set value, it will initiate a warning alarm. |
| 27 | Analog input 4 Wire break | When the controller detects that the flexible sensor 1 is open circuit and the selected action is "Warn", it will initiate a warning alarm. |
| 28 | Analog input 4 High limit | When the controller detects that the sensor 1 value has exceeded the pre-set value, it will initiate a warning alarm. |
| 29 | Analog input 4 Low limit | When the controller detects that the sensor 1 value has fallen below the pre-set value, it will initiate a warning alarm. |
| 30 | Analog input 5 Wire break | When the controller detects that the flexible sensor 2 is open circuit and the selected action is "Warn", it will initiate a warning alarm. |
| 31 | Analog input 5 High limit | When the controller detects that the sensor 2 value has exceeded the pre-set value, it will initiate a warning alarm. |
| 32 | Analog input 5 Low limit | When the controller detects that the sensor 2 value has fallen below the pre-set value, it will initiate a warning alarm. |
| 33 | Discrete input xyz | When digit input port is set as warning and the alarm is active, it will initiate a warning alarm. |

4 Appendix

4.1.3 Shutdown Alarms

| No | Type | Description |
|----|------------------------|---|
| 34 | GSM Communication fail | When select GSM enable but the controller couldn't detect GSM model, controller sends corresponding warning signal. |
| 35 | Ground fault | If earth fault detection is enabled, the controller will initiate a shutdown alarm if it detects that the earth fault current has exceeded the pre-set value and the selected action is "Warn", it will initiate a warning alarm. |

4.1.3 Shutdown Alarms

When controller detects shutdown alarm, it will send signal to open breaker and shuts down generator.

| No | Type | Description |
|----|--------------------------------|--|
| 1 | Emergency stop | When the controller detects an emergency stop alarm signal, it will initiate a shutdown alarm. |
| 2 | Overspeed | When the controller detects that the generator speed has exceeded the pre-set value, it will initiate a shutdown alarm. |
| 3 | Underspeed | When the controller detects that the generator speed has fallen below the pre-set value, it will initiate a shutdown alarm. |
| 4 | Loss of speed signal | When the controller detects that the engine speed is 0 and the selected action is "Shutdown", it will initiate a shutdown alarm. |
| 5 | Gen. overfrequency | When the controller detects that the genset frequency has exceeded the pre-set value, it will initiate a shutdown alarm. |
| 6 | Gen. underfrequency | When the controller detects that the genset frequency has fallen below the pre-set value, it will initiate a shutdown alarm. |
| 7 | Gen. overvoltage | When the controller detects that the generator voltage has exceeded the pre-set value, the controller will initiate a shutdown alarm. |
| 8 | Gen. undervoltage | When the controller detects that the genset voltage has fallen below the pre-set value, it will initiate a shutdown alarm. |
| 9 | Fail to stop | If the engine does not fire after the pre-set number of attempts, it will initiate a shutdown alarm. |
| 10 | Gen. overcurrent | When the controller detects that the genset current has exceeded the pre-set value and the selected action is "Shutdown", it will initiate a shutdown alarm. |
| 11 | Maintenance due | When count down time is 0 and the selected action is "Shutdown", it will initiate a shutdown alarm. |
| 12 | ECU shutdown alarm | If an error message is received from ECU via J1939, it will initiate a shutdown alarm. |
| 13 | ECU communication fail | If the module does not detect the ECU data, it will initiate a shutdown alarm. |
| 14 | Gen. reverse power | If reverse power detection is enabled, the controller will initiate a shutdown alarm, when it detects that the reverse power value (power is negative) has fallen below the pre-set value and the selected action is "Shutdown". |
| 15 | Overload | If over power detection is enabled, the controller will initiate a shutdown alarm, when it detects that the over power value (power is positive) has exceeded the pre-set value and the selected action is "Shutdown". |
| 16 | Temperature sensor wire break | When the controller detects that the temperature sensor is open circuit and the selected action is "Shutdown", it will initiate a shutdown alarm. |
| 17 | High temperature | When the controller detects that engine temperature has exceeded the pre-set value, it will initiate a shutdown alarm. |
| 18 | Oil pressure sensor wire break | When the controller detects that the oil pressure sensor is open circuit and the action select "Shutdown", it will initiate a shutdown alarm. |

| No | Type | Description |
|----|----------------------------------|---|
| 19 | Low oil pressure | When the controller detects that the oil pressure has fallen below the pre-set value, it will initiate a shutdown alarm. |
| 20 | Level sensor wire break | When the controller detects that the level sensor is open circuit and the action select "Shutdown", it will initiate a shutdown alarm. |
| 21 | Analog input 4 Wire break | When the controller detects that the flexible sensor 1 is open circuit and the action select "Shutdown", it will initiate a shutdown alarm. |
| 22 | Analog input 4 High limit | When the controller detects that the sensor 1 value has exceeded the pre-set value, it will initiate a shutdown alarm. |
| 23 | Analog input 4 Low limit | When the controller detects that the sensor 1 value has fallen below the pre-set value, it will initiate a shutdown alarm. |
| 24 | Analog input 5 Wire break | When the controller detects that the flexible sensor 2 is open circuit and the action select "Shutdown", it will initiate a shutdown alarm. |
| 25 | Analog input 5 High limit | When the controller detects that the sensor 2 value has exceeded the pre-set value, it will initiate a shutdown alarm. |
| 26 | Analog input 5 Low limit | When the controller detects that the sensor 2 value has fallen below the pre-set value, it will initiate a shutdown alarm. |
| 27 | Discrete input | When digit input port is set as shutdown and the alarm is active, it will initiate a shutdown alarm. |
| 28 | Ground fault | If earth fault detection is enabled, the controller will initiate a shutdown alarm if it detects that the earth fault current has exceeded the pre-set value and the selected action is "Shutdown". |
| 29 | Low coolant level | Controller initiates shutdown alarm when digital input port has been configured as low coolant level shutdown (is active). |
| 30 | Detonation shutdown (Gas engine) | Controller initiates shutdown alarm when digital input port has been configured as detonation shutdown (is active). |
| 31 | Gas leak shutdown | Controller initiates shutdown alarm when digital input port has been configured as gas leak shutdown (is active). |

4.1.4 Trip and Stop Alarms

Upon initiation of the trip and stop condition, the controller will de-energize the 'Close Generator' Output to remove the load from the generator. Once this has occurred, the controller will start the Cooling delay and allow the engine to cool down before shutting it down.

| No | Type | Description |
|----|--------------------|--|
| 1 | Gen. overcurrent | When the controller detects that the genset current has exceeded the pre-set value and the selected action is "Trip and Stop", it will initiate a trip and stop alarm. |
| 2 | Maintenance due | When count down time is 0 and the action select "Trip and Stop", it will initiate a trip and stop alarm. |
| 3 | Gen. reverse power | If reverse power detection is enabled, the controller will initiate a trip and stop alarm if it detects that the reverse power value (power is negative) has fallen below the pre-set value and the action select "Trip and Stop". |
| 4 | Overload | If over power detection is enabled, the controller will initiate a trip and stop alarm if it detects that the over power value (power is positive) has exceeded the pre-set value and the selected action is "Trip and Stop". |
| 5 | Discrete input | When the digit input port is set to "Trip and Stop" and the alarm is active, it will initiate a trip and stop alarm. |

4 Appendix

4.1.5 Trip Alarms

| No | Type | Description |
|----|--------------|---|
| 6 | Ground fault | If earth fault detection is enabled, the controller it will initiate a trip and stop alarm if it detects that the earth fault current has exceeded the pre-set value and the action select "Trip and Stop". |

4.1.5 Trip Alarms

On initiation of the trip condition the controller will de-energize the 'Close Generator' Output without stop the generator.

| No | Type | Description |
|----|--------------------|---|
| 1 | Gen. overcurrent | The controller will initiate a trip alarm if it detects that the genset current has exceeded the pre-set value and the selected action is "Trip". |
| 2 | Gen. reverse power | If reverse power detection is enabled, the controller will initiate a trip alarm if it detects that the reverse power value (power is negative) has fallen below the pre-set value and the selected action is "Trip". |
| 3 | Overload | If over power detection is enabled, the controller will initiate a trip alarm if it detects that the over power value (power is positive) has exceeded the pre-set value and the selected action is "Trip". |
| 4 | Discrete Input | When digit input port is set to "Trip" and the alarm is active, it will initiate a trip alarm. |
| 5 | Ground fault | If earth fault detection is enabled, the controller will initiate a trip alarm if it detects that the earth fault current has exceeded the pre-set value and the selected action is "Trip". |

5 Glossary and List of Abbreviations

| | |
|------------------|--|
| CB | Circuit Breaker |
| CT | Current Transformer |
| DI | Discrete Input |
| DO | Discrete (Relay) Output |
| ECU | Engine Control Unit |
| FMI | Failure Mode Indicator |
| GCB | Generator Circuit Breaker |
| GOV | (speed) Governor; rpm regulator |
| HMI | Human Machine Interface e.g., a front panel with display and buttons for interaction |
| I | Current |
| MCB | Mains Circuit Breaker |
| MPU | Magnetic Pickup Unit |
| N.C. | Normally Closed (break) contact |
| N.O. | Normally Open (make) contact |
| NC | Neutral Contactor |
| OC | Occurrence Count |
| Operation | In (general) operation. State when the genset is running according to the selected mode, all parameters are in allowed values and ranges, and without OPEN requests or alarms. Somehow "waiting for next occurrence". |
| P | Real power |
| P/N | Part Number |
| PF | Power Factor |
| PT | Potential (Voltage) Transformer |
| Q | Reactive power |
| S | Apparent power |
| S/N | Serial Number |
| SPN | Suspect Parameter Number |
| V | Voltage |

Index

A

Alarms

| | |
|----------------------------|--------|
| Classes | 28 |
| Shutdown Alarms | 30 |
| Trip and Stop Alarms | 31, 32 |

C

| | |
|------------------------|---|
| Contact person | 8 |
| Customer Service | 8 |

F

| | |
|-----------------|----|
| Functions | 11 |
|-----------------|----|

I

| | |
|--------------------|---|
| Intended use | 8 |
|--------------------|---|

K

| | |
|------------|----|
| Keys | 15 |
|------------|----|

O

| | |
|-----------------------|----|
| Operation | 15 |
| Operation Modes | 18 |

P

| | |
|-----------------|---|
| Personnel | 9 |
|-----------------|---|

S

| | |
|---------------------------|----|
| Service | 8 |
| Symbols | |
| in the instructions | 6 |
| System Overview | 11 |

T

Trouble Shooting 26

U

Use 8

W

Warnings 28

Warranty 8



Woodward GmbH
Handwerkstraße 29 — 70565 Stuttgart — Germany
Phone +49 (0) 711 789 54-510
Fax +49 (0) 711 789 54-101
marketing_pg@woodward.com